



## APPENDIX D - MPD/MRB/TASK CARD CROSS REFERENCE INDEXES

### **A. SCOPE**

This appendix to the MPD includes cross-reference indexes to the MRB, MPD, and Task Card Numbers. These indexes are sorted by MRB item no., MPD item no., and Task Card no. This appendix contains all airplane configurations, and is not specific to an individual operator fleet. Since operator task card decks reflect delivery configuration, not all listed task cards may apply to an individual operator.

### **B. NOTES**

This Appendix is arranged into three sections. The first section is sorted by MPD item no., the second section by MRB item no. and the last section by Task Card no.

### **C. PAGE FORMAT**

#### 1. MPD ITEM NUMBER

MPD item number for each task.

#### 2. MRB ITEM NUMBER

MRB item number for each task.

#### 3. TASK CARD NO.

Task card number for each task.

Task card numbers reflect all fleet configurations.

#### 4. RELATED DESCRIPTION TASK CODE

- A- Perform AFTER the related task.
- B- Perform BEFORE the related task.
- W- Perform WITH the related task.
- P- Task PRECLUDED by performing the related task.
- R- Task PRECLUDES performing the related task.
- G- Task is GROUPED with other systems tasks which are accomplished at the same time.

#### 5. TASK TITLE

The type of task performed.

#### 6. TASK DESCRIPTION

A short description of the task intent





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
12-002-01	12-002-01	12-002-01-01 12-002-01-02		LUBRICATE	Elevator Power Control Actuators and Elevator Hinges
12-004-00	12-004-00	12-004-00-01		LUBRICATE	Rudder and Rudder Tab Hinge Bearings, PCU'S Reaction Link Rod Ends and PCU Rod Ends
12-006-00	12-006-00	12-006-00-01		LUBRICATE	Stabilizer Trim Ballscrew and Ballscrew Actuator
12-008-00	12-008-00	12-008-00-01 12-008-00-02 12-008-00-11 12-008-00-12		LUBRICATE	LE Slat Torque Tube Couplings, Supports and Gearbox Couplings
12-008-01	12-008-01	12-008-01-01 12-008-01-02 12-008-01-03 12-008-01-04 12-008-01-05 12-008-01-06		LUBRICATE	Forward Cargo Compartment Torque Tube Supports and Couplings
12-010-00	12-010-00	12-010-00-01 12-010-00-02		LUBRICATE	Wing Inboard Slat Main Tracks
12-012-00	12-012-00	12-012-00-01 12-012-00-02		LUBRICATE	Wing Outboard Slats Main Tracks
12-014-00	12-014-00	12-014-00-01 12-014-00-02 12-014-00-11 12-014-00-12		LUBRICATE	Leading Edge Slat Track Rollers and Pinion Bearings
12-018-00	12-018-00	12-018-00-01 12-018-00-02		LUBRICATE	Wing Krueger Flap Drive Arm Bearing
12-020-00	12-020-00	12-020-00-01 12-020-00-02		LUBRICATE	Wing Inboard Spoilers PCU's, Center Hinges and Hinge Links
12-022-00	12-022-00	12-022-00-01 12-022-00-02		LUBRICATE	Wing Outboard Spoiler PCU's, Center Hinges and Hinge Links
12-024-00	12-024-00	12-024-00-01 12-024-00-02		LUBRICATE	Wing Aileron Power Control Units (PCUs) and Hinges



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
12-026-00	12-026-00	12-026-00-01 12-026-00-02		LUBRICATE	Wing Flaperon Power Control Units (PCU's) Rod Ends, Hinge Fittings and PCU Yoke Assemblies (if installed)
12-030-00	12-030-00	12-030-00-01 12-030-00-02		LUBRICATE	Wing Trailing Edge Torque Tubes, Torque Tube Supports, and Couplings
12-034-00	12-034-00	12-034-00-01 12-034-00-02 12-034-00-11 12-034-00-12 12-034-00-21 12-034-00-22 12-034-00-31 12-034-00-32	W-12-034-00-21 W-12-034-00-22 W-12-034-00-31 W-12-034-00-32	LUBRICATE	Wing Trailing Edge Flap Transmissions, Ballscrews and Gimbals
12-050-00	12-050-00	12-050-00-01 12-050-00-02 12-050-00-03 12-050-00-04 12-050-00-11 12-050-00-12 12-050-00-21 12-050-00-22 12-050-00-31 12-050-00-32 12-050-00-41 12-050-00-42 12-050-00-51 12-050-00-52	W-12-050-00-21 W-12-050-00-22 W-12-050-00-31 W-12-050-00-32	LUBRICATE	Wing Trailing Edge Flap Supports and Support Mechanisms
12-070-00	12-070-00	12-070-00-01 12-070-00-10		LUBRICATE	Nose Landing Gear Steering and Actuating Components and Mechanisms
12-074-00	12-074-00	12-074-00-01		LUBRICATE	Nose Landing Gear Doors and Door Actuating Mechanisms



# 777-200/300 MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
12-080-00	12-080-00	12-080-00-01 12-080-00-02 12-080-00-03 12-080-00-04 12-080-00-05 12-080-00-06 12-080-00-11 12-080-00-12 12-080-00-13 12-080-00-14	W-12-082-00-01 W-12-082-00-02 W-12-082-00-03 W-12-082-00-04	LUBRICATE	Main Landing Gear Components and Actuating Mechanisms
12-081-00	12-081-00	12-081-00-01 12-081-00-02		LUBRICATE	Main Landing Gear Truck Beam and Inner Cylinder Pivot Joints
12-082-00	12-082-00	12-082-00-01 12-082-00-02 12-082-00-03 12-082-00-04	W-12-080-00-01 W-12-080-00-02 W-12-080-00-03 W-12-080-00-04	LUBRICATE	Main Landing Gear Forward Trunnion Bearing Housing and Retract Arm Assembly
12-086-00	12-086-00	12-086-00-01 12-086-00-02 12-086-00-03 12-086-00-04		LUBRICATE	Main Landing Gear Doors and Actuating Mechanisms
12-088-00	12-088-00	12-088-00-01 12-088-00-02 12-088-00-03 12-088-00-04		LUBRICATE	Main Landing Gear Support Beam
12-090-00	12-090-00	12-090-00-01		LUBRICATE	Forward Large Cargo Door Hinge Pins
12-092-00	12-092-00	12-092-00-01		LUBRICATE	Aft Large Cargo Door Hinge Pins
12-094-00	12-094-00	12-094-00-01		LUBRICATE	Forward Large Cargo Door Components and Door to Cutout Mating Surfaces
12-096-00	12-096-00	12-096-00-01		LUBRICATE	Aft Large Cargo Door Components and Door to Cutout Mating Surfaces
12-100-00	12-100-00	12-100-00-01		LUBRICATE	Forward Large Cargo Door Mechanisms (Pushrods, Links, Hooks and Pins)
12-102-00	12-102-00	12-102-00-01		LUBRICATE	Aft Large Cargo Door Mechanisms (Pushrods, Links, Hooks and Pins)
12-104-00	12-104-00	12-104-00-01		LUBRICATE	Aft Small Cargo Door Hinge Arms, Adjustment Rods and Latch Rollers



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
12-106-00	12-106-00	12-106-00-01 12-106-00-03 12-106-00-04		LUBRICATE	Passenger Entry Door Mechanisms
12-108-00	12-108-00	12-108-00-01		LUBRICATE	Bulk Cargo Door Probe Support Fittings
12-110-00	12-110-00	12-110-00-01 12-110-00-02 12-110-00-03 12-110-00-04 12-110-00-05 12-110-00-06		LUBRICATE	Forward Access Door Latch Pin
12-112-00	12-112-00	12-112-00-01		LUBRICATE	Main Equipment Center Access Door Latch Pin
12-114-00	12-114-00	12-114-00-01		LUBRICATE	Ram Air Turbine (RAT) Actuator Strut and Door Actuation Link
12-118-00	12-118-00	12-118-00-01 12-118-00-02 12-118-00-03 12-118-00-04 12-118-00-05 12-118-00-06		LUBRICATE	Wing Nacelle Attach Fittings
12-122-00	12-122-00	12-122-00-01		LUBRICATE	No. 2 Left and Right Flight Compartment Window Drive Tracks
20-010-00	20-010-00	20-010-00-01 20-010-00-02 20-010-00-03 20-010-00-04 20-010-00-05		INSPECTION - DETAILED	Primary Flight Control and Brake Control Cables Turns
20-012-00		20-012-00-01 20-012-00-02		INSPECTION - DETAILED	Nose Gear Steering Control Cable Turns



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-015-00	20-015-00	20-015-00-01 20-015-00-02 20-015-00-03 20-015-00-04 20-015-00-05 20-015-00-06 20-015-00-07 20-015-00-08 20-015-00-09		INSPECTION - DETAILED	Primary Flight Control and Brake Control Cables - straight runs
20-018-00		20-018-00-01 20-018-00-02		INSPECTION - DETAILED	Nose Gear Steering Control Cables - straight runs
20-070-00	20-070-00	20-070-00-01 20-070-00-02		INSPECTION - DETAILED	Exposed, Unprotected Brake Control Cables in the Wheel Well
20-110-00	20-110-00	20-110-00-01 20-110-00-02 20-110-00-03 20-110-00-04 20-110-00-05		INSPECTION - DETAILED	Primary Flight Control Cables - PROTECTED/UNPROTECTED UNPRESSURIZED AREAS
20-200-00	20-200-00	20-200-00-01		FUNCTIONAL	HIRF/L AFDC Task for ILS, RA, AIMS, Backdrive and Cross Channel
20-250-10	20-250-10	20-250-10-01		INSPECTION - DETAILED	FOIL/MESH PANELS; ENGINE COWLS, STRUT, LEADING EDGE
20-250-20	20-250-20	20-250-20-01		INSPECTION - DETAILED	FOIL/MESH PANELS; ENGINE COWLS, STRUT, LEADING EDGE
20-251-10	20-251-10	20-251-10-01		INSPECTION - DETAILED	FOIL/MESH PANELS; ENGINE COWLS, STRUT, LEADING EDGE
20-251-20	20-251-20	20-251-20-01		INSPECTION - DETAILED	FOIL/MESH PANELS; ENGINE COWLS, STRUT, LEADING EDGE
20-252-10	20-252-10	20-252-10-01		INSPECTION - DETAILED	FOIL/MESH PANELS; ENGINE COWLS, STRUT, LEADING EDGE
20-252-20	20-252-20	20-252-20-01		INSPECTION - DETAILED	FOIL/MESH PANELS; ENGINE COWLS, STRUT, LEADING EDGE



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-260-00	20-260-00	20-260-00-01		FUNCTIONAL	Ram Air Turbine (RAT) Wire Shielding Functional Check
20-270-01	20-270-01	20-270-01-01		FUNCTIONAL	PFCS Wire Shielding Functional Check - Left Wing
20-270-02	20-270-02	20-270-02-01		FUNCTIONAL	PFCS Wire Shielding Functional Check - Right Wing
20-280-00	20-280-00	20-280-00-01		FUNCTIONAL	PFCS Wire Shielding Functional Check - Empennage
20-290-00	20-290-00	20-290-00-01		FUNCTIONAL	HIRF/Lightning Ace Wire Bundle Shielding
20-300-00	20-300-00	20-300-00-01		FUNCTIONAL	HIRF/Arlinc 629 Buses for Flight Controls, Couplers to EE Racks
20-310-01	20-310-01	20-310-01-01		FUNCTIONAL	Functional Check Wire Bundle Inspection Left Flaps, Slats, Skew Sensors
20-310-02	20-310-02	20-310-02-01		FUNCTIONAL	Functional Check Wire Bundle Right Flaps, Slats, Skew Sensors
20-320-00	20-320-00	20-320-00-01		FUNCTIONAL	Gust Suppression Transducers Wire Shielding Functional Check
20-330-00	20-330-00	20-330-00-01		FUNCTIONAL	HIRF/Lightning ACE Disconnects to Modal Suppression Transducers
20-340-00	20-340-00	20-340-00-01		FUNCTIONAL	HIRF/lightning ACE disconnects to pitch rate sensors
20-400-00	20-400-00	20-400-00-01		FUNCTIONAL	HIRF/Lightning Glide Slope and Localizer Antenna Coax
20-410-00	20-410-00	20-410-00-01		INSPECTION - DETAILED	Radome Diverter Strips Detailed Visual Inspection
20-420-00	20-420-00	20-420-00-01		FUNCTIONAL	HIRF/Lightning Localizer Tracking, VOR/Localizer Antenna COAX
20-430-00	20-430-00	20-430-00-01		FUNCTIONAL	HIRF/Lightning Glide Slope Tracking Antenna COAX
20-440-00	20-440-00	20-440-00-01		FUNCTIONAL	HIRF/Lightning VOR/Localizer Capture Antenna COAX
20-445-00	20-445-00	20-445-00-01		INSPECTION - DETAILED	Fin Tip Diverter Strip
20-450-00	20-450-00	20-450-00-01		FUNCTIONAL	HIRF/Lightning Radio Altimeter Antenna to Transceiver Coax
20-451-00	20-451-00	20-451-00-01		FUNCTIONAL	HIRF/Lightning Radio Altimeter Antenna to Transceiver Coax
20-460-00	20-460-00	20-460-00-01		FUNCTIONAL	HIRF/Lightning GPS Antenna to Left and Right MMR
20-470-00	20-470-00	20-470-00-01		FUNCTIONAL	HIRF/Lightning Protection - Air Supply Isolation Valves
20-471-00	20-471-00	20-471-00-01		FUNCTIONAL	HIRF/Lightning Protection - Main Landing Gear (MLG) Selector/Bypass Valve Module





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-472-00	20-472-00	20-472-00-01		FUNCTIONAL	HIRF/Lightning Protection - Center Hydraulic System Quantity Transmitter
20-473-01	20-473-01	20-473-01-01		FUNCTIONAL	HIRF/Lightning Protection - Flight Control Shutoff Valves - LH Wing & LH MLG W/W
20-473-02	20-473-02	20-473-02-01		FUNCTIONAL	HIRF/Lightning Protection - Flight Control Shutoff Valves - RH Wing & RH MLG W/W
20-474-01	20-474-01	20-474-01-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Crossfeed and Isolation Valves - LH Wing & LH MLG W/W
20-474-02	20-474-02	20-474-02-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Crossfeed and Isolation Valves - RH Wing & RH MLG W/W
20-475-00	20-475-00	20-475-00-01		FUNCTIONAL	HIRF/Lightning Protection - Center Override Jettison Fuel Pumps - MLG W/W
20-476-01	20-476-01	20-476-01-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Boost Pumps - LH Wing & LH MLG W/W
20-476-02	20-476-02	20-476-02-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Boost Pumps - RH Wing & RH MLG W/W
20-477-01	20-477-01	20-477-01-01		FUNCTIONAL	HIRF/Lightning Protection - Main Tank Fuel Jettison Pump - LH Wing
20-477-02	20-477-02	20-477-02-01		FUNCTIONAL	HIRF/Lightning Protection - Main Tank Fuel Jettison Pump - RH Wing
20-478-01	20-478-01	20-478-01-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Jettison Nozzle Valves - LH Wing
20-478-02	20-478-02	20-478-02-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Jettison Nozzle Valves - RH Wing
20-479-01	20-479-01	20-479-01-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Jettison Nozzle Valves - LH Wing
20-479-02	20-479-02	20-479-02-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Jettison Nozzle Valves - RH Wing
20-500-01	20-500-01	20-500-01-01		INSPECTION - DETAILED	GE90 FADEC Control System Wires Detail Inspection
20-500-02	20-500-02	20-500-02-01		INSPECTION - DETAILED	GE90 FADEC Control System Wires Detail Inspection
20-520-01	20-520-01	20-520-01-01		INSPECTION - DETAILED	PW4000 Electronic Engine Control System Wire Run
20-520-02	20-520-02	20-520-02-01		INSPECTION - DETAILED	PW4000 Electronic Engine Control System Wire Run



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-540-01	20-540-01	20-540-01-01		INSPECTION - DETAILED	Trent Electronic Engine Control System Wire Runs
20-540-02	20-540-02	20-540-02-01		INSPECTION - DETAILED	Trent Electronic Engine Control System Wire Runs
20-560-01	20-560-01	20-560-01-01		FUNCTIONAL	HIRF/ L Functional Test for FQIS, Left Side
20-560-02	20-560-02	20-560-02-01		FUNCTIONAL	HIRF/ L Functional Test for FQIS, Right Side
20-600-00	20-600-00	20-600-00-01		INSPECTION - DETAILED	Power Feeders connected to P100 and P200 Power Panels
20-602-00	20-602-00	20-602-00-01		RESTORE	Area Above Nose Landing Gear Wheel Well
20-640-10	20-640-10	20-640-10-01		INSPECTION - DETAILED	Wing Center Section Fuel Tank (SFAR 88)
20-641-00	20-641-00	20-641-00-01		INSPECTION - GEN VISUAL	ECS Bay Installed EWIS
20-642-00	20-642-00	20-642-00-01		INSPECTION - GEN VISUAL	Forward Bulkhead Left Main Landing Gear Wheel Well
20-644-00	20-644-00	20-644-00-01		INSPECTION - GEN VISUAL	Forward Bulkhead Right Main Landing Gear Wheel Well
20-648-00	20-648-00	20-648-00-01		INSPECTION - GEN VISUAL	Forward Cargo Power Drive Unit Wire Bundles
20-650-00	20-650-00	20-650-00-01 20-650-00-02 20-650-00-03 20-650-00-04 20-650-00-05		RESTORE	Areas Behind the FWD Cargo Compartment Sidewalls
20-651-00	20-651-00	20-651-00-01		RESTORE	Areas Below the AFT Cargo Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-652-00	20-652-00	20-652-00-01 20-652-00-02 20-652-00-03 20-652-00-04 20-652-00-05 20-652-00-06		INSPECTION - GEN VISUAL	Forward Cargo Compartment Power Feeders
20-654-00	20-654-00	20-654-00-01		RESTORE	Areas Behind the FWD Cargo Compartment Sidewalls
20-656-00	20-656-00	20-656-00-01 20-656-00-02 20-656-00-03 20-656-00-04 20-656-00-05 20-656-00-06		RESTORE	Areas Below the FWD Cargo Compartment
20-658-00	20-658-00	20-658-00-01 20-658-00-02 20-658-00-03 20-658-00-04 20-658-00-05 20-658-00-06		RESTORE	Area Behind the Forward Cargo Compartment
20-659-00	20-659-00	20-659-00-01 20-659-00-02 20-659-00-03 20-659-00-04 20-659-00-05 20-659-00-06		INSPECTION - GEN VISUAL	Area Behind the Forward Cargo Compartment
20-660-00	20-660-00	20-660-00-01 20-660-00-02 20-660-00-03 20-660-00-04 20-660-00-05 20-660-00-06		INSPECTION - GEN VISUAL	Aft Cargo Compartment Power Feeders
20-662-00	20-662-00	20-662-00-01		RESTORE	Areas Behind the Aft Cargo Compartment Sidewalls
20-664-00	20-664-00	20-664-00-01		RESTORE	Areas Behind the Aft Cargo Compartment Sidewalls



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-665-00	20-665-00	20-665-00-01		INSPECTION - GEN VISUAL	Aft Cargo Power Drive Unit Wire Bundles
20-668-00	20-668-00	20-668-00-01		INSPECTION - GEN VISUAL	APU Battery Installation and Power Feeders
20-670-00	20-670-00	20-670-00-01		RESTORE	Area Behind the Bulk Cargo Compartment Sidewalls
20-672-00	20-672-00	20-672-00-01		RESTORE	Area Behind the Bulk Cargo Compartment
20-700-00	20-700-00	20-700-00-01 20-700-00-02 20-700-00-03 20-700-00-04 20-700-00-05		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-701-00	20-701-00	20-701-00-01 20-701-00-02 20-701-00-03 20-701-00-04 20-701-00-05		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-702-00	20-702-00	20-702-00-01 20-702-00-02		INSPECTION - DETAILED	APU and RAT Power Feeders, and Galley and Cabin Power Feeders
20-704-00	20-704-00	20-704-00-01		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-705-00	20-705-00	20-705-00-01		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-706-00	20-706-00	20-706-00-01		INSPECTION - DETAILED	APU, RAT, Galley and Cabin Power Feeders in Passenger Compartment
20-708-00	20-708-00	20-708-00-01 20-708-00-02 20-708-00-03 20-708-00-04 20-708-00-05		RESTORE	Upper Surface of Ceiling Panels, Bins and Modules



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-712-00	20-712-00	20-712-00-01 20-712-00-02 20-712-00-03 20-712-00-04 20-712-00-05 20-712-00-06		INSPECTION - GEN VISUAL	Flight Deck EWIS
20-714-00	20-714-00	20-714-00-01		RESTORE	Flight Deck
20-716-00	20-716-00	20-716-00-01 20-716-00-02		RESTORE	Area Around the Video Control Center
20-724-00	20-724-00	20-724-00-01		INSPECTION - DETAILED	Rat Cabin and Galley Power Feeders in the Passenger Compartment
20-728-00	20-728-00	20-728-00-01		INSPECTION - DETAILED	Rat and Cabin Power Feeder Bundles in Passenger Compartment
20-730-00	20-730-00	20-730-00-01		RESTORE	Equipment Racks in Main Equipment Center.
20-732-00	20-732-00	20-732-00-01		INSPECTION - DETAILED	APU, IDG, BAT. & CHGR and Ground Power Feeders in the Main Equipment Center
20-734-00	20-734-00	20-734-00-01		INSPECTION - GEN VISUAL	External Power Receptacle in the Main Equipment Center.
20-736-00	20-736-00	20-736-00-01		INSPECTION - DETAILED	APU Power Feeders in Main Deck Cargo Compartment
20-737-00	20-737-00	20-737-00-01		CLEAN	Main Deck Cargo Compartment Air Grilles
20-738-00	20-738-00	20-738-00-01 20-738-00-02 20-738-00-03		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-740-00	20-740-00	20-740-00-01 20-740-00-02 20-740-00-03		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-742-00	20-742-00	20-742-00-01 20-742-00-02		RESTORE	Areas Behind the Passenger Compartment Air Grilles



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-744-00	20-744-00	20-744-00-01 20-744-00-02		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-746-00	20-746-00	20-746-00-01 20-746-00-02 20-746-00-03		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-748-00	20-748-00	20-748-00-01 20-748-00-02 20-748-00-03		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-750-00	20-750-00	20-750-00-01 20-750-00-02		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-752-00	20-752-00	20-752-00-01 20-752-00-02		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-754-00	20-754-00	20-754-00-01 20-754-00-02 20-754-00-03 20-754-00-04 20-754-00-05		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-756-00	20-756-00	20-756-00-01 20-756-00-02 20-756-00-03 20-756-00-04 20-756-00-05		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-758-00	20-758-00	20-758-00-01 20-758-00-02 20-758-00-03 20-758-00-04 20-758-00-05		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-760-00	20-760-00	20-760-00-01 20-760-00-02 20-760-00-03 20-760-00-04 20-760-00-05		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-762-00	20-762-00	20-762-00-01 20-762-00-02 20-762-00-03		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-764-00	20-764-00	20-764-00-01 20-764-00-02 20-764-00-03		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-766-00	20-766-00	20-766-00-01 20-766-00-02		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-768-00	20-768-00	20-768-00-01 20-768-00-02		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-770-00	20-770-00	20-770-00-01 20-770-00-02 20-770-00-03		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-772-00	20-772-00	20-772-00-01 20-772-00-02 20-772-00-03		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-774-00	20-774-00	20-774-00-01 20-774-00-02		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-776-00	20-776-00	20-776-00-01 20-776-00-02		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-778-00	20-778-00	20-778-00-01 20-778-00-02 20-778-00-03 20-778-00-04 20-778-00-05		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-780-00	20-780-00	20-780-00-01 20-780-00-02 20-780-00-03 20-780-00-04 20-780-00-05		RESTORE	Areas Behind the Passenger Compartment Air Grilles



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-782-00	20-782-00	20-782-00-01 20-782-00-02 20-782-00-03 20-782-00-04 20-782-00-05		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-784-00	20-784-00	20-784-00-01 20-784-00-02 20-784-00-03 20-784-00-04 20-784-00-05		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-790-00	20-790-00	20-790-00-01		INSPECTION - GEN VISUAL	APU and APU Starter Power Feeders
20-792-00	20-792-00	20-792-00-01		INSPECTION - GEN VISUAL	APU and APU Starter Power Feeders
20-794-00	20-794-00	20-794-00-01		INSPECTION - DETAILED	APU and APU Starter Power Feeders
20-796-00	20-796-00	20-796-00-01		RESTORE	Main Deck Entry Doors
20-800-00	20-800-00	20-800-00-01		INSPECTION - DETAILED	Engine IDG and Backup Generator Power Feeders - Left Engine
20-802-00	20-802-00	20-802-00-01		INSPECTION - DETAILED	Engine IDG and Backup Generator Power Feeders - Right Engine
20-840-01	20-840-01	20-840-01-01		INSPECTION - GEN VISUAL	IDG and Backup Power Feeders - Left Wing
20-840-02	20-840-02	20-840-02-01		INSPECTION - GEN VISUAL	IDG and Backup Power Feeders - Right Wing
20-842-00	20-842-00	20-842-00-01 20-842-00-02		INSPECTION - GEN VISUAL	EWIS within Nacelle Gap - Left and Right Wings
20-844-00	20-844-00	20-844-00-01 20-844-00-02		INSPECTION - GEN VISUAL	IDG and Backup Power Feeders - Right and Left Wings
20-850-00	20-850-00	20-850-00-01		INSPECTION - GEN VISUAL	Wing Leading Edge Wiring - Left Wing





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-851-00	20-851-00	20-851-00-01		INSPECTION - GEN VISUAL	Wing Leading Edge Wiring - Right Wing
20-852-00	20-852-00	20-852-00-01 20-852-00-02		INSPECTION - DETAILED	FQIS Wiring in the Wing Main Tank
20-856-11	20-856-11	20-856-11-01		INSPECTION - DETAILED	Center Fuel Tank (Rib 1 to Rib 8) - Left Wing (SFAR 88)
20-856-12	20-856-12	20-856-12-01		INSPECTION - DETAILED	Center Fuel Tank (Rib 1 to Rib 8) - Right Wing (SFAR 88)
20-858-11	20-858-11	20-858-11-01		INSPECTION - DETAILED	Main Tank (Rib 8 to Rib 17) - Left Wing (SFAR 88)
20-858-12	20-858-12	20-858-12-01		INSPECTION - DETAILED	Main Tank (Rib 8 to Rib 17) - Right Wing (SFAR 88)
20-860-11	20-860-11	20-860-11-01		INSPECTION - DETAILED	Main Tank (Rib 17 to Rib 32) - Left Wing (SFAR 88)
20-860-12	20-860-12	20-860-12-01		INSPECTION - DETAILED	Main Tank (Rib 17 to Rib 32) - Right Wing (SFAR 88)
20-866-00	20-866-00	20-866-00-01		INSPECTION - GEN VISUAL	Flap Supports No. 3
20-868-00	20-868-00	20-868-00-01		INSPECTION - GEN VISUAL	Flap Support No. 6
21-010-00	21-010-00	21-010-00-01		REPLACE	Upper Recirculation Air Filters
21-020-00	21-020-00	21-020-00-01		REPLACE	Lower Recirculation Air Filters
21-030-00	21-030-00	21-030-00-01		REPLACE	Galley Ventilation Filters
21-033-00	21-033-00	21-033-00-01		OPERATIONAL	Main Deck Alerting System
21-034-00	21-034-00	21-034-00-01		OPERATIONAL	Alternate Ventilation System (AVS)
21-036-00	21-036-00	21-036-00-01		INSPECTION - DETAILED	Lavatory/Galley and Alternate Ventilation System (LGVS and AVS)
21-037-00	21-037-00	21-037-00-01		RESTORE	Lav/Galley Ventilation System (LGVS)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
21-048-00	21-048-00	21-048-00-01		OPERATIONAL	E/E Cooling System Override Switch
21-050-00	21-050-00	21-050-00-01		CLEAN	Equipment Cooling Air Filter
21-052-00	21-052-00	21-052-00-01		INSPECTION - DETAILED	IFE Cooling Smoke Detector
21-054-00	21-054-00	21-054-00-01		INSPECTION - DETAILED	IFE Cooling System Air Supply Multi-holed Orifices
21-055-00	21-055-00	21-055-00-01		FUNCTIONAL	Condenser/Reheater
21-060-00	21-060-00	21-060-00-01	W-21-070-00-01	INSPECTION - DETAILED	E11 Rack Satcom Backup Fan Check Valves
21-065-00	21-065-00	21-065-00-01	W-21-075-00-01	INSPECTION - DETAILED	E13 Rack Satcom Backup Fan Check Valves
21-070-00	21-070-00	21-070-00-01	W-21-060-00-01	INSPECTION - DETAILED	E11 Rack Satcom Backup Cooling Check Valve
21-075-00	21-075-00	21-075-00-01	W-21-065-00-01	INSPECTION - DETAILED	E13 Rack Satcom Backup Cooling Check Valve
21-080-00	21-080-00	21-080-00-01	W-21-105-00-01 W-21-105-00-02	OPERATIONAL	Outflow Valve Manual Control
21-090-00	21-090-00	21-090-00-01		OPERATIONAL	Landing Altitude Manual Select Switch
21-100-00	21-100-00	21-100-00-01 21-100-00-02		CLEAN/INSP	Cabin Pressure Control Outflow Valves
21-105-00	21-105-00	21-105-00-01 21-105-00-02	W-21-100-00-01 W-21-100-00-02	INSPECTION - GEN VISUAL	Cabin Pressure Control Outflow Valves
21-110-00	21-110-00	21-110-00-01 21-110-00-02	R-21-110-00-01 P-21-110-00-02	FUNCTIONAL	Cabin Positive Pressure Relief Valves
21-120-00	21-120-00	21-120-00-01		REPLACE	Cabin Positive Pressure Relief Filters
21-130-00	21-130-00	21-130-00-01		OPERATIONAL	AFT and Bulk Cargo Temperature Selector Switches
21-131-00	21-131-00	21-131-00-01		FUNCTIONAL	AFT/Bulk Cargo Overheat Protection Switch & Relay
21-132-00	21-132-00	21-132-00-01		OPERATIONAL	AFT Cargo Temperature Selector Switch



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
21-133-00	21-133-00	21-133-00-01	W-21-170-00-01	OPERATIONAL	Aft Cargo Air Conditioning (ACAC)/Aft Lower Cargo Temperature Selector Switch
21-134-00	21-134-00	21-134-00-01		FUNCTIONAL	Aft Cargo Overheat Protection Switch & Relay
21-140-00	21-140-00	21-140-00-01		OPERATIONAL	AC Pack Flow Sensors
21-150-00	21-150-00	21-150-00-01		CLEAN	AC Pack Heat Exchangers
21-160-00	21-160-00	21-160-00-01	W-21-150-00-01	FUNCTIONAL	AC Pack Heat Exchangers
21-170-00	21-170-00	21-170-00-01		INSPECTION - DETAILED	AC Pack Fan Bypass Check Valve
21-180-00	21-180-00	21-180-00-01 21-180-00-02		INSPECTION - DETAILED	AC Pack Conditioned Air Check Valves
21-190-00	21-190-00	21-190-00-01		OPERATIONAL	AC Pack Condenser Low Limit Valves
21-200-00	21-200-00	21-200-00-01		OPERATIONAL	AC Pack 2nd Stage Turbine Bypass Valves
21-210-00	21-210-00	21-210-00-01		OPERATIONAL	AC Pack Secondary Heat Exchangers Outlet Temperature Sensor
21-220-00	21-220-00	21-220-00-01		OPERATIONAL	Cabin Air Conditioning and Temperature Controllers
21-230-00	21-230-00	21-230-00-01		CLEAN	Ozone Converters
21-240-00	21-240-00	21-240-00-01		CLEAN	Ozone Converters
21-250-00	21-250-00	21-250-00-01		INSPECTION - GEN VISUAL	E/E Equipment Cooling Override Duct
21-260-00	21-260-00	21-260-00-01		INSPECTION - DETAILED	Lower Recirculation Air Fan Check Valves
22-040-00	22-040-00	22-040-00-01		OPERATIONAL	Take-Off/ Go-Around (TO/GA) Switch
23-010-00	23-010-00	23-010-00-01 23-010-00-02		FUNCTIONAL	Passenger Address System
23-020-00	23-020-00	23-020-00-01		OPERATIONAL	Passenger Address System
23-030-00	23-030-00	23-030-00-01		OPERATIONAL	Passenger Address System
23-040-00	23-040-00	23-040-00-01		OPERATIONAL	Cabin Interphone System Alternate Channel
23-050-00	23-050-00	23-050-00-01		OPERATIONAL	Flight Interphone System - Audio Transfer



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
23-060-00	23-060-00	23-060-00-01		INSPECTION - GEN VISUAL	Static Dischargers
23-070-00	23-070-00	23-070-00-01		OPERATIONAL	Voice Recorder System
23-080-00	23-080-00	23-080-00-01		FUNCTIONAL	Voice Recorder System - Four Channel Operation
23-085-00	23-085-00	23-085-00-01		FUNCTIONAL	Voice recorder back up power system
23-090-00	23-090-00	23-090-00-01 23-090-00-02		REPLACE	Voice Recorder - Underwater Locator Beacon
23-100-00	23-100-00	23-100-00-01 23-100-00-02		OPERATIONAL	Voice Recorder System - Under Water Locator Beacon
23-110-00	23-110-00	23-110-00-01 23-110-00-02 23-110-00-03 23-110-00-04 23-110-00-05		OPERATIONAL	Emergency Locator Transmitter
23-120-00	23-120-00	23-120-00-01 23-120-00-02 23-120-00-03 23-120-00-04		REPLACE	Emergency Locator Transmitter
23-180-00	23-180-00	23-180-00-01		OPERATIONAL	Low Frequency Underwater Locator Device
23-190-00	23-190-00	23-190-00-01		DISCARD	Low Frequency Underwater Locator Device Battery
24-010-00	24-010-00	24-010-00-01 24-010-00-02		SERVICE	IDG Oil Servicing
24-011-00	24-011-00	24-011-00-01 24-011-00-02		SERVICE	IDG OIL Servicing
24-012-00	24-012-00	24-012-00-01 24-012-00-02		SERVICE	IDG Oil Servicing
24-030-00	24-030-00	24-030-00-01 24-030-00-02		SERVICE	VSCF Backup Generator Oil Servicing



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
24-040-00	24-040-00	24-040-00-01 24-040-00-02	W-24-070-00-01 W-24-070-00-02	SERVICE	IDG Oil Change
24-041-00	24-041-00	24-041-00-01 24-041-00-02	W-24-071-00-01 W-24-071-00-02	SERVICE	IDG Oil Change
24-042-00	24-042-00	24-042-00-01 24-042-00-02	W-24-072-00-01 W-24-072-00-02	SERVICE	IDG Oil Change
24-050-00	24-050-00	24-050-00-01 24-050-00-02 24-050-00-03 24-050-00-04 24-050-00-05 24-050-00-06		SERVICE	VSCF Backup Generator Oil and Filter Change
24-060-00	24-060-00	24-060-00-01 24-060-00-02		OPERATIONAL	Generator Drive Disconnect
24-061-00	24-061-00	24-061-00-01 24-061-00-02		OPERATIONAL	Generator Drive Disconnect
24-062-00	24-062-00	24-062-00-01 24-062-00-02		OPERATIONAL	Generator Drive Disconnect
24-070-00	24-070-00	24-070-00-01 24-070-00-02	W-24-040-00-01 W-24-040-00-02 W-24-075-00-01 W-24-075-00-02	REPLACE	IDG Oil Filter
24-071-00	24-071-00	24-071-00-01 24-071-00-02	W-24-041-00-01 W-24-041-00-02 W-24-075-00-01 W-24-075-00-02	REPLACE	IDG Oil Filter
24-072-00	24-072-00	24-072-00-01 24-072-00-02	W-24-042-00-01 W-24-042-00-02 W-24-075-00-01 W-24-075-00-02	REPLACE	IDG Oil Filter



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
24-075-00		24-075-00-01 24-075-00-02	W-24-070-00-01 W-24-070-00-02 W-24-071-00-01 W-24-071-00-02 W-24-072-00-01 W-24-072-00-02	VISUAL CHECK	IDG Oil Filter
24-080-00	24-080-00	24-080-00-01 24-080-00-02		INSPECTION - GEN VISUAL	IDG Oil Filter Element
24-090-00	24-090-00	24-090-00-01 24-090-00-02		FUNCTIONAL	IDG QAD Coupler
24-091-00	24-091-00	24-091-00-01 24-091-00-02		FUNCTIONAL	IDG QAD Coupler
24-092-00	24-092-00	24-092-00-01 24-092-00-02		FUNCTIONAL	IDG QAD Coupler
24-100-00	24-100-00	24-100-00-01 24-100-00-02 24-100-00-03 24-100-00-04 24-100-00-05 24-100-00-06 24-100-00-07		CLEAN	IDG and Backup Generator (VSCF) Heat Exchangers
24-120-00	24-120-00	24-120-00-01 24-120-00-02		CHECK/INSP	VSCF Backup Generator Differential Pressure Switch
24-160-00	24-160-00	24-160-00-01		FUNCTIONAL	APU Battery Charge Capacity
24-160-01	24-160-01	24-160-01-01		RESTORE	APU Battery Charge Capacity
24-170-00	24-170-00	24-170-00-01		FUNCTIONAL	Main Battery Charge Capacity
24-170-01	24-170-01	24-170-01-01		RESTORE	Main Battery Charge Capacity
24-190-00	24-190-00	24-190-00-01		RESTORE	Flight Control DC Power Battery
24-200-00	24-200-00	24-200-00-01		FUNCTIONAL	External Power Receptacles (Wear Check)
24-201-00		24-201-00-01		FUNCTIONAL	Airplane External Power Receptacle Neutral Pin Continuity to Airframe Ground



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
24-210-00	24-210-00	24-210-00-01		INSPECTION - DETAILED	External Power Receptacles (Inspection)
25-010-00	25-010-00	25-010-00-01		INSPECTION - DETAILED	Crew Seat Attachments
25-020-00	25-020-00	25-020-00-01		OPERATIONAL	Crew Seat Lock Mechanism
25-020-02	25-020-02	25-020-02-01 25-020-02-02		OPERATIONAL	Flight Crew Seat Manual Adjustments
25-020-04	25-020-04	25-020-04-01		INSPECTION - DETAILED	Flight Compartment Seat Harness
25-020-06	25-020-06	25-020-06-01		OPERATIONAL	Flight Compartment Seat Inertial Reel
25-030-00	25-030-00	25-030-00-01 25-030-00-02 25-030-00-03 25-030-00-04		VISUAL CHECK	Passenger Compartment Seats
25-040-00	25-040-00	25-040-00-01 25-040-00-02 25-040-00-03		OPERATIONAL	Passenger Seat Belts
25-045-00	25-045-00	25-045-00-01		OPERATIONAL	Crew and/or Attendant Rest Bunk Belts
25-050-00	25-050-00	25-050-00-01		OPERATIONAL	Passenger Compartment Seats
25-055-00	25-055-00	25-055-00-01		OPERATIONAL	Passenger Compartment Articulating Seats
25-056-00	25-056-00	25-056-00-01 25-056-00-02 25-056-00-03 25-056-00-04		OPERATIONAL	Inflatable Seat Restraint System
25-057-00	25-057-00	25-057-00-01		INSPECTION - DETAILED	Inflatable Seat Restraint System Seatbelt Airbag Assembly (SAA)
25-058-00	25-058-00	25-058-00-01 25-058-00-02 25-058-00-03		DISCARD	Inflatable Seat Restraint System Gas Generator Assembly (GGA)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
25-059-00	25-059-00	25-059-00-01 25-059-00-02 25-059-00-03		RESTORE	Inflatable Seat Restraint System Electronic Module Assembly (EMA) Battery
25-060-00	25-060-00	25-060-00-01		OPERATIONAL	Attendant Seat Restraint
25-062-00	25-062-00	25-062-00-01		RESTORE	Life Raft
25-065-00	25-065-00	25-065-00-01		RESTORE	Off-Wing Emergency Escape Slide Assembly
25-066-00	25-066-00	25-066-00-01		VISUAL CHECK	Off-Wing Inflation Cylinder Pressure
25-067-00	25-067-00	25-067-00-01		OPERATIONAL	Off-Wing Slide Compartment Door Lock/Latch System
25-069-00	25-069-00	25-069-00-01		REPLACE	Off-Wing Slide Inflation Cylinder Squib Cartridges
25-070-00	25-070-00	25-070-00-01		INSPECTION - DETAILED	Lavatory Waste Compartment Doors & Flaps
25-071-00	25-071-00	25-071-00-01 25-071-00-02		DISCARD	Off - Wing Slide Reservoir
25-085-00	25-085-00	25-085-00-01		INSPECTION - DETAILED	Aux Fuel Tank Barrier Panel
25-090-00	25-090-00	25-090-00-01		VISUAL CHECK	Flight Deck Escape Rope
25-095-00	25-095-00	25-095-00-01 25-095-00-02		INSPECTION - DETAILED	Overwing Exit Door Lifeline
25-100-00	25-100-00	25-100-00-01		RESTORE	Survival Kit - Life Vests (Jackets)
25-105-00	25-105-00	25-105-00-01		VISUAL CHECK	Crash Axe
25-110-00	25-110-00	25-110-00-01 25-110-00-02		RESTORE	Life Vests (Jackets)
25-115-00	25-115-00	25-115-00-01 25-115-00-02		RESTORE	Flotation Cots
25-120-00	25-120-00	25-120-00-01		FUNCTIONAL	Emergency Locator Transmitters
25-125-00	25-125-00	25-125-00-01		DISCARD	Emergency Locator Transmitter (Batteries)
25-130-00	25-130-00	25-130-00-01		OPERATIONAL	Emergency Evacuation Signal System





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
25-135-00	25-135-00	25-135-00-01		VISUAL CHECK	First Aid Kits
25-140-00	25-140-00	25-140-00-01		RESTORE	Emergency Medical Kit
25-145-00	25-145-00	25-145-00-01		RESTORE	Automated External Defibrillator
25-150-00	25-150-00	25-150-00-01		VISUAL CHECK	Smokehoods
25-160-00	25-160-00	25-160-00-01		OPERATIONAL	Emergency Flashlights
25-170-00	25-170-00	25-170-00-01		REPLACE	Emergency Flashlight Batteries
25-180-00	25-180-00	25-180-00-01		REPLACE	Smokehoods
25-190-00	25-190-00	25-190-00-01		OPERATIONAL	Megaphones
25-200-00	25-200-00	25-200-00-01		REPLACE	Megaphone Batteries
25-210-00	25-210-00	25-210-00-01		RESTORE	Emergency Escape Slide/Rafts
25-230-00	25-230-00	25-230-00-01		VISUAL CHECK	Slide/Raft Inflation Cylinder Pressure
25-240-00	25-240-00	25-240-00-01 25-240-00-02		OPERATIONAL	Passenger Entry Door Emergency Escape Slide
25-250-00	25-250-00	25-250-00-01		INSPECTION - DETAILED	Overhead Flight Crew Rest (OFCR) Seat Assembly Lanyard
25-260-00	25-260-00	25-260-00-01 25-260-00-02		OPERATIONAL	Overhead Crew/Attendant Rests Secondary Egress System
25-270-00	25-270-00	25-270-00-01 25-270-00-02		INSPECTION - DETAILED	Overhead Crew/Attendant Rests Secondary Egress Grab Bar
25-290-00	25-290-00	25-290-00-01		FUNCTIONAL	Tip Alarm System (TAS)
25-320-00	25-320-00	25-320-00-01		INSPECTION - DETAILED	Rigid Cargo Barrier Sliding Door Seal
26-010-00	26-010-00	26-010-00-01		OPERATIONAL	Engine Fire/Overheat Detection
26-014-01	26-014-01	26-014-01-01		OPERATIONAL	Passenger Cabin, High Wall Suites Smoke Detector System
26-014-02	26-014-02	26-014-02-01		OPERATIONAL	Passenger Cabin, High Wall Suites Smoke Detectors System
26-014-03	26-014-03	26-014-03-01		RESTORE	Passenger Cabin, High Wall Suites Smoke Detector System



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
26-015-00	26-015-00	26-015-00-01		OPERATIONAL	APU Fire Detection Control Cards
26-020-00	26-020-00	26-020-00-01		OPERATIONAL	Duct Leak & Overheat Detection Control Card
26-030-00	26-030-00	26-030-00-01 26-030-00-02 26-030-00-03		OPERATIONAL	Lavatory and Overhead Cross-Aisle Stowage (If Installed) Smoke Detector Circuitry
26-035-00	26-035-00	26-035-00-01 26-035-00-04 26-035-00-05 26-035-00-06		OPERATIONAL	OFCR/OFAR Smoke Detector System
26-040-00	26-040-00	26-040-00-01 26-040-00-02 26-040-00-03		OPERATIONAL	Lavatory and Overhead Cross-Aisle Stowage (If Installed) Smoke Detectors
26-045-00	26-045-00	26-045-00-01 26-045-00-04 26-045-00-05 26-045-00-06		OPERATIONAL	OFCR/OFAR Smoke Detector System
26-050-00	26-050-00	26-050-00-01		OPERATIONAL	Wheel Well Fire Detection Sensing Element
26-060-00	26-060-00	26-060-00-01		OPERATIONAL	Duct Leak and Overheat Detection Sensing Element
26-061-00	26-061-00	26-061-00-01		OPERATIONAL	Lower Lobe Attendant Rest (LLAR) Smoke Detection System
26-062-00	26-062-00	26-062-00-01		OPERATIONAL	Lower Lobe Attendant Rest Smoke Detection System
26-064-00	26-064-00	26-064-00-01		FUNCTIONAL	Lower Lobe Attendant Rest (LLAR) Smoke Detection System
26-066-00	26-066-00	26-066-00-01 26-066-00-02		FUNCTIONAL	Cargo Smoke Detector Water Separators
26-067-00	26-067-00	26-067-00-01 26-067-00-02		FUNCTIONAL	Cargo Compartment Smoke Detector Heaters and Controllers
26-068-00	26-068-00	26-068-00-01 26-068-00-02 26-068-00-03		OPERATIONAL	Flight Crew Rest (FCR) or Main Deck Crew Rest (MDCR) Smoke Detection System



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
26-069-00	26-069-00	26-069-00-01 26-069-00-02 26-069-00-03		FUNCTIONAL	Flight Crew Rest (FCR) or Main Deck Crew Rest (MDCR) Smoke Detection System
26-070-00	26-070-00	26-070-00-01 26-070-00-02 26-070-00-03		OPERATIONAL	Engine Fire Extinguishing Bottle Pressure Switches
26-090-00	26-090-00	26-090-00-01 26-090-00-02 26-090-00-03		OPERATIONAL	Engine Fire Switches
26-100-00	26-100-00	26-100-00-01 26-100-00-02 26-100-00-03		FUNCTIONAL	Engine Fire Extinguishing Distribution Lines
26-120-00	26-120-00	26-120-00-01		FUNCTIONAL	Engine Fire Bottle Extinguishing Bottle Pressure Switches
26-130-00	26-130-00	26-130-00-01		REPLACE	Engine Fire Bottle Squib Cartridges
26-140-00	26-140-00	26-140-00-01		OPERATIONAL	APU Fire Extinguishing Bottle Pressure Switch
26-150-00	26-150-00	26-150-00-01		FUNCTIONAL	APU Fire Switch
26-170-00	26-170-00	26-170-00-01		FUNCTIONAL	APU Fire Extinguishing Bottle Pressure Switch
26-180-00	26-180-00	26-180-00-01		REPLACE	APU Fire Bottle Squib Cartridges
26-190-00	26-190-00	26-190-00-01		OPERATIONAL	Cargo Fire Extinguishing Bottle Pressure Switches
26-200-00	26-200-00	26-200-00-01		OPERATIONAL	Cargo Fire Extinguishing Arm & Discharge Switches
26-201-00	26-201-00	26-201-00-01		OPERATIONAL	Main Deck Cargo Fire Extinguishing ARM and DEPRESSURIZATION Switches
26-210-00	26-210-00	26-210-00-01		FUNCTIONAL	Cargo Fire Extinguishing Tubing
26-220-00	26-220-00	26-220-00-01		FUNCTIONAL	Cargo Fire Extinguishing Bottle Pressure Switches
26-235-00		26-235-00-01		INSPECTION - DETAILED	Cargo Fire Extinguishing Bottles
26-240-00	26-240-00	26-240-00-01		REPLACE	Cargo Compartment Fire Extinguishing Bottle SQUIB Cartridges
26-250-00	26-250-00	26-250-00-01		RESTORE	Cargo Fire Extinguishing System Filter/Regulator



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
26-260-00	26-260-00	26-260-00-01		REPLACE	Cargo Fire Extinguishing Flow Valve Squib Cartridges
26-270-00	26-270-00	26-270-00-01 26-270-00-02		INSPECTION - DETAILED	Lavatory Waste Compartment Fire Extinguisher Bottles
26-272-00	26-272-00	26-272-00-01		OPERATIONAL	Lower Lobe Attendant Rest Fire Extinguishing System
26-274-00	26-274-00	26-274-00-01		REPLACE	Lower Lobe Attendant Rest Fire Extinguishing System
26-276-00	26-276-00	26-276-00-01		VISUAL CHECK	LLAR Fire Extinguishing Tubing
26-277-00	26-277-00	26-277-00-01		OPERATIONAL	Lower Lobe Attendant Rest Fire Extinguishing System
26-278-00	26-278-00	26-278-00-01		FUNCTIONAL	Lower Lobe Attendant Rest Fire Extinguishing System
26-290-00	26-290-00	26-290-00-01 26-290-00-02		INSPECTION - DETAILED	Portable Halon Fire Extinguishers
26-300-00	26-300-00	26-300-00-01 26-300-00-02		INSPECTION - DETAILED	Portable Water Fire Extinguishers
27-010-00	27-010-00	27-010-00-01		SERVICE	Stabilizer Primary Brake Housing
27-020-00	27-020-00	27-020-00-01		SERVICE	Slat Power Drive Unit and Slat Electric Motor
27-030-00	27-030-00	27-030-00-01 27-030-00-02		SERVICE	Left and Right Inboard and Outboard Leading Edge No-Back Brake Offset Gearbox
27-040-00	27-040-00	27-040-00-01		SERVICE	Flap Power Drive Unit and Flap Electric Motor
27-050-00	27-050-00	27-050-00-01 27-050-00-02		SERVICE	Left and Right Inboard and Outboard Flap Transmissions
27-055-00	27-055-00	27-055-00-01		OPERATIONAL	Flap Transmission No Back Brakes
27-060-00	27-060-00	27-060-00-01 27-060-00-02		SERVICE	Left and Right Flap Skewed Roller No-Back Brakes
27-140-00	27-140-00	27-140-00-01		OPERATIONAL	Primary Flight Computers (PFC)
27-150-00	27-150-00	27-150-00-01		OPERATIONAL	Primary Flight Computer Disconnect Switch
27-160-00	27-160-00	27-160-00-01		OPERATIONAL	Actuator Control Electronics (ACE)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-170-00	27-170-00	27-170-00-01 27-170-00-02 27-170-00-03		FUNCTIONAL	Wing Aileron and Flaperon System Hydraulic Fuses
27-180-00	27-180-00	27-180-00-01		FUNCTIONAL	Rudder Check Valve
27-190-00	27-190-00	27-190-00-01		OPERATIONAL	Wheel Jam Breakout Mechanism
27-200-00	27-200-00	27-200-00-01		FUNCTIONAL	Rudder Power Control Units
27-210-00	27-210-00	27-210-00-01		OPERATIONAL	Control Column Breakout Mechanism
27-220-00	27-220-00	27-220-00-01		OPERATIONAL	Elevator Power Control Units
27-230-00	27-230-00	27-230-00-01		FUNCTIONAL	Column Force Transducer
27-240-00	27-240-00	27-240-00-01		FUNCTIONAL	Elevator Power Control Unit Bearings
27-250-00	27-250-00	27-250-00-01		OPERATIONAL	Alternate Stabilizer Trim Control System
27-260-00	27-260-00	27-260-00-01		OPERATIONAL	Stabilizer Cutout Switches
27-270-00	27-270-00	27-270-00-01		OPERATIONAL	Stabilizer Secondary Brakes
27-280-00	27-280-00	27-280-00-01		FUNCTIONAL	Stabilizer Trim Limit Switches
27-290-00	27-290-00	27-290-00-01		INSPECTION - DETAILED	Stabilizer Ballscrew Safety Rod
27-300-00	27-300-00	27-300-00-01		INSPECTION - DETAILED	Stabilizer Trim Actuator Gimbals
27-305-00		27-305-00-01		INSPECTION - DETAILED	Stabilizer Trim Actuator - Karon Lined Bushings
27-310-00	27-310-00	27-310-00-01		OPERATIONAL	High Lift System Alternate Control Switches
27-320-00	27-320-00	27-320-00-01 27-320-00-02		FUNCTIONAL	Wing TE Flap No-Back Brakes - Left and Right
27-330-00	27-330-00	27-330-00-01		OPERATIONAL	Auto Speedbrake Function
27-340-00	27-340-00	27-340-00-01 27-340-00-02		OPERATIONAL	Leading Edge Slat No-Back Brakes - Left and Right



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-350-00	27-350-00	27-350-00-01		OPERATIONAL	Autoslat Priority Valves - Main Landing Gear
27-360-00	27-360-00	27-360-00-01 27-360-00-02		OPERATIONAL	Leading Edge Slat Skew/Loss Cable - Left and Right
27-370-00	27-370-00	27-370-00-01		REPLACE	Spoiler Auxiliary Retract Device (SARD) Pyrotechnic Cartridge
27-380-00	27-380-00	27-380-00-01		OPERATIONAL	Spoiler Auxiliary Retract Device (SARD) Operational Check
27-400-00	27-400-00	27-400-00-01		OPERATIONAL	Aileron Trim Inhibit Operational Check
27-410-00	27-410-00	27-410-00-01		FUNCTIONAL	Nose Gear Pressure Switch
27-415-00	27-415-00	27-415-00-01		FUNCTIONAL	Nose Gear Pressure Transducer
27-420-00	27-420-00	27-420-00-01		OPERATIONAL	Rudder Pedal Pogo
27-430-00	27-430-00	27-430-00-01		FUNCTIONAL	Rudder Power Control Unit
27-440-00	27-440-00	27-440-00-01		FUNCTIONAL	Stabilizer Freeplay
27-450-00	27-450-00	27-450-00-01		INSPECTION - DETAILED	Stabilizer Trim Ballscrew, Ballnut, and Ballnut Return Tubes
27-460-00	27-460-00	27-460-00-01		FUNCTIONAL	TRAILING EDGE FLAP SUPPORT LINKAGE PIN FREEPLAY
27-460-01	27-460-01	27-460-01-01		FUNCTIONAL	TRAILING EDGE FLAP SUPPORT LINKAGE PIN FREEPLAY
27-701-01		27-701-01-01		SPECIAL DETAILED	Safety Rod, Horizontal Stabilizer Trim Actuator
28-010-00	28-010-00	28-010-00-01		OPERATIONAL	Fuel Vent Float Valves
28-011-00	28-011-00	28-011-00-01 28-011-00-02		FUNCTIONAL	Hydraulic Tube Spar Penetration (SFAR 88)
28-012-00	28-012-00	28-012-00-01		VISUAL CHECK	Interspace drain valves (AUX TANK)
28-013-20	28-013-20	28-013-20-01 28-013-20-02		FUNCTIONAL	Pressure Relief Valve (SFAR 88)
28-013-30	28-013-30	28-013-30-01 28-013-30-02		FUNCTIONAL	Overfill Float Switch. (SFAR 88)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
28-013-40	28-013-40	28-013-40-01 28-013-40-02		FUNCTIONAL	Vent Scoop Upper Duct (SFAR 88)
28-015-00	28-015-00	28-015-00-01 28-015-00-02		INSPECTION - GEN VISUAL	Surge Tank Vent Flame Arrestor
28-015-20	28-015-20	28-015-20-01 28-015-20-02 28-015-20-03 28-015-20-04 28-015-20-05		FUNCTIONAL	Scavenge Jet Pumps (SFAR 88)
28-020-00	28-020-00	28-020-00-01		OPERATIONAL	Engine Fuel Suction Feed System
28-021-10	28-021-10	28-021-10-01 28-021-10-02 28-021-10-03 28-021-10-04 28-021-10-05 28-021-10-06		INSPECTION - DETAILED	In-tank Tubing and Equipment Static Ground Straps and Clamps (SFAR 88)
28-021-20	28-021-20	28-021-20-01 28-021-20-02		FUNCTIONAL	Fueling Shutoff Valve (SFAR 88)
28-021-30	28-021-30	28-021-30-01 28-021-30-02		FUNCTIONAL	Fueling Receptacle (SFAR 88)
28-022-30	28-022-30	28-022-30-01 28-022-30-02 28-022-30-03		FUNCTIONAL	Pump Housing (SFAR 88)
28-022-40	28-022-40	28-022-40-01 28-022-40-02 28-022-40-03		FUNCTIONAL	Boost, Center Tank Override/Jettison Pumps and Main Tank Jettison Pumps. (SFAR 88)
28-022-50	28-022-50	28-022-50-01 28-022-50-02 28-022-50-03		FUNCTIONAL	Motor Operated Valve (SFAR 88)
28-022-60	28-022-60	28-022-60-01 28-022-60-02		OPERATIONAL	GFI Relay Check



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
28-022-65		28-022-65-01 28-022-65-02 28-022-65-03 28-022-65-04 28-022-65-05 28-022-65-06		OPERATIONAL	AC Fuel Pump Ground Fault Interrupter (GFI) and Ground Fault Protector (GFP)
28-023-00	28-023-00	28-023-00-01		REPLACE	Fuel Spar Valve Battery
28-024-00	28-024-00	28-024-00-01		FUNCTIONAL	Transfer tube penetration (AUX TANK)
28-025-00	28-025-00	28-025-00-01 28-025-00-03		OPERATIONAL	Engine Fuel Spar Valve
28-025-20	28-025-20	28-025-20-01		FUNCTIONAL	APU DC Fuel Pump (SFAR 88)
28-025-30	28-025-30	28-025-30-01		FUNCTIONAL	APU Fuel Shutoff Valve (SFAR 88)
28-025-40	28-025-40	28-025-40-01		FUNCTIONAL	APU Isolation Valve (SFAR 88)
28-026-10	28-026-10	28-026-10-01		FUNCTIONAL	Defuel Valve (SFAR 88)
28-030-00	28-030-00	28-030-00-01		FUNCTIONAL	APU Fuel Supply Line And Shroud
28-031-20	28-031-20	28-031-20-01 28-031-20-02		FUNCTIONAL	Jettison Nozzle Valve (SFAR 88)
28-031-30	28-031-30	28-031-30-01 28-031-30-02		FUNCTIONAL	Jettison Isolation Valve (SFAR 88)
28-031-40	28-031-40	28-031-40-01 28-031-40-02		FUNCTIONAL	Jettison Nozzle Manifold (SFAR 88)
28-040-00	28-040-00	28-040-00-01		OPERATIONAL	Defuel Valve Actuator
28-041-10	28-041-10	28-041-10-01 28-041-10-02 28-041-10-03 28-041-10-04		INSPECTION - DETAILED	FQIS Wiring (SFAR 88)





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
28-041-20	28-041-20	28-041-20-01 28-041-20-02 28-041-20-03 28-041-20-04		INSPECTION - DETAILED	FQIS Equipment (SFAR 88)
28-041-30	28-041-30	28-041-30-01		FUNCTIONAL	FQIS - Out Tank Wiring (SFAR 88)
28-045-00	28-045-00	28-045-00-01		OPERATIONAL	EFLI tank circuits (AUX TANK)
28-045-10	28-045-10	28-045-10-01		OPERATIONAL	EFLI tank unit (AUX TANK)
28-045-20	28-045-20	28-045-20-01		OPERATIONAL	EFLI Processor Display Unit (AUX TANK)
28-050-00	28-050-00	28-050-00-01		OPERATIONAL	Fuel Jettison System
28-050-10	28-050-10	28-050-10-01		FUNCTIONAL	Fuel Scavenge System
28-060-00	28-060-00	28-060-00-01	W-28-070-00-01	OPERATIONAL	Densitometers of Fuel Quantity Indicating System
28-070-00	28-070-00	28-070-00-01	W-28-060-00-01	OPERATIONAL	Tank Units of Fuel Quantity Indicating System
28-080-00	28-080-00	28-080-00-01		OPERATIONAL	Fuel Quantity Processor Unit (FQPU)
28-085-00		28-085-00-01		CHECK/INSP	Center Wing Fuel Tank FQIS Wiring
28-090-00		28-090-00-01		CHECK/INSP	Fuel Tanks Microbial Growth
28-111-00		28-111-00-01		INSPECTION - DETAILED	External Wires Over Center Fuel Tank (28-AWL-01)
28-112-00		28-112-00-01		OPERATIONAL	Auxiliary Fuel Tank AC Fuel Pump Uncommanded On/Auto Shutoff
28-113-00		28-113-00-01		INSPECTION - DETAILED	External Wires Over the Auxiliary Fuel Tank
28-120-00		28-120-00-01		INSPECTION - DETAILED	Out-of-Tank Wire Bundle Cushion Clamps and Teflon Sleeving
29-010-00	29-010-00	29-010-00-01		SERVICE	Air Drive Unit
29-030-00	29-030-00	29-030-00-01		FUNCTIONAL	Hydraulic System Gross Internal Leakage
29-040-00	29-040-00	29-040-00-01 29-040-00-02 29-040-00-03		VISUAL CHECK	Center Hydraulic System Return Filter Module



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
29-050-00	29-050-00	29-050-00-01 29-050-00-02 29-050-00-03		CHECK/INSP	Hydraulic System Return Filter Module
29-060-00	29-060-00	29-060-00-01 29-060-00-02		CHECK/INSP	Hydraulic System EDP Pressure and Case Drain Filter Module
29-070-00	29-070-00	29-070-00-01 29-070-00-02		VISUAL CHECK	Hydraulic System EDP Pressure and Case Drain Filter Module
29-080-00	29-080-00	29-080-00-01 29-080-00-02 29-080-00-03		CHECK/INSP	Hydraulic System ACMP Pressure and Case Drain Filter Module
29-090-00	29-090-00	29-090-00-01 29-090-00-02 29-090-00-03		VISUAL CHECK	Hydraulic System ACMP Pressure and Case Drain Filter Module
29-100-00	29-100-00	29-100-00-01		CHECK/INSP	ADP Pressure and Case Drain Filter Module
29-110-00	29-110-00	29-110-00-01 29-110-00-02 29-110-00-03 29-110-00-04 29-110-00-05 29-110-00-06		VISUAL CHECK	ADP Pressure and Case Drain Filter Module
29-120-00	29-120-00	29-120-00-01 29-120-00-02		FUNCTIONAL	Air Drive Unit (ADU) and ADU Heater System
29-130-00	29-130-00	29-130-00-01		OPERATIONAL	Center Hydraulic Isolation System
29-140-00	29-140-00	29-140-00-01 29-140-00-02 29-140-00-03		RESTORE	Hydraulic System Reservoir Pressurization Module
29-150-00	29-150-00	29-150-00-01	B-29-160-00-01	OPERATIONAL	Ram Air Turbine
29-160-00	29-160-00	29-160-00-01	A-29-150-00-01	INSPECTION - GEN VISUAL	Ram Air Turbine
29-170-00	29-170-00	29-170-00-01		VISUAL CHECK	Ram Air Turbine



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
29-180-00	29-180-00	29-180-00-01 29-180-00-02		FUNCTIONAL	Hydraulic Accumulators
30-010-00	30-010-00	30-010-00-01		OPERATIONAL	Flight Compartment No. 1 Window Backup Anti-Fog
31-010-00	31-010-00	31-010-00-01 31-010-00-02 31-010-00-03 31-010-00-04 31-010-00-05 31-010-00-06		FUNCTIONAL	Flight Data Recorder System
31-020-00	31-020-00	31-020-00-01 31-020-00-02		REPLACE	Flight Data Recorder System
31-030-00	31-030-00	31-030-00-01 31-030-00-02 31-030-00-03		OPERATIONAL	Flight Data Recorder Underwater Locator Beacon (ULB)
31-040-00	31-040-00	31-040-00-01		OPERATIONAL	Airplane Information Management System
31-050-00	31-050-00	31-050-00-01		OPERATIONAL	Airplane Information Management System - Coaxial Splitter
31-060-00	31-060-00	31-060-00-01		OPERATIONAL	Warning Electronic System
31-070-00	31-070-00	31-070-00-01		OPERATIONAL	Primary Display System - Inboard Select Switching
31-080-00	31-080-00	31-080-00-01		OPERATIONAL	Primary Display System - Instrument Source Select Switching
31-090-00	31-090-00	31-090-00-01		OPERATIONAL	Primary Display System - Display Control Switches
31-100-00		31-100-00-01		OPERATIONAL	Fire Warning System
32-010-00	32-010-00	32-010-00-01		SERVICE	Tires
32-011-00	32-011-00	32-011-00-01		FUNCTIONAL	Tire Pressure Indication System (TPIS)
32-012-00	32-012-00	32-012-00-01		FUNCTIONAL	Tire and Brake Monitoring System (TBMS)
32-020-00	32-020-00	32-020-00-01		FUNCTIONAL	Brake Accumulator
32-120-00	32-120-00	32-120-00-01		OPERATIONAL	Landing Gear Alternate Extension System
32-130-00	32-130-00	32-130-00-01		OPERATIONAL	Landing Gear Downlock Springs and Gear Release Hooks



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
32-140-00	32-140-00	32-140-00-01	P-32-260-00-01 R-32-250-00-01	OPERATIONAL	Alternate Source Select Valve
32-150-00	32-150-00	32-150-00-01		OPERATIONAL	Accumulator Isolation Valve
32-160-00	32-160-00	32-160-00-01		FUNCTIONAL	Brake Accumulator
32-170-00	32-170-00	32-170-00-01		FUNCTIONAL	Normal and Alternate Brake Systems
32-180-00	32-180-00	32-180-00-01 32-180-00-02		FUNCTIONAL	Main Landing Gear Antiskid Module Hydraulic Fuses - Left and Right
32-190-00	32-190-00	32-190-00-01		INSPECTION - GEN VISUAL	Wheels
32-200-00	32-200-00	32-200-00-01		INSPECTION - GEN VISUAL	Tires
32-210-00	32-210-00	32-210-00-01		INSPECTION - GEN VISUAL	Brakes
32-220-00	32-220-00	32-220-00-01		RESTORE	Main Landing Gear
32-230-00	32-230-00	32-230-00-01		RESTORE	Nose Landing Gear
32-240-00	32-240-00	32-240-00-01		VISUAL CHECK	Tail Skid
32-250-00	32-250-00	32-250-00-01		SERVICE	Main Landing Gear Shock Strut Servicing
32-260-00	32-260-00	32-260-00-01		FUNCTIONAL	Main Landing Gear Shock Strut Dimension "A"
32-270-00	32-270-00	32-270-00-01		VISUAL CHECK	Nose Landing Gear Pressure Gage
32-280-00	32-280-00	32-280-00-01		SERVICE	Nose Landing Gear Shock Strut Servicing
32-300-00	32-300-00	32-300-00-01 32-300-00-02		INSPECTION - GEN VISUAL	Main Landing Gear Mechanisms
32-310-00	32-310-00	32-310-00-01 32-310-00-02		INSPECTION - GEN VISUAL	Main Landing Gear Door Mechanisms
32-320-00	32-320-00	32-320-00-01		INSPECTION - GEN VISUAL	Nose Landing Gear Mechanisms
32-330-00	32-330-00	32-330-00-01		INSPECTION - GEN VISUAL	Nose Landing Gear Door Mechanisms



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
32-800-00	32-800-00	32-800-00-01		ZONAL (GV)	Nose Landing Gear and Landing Gear Doors - From the Ground
32-802-00	32-802-00	32-802-00-01		ZONAL (GV)	Nose Landing Gear and Landing Gear Doors
32-804-01	32-804-01	32-804-01-01		ZONAL (GV)	Left Main Landing Gear and Landing Gear Doors - From the Ground
32-806-01	32-806-01	32-806-01-01		ZONAL (GV)	Left Main Landing Gear and Landing Gear Doors
32-808-02	32-808-02	32-808-02-01		ZONAL (GV)	Right Main Landing Gear and Landing Gear Doors - From the Ground
32-810-02	32-810-02	32-810-02-01		ZONAL (GV)	Right Main Landing Gear and Landing Gear Doors
33-010-00	33-010-00	33-010-00-01		OPERATIONAL	Flight Compartment Panel Flood Lights
33-020-00	33-020-00	33-020-00-01		OPERATIONAL	Integral Panel Lights
33-030-00	33-030-00	33-030-00-01		OPERATIONAL	Integral Panel Lights
33-040-00	33-040-00	33-040-00-01		OPERATIONAL	Indicator Lights DIM/BRT Relays
33-060-00	33-060-00	33-060-00-01		OPERATIONAL	Emergency Lights
33-070-00	33-070-00	33-070-00-01		OPERATIONAL	Emergency Lights
33-075-00	33-075-00	33-075-00-01		INSPECTION - GEN VISUAL	Photoluminescent floor proximity lighting.
33-076-00	33-076-00	33-076-00-01		FUNCTIONAL	Cabin ceiling lighting intensity
33-080-00	33-080-00	33-080-00-01		FUNCTIONAL	Emergency Lights Battery Packs
33-090-00	33-090-00	33-090-00-01		RESTORE	Emergency Lights Battery Packs
33-095-00	33-095-00	33-095-00-01 33-095-00-02 33-095-00-03 33-095-00-04 33-095-00-05 33-095-00-06		RESTORE	OFCCR/OFAR Backup Lighting Power Supply Battery Packs
33-100-00	33-100-00	33-100-00-01		OPERATIONAL	Lower Lobe Attendant Rest (LLAR) Back-up Lighting System



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
33-105-00	33-105-00	33-105-00-01 33-105-00-02 33-105-00-03 33-105-00-04 33-105-00-05 33-105-00-06		OPERATIONAL	Overhead Flight Crew Rest and/or Overhead Flight Attendant Rest Backup Lights System
33-110-00	33-110-00	33-110-00-01		FUNCTIONAL	Lower Lobe Attendant Rest (LLAR) Back-up Lighting System
33-115-00	33-115-00	33-115-00-01 33-115-00-02 33-115-00-03 33-115-00-04 33-115-00-05 33-115-00-06		FUNCTIONAL	OFAR/OFAR Back-up Lighting Power Packs
33-120-00	33-120-00	33-120-00-01		RESTORE	Lower Lobe Attendant Rest (LLAR) Back-up Lighting System
34-020-00		34-020-00-01 34-020-00-02 34-020-00-04 34-020-00-05		FUNCTIONAL	ATC Transponder System
35-020-00	35-020-00	35-020-00-01		CHECK/INSP	Crew Oxygen System
35-040-00	35-040-00	35-040-00-01		OPERATIONAL	Crew Oxygen Mask, Diluter Demand Regulator, and Microphone
35-050-00	35-050-00	35-050-00-01		INSPECTION - DETAILED	Crew Oxygen Masks
35-060-00	35-060-00	35-060-00-01 35-060-00-02 35-060-00-03 35-060-00-04		OPERATIONAL	Passenger Oxygen System Door Latch/Actuator
35-070-00	35-070-00	35-070-00-01 35-070-00-02 35-070-00-03		VISUAL CHECK	Passenger Chemical Oxygen Generators
35-071-00	35-071-00	35-071-00-01		VISUAL CHECK	Lavatory Constant Dispensing (CDS) oxygen System



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
35-080-00	35-080-00	35-080-00-01 35-080-00-02 35-080-00-03 35-080-00-04		DISCARD	Passenger Chemical Oxygen Generators
35-081-00	35-081-00	35-081-00-01		DISCARD	Lavatory oxygen Constant Dispensing System (CDS) cylinder discard.
35-090-00	35-090-00	35-090-00-01 35-090-00-02 35-090-00-03 35-090-00-04 35-090-00-05 35-090-00-06 35-090-00-07		INSPECTION - DETAILED	Passenger Oxygen Masks
35-110-00	35-110-00	35-110-00-01 35-110-00-02		OPERATIONAL	Passenger Gaseous Oxygen System Pressure Lines
35-120-00	35-120-00	35-120-00-01 35-120-00-02		OPERATIONAL	Passenger/ Supernumerary Gaseous Oxygen System Pressure Regulator
35-130-00	35-130-00	35-130-00-01		OPERATIONAL	Therapeutic Oxygen System
35-140-00	35-140-00	35-140-00-01 35-140-00-02		OPERATIONAL	Passenger/ Supernumerary Gaseous Oxygen System Flow Control Units
35-160-00	35-160-00	35-160-00-01	W-35-161-00-01	CHECK/INSP	Portable Oxygen Equipment Pressure
35-161-00	35-161-00	35-161-00-01	W-35-160-00-01	INSPECTION - GEN VISUAL	Portable oxygen disposable type masks
35-162-00	35-162-00	35-162-00-01		INSPECTION - DETAILED	Portable oxygen non-disposable type masks
35-163-00	35-163-00	35-163-00-01		DISCARD	Portable oxygen cylinders
35-164-00	35-164-00	35-164-00-01		DISCARD	Crew Oxygen Cylinders
35-220-00	35-220-00	35-220-00-01		FUNCTIONAL	Supernumerary Oxygen System Pressure Decay
35-230-00	35-230-00	35-230-00-01 35-230-00-02		INSPECTION - GEN VISUAL	Supernumerary Oxygen System Pressure Indications



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
35-240-00	35-240-00	35-240-00-01		OPERATIONAL	Supernumerary Cylinder Pressure Regulator
35-250-00	35-250-00	35-250-00-01		OPERATIONAL	Supernumerary System Pressure Regulator
35-260-00	35-260-00	35-260-00-01		OPERATIONAL	Supernumerary Stowage Box and Mask Regulator
35-270-00	35-270-00	35-270-00-01		OPERATIONAL	Supernumerary Oxygen Mask and Diluter Demand Regulator
35-280-00	35-280-00	35-280-00-01		VISUAL CHECK	Supernumerary Oxygen Masks
36-010-00	36-010-00	36-010-00-01		FUNCTIONAL	Engine Air Supply Manifold
36-020-00	36-020-00	36-020-00-01 36-020-00-02		FUNCTIONAL	Engine Air Supply IP Check Valve - Left and Right
36-022-00	36-022-00	36-022-00-01 36-022-00-02 36-022-00-03 36-022-00-04		FUNCTIONAL	Engine Air Supply IP Check Valve - Left and Right
36-024-00	36-024-00	36-024-00-01 36-024-00-02		FUNCTIONAL	Engine Air Supply IP Check Valve - Left and Right
36-030-00	36-030-00	36-030-00-01		OPERATIONAL	Air Supply Manifold Dual Temperature Sensor
38-010-00	38-010-00	38-010-00-01		DISINFECT	Potable Water Supply System
38-020-00	38-020-00	38-020-00-01		OPERATIONAL	Potable Water Isolation Valves and Cables
38-030-00	38-030-00	38-030-00-01 38-030-00-02 38-030-00-03 38-030-00-04		FUNCTIONAL	Waste Drain Ball Valve & Fitting Seals
38-050-00	38-050-00	38-050-00-01 38-050-00-02 38-050-00-03		RESTORE	Waste Tank Liquid Separators
38-070-00	38-070-00	38-070-00-01 38-070-00-02		RESTORE	Vacuum Blower Air Filter
38-080-00	38-080-00	38-080-00-01 38-080-00-02		OPERATIONAL	Waste Tank Quantity Indication System





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
38-090-00	38-090-00	38-090-00-01		OPERATIONAL	Waste Tank Quantity Indication
38-100-00	38-100-00	38-100-00-01		REPLACE	Compressor Inlet Filter
38-110-00	38-110-00	38-110-00-01		REPLACE	APU Duct Bleed Air Inline Filter
38-120-00	38-120-00	38-120-00-01		OPERATIONAL	Potable Water Pressure Relief Valve
38-130-00	38-130-00	38-130-00-01		OPERATIONAL	Potable Water System Pressure Limit Switch and Relay Circuit
38-140-00	38-140-00	38-140-00-01		RESTORE	Fill Line Water Filter of Pump Based Potable Water System
47-100-00	47-100-00	47-100-00-01		RESTORE	Restore the Ozone Converter (off-aircraft).
47-110-00	47-110-00	47-110-00-01		RESTORE	Clean the Primary Heat Exchanger (off-aircraft).
47-120-00	47-120-00	47-120-00-01		FUNCTIONAL	Functionally check the Regenerative Heat Exchanger (off-aircraft).
47-130-00	47-130-00	47-130-00-01		FUNCTIONAL	Functionally Check the Filter Differential Pressure Sensor Switch (off-aircraft).
47-135-00		47-135-00-01		FUNCTIONAL	Functional Check of the NGS thermal switch
47-140-00	47-140-00	47-140-00-01		VISUAL CHECK	Visually Check for Fluid Accumulation Through the Drain Valve or Drain Cap.
47-150-00	47-150-00	47-150-00-01		INSPECTION - DETAILED	Inspect (detailed) the Nitrogen Enriched Air (NEA) distribution lines
47-160-00	47-160-00	47-160-00-01		OPERATIONAL	Operationally check the center tank vent cross flow check valve.
49-010-00	49-010-00	49-010-00-01		SERVICE	APU and Generator Lubrication System
49-020-00	49-020-00	49-020-00-01		REPLACE	APU 1st & 2ND Stage Compressor Impellers
49-030-00	49-030-00	49-030-00-01		REPLACE	APU Turbine Wheels
49-040-00	49-040-00	49-040-00-01		REPLACE	APU Load Compressor Impeller
49-060-00	49-060-00	49-060-00-01		FUNCTIONAL	APU Combustor Drain Valve
52-009-00	52-009-00	52-009-00-01		INSPECTION - DETAILED	Main Deck Cargo Door seals.
52-009-10	52-009-10	52-009-10-01		INSPECTION - DETAILED	Main Deck Cargo vent door seal



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-010-00	52-010-00	52-010-00-01		INSPECTION - DETAILED	Passenger Entry Door Seals and Vent Door Seals
52-015-00	52-015-00	52-015-00-01		INSPECTION - DETAILED	No. 3 Over-Wing Door Seals and Vent Door Seals
52-020-00	52-020-00	52-020-00-01		INSPECTION - DETAILED	Forward Large Cargo Door Seals and Vent Door Seals
52-025-00	52-025-00	52-025-00-01		INSPECTION - DETAILED	AFT Large Cargo Door Seals and Vent Door Seals
52-030-00	52-030-00	52-030-00-01		INSPECTION - DETAILED	AFT Small Cargo Door Seals and Vent Door Seals
52-032-00	52-032-00	52-032-00-01		LUBRICATE	Main Deck Cargo Door mechanism.
52-032-10	52-032-10	52-032-10-01		LUBRICATE	Main Deck Cargo Door hinge pin.
52-032-20	52-032-20	52-032-20-01		OPERATIONAL	Manual drive mechanism of Main Deck Cargo Door.
52-032-30	52-032-30	52-032-30-01		FUNCTIONAL	Lock control switches.
52-032-40	52-032-40	52-032-40-01		LUBRICATE	Main Deck Cargo Door Latch Pins and Cam Latches
52-040-00	52-040-00	52-040-00-01		INSPECTION - DETAILED	Bulk Cargo Door Seals
52-050-00	52-050-00	52-050-00-01		INSPECTION - DETAILED	Forward Access Door Seal
52-060-00	52-060-00	52-060-00-01		INSPECTION - DETAILED	Main Equipment Center Door Seals
52-070-00	52-070-00	52-070-00-01		REPLACE	Passenger Entry Door EPAS SQUIBS
52-070-01	52-070-01	52-070-01-01		REPLACE	Passenger Entry Door EPAS SQUIBS
52-070-02	52-070-02	52-070-02-01		DISCARD	Passenger Entry Door EPAS SQUIBS
52-075-00	52-075-00	52-075-00-01		REPLACE	No. 3 Over-Wing Door EPAS Squibs
52-090-00	52-090-00	52-090-00-01 52-090-00-02 52-090-00-03		OPERATIONAL	Passenger Entry Door EPAS Battery



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-090-01	52-090-01	52-090-01-01 52-090-01-02		OPERATIONAL	Passenger Entry Door EPAS Battery
52-090-02	52-090-02	52-090-02-01		OPERATIONAL	Passenger Entry Door EPAS Battery
52-091-00	52-091-00	52-091-00-01 52-091-00-02		RESTORE	Passenger Entry Door EPAS Battery
52-091-01	52-091-01	52-091-01-01 52-091-01-02		RESTORE	Passenger Entry Door EPAS Battery
52-091-02	52-091-02	52-091-02-01		RESTORE	Passenger Entry Door EPAS Battery
52-095-00	52-095-00	52-095-00-01		OPERATIONAL	No. 3 Over-wing Door EPAS/Backup Battery
52-096-00	52-096-00	52-096-00-01		RESTORE	No. 3 Over-Wing Door EPAS/Backup Battery
52-100-00	52-100-00	52-100-00-01		VISUAL CHECK	Passenger Entry Door Girt Bar Floor Fittings
52-100-01	52-100-01	52-100-01-01		VISUAL CHECK	Passenger Entry Door Girt Bar Floor Fittings
52-100-02	52-100-02	52-100-02-01		VISUAL CHECK	Passenger Entry Door Girt Bar Floor Fittings
52-110-00	52-110-00	52-110-00-01		VISUAL CHECK	Passenger Entry Door EPAS Pressure Gauge
52-110-01	52-110-01	52-110-01-01		VISUAL CHECK	Passenger Entry Door EPAS Pressure Gauge
52-110-02	52-110-02	52-110-02-01		VISUAL CHECK	Passenger Entry Door EPAS Pressure Gauge
52-115-00	52-115-00	52-115-00-01		VISUAL CHECK	No. 3 Over-Wing Door EPAS Pressure Gauge
52-120-00	52-120-00	52-120-00-01		INSPECTION - DETAILED	Passenger Entry Door Flight Lock Mechanism
52-120-01	52-120-01	52-120-01-01		INSPECTION - DETAILED	Passenger Entry Door Flight Lock Mechanism
52-120-02	52-120-02	52-120-02-01		INSPECTION - DETAILED	Passenger Entry Door Flight Lock Mechanism
52-125-00	52-125-00	52-125-00-01		INSPECTION - DETAILED	No. 3 Over-Wing Door Flight Lock Mechanism
52-130-00	52-130-00	52-130-00-01		INSPECTION - DETAILED	Passenger Entry Door Girt Bar Mechanism Interlock



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-130-01	52-130-01	52-130-01-01		INSPECTION - DETAILED	Passenger Entry Door Girt Bar Mechanism Interlock
52-130-02	52-130-02	52-130-02-01		INSPECTION - DETAILED	Passenger Entry Door Girt Bar Mechanism Interlock
52-135-00	52-135-00	52-135-00-01		INSPECTION - DETAILED	No. 3 Over-Wing Door Latch Torque Tube Interlock
52-140-00	52-140-00	52-140-00-01		INSPECTION - DETAILED	Passenger Entry Door Mode Select Mechanism and Cables
52-140-01	52-140-01	52-140-01-01		INSPECTION - DETAILED	Passenger Entry Door Mode Select Mechanism and Cables
52-140-02	52-140-02	52-140-02-01		INSPECTION - DETAILED	Passenger Entry Door Mode Select Mechanism and Cables
52-145-00	52-145-00	52-145-00-01		INSPECTION - DETAILED	No. 3 Over-Wing Doors Mode Select Mechanism and Pull Cable
52-150-00	52-150-00	52-150-00-01		INSPECTION - DETAILED	Passenger Entry Door EPAS Tubing
52-150-01	52-150-01	52-150-01-01		INSPECTION - DETAILED	Passenger Entry Door EPAS Tubing
52-150-02	52-150-02	52-150-02-01		INSPECTION - DETAILED	Passenger Entry Door EPAS Tubing
52-155-00	52-155-00	52-155-00-01		INSPECTION - DETAILED	No. 3 Over-Wing Doors EPAS Tubing
52-160-00	52-160-00	52-160-00-01 52-160-00-02 52-160-00-03 52-160-00-04		FUNCTIONAL	Passenger Entry Door EPAS Circuitry
52-165-00	52-165-00	52-165-00-01 52-165-00-02		FUNCTIONAL	No. 3 Over-Wing Door Circuitry
52-166-00	52-166-00	52-166-00-01		FUNCTIONAL	No. 3 Over-Wing Door EPAS Battery Circuitry



## 777-200/300 MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-167-00	52-167-00	52-167-00-01 52-167-00-02	W-52-167-00-01 W-52-167-00-02	FUNCTIONAL	No. 3 Over-Wing Door Backup Battery Circuitry
52-170-00	52-170-00	52-170-00-01		FUNCTIONAL	Passenger Entry Door Mechanisms
52-170-01	52-170-01	52-170-01-01		FUNCTIONAL	Passenger Entry Door Mechanisms
52-170-02	52-170-02	52-170-02-01		FUNCTIONAL	Passenger Entry Door Mechanisms
52-175-00	52-175-00	52-175-00-01		FUNCTIONAL	No. 3 Over-Wing Door Mechanisms
52-180-00	52-180-00	52-180-00-01		OPERATIONAL	Forward Large Cargo Door Manual Drive Mechanism & Lift PDU Brake
52-185-00	52-185-00	52-185-00-01		OPERATIONAL	AFT Large Cargo Door Manual Drive Mechanism & Lift PDU Brake
52-190-00	52-190-00	52-190-00-01		OPERATIONAL	Forward Large Cargo Door Rotary Actuator No-Back
52-195-00	52-195-00	52-195-00-01		OPERATIONAL	AFT Large Cargo Door Rotary Actuator No-Back
52-200-00	52-200-00	52-200-00-01		FUNCTIONAL	Forward Large Cargo Door Lock Handle Load Limiter
52-205-00	52-205-00	52-205-00-01		FUNCTIONAL	AFT Large Cargo Door Lock Handle Load Limiter
52-210-00	52-210-00	52-210-00-01		OPERATIONAL	Forward Large Cargo Door Ditching Interlock Mechanism
52-215-00	52-215-00	52-215-00-01		OPERATIONAL	AFT Large Cargo Door Ditching Interlock Mechanism
52-220-00	52-220-00	52-220-00-01		OPERATIONAL	AFT Small Cargo Door Hinge Power Drive Unit and Manual Drive Mechanism
52-230-00	52-230-00	52-230-00-01		OPERATIONAL	AFT Small Cargo Door Rotary Actuator
52-240-00	52-240-00	52-240-00-01		INSPECTION - DETAILED	Bulk Cargo Door Latch Mechanism
52-250-00	52-250-00	52-250-00-01		INSPECTION - DETAILED	Equipment Compartment Exterior Door Latch Mechanisms
52-255-00	52-255-00	52-255-00-01		OPERATIONAL	Lower Lobe Attendant Rest Emergency Exit Hatch
52-260-00	52-260-00	52-260-00-01		OPERATIONAL	Passenger Entry Door Closed Proximity Sensors
52-265-00	52-265-00	52-265-00-01		OPERATIONAL	No. 3 Over-Wing Doors Closed Proximity Sensors
52-301-00		52-301-00-01		DISCARD	Flight Deck Door Strike Assembly



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-305-00	52-305-00	52-305-00-01		INSPECTION - DETAILED	Flight Deck Door Decompression Panel Latches and Hinges
52-310-00	52-310-00	52-310-00-01		OPERATIONAL	Flight Deck Door Pressure Sensor
52-315-00	52-315-00	52-315-00-01		VISUAL CHECK	FLIGHT DECK DOOR SEALS AND BREAKAWAY PANEL SEAL
52-320-00	52-320-00	52-320-00-01		VISUAL CHECK	Flight Deck Door Decompression Panel Trim Ring Seals
52-501-00	52-501-00	52-501-00-01		GENERAL VISUAL	Forward Large Cargo Door
52-502-00	52-502-00	52-502-00-01		DETAILED	Forward Large Cargo Door
52-503-00	52-503-00	52-503-00-01		DETAILED	Forward Large Cargo Door
52-504-00	52-504-00	52-504-00-01		DETAILED	Forward Large Cargo Door
52-505-00	52-505-00	52-505-00-01		DETAILED	Forward Large Cargo Door
52-506-00	52-506-00	52-506-00-01		GENERAL VISUAL	Aft Small Cargo Door
52-507-00	52-507-00	52-507-00-01		GENERAL VISUAL	Bulk Cargo Door
52-508-00	52-508-00	52-508-00-01		GENERAL VISUAL	Bulk Cargo Door
52-509-00	52-509-00	52-509-00-01		GENERAL VISUAL	Aft Large Cargo Door
52-510-00	52-510-00	52-510-00-01		DETAILED	Aft Large Cargo Door
52-511-00	52-511-00	52-511-00-01		DETAILED	Aft Large Cargo Door
52-512-00	52-512-00	52-512-00-01		DETAILED	Aft Large Cargo Door
52-513-00	52-513-00	52-513-00-01		DETAILED	Aft Large Cargo Door
52-520-01	52-520-01	52-520-01-01		GENERAL VISUAL	Left #1 Entry Door
52-521-01	52-521-01	52-521-01-01		GENERAL VISUAL	Left #2 Passenger Entry Door



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-522-01	52-522-01	52-522-01-01		GENERAL VISUAL	Left #3 Overwing Door
52-523-01	52-523-01	52-523-01-01		GENERAL VISUAL	Left #3 Passenger Entry Door
52-524-01	52-524-01	52-524-01-01		GENERAL VISUAL	Left #4 Passenger Entry Door
52-525-01	52-525-01	52-525-01-01		GENERAL VISUAL	Left #4 Passenger Entry Door
52-526-01	52-526-01	52-526-01-01		GENERAL VISUAL	Left #5 Passenger Entry Door
52-527-01	52-527-01	52-527-01-01		DETAILED	Left #1 Entry Door
52-528-01	52-528-01	52-528-01-01		DETAILED	Left #2 Passenger Entry Door
52-529-01	52-529-01	52-529-01-01		DETAILED	Left #3 Overwing Door
52-530-01	52-530-01	52-530-01-01		DETAILED	Left #3 Passenger Entry Door
52-531-01	52-531-01	52-531-01-01		DETAILED	Left #4 Passenger Entry Door
52-532-01	52-532-01	52-532-01-01		DETAILED	Left #4 Passenger Entry Door
52-533-01	52-533-01	52-533-01-01		DETAILED	Left #5 Passenger Entry Door
52-535-02	52-535-02	52-535-02-01		GENERAL VISUAL	Right #1 Entry Door
52-536-02	52-536-02	52-536-02-01		GENERAL VISUAL	Right #2 Passenger Entry Door
52-537-02	52-537-02	52-537-02-01		GENERAL VISUAL	Right #3 Overwing Door
52-538-02	52-538-02	52-538-02-01		GENERAL VISUAL	Right #3 Passenger Entry Door
52-539-02	52-539-02	52-539-02-01		GENERAL VISUAL	Right #4 Passenger Entry Door



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-540-02	52-540-02	52-540-02-01		GENERAL VISUAL	Right #4 Passenger Entry Door
52-541-02	52-541-02	52-541-02-01		GENERAL VISUAL	Right #5 Passenger Entry Door
52-542-02	52-542-02	52-542-02-01		DETAILED	Right #1 Entry Door
52-543-02	52-543-02	52-543-02-01		DETAILED	Right #2 Passenger Entry Door
52-544-02	52-544-02	52-544-02-01		DETAILED	Right #3 Overwing Door
52-545-02	52-545-02	52-545-02-01		DETAILED	Right #3 Passenger Entry Door
52-546-02	52-546-02	52-546-02-01		DETAILED	Right #4 Passenger Entry Door
52-547-02	52-547-02	52-547-02-01		DETAILED	Right #4 Passenger Entry Door
52-548-02	52-548-02	52-548-02-01		DETAILED	Right #5 Passenger Entry Door
52-549-00	52-549-00	52-549-00-01		GENERAL VISUAL	Main Deck Cargo Door
52-550-00	52-550-00	52-550-00-01		DETAILED	Main Deck Cargo Door
52-551-00	52-551-00	52-551-00-01		DETAILED	Main Deck Cargo Door
52-552-00	52-552-00	52-552-00-01		DETAILED	Main Deck Cargo Door
52-553-00	52-553-00	52-553-00-01		GENERAL VISUAL	Main Deck Cargo Door
52-554-00	52-554-00	52-554-00-01		DETAILED	Main Deck Cargo Door
52-701-01		52-701-01-01		GENERAL VISUAL	Passenger Entry Doors - Outer Skin and Structure
52-701-03		52-701-03-01		DETAILED	Passenger Entry Doors - Outer Skin and Structure
52-702-01		52-702-01-01		SPECIAL DETAILED	Large Cargo Door Latch Support Frame Fittings
52-703-01		52-703-01-01		SPECIAL DETAILED	Large Cargo Door Latch Support Frame Fitting (135W1191)





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-704-01		52-704-01-01		SPECIAL DETAILED	Large Cargo Door Latch Frame Inner Chord
52-705-01		52-705-01-01		SPECIAL DETAILED	Large Cargo Door Outer Skin at Attachment to Main Hinges
52-706-01		52-706-01-01		SPECIAL DETAILED	Large Cargo Door Latch Support Frame Fittings
52-707-01		52-707-01-01		SPECIAL DETAILED	Large Cargo Door Latch Support Frame Fitting (135W1191)
52-708-01		52-708-01-01		SPECIAL DETAILED	Large Cargo Door Latch Frame Inner Chord
52-709-01		52-709-01-01		SPECIAL DETAILED	Large Cargo Door Outer Skin at Attachment to Main Hinges
52-730-00	52-730-00	52-730-00-01		GENERAL VISUAL	Flight Deck Security Door
52-802-00	52-802-00	52-802-00-01		ZONAL (GV)	Forward Large Cargo Door
52-804-00	52-804-00	52-804-00-01		ZONAL (GV)	Forward Large Cargo Door
52-806-00	52-806-00	52-806-00-01		ZONAL (GV)	Aft Small Cargo Door
52-808-00	52-808-00	52-808-00-01		ZONAL (GV)	Aft Small Cargo Door
52-810-00	52-810-00	52-810-00-01		ZONAL (GV)	Aft Large Cargo Door
52-812-00	52-812-00	52-812-00-01		ZONAL (GV)	Aft Large Cargo Door
52-814-00	52-814-00	52-814-00-01		ZONAL (GV)	Bulk Cargo Door
52-816-01	52-816-01	52-816-01-01		ZONAL (GV)	Left No. 1 Passenger/Crew Entry Door - Section 41
52-818-01	52-818-01	52-818-01-01		ZONAL (GV)	Left No. 1 Passenger/Crew Entry Door - Section 41
52-820-01	52-820-01	52-820-01-01		ZONAL (GV)	Left No. 2 Passenger Entry Door - Section 43
52-822-01	52-822-01	52-822-01-01		ZONAL (GV)	Left No. 2 Passenger Entry Door - Section 43
52-824-01	52-824-01	52-824-01-01		ZONAL (GV)	Left No. 3 Overwing Door - Section 44
52-825-01	52-825-01	52-825-01-01		ZONAL (GV)	Left No. 3 Overwing Door - Section 44



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-826-01	52-826-01	52-826-01-01		ZONAL (GV)	Left No. 3 Passenger Entry Door - Section 46
52-827-01	52-827-01	52-827-01-01		ZONAL (GV)	Left No. 4 Passenger Entry Door - Section 46
52-828-01	52-828-01	52-828-01-01		ZONAL (GV)	Left No. 3 Passenger Entry Door - Section 46
52-829-01	52-829-01	52-829-01-01		ZONAL (GV)	Left No. 4 Passenger Entry Door - Section 46
52-830-01	52-830-01	52-830-01-01		ZONAL (GV)	Left No. 4 Passenger Entry Door - Section 47
52-831-01	52-831-01	52-831-01-01		ZONAL (GV)	Left No. 5 Passenger Entry Door - Section 47
52-832-01	52-832-01	52-832-01-01		ZONAL (GV)	Left No. 4 Passenger Entry Door - Section 47
52-833-01	52-833-01	52-833-01-01		ZONAL (GV)	Left No. 5 Passenger Entry Door - Section 47
52-834-02	52-834-02	52-834-02-01		ZONAL (GV)	Right No. 1 Passenger/Crew Entry Door - Section 41
52-836-02	52-836-02	52-836-02-01		ZONAL (GV)	Right No. 1 Passenger/Crew Entry Door - Section 41
52-840-02	52-840-02	52-840-02-01		ZONAL (GV)	Right No. 2 Passenger Entry Door - Section 43
52-842-02	52-842-02	52-842-02-01		ZONAL (GV)	Right No. 2 Passenger Entry Door - Section 43
52-844-02	52-844-02	52-844-02-01		ZONAL (GV)	Right No. 3 Overwing Door - Section 44
52-846-02	52-846-02	52-846-02-01		ZONAL (GV)	Right No. 3 Overwing Door - Section 44
52-848-02	52-848-02	52-848-02-01		ZONAL (GV)	Right No. 3 Passenger Entry Door - Section 46
52-849-02	52-849-02	52-849-02-01		ZONAL (GV)	Right No. 4 Passenger Entry Door - Section 46
52-850-02	52-850-02	52-850-02-01		ZONAL (GV)	Right No. 3 Passenger Entry Door - Section 46
52-851-02	52-851-02	52-851-02-01		ZONAL (GV)	Right No. 4 Passenger Entry Door - Section 46
52-852-02	52-852-02	52-852-02-01		ZONAL (GV)	Right No. 4 Passenger Entry Door - Section 47
52-853-02	52-853-02	52-853-02-01		ZONAL (GV)	Right No. 5 Passenger Entry Door - Section 47
52-854-02	52-854-02	52-854-02-01		ZONAL (GV)	Right No. 4 Passenger Entry Door - Section 47
52-855-02	52-855-02	52-855-02-01		ZONAL (GV)	Right No. 5 Passenger Entry Door - Section 47
52-856-00	52-856-00	52-856-00-01		ZONAL (GV)	Main Deck Cargo Door
52-858-00	52-858-00	52-858-00-01		ZONAL (GV)	Main Deck Cargo Door



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-501-00	53-501-00	53-501-00-01		GENERAL VISUAL	Area Forward of Nose Landing Gear Wheel Well and Forward Access Door
53-502-00	53-502-00	53-502-00-01		GENERAL VISUAL	Area Outboard and Above Nose Landing Gear Wheel Well
53-503-00	53-503-00	53-503-00-01		DETAILED	Left Area Outboard and Above Nose Landing Gear Wheel Well
53-504-00	53-504-00	53-504-00-01		DETAILED	Right Area Outboard and Above Nose Landing Gear Wheel Well
53-505-00	53-505-00	53-505-00-01		GENERAL VISUAL	Main Equipment Center and Main Equipment Center Access Door
53-506-00	53-506-00	53-506-00-01		DETAILED	Main Equipment Center
53-507-00	53-507-00	53-507-00-01		DETAILED	Main Equipment Center
53-508-00	53-508-00	53-508-00-01		GENERAL VISUAL	Main Equipment Center
53-509-00	53-509-00	53-509-00-01		GENERAL VISUAL	Forward Cargo Compartment
53-509-01	53-509-01	53-509-01-01		GENERAL VISUAL	Forward Cargo Compartment
53-511-00	53-511-00	53-511-00-01		DETAILED	Forward Cargo Compartment
53-512-00	53-512-00	53-512-00-01 53-512-00-02 53-512-00-03 53-512-00-04 53-512-00-05		DETAILED	Forward Cargo Compartment
53-512-01	53-512-01	53-512-01-01		DETAILED	Forward Cargo Compartment
53-513-00	53-513-00	53-513-00-01		GENERAL VISUAL	Area Below Forward Cargo Compartment
53-514-00	53-514-00	53-514-00-01		GENERAL VISUAL	Area Below Forward Cargo Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-515-00	53-515-00	53-515-00-01 53-515-00-02 53-515-00-03 53-515-00-04 53-515-00-05 53-515-00-06		DETAILED	Area Below Forward Cargo Compartment
53-516-00	53-516-00	53-516-00-01		GENERAL VISUAL	Area Aft of Forward Cargo Compartment - Body Station 998 to 1035
53-516-01	53-516-01	53-516-01-01		GENERAL VISUAL	Area Aft of Forward Cargo Compartment - Body Station 998 to 1035
53-517-00	53-517-00	53-517-00-01		GENERAL VISUAL	Forward Cargo Compartment Lower Lobe
53-518-00	53-518-00	53-518-00-01		DETAILED	Main Landing Gear Wheel Well, Left
53-519-00	53-519-00	53-519-00-01		DETAILED	Main Landing Gear Wheel Well, Right
53-520-00	53-520-00	53-520-00-01		GENERAL VISUAL	Area Above Main Landing Gear Wheel Well
53-520-01	53-520-01	53-520-01-01		GENERAL VISUAL	Area Above Main Landing Gear Wheel Well
53-521-00	53-521-00	53-521-00-01		GENERAL VISUAL	Aft Cargo Compartment
53-522-00	53-522-00	53-522-00-01		GENERAL VISUAL	Aft Cargo Compartment
53-522-01	53-522-01	53-522-01-01		GENERAL VISUAL	Aft Cargo Compartment
53-523-00	53-523-00	53-523-00-01		GENERAL VISUAL	Aft Cargo Compartment
53-523-01	53-523-01	53-523-01-01		GENERAL VISUAL	Aft Cargo Compartment
53-524-00	53-524-00	53-524-00-01		DETAILED	Aft Cargo Compartment
53-525-00	53-525-00	53-525-00-01		DETAILED	Aft Cargo Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-526-00	53-526-00	53-526-00-01		DETAILED	Aft Cargo Compartment
53-526-01	53-526-01	53-526-01-01		DETAILED	Aft Cargo Compartment
53-527-00	53-527-00	53-527-00-01		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-528-00	53-528-00	53-528-00-01		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-529-00	53-529-00	53-529-00-01		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-529-01	53-529-01	53-529-01-01		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-530-00	53-530-00	53-530-00-01		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-530-01	53-530-01	53-530-01-01		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-532-00	53-532-00	53-532-00-01		DETAILED	Area Below Aft Cargo Compartment
53-532-01	53-532-01	53-532-01-01		DETAILED	Area Below Aft Cargo Compartment
53-533-00	53-533-00	53-533-00-01		DETAILED	Area Below Aft Cargo Compartment
53-533-01	53-533-01	53-533-01-01		DETAILED	Area Below Aft Cargo Compartment
53-534-00	53-534-00	53-534-00-01		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-535-00	53-535-00	53-535-00-01		GENERAL VISUAL	Bulk Cargo Compartment
53-536-00	53-536-00	53-536-00-01		DETAILED	Bulk Cargo Compartment
53-537-00	53-537-00	53-537-00-01 53-537-00-02 53-537-00-03 53-537-00-04 53-537-00-05		DETAILED	Bulk Cargo Compartment
53-537-01	53-537-01	53-537-01-01		DETAILED	Bulk Cargo Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-538-00	53-538-00	53-538-00-01		DETAILED	Area Below Bulk Cargo Compartment
53-539-00	53-539-00	53-539-00-01		DETAILED	Area Aft of Bulk Cargo Compartment
53-540-00	53-540-00	53-540-00-01		DETAILED	Area Aft of Bulk Cargo Compartment
53-541-00	53-541-00	53-541-00-01		GENERAL VISUAL	Aft Cargo Compartment
53-542-00	53-542-00	53-542-00-01		GENERAL VISUAL	Bulk Cargo Compartment
53-543-00	53-543-00	53-543-00-01		GENERAL VISUAL	Overwing Wing-To-Body Fairings, Left
53-544-00	53-544-00	53-544-00-01		GENERAL VISUAL	Overwing Wing-To-Body Fairings, Right
53-545-01	53-545-01	53-545-01-01		DETAILED	Forward Wing-To-Body Fairings - Left
53-545-02	53-545-02	53-545-02-01		DETAILED	Forward Wing-To-Body Fairings - Right
53-546-01	53-546-01	53-546-01-01		GENERAL VISUAL	Overwing Wing-To-Body Fairings - Left
53-546-02	53-546-02	53-546-02-01		GENERAL VISUAL	Overwing Wing-To-Body Fairings - Right
53-547-01	53-547-01	53-547-01-01		DETAILED	Aft Wing-To-Body Fairings - Left
53-547-02	53-547-02	53-547-02-01		DETAILED	Aft Wing-To-Body Fairings - Right
53-547-03	53-547-03	53-547-03-01		DETAILED	Aft Wing-To-Body Fairings - Left
53-547-04	53-547-04	53-547-04-01		DETAILED	Aft Wing-To-Body Fairings - Right
53-548-00	53-548-00	53-548-00-01		SPECIAL DETAILED	Flight Compartment
53-549-00	53-549-00	53-549-00-01		DETAILED	Flight Compartment
53-550-00	53-550-00	53-550-00-01		GENERAL VISUAL	Flight Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>TASK CARD NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-551-00	53-551-00	53-551-00-01		GENERAL VISUAL	Passenger Compartment - Left
53-551-01	53-551-01	53-551-01-01		GENERAL VISUAL	Supernumerary Cabin - Left
53-552-00	53-552-00	53-552-00-01		GENERAL VISUAL	Passenger Compartment - Right
53-552-01	53-552-01	53-552-01-01		GENERAL VISUAL	Supernumerary Cabin - Right
53-553-00	53-553-00	53-553-00-01		GENERAL VISUAL	Passenger Compartment - Left
53-553-01	53-553-01	53-553-01-01		GENERAL VISUAL	Supernumerary Cabin - Left
53-554-00	53-554-00	53-554-00-01		GENERAL VISUAL	Passenger Compartment - Right
53-554-01	53-554-01	53-554-01-01		GENERAL VISUAL	Supernumerary Cabin - Right
53-557-00	53-557-00	53-557-00-01		GENERAL VISUAL	Main Deck Compartment
53-558-00	53-558-00	53-558-00-01		GENERAL VISUAL	Main Deck Compartment
53-559-00	53-559-00	53-559-00-01		DETAILED	Main Deck Compartment
53-560-00	53-560-00	53-560-00-01		DETAILED	Main Deck Compartment
53-561-00	53-561-00	53-561-00-01		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-562-00	53-562-00	53-562-00-01		GENERAL VISUAL	Passenger Compartment - Left
53-563-00	53-563-00	53-563-00-01		GENERAL VISUAL	Passenger Compartment - Right
53-564-00	53-564-00	53-564-00-01		GENERAL VISUAL	Passenger Compartment - Left



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-565-00	53-565-00	53-565-00-01		GENERAL VISUAL	Passenger Compartment - Right
53-568-00	53-568-00	53-568-00-01 53-568-00-02 53-568-00-03 53-568-00-04 53-568-00-05		GENERAL VISUAL	Passenger Compartment - Left
53-568-01	53-568-01	53-568-01-01		GENERAL VISUAL	Main Deck Cargo Compartment - Left
53-569-00	53-569-00	53-569-00-01 53-569-00-02 53-569-00-03 53-569-00-04 53-569-00-05		GENERAL VISUAL	Passenger Compartment - Right
53-569-01	53-569-01	53-569-01-01		GENERAL VISUAL	Main Deck Cargo Compartment - Right
53-570-00	53-570-00	53-570-00-01		DETAILED	Passenger Compartment - Left
53-571-00	53-571-00	53-571-00-01		DETAILED	Passenger Compartment - Right
53-572-00	53-572-00	53-572-00-01		GENERAL VISUAL	Passenger Compartment - Left
53-572-01	53-572-01	53-572-01-01		GENERAL VISUAL	Main Deck Cargo Compartment - Left
53-573-00	53-573-00	53-573-00-01		GENERAL VISUAL	Passenger Compartment - Right
53-573-01	53-573-01	53-573-01-01		GENERAL VISUAL	Main Deck Cargo Compartment - Right
53-574-00	53-574-00	53-574-00-01		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-575-00	53-575-00	53-575-00-01		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-576-00	53-576-00	53-576-00-01 53-576-00-02 53-576-00-03 53-576-00-04 53-576-00-05 53-576-00-06		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-577-00	53-577-00	53-577-00-01 53-577-00-02 53-577-00-03 53-577-00-04 53-577-00-05 53-577-00-06		GENERAL VISUAL	Main Deck Compartment
53-578-00	53-578-00	53-578-00-01 53-578-00-02 53-578-00-03 53-578-00-04 53-578-00-05 53-578-00-06		GENERAL VISUAL	Main Deck Compartment
53-579-00	53-579-00	53-579-00-01		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-580-00	53-580-00	53-580-00-01		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-581-00	53-581-00	53-581-00-01		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-582-00	53-582-00	53-582-00-01		GENERAL VISUAL	Passenger Compartment
53-583-00	53-583-00	53-583-00-01		GENERAL VISUAL	Passenger Compartment
53-584-00	53-584-00	53-584-00-01		GENERAL VISUAL	Passenger Compartment
53-585-00	53-585-00	53-585-00-01		GENERAL VISUAL	Passenger Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-586-00	53-586-00	53-586-00-01		GENERAL VISUAL	Passenger Compartment
53-586-01	53-586-01	53-586-01-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-587-00	53-587-00	53-587-00-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-588-00	53-588-00	53-588-00-01		GENERAL VISUAL	Upper Cargo Compartment
53-589-00	53-589-00	53-589-00-01		GENERAL VISUAL	Passenger Compartment
53-590-00	53-590-00	53-590-00-01		GENERAL VISUAL	Passenger Compartment
53-591-00	53-591-00	53-591-00-01 53-591-00-02 53-591-00-03 53-591-00-04 53-591-00-05		GENERAL VISUAL	Passenger Compartment
53-591-01	53-591-01	53-591-01-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-592-00	53-592-00	53-592-00-01		DETAILED	Passenger Compartment
53-593-00	53-593-00	53-593-00-01		DETAILED	Passenger Compartment
53-594-00	53-594-00	53-594-00-01 53-594-00-02 53-594-00-03 53-594-00-04 53-594-00-05		DETAILED	Passenger Compartment
53-594-01	53-594-01	53-594-01-01		DETAILED	Main Deck Cargo Compartment
53-595-00	53-595-00	53-595-00-01		GENERAL VISUAL	Area above Main Deck Compartment Ceiling



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-596-00	53-596-00	53-596-00-01		GENERAL VISUAL	Area above Main Deck Compartment Ceiling
53-597-00	53-597-00	53-597-00-01 53-597-00-02 53-597-00-03 53-597-00-04 53-597-00-05 53-597-00-06		GENERAL VISUAL	Area above Main Deck Compartment Ceiling
53-598-00	53-598-00	53-598-00-01		GENERAL VISUAL	Area above Main Deck Compartment Ceiling
53-599-00	53-599-00	53-599-00-01		GENERAL VISUAL	Passenger Compartment
53-601-00	53-601-00	53-601-00-01		GENERAL VISUAL	Passenger Compartment
53-602-00	53-602-00	53-602-00-01		GENERAL VISUAL	Passenger Compartment
53-603-00	53-603-00	53-603-00-01		GENERAL VISUAL	Passenger Compartment
53-606-00	53-606-00	53-606-00-01		GENERAL VISUAL	Passenger Compartment
53-607-00	53-607-00	53-607-00-01		GENERAL VISUAL	Passenger Compartment
53-608-00	53-608-00	53-608-00-01		DETAILED	Passenger Compartment
53-609-00	53-609-00	53-609-00-01		DETAILED	Passenger Compartment
53-610-00	53-610-00	53-610-00-01 53-610-00-02		DETAILED	Area above Wing Center Section
53-611-00	53-611-00	53-611-00-01		GENERAL VISUAL	Area above Wing Center Section
53-612-00	53-612-00	53-612-00-01		GENERAL VISUAL	Passenger Compartment Left and Right



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-613-00	53-613-00	53-613-00-01		GENERAL VISUAL	Area above Passenger Compartment Ceiling
53-614-00	53-614-00	53-614-00-01 53-614-00-02		GENERAL VISUAL	Passenger Compartment
53-615-00	53-615-00	53-615-00-01 53-615-00-02		GENERAL VISUAL	Passenger Compartment Left and Right
53-616-00	53-616-00	53-616-00-01 53-616-00-02		DETAILED	Passenger Compartment Left and Right
53-617-00	53-617-00	53-617-00-01 53-617-00-02		GENERAL VISUAL	Passenger Compartment Left and Right
53-618-00	53-618-00	53-618-00-01		GENERAL VISUAL	Passenger Compartment Left and Right
53-619-00	53-619-00	53-619-00-01 53-619-00-02		GENERAL VISUAL	Area above Passenger Compartment Ceiling
53-620-00	53-620-00	53-620-00-01 53-620-00-02		DETAILED	Forward Wing-To-Body Fairings
53-621-00	53-621-00	53-621-00-01 53-621-00-02		DETAILED	Aft Wing-To-Body Fairings
53-623-00	53-623-00	53-623-00-01		DETAILED	Main Deck Compartment Ceiling
53-624-00	53-624-00	53-624-00-01		SPECIAL DETAILED	Main Deck Compartment Ceiling
53-625-00	53-625-00	53-625-00-01		GENERAL VISUAL	Main Deck Compartment Ceiling
53-626-00	53-626-00	53-626-00-01		DETAILED	Auxiliary Body Fuel Tanks
53-627-00	53-627-00	53-627-00-01		DETAILED	Auxiliary Body Fuel Tank Attach Fittings, Links and Pins
53-628-00	53-628-00	53-628-00-01		GENERAL VISUAL	Area Above Main Landing Gear Wheel Well
53-629-00	53-629-00	53-629-00-01		GENERAL VISUAL	Supernumerary Area



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-631-00	53-631-00	53-631-00-01		SPECIAL DETAILED	Main Deck Cargo Compartment
53-632-00	53-632-00	53-632-00-01		DETAILED	Main Deck Cargo Compartment
53-633-00	53-633-00	53-633-00-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-634-00	53-634-00	53-634-00-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-635-00	53-635-00	53-635-00-01		SPECIAL DETAILED	Main Deck Cargo Compartment
53-637-00	53-637-00	53-637-00-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-638-00	53-638-00	53-638-00-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-639-00	53-639-00	53-639-00-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-640-00	53-640-00	53-640-00-01		GENERAL VISUAL	Aft Cargo Compartment
53-641-00	53-641-00	53-641-00-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-645-00	53-645-00	53-645-00-01		DETAILED	Aft Cargo Compartment
53-646-00	53-646-00	53-646-00-01		DETAILED	Main Deck Cargo Compartment
53-647-00	53-647-00	53-647-00-01		DETAILED	Main Deck Cargo Compartment
53-648-00	53-648-00	53-648-00-01		DETAILED	Area Above Main Deck Cargo Compartment
53-671-00	53-671-00	53-671-00-01		GENERAL VISUAL	Lower Fuselage - Subzone 150 and 160
53-673-00	53-673-00	53-673-00-01 53-673-00-02		GENERAL VISUAL	Underwing Wing-To-Body Fairing
53-674-01	53-674-01	53-674-01-01		GENERAL VISUAL	Supernumerary Cabin



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-675-00	53-675-00	53-675-00-01		GENERAL VISUAL	Subzone 220 BS 246 to 655 (Section 41)
53-675-01	53-675-01	53-675-01-01		GENERAL VISUAL	Subzone 220 BS 388 to 655
53-676-00	53-676-00	53-676-00-01		GENERAL VISUAL	Subzone 230 BS 655 to 1035 (Section 43)
53-677-00	53-677-00	53-677-00-01		GENERAL VISUAL	Subzone 240 BS 1035 to 1434 (Section 44)
53-678-00	53-678-00	53-678-00-01		GENERAL VISUAL	Subzone 250 BS 1434 to 1832 (Section 46)
53-679-00	53-679-00	53-679-00-01		GENERAL VISUAL	Subzone 260 BS 1832 to 2195.75 (Section 47)
53-701-01		53-701-01-01		GENERAL VISUAL	Upper Lobe Skin Panels
53-702-01		53-702-01-01		GENERAL VISUAL	Lower Lobe Skin Panels
53-703-01		53-703-01-01		DETAILED	Upper and Lower Lobe Skin Panels
53-704-01		53-704-01-01		SPECIAL DETAILED	Crown Skin Antenna Installation - TCAS
53-705-01		53-705-01-01		SPECIAL DETAILED	ACL Installation External Doubler
53-706-01		53-706-01-01		SPECIAL DETAILED	ACL Installation External Doubler
53-707-01		53-707-01-01		GENERAL VISUAL	Crown Skin Production ACL Installation
53-708-01		53-708-01-01		DETAILED	Ground Maneuver Camera Installation
53-709-01		53-709-01-01		SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin
53-710-01		53-710-01-01		DETAILED	Longitudinal Skin Lap Splices Outer Skin



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-711-01		53-711-01-01		SPECIAL DETAILED	Passenger Entry Door #1 - Cutout
53-712-01		53-712-01-01		SPECIAL DETAILED	Passenger Entry Door #1 - Cutout
53-713-01		53-713-01-01		SPECIAL DETAILED	Passenger Entry Door #1 - Cutout
53-714-01		53-714-01-01		SPECIAL DETAILED	Passenger Entry Door #1 - Cutout
53-715-01		53-715-01-01		SPECIAL DETAILED	Forward Large Cargo Door - Cutout
53-716-01		53-716-01-01		SPECIAL DETAILED	FWD Large Cargo Door - Cutout Outer Chord - Upper Sill
53-717-01		53-717-01-01		SPECIAL DETAILED	Fwd Large Cargo Door - Cutout
53-718-01		53-718-01-01		SPECIAL DETAILED	Fwd Large Cargo Door - Cutout
53-719-01		53-719-01-01		SPECIAL DETAILED	Forward Equipment Bay Access Hatch Cutout Structure
53-720-01		53-720-01-01		SPECIAL DETAILED	E/E Bay Access Hatch Cutout Structure
53-721-01		53-721-01-01		DETAILED	No. 1 Crew Window Cutout Structure
53-722-01		53-722-01-01		SPECIAL DETAILED	No. 3 Crew Window Cutout Structure
53-723-01		53-723-01-01		SPECIAL DETAILED	NLG Well Top Panel
53-724-01		53-724-01-01		SPECIAL DETAILED	WL 152 Beam (C/L 1 to 40)
53-724-02		53-724-02-01		SPECIAL DETAILED	WL 152 Beam (C/L 41 and on)
53-725-01		53-725-01-01		DETAILED	Nose Wheel Well Cutout Structure (C/L 1 to 40)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-725-02		53-725-02-01		SPECIAL DETAILED	Nose Wheel Well Cutout Structure (C/L 41 and on)
53-725-03		53-725-03-01		DETAILED	Nose Landing Gear Well Cutout (C/L 1 to 40)
53-725-04		53-725-04-01		SPECIAL DETAILED	Nose Landing Gear Well Cutout (C/L 1 to 40)
53-725-05		53-725-05-01		DETAILED	Nose Landing Gear Well Cutout (C/L 41 and on)
53-725-06		53-725-06-01		SPECIAL DETAILED	Nose Landing Gear Well Cutout (C/L 41 and on)
53-725-07		53-725-07-01		SPECIAL DETAILED	Nose Wheel Well Cutout Structure (L/N 1 to 40)
53-726-01		53-726-01-01		SPECIAL DETAILED	Nose Wheel Well Trunnion Support Fitting
53-726-02		53-726-02-01		SPECIAL DETAILED	Nose Wheel Well Trunnion Support Fitting (C/L 41 and on)
53-727-01		53-727-01-01		SPECIAL DETAILED	NLG Drag Brace Fitting - Lug and Bushing Interface
53-728-01		53-728-01-01		DETAILED	Crown Panel Skin/Stringer Under Radome
53-728-02		53-728-02-01		DETAILED	Longitudinal Skin Crack Under Radome
53-730-01		53-730-01-01		SPECIAL DETAILED	Longitudinal Skin Crack Under Antenna Attach Angle/Skin Lug Fittings
53-731-01		53-731-01-01		SPECIAL DETAILED	Fuselage Skin adjacent to Strakelet Attach Fitting (L/N 1-218)
53-731-02		53-731-02-01		SPECIAL DETAILED	Fuselage Skin adjacent to Strakelet Attach Fitting (L/N 219 and on)
53-733-01		53-733-01-01		SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice, BS 1035 (L/N 75 and on)
53-733-02		53-733-02-01		SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice, BS 1035 (L/N 75 and on)





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-733-03		53-733-03-01		SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice, BS 1035 (L/N 75 and on)
53-733-04		53-733-04-01		SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice, BS 1035
53-733-05		53-733-05-01		SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice, BS 1035
53-733-06		53-733-06-01		SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice, BS 1035
53-734-01		53-734-01-01		SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin (L/N 1-422)
53-734-02		53-734-02-01		SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin (L/N 423 and on)
53-734-03		53-734-03-01		SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin
53-735-01		53-735-01-01		DETAILED	Longitudinal Skin Lap Splices Outer Skin - Except Lower Row (S-45). Typical - All Section 43 Lap Splices.
53-736-01		53-736-01-01		SPECIAL DETAILED	Passenger Entry Door #2 - Cutout
53-737-01		53-737-01-01		SPECIAL DETAILED	Passenger Entry Door #2 - Cutout
53-739-01		53-739-01-01		SPECIAL DETAILED	Passenger Entry Door #2 - Cutout Upper Sill
53-740-01		53-740-01-01		SPECIAL DETAILED	Passenger Entry Door #2 - Cutout
53-741-01		53-741-01-01		SPECIAL DETAILED	Passenger Entry Door #2 - Cutout Door Stop Backup Fitting
53-742-01		53-742-01-01		SPECIAL DETAILED	Satcom Antenna - Circumferential Cracking with Broken Stringer
53-742-02		53-742-02-01		DETAILED	Skin and Stringer at SATCOM antenna installation



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-743-01		53-743-01-01		SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin (L/N 1-450)
53-743-02		53-743-02-01		SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin (L/N 451 and on)
53-743-03		53-743-03-01		SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin
53-743-04		53-743-04-01		SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin (L/N 1-450)
53-744-01		53-744-01-01		DETAILED	Longitudinal Skin Lap Splices Outer Skin
53-745-01		53-745-01-01		SPECIAL DETAILED	Front Spar Side Fitting Inner Chord Splice
53-746-01		53-746-01-01		SPECIAL DETAILED	Rear Spar Side Fitting Inner Chord Splice
53-746-02		53-746-02-01		SPECIAL DETAILED	Rear Spar Side Fitting
53-746-03		53-746-03-01		SPECIAL DETAILED	Rear Spar Side Fitting at Seat Track Attachment
53-747-01		53-747-01-01		SPECIAL DETAILED	Aft Wheel Well Bulkhead Inner Chord Splice
53-748-01		53-748-01-01		DETAILED	Passenger Entry Overwing Door #3 - Cutout
53-748-02		53-748-02-01		SPECIAL DETAILED	Passenger Entry Overwing Door #3 - Cutout
53-749-01		53-749-01-01		SPECIAL DETAILED	Passenger Entry Overwing Door #3 - Cutout
53-750-01		53-750-01-01		SPECIAL DETAILED	Passenger Entry Overwing Door #3 - Cutout
53-751-01		53-751-01-01		SPECIAL DETAILED	Passenger Entry Overwing Door #3 - Cutout
53-752-01		53-752-01-01		SPECIAL DETAILED	Passenger Entry Overwing Door #3 - Cutout Upper Main Sill



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-753-01		53-753-01-01		SPECIAL DETAILED	Aft Wheel Well Bulkhead Side Fitting Inner Chord Splice
53-753-02		53-753-02-01		SPECIAL DETAILED	Aft Wheel Well Bulkhead Side Fitting Outer Chord
53-753-03		53-753-03-01		SPECIAL DETAILED	Aft Wheel Well Bulkhead Side Fitting Outer Chord
53-753-04		53-753-04-01		DETAILED	Aft Wheel Well Bulkhead Side Fitting Outer Chord
53-753-05		53-753-05-01		SPECIAL DETAILED	Aft Wheel Well Bulkhead Side Fitting Outer Chord
53-753-06		53-753-06-01		SPECIAL DETAILED	Aft Wheel Well Bulkhead Horizontal Stiffeners
53-753-07		53-753-07-01		SPECIAL DETAILED	Aft Wheel Well Bulkhead Horizontal Stiffeners
53-754-01		53-754-01-01		SPECIAL DETAILED	Crown Panel, Skin and Stringer Section 46
53-754-02		53-754-02-01		SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice (L/N 75 and on)
53-754-03		53-754-03-01		SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice (L/N 75 and on)
53-754-04		53-754-04-01		SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice
53-754-05		53-754-05-01		SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice
53-754-06		53-754-06-01		SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice
53-754-07		53-754-07-01		SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice
53-755-01		53-755-01-01		SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin (L/N 1-422)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-755-02		53-755-02-01		SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin (L/N 423 and on)
53-755-03		53-755-03-01		SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin
53-756-01		53-756-01-01		DETAILED	Longitudinal Skin Lap Splices Outer Skin
53-757-01		53-757-01-01		SPECIAL DETAILED	Passenger Entry Door #3 (-200)
53-757-02		53-757-02-01		SPECIAL DETAILED	Passenger Entry Door #4 (-300)
53-757-03		53-757-03-01		SPECIAL DETAILED	Passenger Entry Door #3 (-200ER)
53-757-04		53-757-04-01		SPECIAL DETAILED	Passenger Entry Door #3 (-200ER)
53-758-01		53-758-01-01		SPECIAL DETAILED	Passenger Entry Door #3 (-200)/#4 (-300) Cutout
53-759-01		53-759-01-01		SPECIAL DETAILED	Passenger Entry Door #3 (-200)/#4 (-300) Cutout
53-760-01		53-760-01-01		SPECIAL DETAILED	Passenger Entry Door #3 (-200)/#4 (-300) - Cutout
53-761-01		53-761-01-01		SPECIAL DETAILED	Passenger Entry Door #3 (-200)/#4 (-300) - Cutout
53-762-01		53-762-01-01		SPECIAL DETAILED	Small Cargo Door - Cutout Lower Main Sill
53-763-01		53-763-01-01		SPECIAL DETAILED	Small Cargo Door - Cutout Upper Main Sill
53-764-01		53-764-01-01		SPECIAL DETAILED	Small Cargo Door - Cutout Inner Chord - Edge Frames STA 1678.5 & STA 1754.5
53-765-01		53-765-01-01		SPECIAL DETAILED	Small Cargo Door - Cutout Inner Chord - Edge Frames STA 1678.5 & STA 1754.5



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-766-01		53-766-01-01		SPECIAL DETAILED	Small Cargo Door - Cutout Outer Chord - Edge Frames STA 1678.5 & STA 1754.5
53-767-01		53-767-01-01		DETAILED	Small Cargo Door - Cutout
53-767-02		53-767-02-01		SPECIAL DETAILED	Small Cargo Door - Cutout
53-768-01		53-768-01-01		SPECIAL DETAILED	Aft Large Cargo Door - Cutout
53-769-01		53-769-01-01		SPECIAL DETAILED	Aft Large Cargo Door - Cutout Outer Chord - Upper Sill
53-770-01		53-770-01-01		SPECIAL DETAILED	Aft Large Cargo Door - Upper Main Sill
53-774-01		53-774-01-01		SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin (L/N 1-422)
53-774-02		53-774-02-01		SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin (L/N 423 and on)
53-774-03		53-774-03-01		SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin
53-775-01		53-775-01-01		DETAILED	Longitudinal Skin Lap Splices Outer Skin
53-776-01		53-776-01-01		SPECIAL DETAILED	Passenger Entry Door #4 (-200)/#5 (-300) - Cutout
53-777-01		53-777-01-01		SPECIAL DETAILED	Passenger Entry Door #4 (-200)/#5 (-300) - Cutout
53-778-01		53-778-01-01		SPECIAL DETAILED	Passenger Entry Door #4 (-200)/#5 (-300) - Cutout
53-779-01		53-779-01-01		SPECIAL DETAILED	Passenger Entry Door #4 (-200)/#5 (-300) - Cutout
53-780-01		53-780-01-01		SPECIAL DETAILED	Bulk Cargo Door - Cutout Edge Frames
53-781-01		53-781-01-01		SPECIAL DETAILED	Pressure Bulkhead at STA 2150; Sec 48 Lap Splice (L/N 1-3)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-781-02	53-800-00	53-781-02-01		SPECIAL DETAILED	Pressure Bulkhead at STA 2150; Sec 48 Lap Splice (L/N 1-422)
53-781-03		53-781-03-01		DETAILED	Pressure Bulkhead at STA 2150; Sec 48 Lap Splice (L/N 1-422)
53-781-04		53-781-04-01		SPECIAL DETAILED	Pressure Bulkhead at STA 2150; Sec 48 Lap Splice (L/N 423 and on)
53-781-05		53-781-05-01		DETAILED	Pressure Bulkhead at STA 2150; Sec 48 Lap Splice (L/N 423 and on)
53-782-01		53-782-01-01		DETAILED	Pressure Bulkhead at STA 2150; Sec 48 Circumferential Crack in Web at Radial Stiffener
53-783-01		53-783-01-01		SPECIAL DETAILED	Pressure Bulkhead, STA 2150, Dome Web Attachment to Y-Ring (L/N 1-422)
53-783-02		53-783-02-01		SPECIAL DETAILED	Pressure Bulkhead, STA 2150, Dome Web Attachment to Y-Ring (L/N 423 and on)
53-784-01		53-784-01-01		SPECIAL DETAILED	Stabilizer Pivot Bulkhead STA 2370
53-785-01		53-785-01-01		DETAILED	Stabilizer Pivot Bulkhead STA 2370 - Vertical Stiffeners
53-786-01		53-786-01-01		SPECIAL DETAILED	Stabilizer Pivot Fitting Lug; Section 48
53-787-01		53-787-01-01		SPECIAL DETAILED	Jackscrew Support Fitting Lug
53-800-00		53-800-00-01		ZONAL (GV)	Fuselage Lower Half
		53-800-00-02			
		53-800-00-03			
		53-800-00-04			
		53-800-00-05			
		53-800-00-06			
		53-800-00-07			
		53-800-00-08			
		53-800-00-09			
		53-800-00-10			
		53-800-00-11			
		53-800-00-12			



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-804-00	53-804-00	53-804-00-01 53-804-00-02 53-804-00-03 53-804-00-04 53-804-00-05 53-804-00-06		ZONAL (GV)	Radome
53-806-00	53-806-00	53-806-00-01		ZONAL (GV)	Area Forward of Nose Landing Gear Wheel Well
53-808-00	53-808-00	53-808-00-01		ZONAL (GV)	Nose Gear Wheel Well - from the ground
53-810-00	53-810-00	53-810-00-01		ZONAL (GV)	Nose Gear Wheel Well (Inspection Accomplished from Within Wheel Well)
53-812-00	53-812-00	53-812-00-01		ZONAL (GV)	Area Above and Outboard of the Nose Landing Gear Wheel Well
53-814-00	53-814-00	53-814-00-01		ZONAL (GV)	Main Equipment Center
53-816-00	53-816-00	53-816-00-01		ZONAL (GV)	Forward Cargo Compartment
53-818-00	53-818-00	53-818-00-01		ZONAL (GV)	Forward Cargo Compartment
53-820-00	53-820-00	53-820-00-01		ZONAL (GV)	Forward Cargo Compartment
53-822-00	53-822-00	53-822-00-01		ZONAL (GV)	Area Below Forward Cargo Compartment
53-824-00	53-824-00	53-824-00-01 53-824-00-02 53-824-00-03 53-824-00-04 53-824-00-05 53-824-00-06		ZONAL (GV)	Area Below Forward Cargo Compartment
53-826-00	53-826-00	53-826-00-01		ZONAL (GV)	Area Aft of Forward Cargo Compartment
53-828-00	53-828-00	53-828-00-01		ZONAL (GV)	Area Above Wing Center Section
53-830-00	53-830-00	53-830-00-01 53-830-00-02		ZONAL (GV)	Environmental Control Systems Bay



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-832-00	53-832-00	53-832-00-01 53-832-00-02 53-832-00-03 53-832-00-04 53-832-00-05 53-832-00-06		ZONAL (GV)	Forward Keel Beam
53-834-00	53-834-00	53-834-00-01		ZONAL (GV)	Area Above Main Landing Gear Wheel Well
53-836-00	53-836-00	53-836-00-01		ZONAL (GV)	Left Main Landing Gear Wheel Well - From the Ground
53-838-00	53-838-00	53-838-00-01		ZONAL (GV)	Left Main Landing Gear Wheel Well (Inspection accomplished within WW)
53-840-00	53-840-00	53-840-00-01		ZONAL (GV)	Right Main Landing Gear Wheel Well - From the Ground
53-842-00	53-842-00	53-842-00-01		ZONAL (GV)	Right Main Landing Gear Wheel Well (Inspection accomplished Within WW)
53-844-00	53-844-00	53-844-00-01 53-844-00-02 53-844-00-03 53-844-00-04 53-844-00-05 53-844-00-06		ZONAL (GV)	Aft Keel Beam
53-846-00	53-846-00	53-846-00-01		ZONAL (GV)	Aft Cargo Compartment
53-848-00	53-848-00	53-848-00-01		ZONAL (GV)	Aft Cargo Compartment
53-850-00	53-850-00	53-850-00-01		ZONAL (GV)	Aft Cargo Compartment Lower Lobe Attendant Rest
53-852-00	53-852-00	53-852-00-01		ZONAL (GV)	Aft Cargo Compartment
53-852-01	53-852-01	53-852-01-01		ZONAL (GV)	Aft Cargo Compartment
53-854-00	53-854-00	53-854-00-01		ZONAL (GV)	Aft Cargo Compartment
53-856-00	53-856-00	53-856-00-01		ZONAL (GV)	Aft Cargo Compartment
53-858-00	53-858-00	53-858-00-01		ZONAL (GV)	Aft Cargo Compartment
53-860-00	53-860-00	53-860-00-01		ZONAL (GV)	Area Below Aft Cargo Compartment





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-862-00	53-862-00	53-862-00-01 53-862-00-02 53-862-00-03 53-862-00-04 53-862-00-05 53-862-00-06		ZONAL (GV)	Area Below Aft Cargo Compartment
53-864-00	53-864-00	53-864-00-01		ZONAL (GV)	Area Below Aft Cargo Compartment
53-866-00	53-866-00	53-866-00-01		ZONAL (GV)	Area Below Aft Cargo Compartment
53-868-00	53-868-00	53-868-00-01		ZONAL (GV)	Bulk Cargo Compartment
53-870-00	53-870-00	53-870-00-01		ZONAL (GV)	Bulk Cargo Compartment
53-872-00	53-872-00	53-872-00-01 53-872-00-02 53-872-00-03 53-872-00-04 53-872-00-05 53-872-00-06		ZONAL (GV)	Bulk Cargo Compartment
53-874-00	53-874-00	53-874-00-01		ZONAL (GV)	Area Below Bulk Cargo Compartment
53-876-00	53-876-00	53-876-00-01 53-876-00-02 53-876-00-03 53-876-00-04 53-876-00-05 53-876-00-06		ZONAL (GV)	Area Aft of the Bulk Cargo Compartment
53-878-00	53-878-00	53-878-00-01 53-878-00-02 53-878-00-03 53-878-00-04 53-878-00-05 53-878-00-06		ZONAL (GV)	Area Aft of the Bulk Cargo Compartment
53-880-00	53-880-00	53-880-00-01		ZONAL (GV)	Forward Wing-To-Body Fairings - Left
53-882-00	53-882-00	53-882-00-01		ZONAL (GV)	Forward Wing-To-Body Fairings - Right



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-884-00	53-884-00	53-884-00-01		ZONAL (GV)	Overwing Wing-To-Body Fairing - Left
53-886-00	53-886-00	53-886-00-01		ZONAL (GV)	Overwing Wing-To-Body Fairings - Right
53-888-00	53-888-00	53-888-00-01		ZONAL (GV)	Underwing Wing-to-Body Fairings - Left
53-890-00	53-890-00	53-890-00-01		ZONAL (GV)	Underwing Wing-To-Body Fairings - Right
53-892-00	53-892-00	53-892-00-01		ZONAL (GV)	Aft Wing-to-Body Fairings - Left
53-894-00	53-894-00	53-894-00-01		ZONAL (GV)	Aft Wing-To-Body Fairings - Right
53-896-00	53-896-00	53-896-00-01 53-896-00-02 53-896-00-03 53-896-00-04 53-896-00-05 53-896-00-06		ZONAL (GV)	Upper Fuselage - Left and Right - Section 41 through 47 - BS 246 to BS 2150
53-898-00	53-898-00	53-898-00-01 53-898-00-02		ZONAL (GV)	Upper Fuselage - Flight Compartment - BS 92.5 to 246
53-900-00	53-900-00	53-900-00-01 53-900-00-02 53-900-00-03 53-900-00-04 53-900-00-05 53-900-00-06		ZONAL (GV)	Flight Compartment
53-902-00	53-902-00	53-902-00-01 53-902-00-02 53-902-00-03 53-902-00-04 53-902-00-05 53-902-00-06		ZONAL (GV)	Flight Compartment
53-904-00	53-904-00	53-904-00-01		ZONAL (GV)	Passenger Compartment - Section 41



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-906-00	53-906-00	53-906-00-01 53-906-00-02 53-906-00-03 53-906-00-04 53-906-00-05		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 41
53-907-00	53-907-00	53-907-00-01		ZONAL (GV)	Overhead Flight Crew Rest (OFCR) Compartment
53-908-00	53-908-00	53-908-00-01		ZONAL (GV)	Passenger Compartment - Section 43
53-910-00	53-910-00	53-910-00-01 53-910-00-02 53-910-00-03 53-910-00-04 53-910-00-05		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 43
53-912-00	53-912-00	53-912-00-01		ZONAL (GV)	Passenger Compartment - Section 44
53-914-00	53-914-00	53-914-00-01 53-914-00-02 53-914-00-03 53-914-00-04 53-914-00-05		ZONAL (GV)	Area Above Passenger Compartment - Section 44
53-916-00	53-916-00	53-916-00-01		ZONAL (GV)	Passenger Compartment - Section 46
53-918-00	53-918-00	53-918-00-01 53-918-00-02 53-918-00-03 53-918-00-04 53-918-00-05		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 46
53-919-00	53-919-00	53-919-00-01		ZONAL (GV)	Overhead Flight Attendant Rest (OFAR) Compartment(s)
53-920-00	53-920-00	53-920-00-01		ZONAL (GV)	Passenger Compartment - Section 47
53-922-00	53-922-00	53-922-00-01 53-922-00-02 53-922-00-03 53-922-00-04 53-922-00-05		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 47



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-924-00	53-924-00	53-924-00-01 53-924-00-02		ZONAL (GV)	Body Section 48 - BS 2150 to BS 2570
53-926-00	53-926-00	53-926-00-01		ZONAL (GV)	Fuselage Area Aft of Bulkhead - Inspection Accomplished within Fuselage
53-928-00	53-928-00	53-928-00-01		ZONAL (GV)	APU Compartment
53-930-00	53-930-00	53-930-00-01		ZONAL (GV)	APU Compartment - As visible with APU Removed
53-932-00	53-932-00	53-932-00-01		ZONAL (GV)	Upper Fuselage - Left and Right - Section 43
53-934-00	53-934-00	53-934-00-01		ZONAL (GV)	Area Above Supernumerary Cabin - Left and Right
53-936-00	53-936-00	53-936-00-01		ZONAL (GV)	Supernumerary Cabin - Left and Right
53-937-00	53-937-00	53-937-00-01		ZONAL (GV)	Area Above Main Deck Cargo Compartment Ceiling - Left and Right Sides - BS STA 388 to Aft Pressure Bulkhead
53-938-00	53-938-00	53-938-00-01		ZONAL (GV)	Main Deck Cargo Compartment - Section 41, 43, 44, 46, 47 - Left And Right Sides - BS STA 388 To Aft Pressure Bulkhead
54-005-01	54-005-01	54-005-01-01 54-005-01-02		FUNCTIONAL	Left Strut AFT Upper Spar Drain and AFT Strut Fairing Drain
54-005-02	54-005-02	54-005-02-01 54-005-02-02		FUNCTIONAL	Right Strut AFT Upper Spar Drain and AFT Strut Fairing Drain
54-205-01	54-205-01	54-205-01-01		FUNCTIONAL	Left Strut AFT Upper Spar Drain and AFT Strut Fairing Drain
54-205-02	54-205-02	54-205-02-01		FUNCTIONAL	Right Strut AFT Upper Spar Drain and AFT Strut Fairing Drain
54-210-01	54-210-01	54-210-01-01		FUNCTIONAL	Left Forward Engine Strut Drain.
54-210-02	54-210-02	54-210-02-01		FUNCTIONAL	Right Forward Engine Strut Drain.
54-350-01	54-350-01	54-350-01-01		FUNCTIONAL	Left Strut AFT Upper Spar Drain and AFT Strut Fairing Drain
54-350-02	54-350-02	54-350-02-01		FUNCTIONAL	Right Strut AFT Upper Spar Drain and AFT Strut Fairing Drain
54-501-01	54-501-01	54-501-01-01		GENERAL VISUAL	Powerplant - Left
54-502-01	54-502-01	54-502-01-01		DETAILED	Powerplant - Left



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>TASK CARD NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
54-504-02	54-504-02	54-504-02-01		GENERAL VISUAL	Powerplant - Right
54-505-02	54-505-02	54-505-02-01		DETAILED	Powerplant - Right
54-507-01	54-507-01	54-507-01-01		DETAILED	Left Nacelle Strut
54-508-01	54-508-01	54-508-01-01		SPECIAL DETAILED	Left Nacelle Strut
54-509-01	54-509-01	54-509-01-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut
54-510-01	54-510-01	54-510-01-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut
54-511-01	54-511-01	54-511-01-01		GENERAL VISUAL	AFT Torque Box - Left Nacelle Strut
54-512-01	54-512-01	54-512-01-01		DETAILED	AFT Torque Box - Left Nacelle Strut
54-513-01	54-513-01	54-513-01-01		DETAILED	Strut Forward Torque Box
54-514-01	54-514-01	54-514-01-01		GENERAL VISUAL	AFT Torque Box - Left Nacelle Strut
54-515-02	54-515-02	54-515-02-01		DETAILED	Right Nacelle Strut
54-516-02	54-516-02	54-516-02-01		SPECIAL DETAILED	Right Nacelle Strut
54-517-02	54-517-02	54-517-02-01		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut
54-518-02	54-518-02	54-518-02-01		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut
54-519-02	54-519-02	54-519-02-01		GENERAL VISUAL	AFT Torque Box - Right Nacelle Strut
54-520-02	54-520-02	54-520-02-01		DETAILED	AFT Torque Box - Right Nacelle Strut
54-521-02	54-521-02	54-521-02-01		DETAILED	Strut Forward Torque Box



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-522-02	54-522-02	54-522-02-01		GENERAL VISUAL	AFT Torque Box - Right Nacelle Strut
54-530-01	54-530-01	54-530-01-01		GENERAL VISUAL	Powerplant - Left
54-531-01	54-531-01	54-531-01-01		DETAILED	Powerplant - Left
54-533-02	54-533-02	54-533-02-01		GENERAL VISUAL	Powerplant - Right
54-534-02	54-534-02	54-534-02-01		DETAILED	Powerplant - Right
54-536-01	54-536-01	54-536-01-01		DETAILED	Left Nacelle Strut
54-537-01	54-537-01	54-537-01-01		SPECIAL DETAILED	Left Nacelle Strut
54-538-01	54-538-01	54-538-01-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut
54-539-01	54-539-01	54-539-01-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut
54-540-01	54-540-01	54-540-01-01		GENERAL VISUAL	AFT Torque Box - Left Nacelle Strut
54-541-01	54-541-01	54-541-01-01 54-541-01-02		DETAILED	AFT Torque Box - Left Nacelle Strut
54-542-01	54-542-01	54-542-01-01 54-542-01-02		DETAILED	Strut Forward Torque Box
54-543-01	54-543-01	54-543-01-01 54-543-01-02		GENERAL VISUAL	AFT Torque Box - Left Nacelle Strut
54-544-02	54-544-02	54-544-02-01		DETAILED	Right Nacelle Strut
54-545-02	54-545-02	54-545-02-01		SPECIAL DETAILED	Right Nacelle Strut
54-546-02	54-546-02	54-546-02-01		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-547-02	54-547-02	54-547-02-01		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut
54-548-02	54-548-02	54-548-02-01		GENERAL VISUAL	AFT Torque Box - Right Nacelle Strut
54-549-02	54-549-02	54-549-02-01 54-549-02-02		DETAILED	AFT Torque Box - Right Nacelle Strut
54-550-02	54-550-02	54-550-02-01 54-550-02-02		DETAILED	Strut Forward Torque Box
54-551-02	54-551-02	54-551-02-01 54-551-02-02		GENERAL VISUAL	AFT Torque Box - Right Nacelle Strut
54-560-01	54-560-01	54-560-01-01		GENERAL VISUAL	Powerplant - Left
54-561-01	54-561-01	54-561-01-01		DETAILED	Powerplant - Left
54-563-02	54-563-02	54-563-02-01		GENERAL VISUAL	Powerplant - Right
54-564-02	54-564-02	54-564-02-01		DETAILED	Powerplant - Right
54-566-01	54-566-01	54-566-01-01		DETAILED	Left Nacelle Strut
54-567-01	54-567-01	54-567-01-01		SPECIAL DETAILED	Left Nacelle Strut
54-568-01	54-568-01	54-568-01-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut
54-569-01	54-569-01	54-569-01-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut
54-570-01	54-570-01	54-570-01-01		GENERAL VISUAL	Aft Torque Box - Left Nacelle Strut
54-571-01	54-571-01	54-571-01-01		DETAILED	Aft Torque Box - Left Nacelle Strut
54-572-01	54-572-01	54-572-01-01		DETAILED	Strut Forward - Left Torque Box
54-573-01	54-573-01	54-573-01-01		GENERAL VISUAL	Aft Torque Box - Left Nacelle Strut



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-574-02	54-574-02	54-574-02-01		DETAILED	Right Nacelle Strut
54-575-02	54-575-02	54-575-02-01		SPECIAL DETAILED	Right Nacelle Strut
54-576-02	54-576-02	54-576-02-01		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut
54-577-02	54-577-02	54-577-02-01		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut
54-578-02	54-578-02	54-578-02-01		GENERAL VISUAL	Aft Torque Box - Right Nacelle Strut
54-579-02	54-579-02	54-579-02-01		DETAILED	Aft Torque Box - Right Nacelle Strut
54-580-02	54-580-02	54-580-02-01		DETAILED	Strut Forward - Right Torque Box
54-581-02	54-581-02	54-581-02-01		GENERAL VISUAL	Aft Torque Box - Right Nacelle Strut
54-582-01	54-582-01	54-582-01-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut
54-583-02	54-583-02	54-583-02-01		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut
54-701-02		54-701-02-01		SPECIAL DETAILED	Aft Upper Spar Chord Splice (PW)
54-702-02		54-702-02-01		SPECIAL DETAILED	Strut Upper Spar (PW)
54-702-03		54-702-03-01		SPECIAL DETAILED	Strut Upper Spar (PW)
54-702-04		54-702-04-01		SPECIAL DETAILED	Strut Upper Spar (PW)
54-703-02		54-703-02-01		SPECIAL DETAILED	Strut Side Skin (PW)
54-703-03		54-703-03-01		SPECIAL DETAILED	Strut Side Skin (PW)





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-703-04		54-703-04-01		SPECIAL DETAILED	Strut Side Skin (PW)
54-703-05		54-703-05-01		SPECIAL DETAILED	Strut Side Skin (PW)
54-704-02		54-704-02-01		SPECIAL DETAILED	Lower Spar Chord (PW)
54-704-03		54-704-03-01		SPECIAL DETAILED	Lower Spar Chord (PW)
54-704-04		54-704-04-01		SPECIAL DETAILED	Lower Spar Chord (PW)
54-705-01		54-705-01-01		SPECIAL DETAILED	Lower Spar (PW)
54-705-03		54-705-03-01		SPECIAL DETAILED	Lower Spar (PW)
54-706-01		54-706-01-01		SPECIAL DETAILED	Lower Spar @ AEMB (PW)
54-706-03		54-706-03-01		SPECIAL DETAILED	Lower Spar @ AEMB (PW)
54-706-04		54-706-04-01		SPECIAL DETAILED	Strut Lower Spar (PW)
54-707-01		54-707-01-01		SPECIAL DETAILED	Forward Engine Mount Bulkhead (PW)
54-707-03		54-707-03-01		SPECIAL DETAILED	Forward Engine Mount Bulkhead (PW)
54-707-04		54-707-04-01		SPECIAL DETAILED	Forward Engine Mount Bulkhead (PW)
54-707-05		54-707-05-01		SPECIAL DETAILED	Strut Forward Engine Mount Bulkhead Assembly (PW)
54-708-01		54-708-01-01		SPECIAL DETAILED	Strut Aft Engine Mount Bulkhead Assembly (PW)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-709-01		54-709-01-01		DETAILED	PW 4090 and PW 4098 Forward Engine Mount Assembly (PW)
54-710-02		54-710-02-01		SPECIAL DETAILED	Upper Spar Bay 3 (GE)
54-710-03		54-710-03-01		SPECIAL DETAILED	Upper Spar Bay 3 (GE)
54-710-04		54-710-04-01		SPECIAL DETAILED	Upper Spar Bay 3 (GE)
54-711-02		54-711-02-01		SPECIAL DETAILED	Strut Upper Spar Bay 5/6 at Cutout (GE)
54-711-03		54-711-03-01		SPECIAL DETAILED	Strut Upper Spar Bay 5/6 at Cutout (GE)
54-711-04		54-711-04-01		SPECIAL DETAILED	Strut Upper Spar Bay 5/6 at Cutout (GE)
54-712-02		54-712-02-01		SPECIAL DETAILED	Strut Upper Spar Bay 5 at Cutout (GE)
54-712-03		54-712-03-01		SPECIAL DETAILED	Strut Upper Spar Bay 5 at Cutout (GE)
54-712-04		54-712-04-01		SPECIAL DETAILED	Strut Upper Spar Bay 5 at Cutout (GE)
54-713-02		54-713-02-01		SPECIAL DETAILED	Strut Upper Spar Bay 6 at Cutout (GE)
54-713-03		54-713-03-01		SPECIAL DETAILED	Strut Upper Spar Bay 6 at Cutout (GE)
54-713-04		54-713-04-01		SPECIAL DETAILED	Strut Upper Spar Bay 6 at Cutout (GE)
54-714-02		54-714-02-01		SPECIAL DETAILED	Upper Spar (GE)
54-714-03		54-714-03-01		SPECIAL DETAILED	Upper Spar (GE)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-715-02		54-715-02-01		SPECIAL DETAILED	Upper Spar (GE)
54-716-01		54-716-01-01		SPECIAL DETAILED	Side Skin Cutout (GE)
54-716-02		54-716-02-01		SPECIAL DETAILED	Side Skin Cutout (GE)
54-716-03		54-716-03-01		SPECIAL DETAILED	Side Skin Cutout (GE)
54-717-02		54-717-02-01		SPECIAL DETAILED	Lower Spar Bay 3 (GE)
54-717-03		54-717-03-01		SPECIAL DETAILED	Lower Spar Bay 3 (GE)
54-717-04		54-717-04-01		SPECIAL DETAILED	Lower Spar Bay 3 (GE)
54-718-02		54-718-02-01		SPECIAL DETAILED	Lower Outboard Spar Chord at Aft Engine Mount Bulkhead (GE)
54-719-02		54-719-02-01		SPECIAL DETAILED	Lower Spar at Cutout (GE)
54-720-01		54-720-01-01		SPECIAL DETAILED	Lower Spar (GE)
54-720-03		54-720-03-01		SPECIAL DETAILED	Lower Spar (GE)
54-721-01		54-721-01-01		SPECIAL DETAILED	Forward Engine Mount Bulkhead (GE)
54-773-01		54-773-01-01		SPECIAL DETAILED	Upper Spar Chord (RR)
54-774-01		54-774-01-01		SPECIAL DETAILED	Forward Upper Spar (RR)
54-775-01		54-775-01-01		SPECIAL DETAILED	Forward Upper Spar (RR)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-776-01		54-776-01-01		SPECIAL DETAILED	Lower Chord (RR)
54-777-01		54-777-01-01		SPECIAL DETAILED	Aft Lower Chord at Aft Engine Mount Bulkhead (RR)
54-777-02		54-777-02-01		SPECIAL DETAILED	Aft Lower Chord at Aft Engine Mount Bulkhead (RR)
54-778-01		54-778-01-01		SPECIAL DETAILED	Forward Engine Mount Bulkhead (RR)
54-779-01		54-779-01-01		SPECIAL DETAILED	Aft Engine Mount Bulkhead (RR)
54-779-02		54-779-02-01		SPECIAL DETAILED	Aft Engine Mount Bulkhead (RR)
54-779-03		54-779-03-01		SPECIAL DETAILED	Aft Engine Mount Bulkhead (RR)
54-780-01		54-780-01-01		SPECIAL DETAILED	Strut Aft Bulkhead (RR)
54-780-02		54-780-02-01		SPECIAL DETAILED	Aluminum Aft Strut Bulkhead (RR)
54-781-01		54-781-01-01		SPECIAL DETAILED	Aluminum Aft Strut Bulkhead (RR)
54-781-02		54-781-02-01		SPECIAL DETAILED	Aluminum Aft Strut Bulkhead (RR)
54-781-03		54-781-03-01		SPECIAL DETAILED	Aluminum Aft Strut Bulkhead (RR)
54-800-01	54-800-01	54-800-01-01		ZONAL (GV)	Left Nacelle Strut
54-802-01	54-802-01	54-802-01-01		ZONAL (GV)	Forward Strut Fairing - Left Nacelle Strut
54-804-01	54-804-01	54-804-01-01		ZONAL (GV)	Forward and Aft Torque Box - Left Nacelle Strut
54-806-01	54-806-01	54-806-01-01		ZONAL (GV)	Forward and Aft Torque Box - Left Nacelle Strut
54-808-01	54-808-01	54-808-01-01		ZONAL (GV)	Aft Strut Fairing - Left Nacelle Strut



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-810-02	54-810-02	54-810-02-01		ZONAL (GV)	Right Nacelle Strut
54-812-02	54-812-02	54-812-02-01		ZONAL (GV)	Forward Strut Fairing - Right Nacelle Strut
54-814-02	54-814-02	54-814-02-01		ZONAL (GV)	Forward and Aft Torque Box - Right Nacelle Strut
54-816-02	54-816-02	54-816-02-01		ZONAL (GV)	Forward and Aft Torque Box - Right Nacelle Strut
54-818-02	54-818-02	54-818-02-01		ZONAL (GV)	Aft Strut Fairing - Right Nacelle Strut
54-820-01	54-820-01	54-820-01-01		ZONAL (GV)	Left Nacelle Strut
54-822-01	54-822-01	54-822-01-01		ZONAL (GV)	Forward Strut Fairing - Left Nacelle Strut
54-824-01	54-824-01	54-824-01-01		ZONAL (GV)	Forward and Aft Torque Box - Left Nacelle Strut - Cowls Opened
54-826-01	54-826-01	54-826-01-01		ZONAL (GV)	Forward and Aft Torque Box - Left Nacelle Strut
54-828-01	54-828-01	54-828-01-01		ZONAL (GV)	Aft Strut Fairing - Left Nacelle Strut
54-830-02	54-830-02	54-830-02-01		ZONAL (GV)	Right Nacelle Strut
54-832-02	54-832-02	54-832-02-01		ZONAL (GV)	Forward Strut Fairing - Right Nacelle Strut
54-834-02	54-834-02	54-834-02-01		ZONAL (GV)	Forward and Aft Torque Box - Right Nacelle Strut - Fan Cowls Opened
54-836-02	54-836-02	54-836-02-01		ZONAL (GV)	Forward and Aft Torque Box - Right Nacelle Strut
54-838-02	54-838-02	54-838-02-01		ZONAL (GV)	Aft Strut Fairing - Right Nacelle Strut
54-840-01	54-840-01	54-840-01-01		ZONAL (GV)	Left Nacelle Strut
54-842-01	54-842-01	54-842-01-01		ZONAL (GV)	Forward Strut Fairing - Left Nacelle Strut
54-844-01	54-844-01	54-844-01-01		ZONAL (GV)	Forward and Aft Torque Box - Left Nacelle Strut - Cowls Opened
54-846-01	54-846-01	54-846-01-01		ZONAL (GV)	Forward and Aft Torque Box - Left Nacelle Strut
54-848-01	54-848-01	54-848-01-01		ZONAL (GV)	Aft Strut Fairing - Left Nacelle Strut
54-850-02	54-850-02	54-850-02-01		ZONAL (GV)	Right Nacelle Strut
54-852-02	54-852-02	54-852-02-01		ZONAL (GV)	Forward Strut Fairing - Right Nacelle Strut
54-854-02	54-854-02	54-854-02-01		ZONAL (GV)	Forward and Aft Torque Box - Right Nacelle Strut - Fan Cowls Opened
54-856-02	54-856-02	54-856-02-01		ZONAL (GV)	Forward and Aft Torque Box - Right Nacelle Strut



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-858-02	54-858-02	54-858-02-01		ZONAL (GV)	Aft Strut Fairing - Right Nacelle Strut
55-501-00	55-501-00	55-501-00-01		DETAILED	Horizontal Stabilizer Center Section
55-502-00	55-502-00	55-502-00-01		DETAILED	Horizontal Stabilizer Center Section
55-503-00	55-503-00	55-503-00-01		DETAILED	Area Aft of Bulkhead
55-504-00	55-504-00	55-504-00-01		DETAILED	Area Aft of Bulkhead Stabilizer Torsion Box Compartment
55-505-00	55-505-00	55-505-00-01		DETAILED	Stabilizer Torsion Box Compartment
55-507-00	55-507-00	55-507-00-01		GENERAL VISUAL	Fuselage - BS 2150-2570.3 (Section 48)
55-508-00	55-508-00	55-508-00-01		SPECIAL DETAILED	Fuselage - BS 2150-2570.3 (Section 48)
55-509-00	55-509-00	55-509-00-01	W-55-511-00-01	DETAILED	Vertical Stabilizer - Auxiliary Spar to Front Spar
55-510-00	55-510-00	55-510-00-01 55-510-00-02	W-55-514-00-01	DETAILED	Vertical Stabilizer - Auxiliary Spar to Front Spar
55-511-00	55-511-00	55-511-00-01	W-55-509-00-01	DETAILED	Vertical Stabilizer - Front Spar to Rear Spar
55-512-00	55-512-00	55-512-00-01		GENERAL VISUAL	Vertical Stabilizer - Front Spar to Rear Spar
55-513-00	55-513-00	55-513-00-01		DETAILED	Vertical Stabilizer - Front Spar to Rear Spar
55-513-01	55-513-01	55-513-01-01		DETAILED	Vertical Stabilizer - Front Spar to Rear Spar
55-514-00	55-514-00	55-514-00-01	W-55-510-00-01 W-55-510-00-02	DETAILED	Vertical Stabilizer - Front Spar to Rear Spar
55-514-01	55-514-01	55-514-01-01		DETAILED	Vertical Stabilizer - Front Spar to Rear Spar
55-515-00	55-515-00	55-515-00-01	W-55-518-00-01	DETAILED	Vertical Stabilizer - Rear Spar to Trailing Edge
55-515-01	55-515-01	55-515-01-01		DETAILED	Vertical Stabilizer - Rear Spar to Trailing Edge
55-516-00	55-516-00	55-516-00-01		DETAILED	Vertical Stabilizer - Rear Spar to Trailing Edge
55-516-01	55-516-01	55-516-01-01		DETAILED	Vertical Stabilizer - Rear Spar to Trailing Edge



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-517-00	55-517-00	55-517-00-01	W-55-515-00-01	GENERAL VISUAL	Vertical Stabilizer - Rear Spar to Trailing Edge
55-517-01	55-517-01	55-517-01-01		GENERAL VISUAL	Vertical Stabilizer - Rear Spar to Trailing Edge
55-518-00	55-518-00	55-518-00-01		DETAILED	Vertical Stabilizer - Rear Spar to Trailing Edge
55-518-01	55-518-01	55-518-01-01		DETAILED	Vertical Stabilizer - Rear Spar to Trailing Edge
55-519-00	55-519-00	55-519-00-01 55-519-00-02		GENERAL VISUAL	Rudder
55-520-00	55-520-00	55-520-00-01		DETAILED	Rudder
55-520-01	55-520-01	55-520-01-01		DETAILED	Rudder
55-521-00	55-521-00	55-521-00-01		GENERAL VISUAL	Rudder Tab
55-522-00	55-522-00	55-522-00-01 55-522-00-02		DETAILED	Rudder Tab
55-523-00	55-523-00	55-523-00-01		DETAILED	Rudder Tab
55-524-00	55-524-00	55-524-00-01		DETAILED	Vertical Stabilizer Leading Edge
55-524-01	55-524-01	55-524-01-01		DETAILED	Vertical Stabilizer Leading Edge
55-525-00	55-525-00	55-525-00-01		DETAILED	Vertical Stabilizer - Auxiliary Spar to Front Spar
55-525-01	55-525-01	55-525-01-01		DETAILED	Vertical Stabilizer - Auxiliary Spar to Front Spar
55-526-00	55-526-00	55-526-00-01	W-55-538-02-01 W-55-539-02-01 W-55-539-04-01 W-55-539-06-01	GENERAL VISUAL	Vertical Stabilizer - Front Spar to Rear Spar
55-527-01	55-527-01	55-527-01-01		DETAILED	Left Horizontal Stabilizer Center Section
55-528-01	55-528-01	55-528-01-01		DETAILED	Left Horizontal Stabilizer Center Section
55-528-03	55-528-03	55-528-03-01		DETAILED	Left Horizontal Stabilizer Center Section
55-528-05	55-528-05	55-528-05-01		DETAILED	Left Horizontal Stabilizer Center Section
55-529-01	55-529-01	55-529-01-01		DETAILED	Left Horizontal Stabilizer Center Section



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-530-01	55-530-01	55-530-01-01		GENERAL VISUAL	Left Horizontal Stabilizer Center Section
55-531-01	55-531-01	55-531-01-01		DETAILED	Left Horizontal Stabilizer Center Section
55-532-01	55-532-01	55-532-01-01		GENERAL VISUAL	Left Horizontal Stabilizer - Front Spar to Rear Spar
55-533-01	55-533-01	55-533-01-01		DETAILED	Left Horizontal Stabilizer - Front Spar to Rear Spar
55-534-01	55-534-01	55-534-01-01		DETAILED	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-534-03	55-534-03	55-534-03-01		DETAILED	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-535-01	55-535-01	55-535-01-01		DETAILED	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-535-03	55-535-03	55-535-03-01		DETAILED	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-536-01	55-536-01	55-536-01-01		DETAILED	Left Elevator
55-536-03	55-536-03	55-536-03-01		DETAILED	Left Elevator
55-537-01	55-537-01	55-537-01-01		GENERAL VISUAL	Left Horizontal Stabilizer Tip
55-538-02	55-538-02	55-538-02-01	W-55-527-01-01	DETAILED	Right Horizontal Stabilizer Center Section
55-539-02	55-539-02	55-539-02-01	W-55-528-01-01	DETAILED	Right Horizontal Stabilizer Center Section
55-539-04	55-539-04	55-539-04-01	W-55-528-03-01	DETAILED	Right Horizontal Stabilizer Center Section
55-539-06	55-539-06	55-539-06-01	W-55-528-05-01	DETAILED	Right Horizontal Stabilizer Center Section
55-540-02	55-540-02	55-540-02-01		DETAILED	Right Horizontal Stabilizer Center Section
55-541-02	55-541-02	55-541-02-01		GENERAL VISUAL	Right Horizontal Stabilizer Center Section
55-542-02	55-542-02	55-542-02-01		DETAILED	Right Horizontal Stabilizer Center Section
55-543-02	55-543-02	55-543-02-01		GENERAL VISUAL	Right Horizontal Stabilizer - Front Spar to Rear Spar
55-544-02	55-544-02	55-544-02-01		DETAILED	Right Horizontal Stabilizer - Front Spar to Rear Spar
55-545-02	55-545-02	55-545-02-01		DETAILED	Right Horizontal Stabilizer - Rear Spar to Trailing Edge





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-545-04	55-545-04	55-545-04-01		DETAILED	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-546-02	55-546-02	55-546-02-01		DETAILED	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-546-04	55-546-04	55-546-04-01		DETAILED	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-547-02	55-547-02	55-547-02-01		DETAILED	Right Elevator
55-547-04	55-547-04	55-547-04-01		DETAILED	Right Elevator
55-548-02	55-548-02	55-548-02-01		GENERAL VISUAL	Right Horizontal Stabilizer Tip
55-549-00	55-549-00	55-549-00-01		SPECIAL DETAILED	Area Aft of Bulkhead and Stabilizer Torsion Box Compartment
55-550-00	55-550-00	55-550-00-01		DETAILED	Vertical Stabilizer - Front Spar to Rear Spar
55-550-01	55-550-01	55-550-01-01		GENERAL VISUAL	Vertical Stabilizer - Front Spar to Rear Spar
55-551-00	55-551-00	55-551-00-01		DETAILED	Left Horizontal Stabilizer Tip
55-552-00	55-552-00	55-552-00-01		DETAILED	Right Horizontal Stabilizer Tip
55-656-01	55-656-01	55-656-01-01		GENERAL VISUAL	Left Horizontal Stabilizer Leading Edge
55-660-02	55-660-02	55-660-02-01		GENERAL VISUAL	Right Horizontal Stabilizer Leading Edge
55-701-01		55-701-01-01		SPECIAL DETAILED	Upper Double Plus Chord Horizontal Stabilizer
55-702-01		55-702-01-01		SPECIAL DETAILED	Splice Fitting - Front Spar Upper Chord Horizontal Stabilizer
55-703-01		55-703-01-01		SPECIAL DETAILED	Pivot Fitting Lugs
55-704-01		55-704-01-01		SPECIAL DETAILED	Pivot Fitting Straps (Both Pairs - Upper and Lower) L/N 1-40
55-704-02		55-704-02-01		SPECIAL DETAILED	Pivot Fitting Straps (Both Pairs - Upper and Lower) L/N 1-40



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-704-03		55-704-03-01		SPECIAL DETAILED	Pivot Fitting Straps (Both Pairs - Upper and Lower) L/N 41 and on
55-704-04		55-704-04-01		SPECIAL DETAILED	Pivot Fitting Straps (Both Pairs - Upper and Lower) L/N 41 and on
55-705-01		55-705-01-01		SPECIAL DETAILED	Pivot Fitting Pins Outer Pin
55-706-01		55-706-01-01		SPECIAL DETAILED	Jackscrew Fitting Lugs DWG 182W7402
55-707-01		55-707-01-01		SPECIAL DETAILED	Elevator Actuator Fitting 183W1312 L/N 718 and on and all retrofitted airplanes.
55-800-00	55-800-00	55-800-00-01		ZONAL (GV)	Stabilizer Torsion Box Compartment - Left and Right Sides (Internal of Fuselage)
55-804-00	55-804-00	55-804-00-01	W-55-814-00-01 W-55-822-00-01 W-55-824-00-01	ZONAL (GV)	Vertical Stabilizer Leading Edge
55-806-00	55-806-00	55-806-00-01		ZONAL (GV)	Vertical Stabilizer Leading Edge
55-808-00	55-808-00	55-808-00-01		ZONAL (GV)	Vertical Stabilizer - Auxiliary Spar to Rear Spar
55-810-00	55-810-00	55-810-00-01		ZONAL (GV)	Vertical Stabilizer - Auxiliary Spar to Front Spar
55-811-00	55-811-00	55-811-00-01		ZONAL (GV)	Vertical Stabilizer - Auxiliary Spar / Front Spar
55-812-00	55-812-00	55-812-00-01		ZONAL (GV)	Vertical Stabilizer - Front Spar to Rear Spar - Between Ribs 8 and 9
55-814-00	55-814-00	55-814-00-01	W-55-804-00-01 W-55-820-00-01 W-55-822-00-01	ZONAL (GV)	Vertical Stabilizer - Rear Spar to Trailing Edge
55-816-00	55-816-00	55-816-00-01		ZONAL (GV)	Vertical Stabilizer - Rear Spar to Trailing Edge
55-817-00	55-817-00	55-817-00-01		ZONAL (GV)	Vertical Stabilizer - Rear Spar to Trailing Edge
55-818-00	55-818-00	55-818-00-01		ZONAL (GV)	Vertical Stabilizer - Rear Spar to Trailing Edge
55-819-00	55-819-00	55-819-00-01		ZONAL (GV)	Vertical Stabilizer - Rear Spar to Trailing Edge



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-820-00	55-820-00	55-820-00-01	W-55-814-00-01 W-55-822-00-01 W-55-824-00-01	ZONAL (GV)	Rudder
55-822-00	55-822-00	55-822-00-01	W-55-804-00-01 W-55-814-00-01 W-55-820-00-01	ZONAL (GV)	Rudder Tab
55-824-00	55-824-00	55-824-00-01	W-55-804-00-01 W-55-820-00-01	ZONAL (GV)	Vertical Stabilizer Forward Tip
55-826-00	55-826-00	55-826-00-01		ZONAL (GV)	Vertical Stabilizer Forward Tip
55-828-01	55-828-01	55-828-01-01	W-55-848-02-01	ZONAL (GV)	Left Horizontal Stabilizer - Center Section
55-830-01	55-830-01	55-830-01-01	W-55-838-01-01 W-55-844-01-01 W-55-846-01-01	ZONAL (GV)	Left Horizontal Stabilizer - Leading Edge
55-832-01	55-832-01	55-832-01-01		ZONAL (GV)	Left Horizontal Stabilizer - Auxiliary Spar to Rear Spar
55-834-01	55-834-01	55-834-01-01		ZONAL (GV)	Left Horizontal Stabilizer - Auxiliary Spar to Front Spar
55-836-01	55-836-01	55-836-01-01		ZONAL (GV)	Left Horizontal Stabilizer - Front Spar to Rear Spar
55-838-01	55-838-01	55-838-01-01	W-55-830-01-01 W-55-844-01-01 W-55-846-01-01	ZONAL (GV)	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-838-03	55-838-03	55-838-03-02		ZONAL (GV)	Left Horizontal Stabilizer - Front Spar to Rear Spar
55-840-01	55-840-01	55-840-01-01		ZONAL (GV)	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-841-00	55-841-00	55-841-00-01		ZONAL (GV)	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-842-01	55-842-01	55-842-01-01		ZONAL (GV)	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-843-00	55-843-00	55-843-00-01		ZONAL (GV)	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-844-01	55-844-01	55-844-01-01	W-55-830-01-01 W-55-838-01-01	ZONAL (GV)	Left Elevator
55-846-01	55-846-01	55-846-01-01	W-55-830-01-01 W-55-838-01-01	ZONAL (GV)	Left Horizontal Stabilizer Tip



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-848-02	55-848-02	55-848-02-01	W-55-828-01-01	ZONAL (GV)	Right Horizontal Stabilizer Center Section
55-850-02	55-850-02	55-850-02-01	W-55-858-02-01 W-55-864-02-01 W-55-866-02-01	ZONAL (GV)	Right Horizontal Stabilizer - Leading Edge
55-852-02	55-852-02	55-852-02-01		ZONAL (GV)	Right Horizontal Stabilizer - Auxiliary Spar to Rear Spar
55-854-02	55-854-02	55-854-02-01		ZONAL (GV)	Right Horizontal Stabilizer Auxiliary Spar to Front Spar
55-856-02	55-856-02	55-856-02-01		ZONAL (GV)	Right Horizontal Stabilizer - Front Spar to Rear Spar
55-856-04	55-856-04	55-856-04-01		ZONAL (GV)	Right Horizontal Stabilizer - Front Spar to Rear Spar
55-858-02	55-858-02	55-858-02-01	W-55-850-02-01 W-55-866-02-01	ZONAL (GV)	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-860-02	55-860-02	55-860-02-01		ZONAL (GV)	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-861-00	55-861-00	55-861-00-01		ZONAL (GV)	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-862-02	55-862-02	55-862-02-01		ZONAL (GV)	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-863-00	55-863-00	55-863-00-01		ZONAL (GV)	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-864-02	55-864-02	55-864-02-01	W-55-850-02-01	ZONAL (GV)	Right Elevator
55-866-02	55-866-02	55-866-02-01	W-55-850-02-01 W-55-858-02-01	ZONAL (GV)	Right Horizontal Stabilizer Tip
56-010-00	56-010-00	56-010-00-01		OPERATIONAL	Flight Deck #2 Windows MICROSWITCH
56-020-00	56-020-00	56-020-00-01		LUBRICATE	Flight Deck Number 2 Windows Guide Bearings
56-030-00	56-030-00	56-030-00-01		OPERATIONAL	Flight Deck Number 2 Windows Open/Close Function
57-501-00	57-501-00	57-501-00-01		DETAILED	Wing Center Section
57-502-01	57-502-01	57-502-01-01		GENERAL VISUAL	Slat Number 7
57-503-01	57-503-01	57-503-01-01		GENERAL VISUAL	Slat Number 7
57-504-01	57-504-01	57-504-01-01		GENERAL VISUAL	Slats Number 1 Through 6



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-505-01	57-505-01	57-505-01-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17
57-506-01	57-506-01	57-506-01-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17
57-507-01	57-507-01	57-507-01-01		GENERAL VISUAL	Wing Inspar Area (Fuel Tanks) - Rib 17 to Wing Tip
57-508-01	57-508-01	57-508-01-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Rib 17 to Rib 34
57-509-01	57-509-01	57-509-01-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Rib 34 to Wing Tip
57-510-01	57-510-01	57-510-01-01		SPECIAL DETAILED	Main Tank - Rib 17 to Rib 32 - Left Wing
57-511-01	57-511-01	57-511-01-01		DETAILED	Main Tank - Rib 17 to Rib 32 - Left Wing
57-512-00	57-512-00	57-512-00-01		DETAILED	Slats Number 1 Through 6 Cove Skin
57-514-00	57-514-00	57-514-00-01		SPECIAL DETAILED	Wing Inboard and Outboard Main Flap Attach Bolts
57-515-01	57-515-01	57-515-01-01		DETAILED	Left Wing Inboard Main Flap
57-516-01	57-516-01	57-516-01-01		GENERAL VISUAL	Left Wing Inboard Main Flap
57-517-01	57-517-01	57-517-01-01		DETAILED	Left Wing Inboard Main Flap
57-518-01	57-518-01	57-518-01-01		GENERAL VISUAL	Left Wing Inboard Aft Flap
57-519-01	57-519-01	57-519-01-01		GENERAL VISUAL	Left Wing Flaperon
57-520-01	57-520-01	57-520-01-01		DETAILED	Left Wing Flaperon
57-521-00	57-521-00	57-521-00-01 57-521-00-02		DETAILED	Wing Inboard Trailing Edge Flap Torque Tube
57-523-01	57-523-01	57-523-01-01		GENERAL VISUAL	Left Wing Outboard Flap
57-524-01	57-524-01	57-524-01-01		DETAILED	Left Wing Outboard Flap



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>TASK CARD NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
57-530-01	57-530-01	57-530-01-01		SPECIAL DETAILED	Left Wing Flap Support Fairing Number 4
57-531-01	57-531-01	57-531-01-01		GENERAL VISUAL	Inboard Flap Center Track Fairing - Left Wing
57-532-01	57-532-01	57-532-01-01		SPECIAL DETAILED	Left Wing Flap Support Fairing Number 3
57-533-01	57-533-01	57-533-01-01		GENERAL VISUAL	Outboard Flaperon Support Fairing - Left Wing
57-535-02	57-535-02	57-535-02-01		GENERAL VISUAL	Slat Number 8
57-536-02	57-536-02	57-536-02-01		GENERAL VISUAL	Slat Number 8
57-538-02	57-538-02	57-538-02-01		GENERAL VISUAL	Slats Number 9 Through 14
57-539-00	57-539-00	57-539-00-01		DETAILED	Slats Number 9 Through 14 Cove Skin
57-540-02	57-540-02	57-540-02-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17
57-541-02	57-541-02	57-541-02-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17
57-542-02	57-542-02	57-542-02-01		GENERAL VISUAL	Wing Inspar Area (Fuel Tanks) - Rib 17 to Wing Tip
57-543-02	57-543-02	57-543-02-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Rib 17 to Rib 34
57-544-02	57-544-02	57-544-02-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Rib 34 to Wing Tip
57-545-02	57-545-02	57-545-02-01		SPECIAL DETAILED	Main Tank - Rib17 to Rib 32 - Right Wing
57-546-02	57-546-02	57-546-02-01		DETAILED	Main Tank - Rib 17 to Rib 32 - Right Wing
57-550-02	57-550-02	57-550-02-01		DETAILED	Right Wing Inboard Main Flap
57-551-02	57-551-02	57-551-02-01		GENERAL VISUAL	Right Wing Inboard Main Flap
57-552-02	57-552-02	57-552-02-01		DETAILED	Right Wing Inboard Main Flap



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-553-02	57-553-02	57-553-02-01		GENERAL VISUAL	Right Wing Inboard Aft Flap
57-554-02	57-554-02	57-554-02-01		GENERAL VISUAL	Right Wing Flaperon
57-555-02	57-555-02	57-555-02-01		DETAILED	Right Wing Flaperon
57-556-02	57-556-02	57-556-02-01		GENERAL VISUAL	Right Wing Outboard Flap
57-557-02	57-557-02	57-557-02-01		DETAILED	Right Wing Outboard Flap
57-560-02	57-560-02	57-560-02-01		SPECIAL DETAILED	Right Wing Flap Support Fairing Number 5
57-561-02	57-561-02	57-561-02-01		GENERAL VISUAL	Inboard Flap Center Track Fairing - Right Wing
57-562-02	57-562-02	57-562-02-01		SPECIAL DETAILED	Right Wing Flap Support Fairing Number 6
57-563-02	57-563-02	57-563-02-01		GENERAL VISUAL	Outboard Flaperon Support Fairing - Right Wing
57-606-00	57-606-00	57-606-00-01 57-606-00-02 57-606-00-03		GENERAL VISUAL	Lower Fuselage - Subzone 130
57-607-01	57-607-01	57-607-01-01		GENERAL VISUAL	Left Wing
57-608-01	57-608-01	57-608-01-01		GENERAL VISUAL	Left Wing
57-620-02	57-620-02	57-620-02-01		GENERAL VISUAL	Right Wing
57-621-02	57-621-02	57-621-02-01		GENERAL VISUAL	Right Wing
57-630-00	57-630-00	57-630-00-01		GENERAL VISUAL	Area Above Wing Center Section



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-701-02		57-701-02-01		SPECIAL DETAILED	SOB Splice, Lower Surface, T-Chord
57-701-03		57-701-03-01		SPECIAL DETAILED	SOB Splice, Lower Surface, T-Chord
57-702-02		57-702-02-01		SPECIAL DETAILED	SOB Splice, Lower Surface, T-Chord
57-702-03		57-702-03-01		SPECIAL DETAILED	SOB Splice, Lower Surface, T-Chord
57-703-02		57-703-02-01		SPECIAL DETAILED	SOB Splice, Lower Surface, T-Chord
57-703-03		57-703-03-01		SPECIAL DETAILED	SOB Splice, Lower Surface, T-Chord
57-704-01		57-704-01-01		SPECIAL DETAILED	SOB Splice, Front Spar Chord
57-704-02		57-704-02-01		SPECIAL DETAILED	SOB Splice, Front Spar Chord
57-704-03		57-704-03-01		SPECIAL DETAILED	SOB Splice, Front Spar Chord
57-706-02		57-706-02-01		SPECIAL DETAILED	SOB Splice, Rear Spar Chord
57-706-03		57-706-03-01		SPECIAL DETAILED	SOB Splice, Rear Spar Chord
57-706-04		57-706-04-01		SPECIAL DETAILED	SOB Splice, Rear Spar Chord
57-708-02		57-708-02-01		SPECIAL DETAILED	Body Chord Inspection at Stringer 36 to 41
57-708-03		57-708-03-01		SPECIAL DETAILED	Body Chord Inspection at Splice Plate
57-709-02		57-709-02-01		GENERAL VISUAL	Wing Center Section, Lower Panel, Typical and Splice Stringer





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-709-03		57-709-03-01		DETAILED	Wing Center Section (WCS), Lower Panel, Typical Stringer
57-710-02		57-710-02-01		GENERAL VISUAL	Wing Center Section (WCS), Lower Panel, Splice Stringer
57-711-02		57-711-02-01		DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-03		57-711-03-01		DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-04		57-711-04-01		SPECIAL DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-05		57-711-05-01		SPECIAL DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-06		57-711-06-01		DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-07		57-711-07-01		SPECIAL DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-08		57-711-08-01		SPECIAL DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-09		57-711-09-01		DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-10		57-711-10-01		SPECIAL DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-11		57-711-11-01		SPECIAL DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-12		57-711-12-01		SPECIAL DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-712-02		57-712-02-01		DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Skin
57-712-03		57-712-03-01		DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Skin
57-712-04		57-712-04-01		DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Skin
57-712-05		57-712-05-01		GENERAL VISUAL	Wing Center Section, Lower Rear Spar Chord, Lower Skin
57-712-06		57-712-06-01		SPECIAL DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Skin



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-713-02		57-713-02-01		DETAILED	Wing Center Section, Lower Panel Keel Beam Chord, Lower Skin
57-713-03		57-713-03-01		SPECIAL DETAILED	Wing Center Section, Lower Panel Keel Beam Chord, Lower Skin
57-713-04		57-713-04-01		SPECIAL DETAILED	Wing Center Section, Lower Panel Keel Beam Chord, Lower Skin
57-713-05		57-713-05-01		SPECIAL DETAILED	Wing Center Section, Lower Panel Keel Beam Chord, Lower Skin
57-714-02		57-714-02-01		SPECIAL DETAILED	Wing Center Section, Lower Panel Keel Beam Chord, Lower Chord
57-714-03		57-714-03-01		DETAILED	Wing Center Section, Lower Panel Keel Beam Chord, Lower Chord
57-716-02		57-716-02-01		SPECIAL DETAILED	Wing Outboard, Typical Rear Spar Attachment, Lower Chord
57-716-03		57-716-03-01		SPECIAL DETAILED	Wing Outboard, Typical Rear Spar Attachment, Lower Chord
57-716-04		57-716-04-01		SPECIAL DETAILED	Wing Outboard, Typical Rear Spar Attachment, Lower Chord
57-716-05		57-716-05-01		SPECIAL DETAILED	Wing Outboard, Typical Rear Spar Attachment, Lower Chord
57-719-02		57-719-02-01		SPECIAL DETAILED	Wing Outboard, Typical Splice Stringers
57-719-03		57-719-03-01		DETAILED	Wing Outboard, Typical Splice Stringers
57-719-04		57-719-04-01		DETAILED	Wing Outboard, Typical Splice Stringers
57-721-01		57-721-01-01		SPECIAL DETAILED	Wing Outboard, Typical Splice Stringer
57-721-02		57-721-02-01		SPECIAL DETAILED	Wing Outboard, Typical Splice Stringer
57-721-03		57-721-03-01		SPECIAL DETAILED	Wing Outboard, Typical Splice Stringer



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-722-01		57-722-01-01		SPECIAL DETAILED	Wing Outboard, Lower Panel Rear Spar Chord, Lower Chord
57-722-02		57-722-02-01		SPECIAL DETAILED	Wing Outboard, Lower Panel Rear Spar Chord, Lower Chord
57-722-03		57-722-03-01		SPECIAL DETAILED	Wing Outboard, Lower Panel Rear Spar Chord, Lower Chord
57-722-04		57-722-04-01		SPECIAL DETAILED	Wing Outboard, Lower Panel Rear Spar Chord, Lower Chord
57-722-05		57-722-05-01		SPECIAL DETAILED	Wing Outboard, Lower Panel Rear Spar Chord, Lower Chord
57-722-06		57-722-06-01		SPECIAL DETAILED	Wing Outboard, Lower Panel Rear Spar Chord, Lower Chord
57-722-07		57-722-07-01		SPECIAL DETAILED	Wing Outboard, Lower Panel Rear Spar Chord, Lower Chord
57-724-02		57-724-02-01		SPECIAL DETAILED	Wing Outboard, Lower Panel Front Spar Chord, Lower Chord
57-728-02		57-728-02-01		SPECIAL DETAILED	Wing Outboard, MLG Beam Support Fitting, Mid Rib Lower Skin
57-729-01		57-729-01-01		SPECIAL DETAILED	Wing Outboard, Typical Stringer Attachment at Nacelle Fitting
57-729-02		57-729-02-01		DETAILED	Wing Outboard, Typical Stringer Attachment at Nacelle Fitting
57-729-03		57-729-03-01		SPECIAL DETAILED	Wing Outboard, Typical Stringer Attachment at Nacelle Fitting
57-729-04		57-729-04-01		DETAILED	Wing Outboard, Typical Stringer Attachment at Nacelle Fitting
57-729-05		57-729-05-01		SPECIAL DETAILED	Wing Outboard, Typical Stringer Attachment at Nacelle Fitting
57-729-06		57-729-06-01		SPECIAL DETAILED	Wing Outboard, Typical Stringer Attachment at Nacelle Fitting
57-730-01		57-730-01-01		DETAILED	Wing Outboard, Stringer Attachment at Nacelle Fitting



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-734-01		57-734-01-01		SPECIAL DETAILED	Wing Outboard, Upper Panel, MLG Beam Support Fitting Upper Skin
57-735-01		57-735-01-01		DETAILED	Wing Outboard, Upper Panel, Front Spar Upper Chord
57-735-03		57-735-03-01		DETAILED	Wing Outboard, Upper Panel, Front Spar Upper Chord
57-735-04		57-735-04-01		DETAILED	Wing Outboard, Upper Panel, Front Spar Upper Chord
57-737-01		57-737-01-01		SPECIAL DETAILED	Wing Outboard Upper Panel, Rear Spar Upper Chord
57-737-03		57-737-03-01		SPECIAL DETAILED	Wing Outboard Upper Panel, Rear Spar Upper Chord
57-737-04		57-737-04-01		SPECIAL DETAILED	Wing Outboard Upper Panel, Rear Spar Upper Chord
57-737-05		57-737-05-01		SPECIAL DETAILED	Wing Outboard Upper Panel, Rear Spar Upper Chord
57-737-06		57-737-06-01		SPECIAL DETAILED	Wing Outboard Upper Panel, Rear Spar Upper Chord
57-739-01		57-739-01-01		DETAILED	Wing Outboard, Upper Panel, Rear Spar Upper Chord
57-739-03		57-739-03-01		DETAILED	Wing Outboard, Upper Panel, Rear Spar Upper Chord
57-739-04		57-739-04-01		DETAILED	Wing Outboard, Upper Panel, Rear Spar Upper Chord
57-740-01		57-740-01-01		DETAILED	Wing Outboard, Upper Skin Tab
57-743-01		57-743-01-01		SPECIAL DETAILED	Wing Outboard, Rear Spar Web at Forward Trunnion Fitting
57-743-03		57-743-03-01		SPECIAL DETAILED	Wing Outboard, Rear Spar Web at Forward Trunnion Fitting
57-751-01		57-751-01-01		SPECIAL DETAILED	Inboard Main Flap Outboard Closeout Rib
57-752-01		57-752-01-01		SPECIAL DETAILED	Inboard Main Flap Outboard Ribs



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-753-01		57-753-01-01		SPECIAL DETAILED	Inboard Main Flap Torque Tube
57-754-01		57-754-01-01		SPECIAL DETAILED	Inboard Main Flap Inboard Closeout Rib
57-755-01		57-755-01-01		SPECIAL DETAILED	Inboard Main Flap Inboard Closeout Rib
57-755-03		57-755-03-01		SPECIAL DETAILED	Inboard Main Flap Inboard Closeout Rib
57-755-04		57-755-04-01		DETAILED	Inboard Main Flap Inboard Closeout Rib
57-756-01		57-756-01-01		SPECIAL DETAILED	Inboard Main Flap Inboard Closeout Rib Fitting
57-757-01		57-757-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Underwing Fitting
57-758-01		57-758-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Underwing Fitting
57-759-01		57-759-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Underwing Fitting
57-760-01		57-760-01-01		DETAILED	No. 3 and No. 6 Inboard Flap Support Forward Tension Link
57-760-03		57-760-03-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Forward Tension Link
57-761-01		57-761-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Forward Tension Link
57-761-03		57-761-03-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Forward Tension Link
57-761-04		57-761-04-01		DETAILED	No. 3 and No. 6 Inboard Flap Support Forward Tension Link
57-762-01		57-762-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Forward Tension Link
57-763-01		57-763-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Aft Tension Beam



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-764-01		57-764-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Aft Tension Beam
57-764-03		57-764-03-01		DETAILED	No. 3 and No. 6 Inboard Flap Support Aft Tension Beam
57-765-01		57-765-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Aft Tension Beam
57-765-03		57-765-03-01		GENERAL VISUAL	No. 3 and No. 6 Inboard Flap Support Aft Tension Beam
57-765-04		57-765-04-01		DETAILED	No. 3 and No. 6 Inboard Flap Support Aft Tension Beam
57-766-01		57-766-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Pivot Link
57-767-01		57-767-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Pivot Link
57-768-01		57-768-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Drive Arm Assembly
57-768-03		57-768-03-01		GENERAL VISUAL	No. 3 and No. 6 Inboard Flap Support Drive Arm Assembly
57-769-01		57-769-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-769-03		57-769-03-01		DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-771-01		57-771-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-771-03		57-771-03-01		DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-772-01		57-772-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-773-01		57-773-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-774-01		57-774-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-775-01		57-775-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-776-01		57-776-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-777-01		57-777-01-01		SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-778-01		57-778-01-01		SPECIAL DETAILED	No. 4 and No. 5 Inboard Flap Support Drive Arm
57-779-01		57-779-01-01		SPECIAL DETAILED	No. 4 and No. 5 Inboard Flap Support Drive Arm
57-780-01		57-780-01-01		SPECIAL DETAILED	No. 4 and No. 5 Inboard Flap Actuator Support Fitting
57-781-01		57-781-01-01		SPECIAL DETAILED	No. 4 and No. 5 Inboard Flap Actuator Support Fitting
57-782-01		57-782-01-01		SPECIAL DETAILED	No. 4 and No. 5 Inboard Flap Support Carrier Beam
57-783-01		57-783-01-01		SPECIAL DETAILED	No. 4 and No. 5 Inboard Flap Support Pillow Block
57-784-01		57-784-01-01		SPECIAL DETAILED	No. 4 and No. 5 Inboard Flap Support Pillow Block
57-785-01		57-785-01-01		SPECIAL DETAILED	No. 1, No. 2, No. 7 and No. 8 Outboard Flap Supports
57-786-01		57-786-01-01		SPECIAL DETAILED	MLG Forward Trunnion Sideload Fitting
57-787-01		57-787-01-01		DETAILED	MLG Forward Trunnion Sideload Straps
57-788-01		57-788-01-01		DETAILED	MLG Forward Trunnion Outboard Support Fitting
57-788-02		57-788-02-01		DETAILED	MLG Forward Trunnion Outboard Support Fitting
57-788-03		57-788-03-01		DETAILED	MLG Forward Trunnion Outboard Support Fitting



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-788-04		57-788-04-01		SPECIAL DETAILED	MLG Forward Trunnion Outboard Support Fitting
57-788-05		57-788-05-01		SPECIAL DETAILED	MLG Forward Trunnion Outboard Support Fitting
57-790-01		57-790-01-01		DETAILED	MLG Beam Outboard Support Fitting, Lower Skin Flange
57-790-02		57-790-02-01		GENERAL VISUAL	MLG Beam Outboard Support Fitting, Lower Skin Flange
57-790-03		57-790-03-01		SPECIAL DETAILED	MLG Beam Outboard Support Fitting, Lower Skin Flange
57-793-01		57-793-01-01		SPECIAL DETAILED	MLG Drag Brace Support Fitting
57-793-02		57-793-02-01		SPECIAL DETAILED	MLG Drag Brace Support Fitting
57-794-01		57-794-01-01		SPECIAL DETAILED	MLG Drag Brace Support Fitting, Base of Fitting
57-795-01		57-795-01-01		DETAILED	MLG Drag Brace Internal Backup Fitting
57-796-01		57-796-01-01		DETAILED	Retraction Actuator Support Fitting Attach Flange
57-800-00		57-800-00-01		ZONAL (GV)	Wing Center Section
57-802-00		57-802-00-01		ZONAL (GV)	Wing Center Section
57-804-01		57-804-01-01		ZONAL (GV)	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing
57-806-01		57-806-01-01		ZONAL (GV)	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing
57-808-01		57-808-01-01		ZONAL (GV)	Slat No. 7
57-810-01		57-810-01-01		ZONAL (GV)	Krueger Seal Flap/Nacelle Gap Cover Area - Left Wing
57-812-01		57-812-01-01		ZONAL (GV)	Krueger Seal Flap/Nacelle Gap Cover Area - Left Wing
57-814-01		57-814-01-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
57-816-01		57-816-01-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
57-817-01		57-817-01-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-818-01	57-818-01	57-818-01-01		ZONAL (GV)	Left Wing Outboard Leading Edge Slats Number 1 through 6
57-820-01	57-820-01	57-820-01-01		ZONAL (GV)	Slat Number 6
57-822-01	57-822-01	57-822-01-01		ZONAL (GV)	Slat Number 5
57-824-01	57-824-01	57-824-01-01		ZONAL (GV)	Slat Number 4
57-826-01	57-826-01	57-826-01-01		ZONAL (GV)	Slat Number 3
57-828-01	57-828-01	57-828-01-01		ZONAL (GV)	Slat Number 2
57-830-01	57-830-01	57-830-01-01		ZONAL (GV)	Slat Number 1
57-831-01	57-831-01	57-831-01-01		ZONAL (GV)	Slat Number 1
57-832-01	57-832-01	57-832-01-01 57-832-01-02		ZONAL (GV)	Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17 - Left Wing
57-834-01	57-834-01	57-834-01-01		ZONAL (GV)	Center Fuel Tank - Rib 1 to Rib 8 - Left Wing
57-836-01	57-836-01	57-836-01-01		ZONAL (GV)	Left Wing Dry Bay
57-838-01	57-838-01	57-838-01-01		ZONAL (GV)	Main Tank - Rib 8 to Rib 17 - Left Wing
57-840-01	57-840-01	57-840-01-01 57-840-01-02		ZONAL (GV)	Wing Inspar Area (Fuel Tanks) - Rib 17 to Wing Tip - Left Wing
57-842-01	57-842-01	57-842-01-01		ZONAL (GV)	Main Tank - Rib 17 to Rib 32 - Left Wing
57-844-01	57-844-01	57-844-01-01		ZONAL (GV)	Left Wing Surge Tank - Rib 32 to Rib 34
57-845-01	57-845-01	57-845-01-01		ZONAL (GV)	Main Tank Rib 32 to Rib 34 - Left Wing
57-846-01	57-846-01	57-846-01-01		ZONAL (GV)	Inspar Area - Rib 34 to Wing Tip - Left Wing
57-847-01	57-847-01	57-847-01-01		ZONAL (GV)	Main Tank, Surge Tank, and Inspar Area - Left Wing
57-848-01	57-848-01	57-848-01-01		ZONAL (GV)	Left Wing Tip
57-850-01	57-850-01	57-850-01-01		ZONAL (GV)	Left Wing Tip
57-851-01	57-851-01	57-851-01-01		ZONAL (GV)	Left Wing Tip
57-852-01	57-852-01	57-852-01-01		ZONAL (GV)	Left Wing Fixed T.E. - Aft of Rear Spar, Inbd of Outbd Support Fairing



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-854-01	57-854-01	57-854-01-01		ZONAL (GV)	Rear Spar to Landing Gear Support Beam - Left Wing
57-856-01	57-856-01	57-856-01-01		ZONAL (GV)	Landing Gear Support Beam and Rear Spar to Trailing Edge - Left Wing
57-858-01	57-858-01	57-858-01-01		ZONAL (GV)	Inboard Spoilers Numbers 6 and 7
57-860-01	57-860-01	57-860-01-01		ZONAL (GV)	Inboard Trailing Edge Flaps - Left Wing
57-862-01	57-862-01	57-862-01-01		ZONAL (GV)	Left Wing Flaperon
57-864-01	57-864-01	57-864-01-01		ZONAL (GV)	Rear Spar to Trailing Edge - Outboard of Flaperon - Left Wing
57-866-01	57-866-01	57-866-01-01		ZONAL (GV)	Rear Spar to Trailing Edge - Outboard of Flaperon - Left Wing
57-868-01	57-868-01	57-868-01-01		ZONAL (GV)	Outboard Spoilers Numbers 1 through 5
57-870-01	57-870-01	57-870-01-01		ZONAL (GV)	Left Wing Outboard Flap
57-872-01	57-872-01	57-872-01-01		ZONAL (GV)	Left Wing Aileron
57-874-01	57-874-01	57-874-01-01		ZONAL (GV)	Flap Support Fairing No. 4
57-876-01	57-876-01	57-876-01-01		ZONAL (GV)	Flap Support Fairing No. 4
57-878-01	57-878-01	57-878-01-01		ZONAL (GV)	Inboard Flap Center Track Fairing - Left Wing
57-880-01	57-880-01	57-880-01-01		ZONAL (GV)	Flap Support Fairing No. 3 and Inboard Flaperon Support Fairing
57-882-01	57-882-01	57-882-01-01		ZONAL (GV)	Flap Support Fairing No. 3 and Inboard Flaperon Support Fairing
57-884-01	57-884-01	57-884-01-01		ZONAL (GV)	Outboard Flaperon Support Fairing - Left Wing
57-886-01	57-886-01	57-886-01-01		ZONAL (GV)	Flap Support Fairing No. 2
57-888-01	57-888-01	57-888-01-01		ZONAL (GV)	Flap Support Fairing No. 2
57-890-01	57-890-01	57-890-01-01		ZONAL (GV)	Flap Support Fairing No. 1
57-892-01	57-892-01	57-892-01-01		ZONAL (GV)	Flap Support Fairing No. 1
57-894-01	57-894-01	57-894-01-01		ZONAL (GV)	Outboard Auxiliary Support Fairing - Left Wing
57-896-02	57-896-02	57-896-02-01		ZONAL (GV)	Leading Edge to Front Spar - Inboard of Nacelle Strut - Right Wing
57-898-02	57-898-02	57-898-02-01		ZONAL (GV)	Leading Edge to Front Spar - Inboard of Nacelle Strut - Right Wing
57-900-02	57-900-02	57-900-02-01		ZONAL (GV)	Slat No. 8



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-902-02	57-902-02	57-902-02-01		ZONAL (GV)	Krueger Seal Flap/Nacelle Gap Cover Area - Right Wing
57-904-02	57-904-02	57-904-02-01		ZONAL (GV)	Krueger Seal Flap/Nacelle Gap Cover Area - Right Wing
57-906-02	57-906-02	57-906-02-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Right Wing
57-908-02	57-908-02	57-908-02-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Right Wing
57-909-02	57-909-02	57-909-02-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Right Wing
57-910-02	57-910-02	57-910-02-01		ZONAL (GV)	Outboard Leading Edge Slats Number 9 through 14
57-912-02	57-912-02	57-912-02-01		ZONAL (GV)	Slat Number 9
57-914-02	57-914-02	57-914-02-01		ZONAL (GV)	Slat Number 10
57-916-02	57-916-02	57-916-02-01		ZONAL (GV)	Slat Number 11
57-918-02	57-918-02	57-918-02-01		ZONAL (GV)	Slat Number 12
57-920-02	57-920-02	57-920-02-01		ZONAL (GV)	Slat Number 13
57-922-02	57-922-02	57-922-02-01		ZONAL (GV)	Slat Number 14
57-923-02	57-923-02	57-923-02-01		ZONAL (GV)	Slat Number 14
57-924-02	57-924-02	57-924-02-01 57-924-02-02		ZONAL (GV)	Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17 - Right Wing
57-926-02	57-926-02	57-926-02-01		ZONAL (GV)	Center Fuel Tank - Rib 1 to Rib 8 - Right Wing
57-928-02	57-928-02	57-928-02-01		ZONAL (GV)	Right Wing Dry Bay
57-930-02	57-930-02	57-930-02-01		ZONAL (GV)	Main Tank - Rib 8 to Rib 17 - Right Wing
57-932-02	57-932-02	57-932-02-01 57-932-02-02		ZONAL (GV)	Wing Inspar Area (Fuel Tanks) - Rib 17 to Wing Tip - Right Wing
57-934-02	57-934-02	57-934-02-01		ZONAL (GV)	Main Tank - Rib 17 to Rib 32 - Right Wing
57-936-02	57-936-02	57-936-02-01		ZONAL (GV)	Right Wing Surge Tank - Rib 32 to Rib 34
57-937-02	57-937-02	57-937-02-01		ZONAL (GV)	Main Tank - Rib 32 to Rib 34 - Right Wing
57-938-02	57-938-02	57-938-02-01		ZONAL (GV)	Inspar Area - Rib 34 to Wing Tip - Right Wing



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-939-02	57-939-02	57-939-02-01		ZONAL (GV)	Main Tank, Surge Tank, and Inspar Area - Right Wing
57-940-02	57-940-02	57-940-02-01		ZONAL (GV)	Right Wing Tip
57-942-02	57-942-02	57-942-02-01		ZONAL (GV)	Right Wing Tip
57-943-02	57-943-02	57-943-02-01		ZONAL (GV)	Right Wing Tip
57-944-02	57-944-02	57-944-02-01		ZONAL (GV)	Right Wing Fixed T.E. - Aft of Rear Spar, Inbd of Outbd Support Fairing
57-946-02	57-946-02	57-946-02-01		ZONAL (GV)	Rear Spar to Landing Gear Support Beam - Right Wing
57-948-02	57-948-02	57-948-02-01		ZONAL (GV)	Landing Gear Support Beam and Rear Spar to Trailing Edge - Right Wing
57-950-02	57-950-02	57-950-02-01		ZONAL (GV)	Inboard Spoilers Numbers 8 and 9
57-952-02	57-952-02	57-952-02-01		ZONAL (GV)	Inboard Trailing Edge Flaps - Right Wing
57-954-02	57-954-02	57-954-02-01		ZONAL (GV)	Right Wing Flaperon
57-956-02	57-956-02	57-956-02-01		ZONAL (GV)	Rear Spar to Trailing Edge - Outboard of Flaperon - Right Wing
57-958-02	57-958-02	57-958-02-01		ZONAL (GV)	Rear Spar to Trailing Edge - Outboard of Flaperon - Right Wing
57-960-02	57-960-02	57-960-02-01		ZONAL (GV)	Outboard Spoilers Numbers 10 through 14
57-962-02	57-962-02	57-962-02-01		ZONAL (GV)	Right Wing Outboard Flap
57-964-02	57-964-02	57-964-02-01		ZONAL (GV)	Right Wing Aileron
57-966-02	57-966-02	57-966-02-01		ZONAL (GV)	Flap Support Fairing No. 5
57-968-02	57-968-02	57-968-02-01		ZONAL (GV)	Flap Support Fairing No. 5
57-970-02	57-970-02	57-970-02-01		ZONAL (GV)	Inboard Flap Center Track Fairing - Right Wing
57-972-02	57-972-02	57-972-02-01		ZONAL (GV)	Flap Support Fairing No. 6 and Inbd Flaperon Support Fairing
57-974-02	57-974-02	57-974-02-01		ZONAL (GV)	Flap Support Fairing No. 6 and Inbd Flaperon Support Fairing
57-976-02	57-976-02	57-976-02-01		ZONAL (GV)	Outboard Flaperon Support Fairing - Right Wing
57-978-02	57-978-02	57-978-02-01		ZONAL (GV)	Flap Support Fairing No. 7
57-980-02	57-980-02	57-980-02-01		ZONAL (GV)	Flap Support Fairing No. 7
57-982-02	57-982-02	57-982-02-01		ZONAL (GV)	Flap Support Fairing No. 8



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-984-02	57-984-02	57-984-02-01		ZONAL (GV)	Flap Support Fairing No. 8
57-986-02	57-986-02	57-986-02-01		ZONAL (GV)	Outboard Auxiliary Support Fairing - Right Wing
71-205-01	71-205-01	71-205-01-01		INSPECTION - DETAILED	Inspection of the Forward Mount
71-205-02	71-205-02	71-205-02-01		INSPECTION - DETAILED	Inspection of the Forward Mount
71-210-01	71-210-01	71-210-01-01		INSPECTION - DETAILED	Inspection of the Aft Lower Mount
71-210-02	71-210-02	71-210-02-01		INSPECTION - DETAILED	Inspection of the Aft Lower Mount
71-350-01	71-350-01	71-350-01-01		INSPECTION - DETAILED	Inspection of the Forward Mount
71-350-02	71-350-02	71-350-02-01		INSPECTION - DETAILED	Inspection of the Forward Mount
71-355-01	71-355-01	71-355-01-01		INSPECTION - DETAILED	Inspection of the AFT Engine Mount
71-355-02	71-355-02	71-355-02-01		INSPECTION - DETAILED	Inspection of the AFT Engine Mount
71-800-01	71-800-01	71-800-01-01		ZONAL (GV)	Left Powerplant
71-802-01	71-802-01	71-802-01-01		ZONAL (GV)	Left Engine
71-804-01	71-804-01	71-804-01-01		ZONAL (GV)	Inlet Cowl - Left Engine
71-806-01	71-806-01	71-806-01-01		ZONAL (GV)	Left Engine Fan Cowls
71-808-01	71-808-01	71-808-01-01		ZONAL (GV)	Left Engine Thrust Reversers
71-810-01	71-810-01	71-810-01-01		ZONAL (GV)	Left Engine Thrust Reversers
71-812-02	71-812-02	71-812-02-01		ZONAL (GV)	Right Powerplant
71-814-02	71-814-02	71-814-02-01		ZONAL (GV)	Right Engine
71-816-02	71-816-02	71-816-02-01		ZONAL (GV)	Inlet Cowl - Right Engine



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
71-818-02	71-818-02	71-818-02-01		ZONAL (GV)	Right Engine Fan Cowl
71-820-02	71-820-02	71-820-02-01		ZONAL (GV)	Right Engine Thrust Reversers
71-822-02	71-822-02	71-822-02-01		ZONAL (GV)	Right Engine Thrust Reversers
71-830-01	71-830-01	71-830-01-01		ZONAL (GV)	Left Powerplant - From the Ground
71-832-01	71-832-01	71-832-01-01		ZONAL (GV)	Left Powerplant
71-834-01	71-834-01	71-834-01-01		ZONAL (GV)	Left Engine
71-836-01	71-836-01	71-836-01-01		ZONAL (GV)	Inlet Cowl - Left Engine
71-838-01	71-838-01	71-838-01-01		ZONAL (GV)	Left Engine Fan Cowl
71-840-01	71-840-01	71-840-01-01		ZONAL (GV)	Left Engine Thrust Reversers
71-842-01	71-842-01	71-842-01-01		ZONAL (GV)	Left Engine Thrust Reversers
71-844-02	71-844-02	71-844-02-01		ZONAL (GV)	Right Powerplant - From the Ground
71-846-02	71-846-02	71-846-02-01		ZONAL (GV)	Right Powerplant
71-848-02	71-848-02	71-848-02-01		ZONAL (GV)	Right Engine
71-850-02	71-850-02	71-850-02-01		ZONAL (GV)	Inlet Cowl - Right Engine
71-852-02	71-852-02	71-852-02-01		ZONAL (GV)	Right Engine Fan Cowl
71-854-02	71-854-02	71-854-02-01		ZONAL (GV)	Right Engine Thrust Reversers
71-856-02	71-856-02	71-856-02-01		ZONAL (GV)	Right Engine Thrust Reversers
71-860-01	71-860-01	71-860-01-01		ZONAL (GV)	Left Powerplant - From the Ground
71-862-01	71-862-01	71-862-01-01		ZONAL (GV)	Left Powerplant
71-864-01	71-864-01	71-864-01-01		ZONAL (GV)	Left Engine
71-866-01	71-866-01	71-866-01-01		ZONAL (GV)	Inlet Cowl - Left Engine
71-868-01	71-868-01	71-868-01-01		ZONAL (GV)	Left Engine Fan Cowl
71-870-01	71-870-01	71-870-01-01		ZONAL (GV)	Left Engine Thrust Reversers
71-872-01	71-872-01	71-872-01-01		ZONAL (GV)	Left Engine Thrust Reversers



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
71-874-02	71-874-02	71-874-02-01		ZONAL (GV)	Right Powerplant - From the Ground
71-876-02	71-876-02	71-876-02-01		ZONAL (GV)	Right Powerplant
71-878-02	71-878-02	71-878-02-01		ZONAL (GV)	Right Engine
71-880-02	71-880-02	71-880-02-01		ZONAL (GV)	Inlet Cowl - Right Engine
71-882-02	71-882-02	71-882-02-01		ZONAL (GV)	Right Engine Fan Cowl
71-884-02	71-884-02	71-884-02-01		ZONAL (GV)	Right Engine Thrust Reversers
71-886-02	71-886-02	71-886-02-01		ZONAL (GV)	Right Engine Thrust Reversers
72-001-00	72-001-00	72-001-00-01 72-001-00-02		CLEAN	Engine Gas Path
72-005-01	72-005-01	72-005-01-01 72-005-01-03		INSPECTION - DETAILED	Fan Blade Inspection - Left
72-005-02	72-005-02	72-005-02-02 72-005-02-04		INSPECTION - DETAILED	Fan Blade Inspection - Right
72-010-00	72-010-00	72-010-00-01 72-010-00-02		REPLACE	Discard Fan Disk and Booster Spool
72-015-00	72-015-00	72-015-00-01 72-015-00-02		REPLACE	Discard Fan Shaft
72-020-01	72-020-01	72-020-01-01 72-020-01-02		INSPECTION - DETAILED	Check for Bearing and Gear Degradation - Left
72-020-02	72-020-02	72-020-02-01 72-020-02-02		INSPECTION - DETAILED	Check for Bearing and Gear Degradation - Right
72-021-01	72-021-01	72-021-01-01		INSPECTION - DETAILED	Check for Bearing and Gear Degradation - Left
72-021-02	72-021-02	72-021-02-01		INSPECTION - DETAILED	Check for Bearing and Gear Degradation - Right
72-025-01	72-025-01	72-025-01-01 72-025-01-03		INSPECTION - DETAILED	Inspection of the forward Mount - Left



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-025-02	72-025-02	72-025-02-02 72-025-02-04		INSPECTION - DETAILED	Inspection of the forward Mount - Right
72-030-01	72-030-01	72-030-01-01 72-030-01-03		INSPECTION - GEN VISUAL	General Visual Inspection of the Fan Area - Left
72-030-02	72-030-02	72-030-02-02 72-030-02-04		INSPECTION - GEN VISUAL	General Visual Inspection of the Fan Area - Right
72-035-00	72-035-00	72-035-00-01 72-035-00-02		REPLACE	Discard HPC Stage 1 Disk/Shaft
72-040-00	72-040-00	72-040-00-01 72-040-00-02		REPLACE	Discard HPC Stage 2 thru 6 Spool
72-045-00	72-045-00	72-045-00-01 72-045-00-02		REPLACE	Discard HPC Stage 7 Disk
72-050-00	72-050-00	72-050-00-01 72-050-00-02		REPLACE	Discard HPC Stage 8 thru 10 Spool
72-055-00	72-055-00	72-055-00-01 72-055-00-02		REPLACE	Discard CDP Seal
72-060-01	72-060-01	72-060-01-01 72-060-01-03		SPECIAL DETAILED	Borescope Inspection of the Combustor - Left
72-060-02	72-060-02	72-060-02-02 72-060-02-04		SPECIAL DETAILED	Borescope Inspection of the Combustor - Right
72-065-01	72-065-01	72-065-01-01 72-065-01-03		SPECIAL DETAILED	Borescope Inspection of the 1 St. & 2 ND. Stage Turbine Blades - Left
72-065-02	72-065-02	72-065-02-02 72-065-02-04		SPECIAL DETAILED	Borescope Inspection of the 1 St. & 2 ND. Stage Turbine Blades - Right
72-070-00	72-070-00	72-070-00-01 72-070-00-02		REPLACE	Discard HPT Stage 1 and 2 Disks and Seals
72-075-00	72-075-00	72-075-00-01 72-075-00-02		REPLACE	Discard LPT Shaft, LPT Cone Shaft and LPT Stage 1 thru 6 Disks





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>TASK CARD NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
72-080-01	72-080-01	72-080-01-01		INSPECTION - DETAILED	Detailed Inspection of TRF AFT Engine Mount Lugs- Left
72-080-02	72-080-02	72-080-02-02		INSPECTION - DETAILED	Detailed Inspection of TRF AFT Engine Mount Lugs - Right
72-083-01	72-083-01	72-083-01-01		INSPECTION - DETAILED	Detailed Inspection of TRF AFT Engine Mount Lugs- Left
72-083-02	72-083-02	72-083-02-01		INSPECTION - DETAILED	Detailed Inspection of TRF AFT Engine Mount Lugs - Right
72-090-01	72-090-01	72-090-01-01 72-090-01-03		INSPECTION - DETAILED	Detailed Inspection ACC GB. and Fittings - Left
72-090-02	72-090-02	72-090-02-02 72-090-02-04		INSPECTION - DETAILED	Detailed Inspection ACC GB. and Fittings - Right
72-206-01	72-206-01	72-206-01-01		INSPECTION - DETAILED	Turbine Section - Left
72-206-02	72-206-02	72-206-02-01		INSPECTION - DETAILED	Turbine Section - Right
72-207-01	72-207-01	72-207-01-01		INSPECTION - DETAILED	Turbine Section - Left
72-207-02	72-207-02	72-207-02-01		INSPECTION - DETAILED	Turbine Section - Right
72-211-01	72-211-01	72-211-01-01		INSPECTION - DETAILED	Diffuser Case Section - Left
72-211-02	72-211-02	72-211-02-01		INSPECTION - DETAILED	Diffuser Case Section - Right
72-212-01	72-212-01	72-212-01-01		INSPECTION - DETAILED	Diffuser Case Section - Left
72-212-02	72-212-02	72-212-02-01		INSPECTION - DETAILED	Diffuser Case Section - Right
72-220-01	72-220-01	72-220-01-01		INSPECTION - DETAILED	Low Pressure Compressor Section - Left



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-220-02	72-220-02	72-220-02-01		INSPECTION - DETAILED	Low Pressure Compressor Section - Right
72-225-00	72-225-00	72-225-00-01		REPLACE	Discard Fan Hub & LPC Drum Rotor
72-235-01	72-235-01	72-235-01-01		CHECK/INSP	Fan Case Section - Left
72-235-02	72-235-02	72-235-02-01		CHECK/INSP	Fan Case Section - Right
72-240-01	72-240-01	72-240-01-01		INSPECTION - GEN VISUAL	Kevlar Inspection on Fan Case - Left
72-240-02	72-240-02	72-240-02-01		INSPECTION - GEN VISUAL	Kevlar Inspection on Fan Case - Right
72-245-01	72-245-01	72-245-01-01 72-245-01-02 72-245-01-04 72-245-01-05 72-245-01-06		INSPECTION - DETAILED	Fan Case Section - Left
72-245-02	72-245-02	72-245-02-01 72-245-02-02 72-245-02-04 72-245-02-05 72-245-02-06		INSPECTION - DETAILED	Fan Case Section - Right
72-250-00	72-250-00	72-250-00-01		REPLACE	Discard Front HUB, 5th Disk, Drum Rotor/Drive Turbine Shaft
72-255-00	72-255-00	72-255-00-01		REPLACE	Discard HUBS, ROTATING AIRSEAL, AND BLADE RETAINING PLATES
72-260-00	72-260-00	72-260-00-01		REPLACE	Discard LPC/LPT COUPLING
72-265-00	72-265-00	72-265-00-01		REPLACE	Discard Disks, Rotating Airseals and Shafts
72-270-01	72-270-01	72-270-01-01		INSPECTION - DETAILED	Lubrication and Scavage System - Left
72-270-02	72-270-02	72-270-02-01		INSPECTION - DETAILED	Lubrication and Scavage System - Right
72-280-01	72-280-01	72-280-01-01		INSPECTION - DETAILED	Inspection of the Turbine Exhaust Case Rail Mount (AFT Eng Mount) - Left



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-280-02	72-280-02	72-280-02-01		INSPECTION - DETAILED	Inspection of the Turbine Exhaust Case Rail Mount (AFT Eng Mount) - Right
72-345-01		72-345-01-01		SPECIAL DETAILED	Fan Blade Ultrasonic Test
72-345-02		72-345-02-01		SPECIAL DETAILED	Fan Blade Ultrasonic Test
72-346-01		72-346-01-01		LUBRICATE	Fan Blade Lubrication
72-346-02		72-346-02-01		LUBRICATE	Fan Blade Lubrication
72-350-01	72-350-01	72-350-01-01		INSPECTION - DETAILED	Fan Blade Inspection
72-350-02	72-350-02	72-350-02-01		INSPECTION - DETAILED	Fan Blade Inspection
72-355-00	72-355-00	72-355-00-01		REPLACE	Discard LPC Disk
72-360-00	72-360-00	72-360-00-01		REPLACE	Discard LPC Shaft
72-365-00	72-365-00	72-365-00-01		REPLACE	Discard Fan Shaft
72-370-01	72-370-01	72-370-01-01		INSPECTION - DETAILED	Inspection of the Lugs
72-370-02	72-370-02	72-370-02-01		INSPECTION - DETAILED	Inspection of the Lugs
72-375-01	72-375-01	72-375-01-01		INSPECTION - DETAILED	MCD Inspection
72-375-02	72-375-02	72-375-02-01		INSPECTION - DETAILED	MCD Inspection
72-376-01	72-376-01	72-376-01-01		RESTORE	Restore (Clean) Master Electric Chip Detector (active DMS) Left Engine
72-376-02	72-376-02	72-376-02-01		RESTORE	Restore (Clean) Master Electric Chip Detector (active DMS) Right Engine
72-377-01	72-377-01	72-377-01-01		FUNCTIONAL	Functionally Check Master Electric Chip Detector (active DMS) Left Engine
72-377-02	72-377-02	72-377-02-01		FUNCTIONAL	Functionally Check Master Electric Chip Detector (active DMS) Right Engine



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>TASK CARD NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
72-380-00	72-380-00	72-380-00-01		REPLACE	Discard IPC Rear Stubshaft
72-385-01	72-385-01	72-385-01-01		INSPECTION - DETAILED	Inspect Detailed Kevlar
72-385-02	72-385-02	72-385-02-01		INSPECTION - DETAILED	Inspect Detailed Kevlar
72-390-01	72-390-01	72-390-01-01		INSPECTION - GEN VISUAL	General Visual of the Splitter Fairing
72-390-02	72-390-02	72-390-02-01		INSPECTION - GEN VISUAL	General Visual of the Splitter Fairing
72-400-01	72-400-01	72-400-01-01		INSPECTION - GEN VISUAL	General Visual of OGV's
72-400-02	72-400-02	72-400-02-01		INSPECTION - GEN VISUAL	General Visual of OGV's
72-405-00	72-405-00	72-405-00-01		REPLACE	Discard HPC Shaft/Assemblies
72-410-01	72-410-01	72-410-01-01		INSPECTION - DETAILED	Borescope Combustor
72-410-02	72-410-02	72-410-02-01		INSPECTION - DETAILED	Borescope Combustor
72-415-01	72-415-01	72-415-01-01		INSPECTION - DETAILED	Borescope Turbine Blades
72-415-02	72-415-02	72-415-02-01		INSPECTION - DETAILED	Borescope Turbine Blades
72-420-00	72-420-00	72-420-00-01		REPLACE	Discard HPT Disk
72-425-00	72-425-00	72-425-00-01		REPLACE	Discard IPT Disk
72-430-00	72-430-00	72-430-00-01		REPLACE	Discard IPT Shaft
72-435-00	72-435-00	72-435-00-01		REPLACE	Discard IPT Disks
72-440-00	72-440-00	72-440-00-01		REPLACE	Discard LPT Shaft



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-445-01	72-445-01	72-445-01-01		INSPECTION - DETAILED	Borescope Nozzle Guide Vanes
72-445-02	72-445-02	72-445-02-01		INSPECTION - DETAILED	Borescope Nozzle Guide Vanes
73-010-01	73-010-01	73-010-01-01 73-010-01-03		OPERATIONAL	Restore All C2 Messages - Left
73-010-02	73-010-02	73-010-02-02 73-010-02-04		OPERATIONAL	Restore All C2 Messages - Right
73-011-00	73-011-00	73-011-00-01 73-011-00-02 73-011-00-03 73-011-00-04		RESTORE	Engine Fuel
73-055-01	73-055-01	73-055-01-01 73-055-01-03		INSPECTION - DETAILED	Inspect Detailed Fuel Filter
73-055-02	73-055-02	73-055-02-02 73-055-02-04		INSPECTION - DETAILED	Inspect Detailed Fuel Filter
73-210-01	73-210-01	73-210-01-01		REPLACE	Fuel Pump Filter Element - Left
73-210-02	73-210-02	73-210-02-01		REPLACE	Fuel Pump Filter Element - Right
73-350-01	73-350-01	73-350-01-01		DISCARD	Discard LP Fuel Filter
73-350-02	73-350-02	73-350-02-01		DISCARD	Discard LP Fuel Filter
77-005-01	77-005-01	77-005-01-01 77-005-01-03		INSPECTION - DETAILED	Inspect for EGT System Degradation - Left
77-005-02	77-005-02	77-005-02-02 77-005-02-04		INSPECTION - DETAILED	Inspect for EGT System Degradation - Right
78-005-01	78-005-01	78-005-01-01 78-005-01-03		INSPECTION - GEN VISUAL	Inspect General Visual Exhaust Sleeve/Center Body - Left
78-005-02	78-005-02	78-005-02-02 78-005-02-04		INSPECTION - GEN VISUAL	Inspect General Visual Exhaust Sleeve/Center Body - Right



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
78-010-01	78-010-01	78-010-01-01 78-010-01-03		INSPECTION - DETAILED	Inspect Detailed T/R Blocker Door Hinges, Drag Links and Attachments - Left
78-010-02	78-010-02	78-010-02-02 78-010-02-04		INSPECTION - DETAILED	Inspect Detailed T/R Blocker Door Hinges, Drag Links and Attachments - Right
78-015-01	78-015-01	78-015-01-01 78-015-01-03		INSPECTION - DETAILED	Thrust Reverser Bullnose Seal
78-015-02	78-015-02	78-015-02-02 78-015-02-04		INSPECTION - DETAILED	Thrust Reverser Bullnose Seal
78-020-01	78-020-01	78-020-01-01 78-020-01-03		OPERATIONAL	Thrust Reverser Locks - Left
78-020-02	78-020-02	78-020-02-02 78-020-02-04		OPERATIONAL	Thrust Reverser Locks - Right
78-025-01	78-025-01	78-025-01-01 78-025-01-03		OPERATIONAL	Thrust Reverser Sync Lock- Left
78-025-02	78-025-02	78-025-02-02 78-025-02-04		OPERATIONAL	Thrust Reverser Sync Lock - Right
78-030-01	78-030-01	78-030-01-01 78-030-01-03		OPERATIONAL	Operationally Check DCV and Locking Sensors - Left
78-030-02	78-030-02	78-030-02-02 78-030-02-04		OPERATIONAL	Operationally Check DCV and Locking Sensors - Right
78-205-01	78-205-01	78-205-01-01		INSPECTION - GEN VISUAL	Thrust Reverser Bullnose Seal - Left
78-205-02	78-205-02	78-205-02-01		INSPECTION - GEN VISUAL	Thrust Reverser Bullnose Seal - Right
78-210-01	78-210-01	78-210-01-01		OPERATIONAL	Thrust Reverser System
78-210-02	78-210-02	78-210-02-01		OPERATIONAL	Thrust Reverser System
78-215-01	78-215-01	78-215-01-01		OPERATIONAL	Thrust Reverser System
78-215-02	78-215-02	78-215-02-01		OPERATIONAL	Thrust Reverser System



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**


MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
78-220-01	78-220-01	78-220-01-01		OPERATIONAL	Operationally Check Sync Lock on Thrust Reverser
78-220-02	78-220-02	78-220-02-01		OPERATIONAL	Operationally Check Sync Lock on Thrust Reverser
78-225-01	78-225-01	78-225-01-01		INSPECTION - DETAILED	Inspect Detailed T/R Blocker Door Hinge and Drag Link Attachments - Left
78-225-02	78-225-02	78-225-02-01		INSPECTION - DETAILED	Inspect Detailed T/R Blocker Door Hinge and Drag Link Attachments - Right
78-350-01	78-350-01	78-350-01-01		INSPECTION - DETAILED	Inspect Detailed Thrust Reverser Blocker Door Hinge and Drag Link Attachments
78-350-02	78-350-02	78-350-02-01		INSPECTION - DETAILED	Inspect Detailed Thrust Reverser Blocker Door Hinge and Drag Link Attachments
78-355-01	78-355-01	78-355-01-01		INSPECTION - DETAILED	Thrust Reverser Bullnose Seal
78-355-02	78-355-02	78-355-02-01		INSPECTION - DETAILED	Thrust Reverser Bullnose Seal
78-360-01	78-360-01	78-360-01-01		OPERATIONAL	Thrust Reverser Locks
78-360-02	78-360-02	78-360-02-01		OPERATIONAL	Thrust Reverser Locks
78-365-01	78-365-01	78-365-01-01		OPERATIONAL	Thrust Reverser Sync Lock
78-365-02	78-365-02	78-365-02-01		OPERATIONAL	Thrust Reverser Sync Lock
78-370-01	78-370-01	78-370-01-01		OPERATIONAL	Thrust Reverser Sensor Checks
78-370-02	78-370-02	78-370-02-01		OPERATIONAL	Thrust Reverser Sensor Checks
78-375-01	78-375-01	78-375-01-01		INSPECTION - GEN VISUAL	Inspect Fire Seal
78-375-02	78-375-02	78-375-02-01		INSPECTION - GEN VISUAL	Inspect Fire Seal
78-380-01	78-380-01	78-380-01-01		INSPECTION - GEN VISUAL	Inspect Thrust Reverser Hinges
78-380-02	78-380-02	78-380-02-01		INSPECTION - GEN VISUAL	Inspect Thrust Reverser Hinges



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
78-385-01	78-385-01	78-385-01-01		VISUAL CHECK	Thrust Reverser Thermal Protection System
78-385-02	78-385-02	78-385-02-01		VISUAL CHECK	Thrust Reverser Thermal Protection System
78-390-01		78-390-01-01		INSPECTION - DETAILED	Inspect Thrust Reverser Inner Wall
78-390-02		78-390-02-01		INSPECTION - DETAILED	Inspect Thrust Reverser Inner Wall
79-010-01	79-010-01	79-010-01-01 79-010-01-03		INSPECTION - DETAILED	Inspect Oil Filter Scavenge Screen - Left
79-010-02	79-010-02	79-010-02-02 79-010-02-04		INSPECTION - DETAILED	Inspect Oil Filter Scavenge Screen - Right
79-385-01	79-385-01	79-385-01-01		RESTORE	Restore Oil Pressure Filter
79-385-02	79-385-02	79-385-02-01		RESTORE	Restore Oil Pressure Filter
79-390-01	79-390-01	79-390-01-01		REPLACE	Replace Scavenge Oil Filter
79-390-02	79-390-02	79-390-02-01		REPLACE	Replace Scavenge Oil Filter
80-005-01	80-005-01	80-005-01-01 80-005-01-03		INSPECTION - DETAILED	Inspect Starter Chip Detector - Left
80-005-02	80-005-02	80-005-02-02 80-005-02-04		INSPECTION - DETAILED	Inspect Starter Chip Detector - Right
80-205-01	80-205-01	80-205-01-01		SERVICE	Starter Oil
80-205-02	80-205-02	80-205-02-01		SERVICE	Starter Oil
80-210-01	80-210-01	80-210-01-01		INSPECTION - DETAILED	Starter Chip Detector
80-210-02	80-210-02	80-210-02-01		INSPECTION - DETAILED	Starter Chip Detector
80-350-01	80-350-01	80-350-01-01		SERVICE	Starter Oil
80-350-02	80-350-02	80-350-02-01		SERVICE	Starter Oil



May 05/2020





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
12-002-01	12-002-01	12-002-01-01 12-002-01-02		LUBRICATE	Elevator Power Control Actuators and Elevator Hinges
12-004-00	12-004-00	12-004-00-01		LUBRICATE	Rudder and Rudder Tab Hinge Bearings, PCU'S Reaction Link Rod Ends and PCU Rod Ends
12-006-00	12-006-00	12-006-00-01		LUBRICATE	Stabilizer Trim Ballscrew and Ballscrew Actuator
12-008-00	12-008-00	12-008-00-01 12-008-00-02 12-008-00-11 12-008-00-12		LUBRICATE	LE Slat Torque Tube Couplings, Supports and Gearbox Couplings
12-008-01	12-008-01	12-008-01-01 12-008-01-02 12-008-01-03 12-008-01-04 12-008-01-05 12-008-01-06		LUBRICATE	Forward Cargo Compartment Torque Tube Supports and Couplings
12-010-00	12-010-00	12-010-00-01 12-010-00-02		LUBRICATE	Wing Inboard Slat Main Tracks
12-012-00	12-012-00	12-012-00-01 12-012-00-02		LUBRICATE	Wing Outboard Slats Main Tracks
12-014-00	12-014-00	12-014-00-01 12-014-00-02 12-014-00-11 12-014-00-12		LUBRICATE	Leading Edge Slat Track Rollers and Pinion Bearings
12-018-00	12-018-00	12-018-00-01 12-018-00-02		LUBRICATE	Wing Krueger Flap Drive Arm Bearing
12-020-00	12-020-00	12-020-00-01 12-020-00-02		LUBRICATE	Wing Inboard Spoilers PCU's, Center Hinges and Hinge Links
12-022-00	12-022-00	12-022-00-01 12-022-00-02		LUBRICATE	Wing Outboard Spoiler PCU's, Center Hinges and Hinge Links
12-024-00	12-024-00	12-024-00-01 12-024-00-02		LUBRICATE	Wing Aileron Power Control Units (PCUs) and Hinges



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
12-026-00	12-026-00	12-026-00-01 12-026-00-02		LUBRICATE	Wing Flaperon Power Control Units (PCU's) Rod Ends, Hinge Fittings and PCU Yoke Assemblies (if installed)
12-030-00	12-030-00	12-030-00-01 12-030-00-02		LUBRICATE	Wing Trailing Edge Torque Tubes, Torque Tube Supports, and Couplings
12-034-00	12-034-00	12-034-00-01 12-034-00-02 12-034-00-11 12-034-00-12 12-034-00-21 12-034-00-22 12-034-00-31 12-034-00-32	W-12-034-00-21 W-12-034-00-22 W-12-034-00-31 W-12-034-00-32	LUBRICATE	Wing Trailing Edge Flap Transmissions, Ballscrews and Gimbals
12-050-00	12-050-00	12-050-00-01 12-050-00-02 12-050-00-03 12-050-00-04 12-050-00-11 12-050-00-12 12-050-00-21 12-050-00-22 12-050-00-31 12-050-00-32 12-050-00-41 12-050-00-42 12-050-00-51 12-050-00-52	W-12-050-00-21 W-12-050-00-22 W-12-050-00-31 W-12-050-00-32	LUBRICATE	Wing Trailing Edge Flap Supports and Support Mechanisms
12-070-00	12-070-00	12-070-00-01 12-070-00-10		LUBRICATE	Nose Landing Gear Steering and Actuating Components and Mechanisms
12-074-00	12-074-00	12-074-00-01		LUBRICATE	Nose Landing Gear Doors and Door Actuating Mechanisms



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
12-080-00	12-080-00	12-080-00-01 12-080-00-02 12-080-00-03 12-080-00-04 12-080-00-05 12-080-00-06 12-080-00-11 12-080-00-12 12-080-00-13 12-080-00-14	W-12-082-00-01 W-12-082-00-02 W-12-082-00-03 W-12-082-00-04	LUBRICATE	Main Landing Gear Components and Actuating Mechanisms
12-081-00	12-081-00	12-081-00-01 12-081-00-02		LUBRICATE	Main Landing Gear Truck Beam and Inner Cylinder Pivot Joints
12-082-00	12-082-00	12-082-00-01 12-082-00-02 12-082-00-03 12-082-00-04	W-12-080-00-01 W-12-080-00-02 W-12-080-00-03 W-12-080-00-04	LUBRICATE	Main Landing Gear Forward Trunnion Bearing Housing and Retract Arm Assembly
12-086-00	12-086-00	12-086-00-01 12-086-00-02 12-086-00-03 12-086-00-04		LUBRICATE	Main Landing Gear Doors and Actuating Mechanisms
12-088-00	12-088-00	12-088-00-01 12-088-00-02 12-088-00-03 12-088-00-04		LUBRICATE	Main Landing Gear Support Beam
12-090-00	12-090-00	12-090-00-01		LUBRICATE	Forward Large Cargo Door Hinge Pins
12-092-00	12-092-00	12-092-00-01		LUBRICATE	Aft Large Cargo Door Hinge Pins
12-094-00	12-094-00	12-094-00-01		LUBRICATE	Forward Large Cargo Door Components and Door to Cutout Mating Surfaces
12-096-00	12-096-00	12-096-00-01		LUBRICATE	Aft Large Cargo Door Components and Door to Cutout Mating Surfaces
12-100-00	12-100-00	12-100-00-01		LUBRICATE	Forward Large Cargo Door Mechanisms (Pushrods, Links, Hooks and Pins)
12-102-00	12-102-00	12-102-00-01		LUBRICATE	Aft Large Cargo Door Mechanisms (Pushrods, Links, Hooks and Pins)
12-104-00	12-104-00	12-104-00-01		LUBRICATE	Aft Small Cargo Door Hinge Arms, Adjustment Rods and Latch Rollers



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
12-106-00	12-106-00	12-106-00-01 12-106-00-03 12-106-00-04		LUBRICATE	Passenger Entry Door Mechanisms
12-108-00	12-108-00	12-108-00-01		LUBRICATE	Bulk Cargo Door Probe Support Fittings
12-110-00	12-110-00	12-110-00-01 12-110-00-02 12-110-00-03 12-110-00-04 12-110-00-05 12-110-00-06		LUBRICATE	Forward Access Door Latch Pin
12-112-00	12-112-00	12-112-00-01		LUBRICATE	Main Equipment Center Access Door Latch Pin
12-114-00	12-114-00	12-114-00-01		LUBRICATE	Ram Air Turbine (RAT) Actuator Strut and Door Actuation Link
12-118-00	12-118-00	12-118-00-01 12-118-00-02 12-118-00-03 12-118-00-04 12-118-00-05 12-118-00-06		LUBRICATE	Wing Nacelle Attach Fittings
12-122-00	12-122-00	12-122-00-01		LUBRICATE	No. 2 Left and Right Flight Compartment Window Drive Tracks
20-010-00	20-010-00	20-010-00-01 20-010-00-02 20-010-00-03 20-010-00-04 20-010-00-05		INSPECTION - DETAILED	Primary Flight Control and Brake Control Cables Turns
20-015-00	20-015-00	20-015-00-01 20-015-00-02 20-015-00-03 20-015-00-04 20-015-00-05 20-015-00-06 20-015-00-07 20-015-00-08 20-015-00-09		INSPECTION - DETAILED	Primary Flight Control and Brake Control Cables - straight runs



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-070-00	20-070-00	20-070-00-01 20-070-00-02		INSPECTION - DETAILED	Exposed, Unprotected Brake Control Cables in the Wheel Well
20-110-00	20-110-00	20-110-00-01 20-110-00-02 20-110-00-03 20-110-00-04 20-110-00-05		INSPECTION - DETAILED	Primary Flight Control Cables - PROTECTED/UNPROTECTED UNPRESSURIZED AREAS
20-200-00	20-200-00	20-200-00-01		FUNCTIONAL	HIRF/L AFDC Task for ILS, RA, AIMS, Backdrive and Cross Channel
20-250-10	20-250-10	20-250-10-01		INSPECTION - DETAILED	FOIL/MESH PANELS; ENGINE COWLS, STRUT, LEADING EDGE
20-250-20	20-250-20	20-250-20-01		INSPECTION - DETAILED	FOIL/MESH PANELS; ENGINE COWLS, STRUT, LEADING EDGE
20-251-10	20-251-10	20-251-10-01		INSPECTION - DETAILED	FOIL/MESH PANELS; ENGINE COWLS, STRUT, LEADING EDGE
20-251-20	20-251-20	20-251-20-01		INSPECTION - DETAILED	FOIL/MESH PANELS; ENGINE COWLS, STRUT, LEADING EDGE
20-252-10	20-252-10	20-252-10-01		INSPECTION - DETAILED	FOIL/MESH PANELS; ENGINE COWLS, STRUT, LEADING EDGE
20-252-20	20-252-20	20-252-20-01		INSPECTION - DETAILED	FOIL/MESH PANELS; ENGINE COWLS, STRUT, LEADING EDGE
20-260-00	20-260-00	20-260-00-01		FUNCTIONAL	Ram Air Turbine (RAT) Wire Shielding Functional Check
20-270-01	20-270-01	20-270-01-01		FUNCTIONAL	PFCS Wire Shielding Functional Check - Left Wing
20-270-02	20-270-02	20-270-02-01		FUNCTIONAL	PFCS Wire Shielding Functional Check - Right Wing
20-280-00	20-280-00	20-280-00-01		FUNCTIONAL	PFCS Wire Shielding Functional Check - Empennage
20-290-00	20-290-00	20-290-00-01		FUNCTIONAL	HIRF/Lightning Ace Wire Bundle Shielding
20-300-00	20-300-00	20-300-00-01		FUNCTIONAL	HIRF/Arlinc 629 Buses for Flight Controls, Couplers to EE Racks
20-310-01	20-310-01	20-310-01-01		FUNCTIONAL	Functional Check Wire Bundle Inspection Left Flaps, Slats, Skew Sensors
20-310-02	20-310-02	20-310-02-01		FUNCTIONAL	Functional Check Wire Bundle Right Flaps, Slats, Skew Sensors



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-320-00	20-320-00	20-320-00-01		FUNCTIONAL	Gust Suppression Transducers Wire Shielding Functional Check
20-330-00	20-330-00	20-330-00-01		FUNCTIONAL	HIRF/Lightning ACE Disconnects to Modal Suppression Transducers
20-340-00	20-340-00	20-340-00-01		FUNCTIONAL	HIRF/lightning ACE disconnects to pitch rate sensors
20-400-00	20-400-00	20-400-00-01		FUNCTIONAL	HIRF/Lightning Glide Slope and Localizer Antenna Coax
20-410-00	20-410-00	20-410-00-01		INSPECTION - DETAILED	Radome Diverter Strips Detailed Visual Inspection
20-420-00	20-420-00	20-420-00-01		FUNCTIONAL	HIRF/Lightning Localizer Tracking, VOR/Localizer Antenna COAX
20-430-00	20-430-00	20-430-00-01		FUNCTIONAL	HIRF/Lightning Glide Slope Tracking Antenna COAX
20-440-00	20-440-00	20-440-00-01		FUNCTIONAL	HIRF/Lightning VOR/Localizer Capture Antenna COAX
20-445-00	20-445-00	20-445-00-01		INSPECTION - DETAILED	Fin Tip Diverter Strip
20-450-00	20-450-00	20-450-00-01		FUNCTIONAL	HIRF/Lightning Radio Altimeter Antenna to Transceiver Coax
20-451-00	20-451-00	20-451-00-01		FUNCTIONAL	HIRF/Lightning Radio Altimeter Antenna to Transceiver Coax
20-460-00	20-460-00	20-460-00-01		FUNCTIONAL	HIRF/Lightning GPS Antenna to Left and Right MMR
20-470-00	20-470-00	20-470-00-01		FUNCTIONAL	HIRF/Lightning Protection - Air Supply Isolation Valves
20-471-00	20-471-00	20-471-00-01		FUNCTIONAL	HIRF/Lightning Protection - Main Landing Gear (MLG) Selector/Bypass Valve Module
20-472-00	20-472-00	20-472-00-01		FUNCTIONAL	HIRF/Lightning Protection - Center Hydraulic System Quantity Transmitter
20-473-01	20-473-01	20-473-01-01		FUNCTIONAL	HIRF/Lightning Protection - Flight Control Shutoff Valves - LH Wing & LH MLG W/W
20-473-02	20-473-02	20-473-02-01		FUNCTIONAL	HIRF/Lightning Protection - Flight Control Shutoff Valves - RH Wing & RH MLG W/W
20-474-01	20-474-01	20-474-01-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Crossfeed and Isolation Valves - LH Wing & LH MLG W/W
20-474-02	20-474-02	20-474-02-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Crossfeed and Isolation Valves - RH Wing & RH MLG W/W





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-475-00	20-475-00	20-475-00-01		FUNCTIONAL	HIRF/Lightning Protection - Center Override Jettison Fuel Pumps - MLG W/W
20-476-01	20-476-01	20-476-01-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Boost Pumps - LH Wing & LH MLG W/W
20-476-02	20-476-02	20-476-02-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Boost Pumps - RH Wing & RH MLG W/W
20-477-01	20-477-01	20-477-01-01		FUNCTIONAL	HIRF/Lightning Protection - Main Tank Fuel Jettison Pump - LH Wing
20-477-02	20-477-02	20-477-02-01		FUNCTIONAL	HIRF/Lightning Protection - Main Tank Fuel Jettison Pump - RH Wing
20-478-01	20-478-01	20-478-01-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Jettison Nozzle Valves - LH Wing
20-478-02	20-478-02	20-478-02-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Jettison Nozzle Valves - RH Wing
20-479-01	20-479-01	20-479-01-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Jettison Nozzle Valves - LH Wing
20-479-02	20-479-02	20-479-02-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Jettison Nozzle Valves - RH Wing
20-500-01	20-500-01	20-500-01-01		INSPECTION - DETAILED	GE90 FADEC Control System Wires Detail Inspection
20-500-02	20-500-02	20-500-02-01		INSPECTION - DETAILED	GE90 FADEC Control System Wires Detail Inspection
20-520-01	20-520-01	20-520-01-01		INSPECTION - DETAILED	PW4000 Electronic Engine Control System Wire Run
20-520-02	20-520-02	20-520-02-01		INSPECTION - DETAILED	PW4000 Electronic Engine Control System Wire Run
20-540-01	20-540-01	20-540-01-01		INSPECTION - DETAILED	Trent Electronic Engine Control System Wire Runs
20-540-02	20-540-02	20-540-02-01		INSPECTION - DETAILED	Trent Electronic Engine Control System Wire Runs
20-560-01	20-560-01	20-560-01-01		FUNCTIONAL	HIRF/ L Functional Test for FQIS, Left Side
20-560-02	20-560-02	20-560-02-01		FUNCTIONAL	HIRF/ L Functional Test for FQIS, Right Side
20-600-00	20-600-00	20-600-00-01		INSPECTION - DETAILED	Power Feeders connected to P100 and P200 Power Panels
20-602-00	20-602-00	20-602-00-01		RESTORE	Area Above Nose Landing Gear Wheel Well



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-640-10	20-640-10	20-640-10-01		INSPECTION - DETAILED	Wing Center Section Fuel Tank (SFAR 88)
20-641-00	20-641-00	20-641-00-01		INSPECTION - GEN VISUAL	ECS Bay Installed EWIS
20-642-00	20-642-00	20-642-00-01		INSPECTION - GEN VISUAL	Forward Bulkhead Left Main Landing Gear Wheel Well
20-644-00	20-644-00	20-644-00-01		INSPECTION - GEN VISUAL	Forward Bulkhead Right Main Landing Gear Wheel Well
20-648-00	20-648-00	20-648-00-01		INSPECTION - GEN VISUAL	Forward Cargo Power Drive Unit Wire Bundles
20-650-00	20-650-00	20-650-00-01 20-650-00-02 20-650-00-03 20-650-00-04 20-650-00-05		RESTORE	Areas Behind the FWD Cargo Compartment Sidewalls
20-651-00	20-651-00	20-651-00-01		RESTORE	Areas Below the AFT Cargo Compartment
20-652-00	20-652-00	20-652-00-01 20-652-00-02 20-652-00-03 20-652-00-04 20-652-00-05 20-652-00-06		INSPECTION - GEN VISUAL	Forward Cargo Compartment Power Feeders
20-654-00	20-654-00	20-654-00-01		RESTORE	Areas Behind the FWD Cargo Compartment Sidewalls
20-656-00	20-656-00	20-656-00-01 20-656-00-02 20-656-00-03 20-656-00-04 20-656-00-05 20-656-00-06		RESTORE	Areas Below the FWD Cargo Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-658-00	20-658-00	20-658-00-01 20-658-00-02 20-658-00-03 20-658-00-04 20-658-00-05 20-658-00-06		RESTORE	Area Behind the Forward Cargo Compartment
20-659-00	20-659-00	20-659-00-01 20-659-00-02 20-659-00-03 20-659-00-04 20-659-00-05 20-659-00-06		INSPECTION - GEN VISUAL	Area Behind the Forward Cargo Compartment
20-660-00	20-660-00	20-660-00-01 20-660-00-02 20-660-00-03 20-660-00-04 20-660-00-05 20-660-00-06		INSPECTION - GEN VISUAL	Aft Cargo Compartment Power Feeders
20-662-00	20-662-00	20-662-00-01		RESTORE	Areas Behind the Aft Cargo Compartment Sidewalls
20-664-00	20-664-00	20-664-00-01		RESTORE	Areas Behind the Aft Cargo Compartment Sidewalls
20-665-00	20-665-00	20-665-00-01		INSPECTION - GEN VISUAL	Aft Cargo Power Drive Unit Wire Bundles
20-668-00	20-668-00	20-668-00-01		INSPECTION - GEN VISUAL	APU Battery Installation and Power Feeders
20-670-00	20-670-00	20-670-00-01		RESTORE	Area Behind the Bulk Cargo Compartment Sidewalls
20-672-00	20-672-00	20-672-00-01		RESTORE	Area Behind the Bulk Cargo Compartment
20-700-00	20-700-00	20-700-00-01 20-700-00-02 20-700-00-03 20-700-00-04 20-700-00-05		RESTORE	Areas Behind the Passenger Compartment Air Grilles



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-701-00	20-701-00	20-701-00-01 20-701-00-02 20-701-00-03 20-701-00-04 20-701-00-05		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-702-00	20-702-00	20-702-00-01 20-702-00-02		INSPECTION - DETAILED	APU and RAT Power Feeders, and Galley and Cabin Power Feeders
20-704-00	20-704-00	20-704-00-01		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-705-00	20-705-00	20-705-00-01		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-706-00	20-706-00	20-706-00-01		INSPECTION - DETAILED	APU, RAT, Galley and Cabin Power Feeders in Passenger Compartment
20-708-00	20-708-00	20-708-00-01 20-708-00-02 20-708-00-03 20-708-00-04 20-708-00-05		RESTORE	Upper Surface of Ceiling Panels, Bins and Modules
20-712-00	20-712-00	20-712-00-01 20-712-00-02 20-712-00-03 20-712-00-04 20-712-00-05 20-712-00-06		INSPECTION - GEN VISUAL	Flight Deck EWIS
20-714-00	20-714-00	20-714-00-01		RESTORE	Flight Deck
20-716-00	20-716-00	20-716-00-01 20-716-00-02		RESTORE	Area Around the Video Control Center
20-724-00	20-724-00	20-724-00-01		INSPECTION - DETAILED	Rat Cabin and Galley Power Feeders in the Passenger Compartment
20-728-00	20-728-00	20-728-00-01		INSPECTION - DETAILED	Rat and Cabin Power Feeder Bundles in Passenger Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-730-00	20-730-00	20-730-00-01		RESTORE	Equipment Racks in Main Equipment Center.
20-732-00	20-732-00	20-732-00-01		INSPECTION - DETAILED	APU, IDG, BAT. & CHGR and Ground Power Feeders in the Main Equipment Center
20-734-00	20-734-00	20-734-00-01		INSPECTION - GEN VISUAL	External Power Receptacle in the Main Equipment Center.
20-736-00	20-736-00	20-736-00-01		INSPECTION - DETAILED	APU Power Feeders in Main Deck Cargo Compartment
20-737-00	20-737-00	20-737-00-01		CLEAN	Main Deck Cargo Compartment Air Grilles
20-738-00	20-738-00	20-738-00-01 20-738-00-02 20-738-00-03		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-740-00	20-740-00	20-740-00-01 20-740-00-02 20-740-00-03		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-742-00	20-742-00	20-742-00-01 20-742-00-02		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-744-00	20-744-00	20-744-00-01 20-744-00-02		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-746-00	20-746-00	20-746-00-01 20-746-00-02 20-746-00-03		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-748-00	20-748-00	20-748-00-01 20-748-00-02 20-748-00-03		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-750-00	20-750-00	20-750-00-01 20-750-00-02		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-752-00	20-752-00	20-752-00-01 20-752-00-02		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-754-00	20-754-00	20-754-00-01 20-754-00-02 20-754-00-03 20-754-00-04 20-754-00-05		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-756-00	20-756-00	20-756-00-01 20-756-00-02 20-756-00-03 20-756-00-04 20-756-00-05		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-758-00	20-758-00	20-758-00-01 20-758-00-02 20-758-00-03 20-758-00-04 20-758-00-05		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-760-00	20-760-00	20-760-00-01 20-760-00-02 20-760-00-03 20-760-00-04 20-760-00-05		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-762-00	20-762-00	20-762-00-01 20-762-00-02 20-762-00-03		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-764-00	20-764-00	20-764-00-01 20-764-00-02 20-764-00-03		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-766-00	20-766-00	20-766-00-01 20-766-00-02		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-768-00	20-768-00	20-768-00-01 20-768-00-02		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-770-00	20-770-00	20-770-00-01 20-770-00-02 20-770-00-03		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-772-00	20-772-00	20-772-00-01 20-772-00-02 20-772-00-03		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-774-00	20-774-00	20-774-00-01 20-774-00-02		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-776-00	20-776-00	20-776-00-01 20-776-00-02		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-778-00	20-778-00	20-778-00-01 20-778-00-02 20-778-00-03 20-778-00-04 20-778-00-05		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-780-00	20-780-00	20-780-00-01 20-780-00-02 20-780-00-03 20-780-00-04 20-780-00-05		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-782-00	20-782-00	20-782-00-01 20-782-00-02 20-782-00-03 20-782-00-04 20-782-00-05		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-784-00	20-784-00	20-784-00-01 20-784-00-02 20-784-00-03 20-784-00-04 20-784-00-05		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-790-00	20-790-00	20-790-00-01		INSPECTION - GEN VISUAL	APU and APU Starter Power Feeders
20-792-00	20-792-00	20-792-00-01		INSPECTION - GEN VISUAL	APU and APU Starter Power Feeders



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-794-00	20-794-00	20-794-00-01		INSPECTION - DETAILED	APU and APU Starter Power Feeders
20-796-00	20-796-00	20-796-00-01		RESTORE	Main Deck Entry Doors
20-800-00	20-800-00	20-800-00-01		INSPECTION - DETAILED	Engine IDG and Backup Generator Power Feeders - Left Engine
20-802-00	20-802-00	20-802-00-01		INSPECTION - DETAILED	Engine IDG and Backup Generator Power Feeders - Right Engine
20-840-01	20-840-01	20-840-01-01		INSPECTION - GEN VISUAL	IDG and Backup Power Feeders - Left Wing
20-840-02	20-840-02	20-840-02-01		INSPECTION - GEN VISUAL	IDG and Backup Power Feeders - Right Wing
20-842-00	20-842-00	20-842-00-01 20-842-00-02		INSPECTION - GEN VISUAL	EWIS within Nacelle Gap - Left and Right Wings
20-844-00	20-844-00	20-844-00-01 20-844-00-02		INSPECTION - GEN VISUAL	IDG and Backup Power Feeders - Right and Left Wings
20-850-00	20-850-00	20-850-00-01		INSPECTION - GEN VISUAL	Wing Leading Edge Wiring - Left Wing
20-851-00	20-851-00	20-851-00-01		INSPECTION - GEN VISUAL	Wing Leading Edge Wiring - Right Wing
20-852-00	20-852-00	20-852-00-01 20-852-00-02		INSPECTION - DETAILED	FQIS Wiring in the Wing Main Tank
20-856-11	20-856-11	20-856-11-01		INSPECTION - DETAILED	Center Fuel Tank (Rib 1 to Rib 8) - Left Wing (SFAR 88)
20-856-12	20-856-12	20-856-12-01		INSPECTION - DETAILED	Center Fuel Tank (Rib 1 to Rib 8) - Right Wing (SFAR 88)
20-858-11	20-858-11	20-858-11-01		INSPECTION - DETAILED	Main Tank (Rib 8 to Rib 17) - Left Wing (SFAR 88)
20-858-12	20-858-12	20-858-12-01		INSPECTION - DETAILED	Main Tank (Rib 8 to Rib 17) - Right Wing (SFAR 88)





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-860-11	20-860-11	20-860-11-01		INSPECTION - DETAILED	Main Tank (Rib 17 to Rib 32) - Left Wing (SFAR 88)
20-860-12	20-860-12	20-860-12-01		INSPECTION - DETAILED	Main Tank (Rib 17 to Rib 32) - Right Wing (SFAR 88)
20-866-00	20-866-00	20-866-00-01		INSPECTION - GEN VISUAL	Flap Supports No. 3
20-868-00	20-868-00	20-868-00-01		INSPECTION - GEN VISUAL	Flap Support No. 6
21-010-00	21-010-00	21-010-00-01		REPLACE	Upper Recirculation Air Filters
21-020-00	21-020-00	21-020-00-01		REPLACE	Lower Recirculation Air Filters
21-030-00	21-030-00	21-030-00-01		REPLACE	Galley Ventilation Filters
21-033-00	21-033-00	21-033-00-01		OPERATIONAL	Main Deck Alerting System
21-034-00	21-034-00	21-034-00-01		OPERATIONAL	Alternate Ventilation System (AVS)
21-036-00	21-036-00	21-036-00-01		INSPECTION - DETAILED	Lavatory/Galley and Alternate Ventilation System (LGVS and AVS)
21-037-00	21-037-00	21-037-00-01		RESTORE	Lav/Galley Ventilation System (LGVS)
21-048-00	21-048-00	21-048-00-01		OPERATIONAL	E/E Cooling System Override Switch
21-050-00	21-050-00	21-050-00-01		CLEAN	Equipment Cooling Air Filter
21-052-00	21-052-00	21-052-00-01		INSPECTION - DETAILED	IFE Cooling Smoke Detector
21-054-00	21-054-00	21-054-00-01		INSPECTION - DETAILED	IFE Cooling System Air Supply Multi-holed Orifices
21-055-00	21-055-00	21-055-00-01		FUNCTIONAL	Condenser/Reheater
21-060-00	21-060-00	21-060-00-01	W-21-070-00-01	INSPECTION - DETAILED	E11 Rack Satcom Backup Fan Check Valves
21-065-00	21-065-00	21-065-00-01	W-21-075-00-01	INSPECTION - DETAILED	E13 Rack Satcom Backup Fan Check Valves



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
21-070-00	21-070-00	21-070-00-01	W-21-060-00-01	INSPECTION - DETAILED	E11 Rack Satcom Backup Cooling Check Valve
21-075-00	21-075-00	21-075-00-01	W-21-065-00-01	INSPECTION - DETAILED	E13 Rack Satcom Backup Cooling Check Valve
21-080-00	21-080-00	21-080-00-01		OPERATIONAL	Outflow Valve Manual Control
21-090-00	21-090-00	21-090-00-01		OPERATIONAL	Landing Altitude Manual Select Switch
21-100-00	21-100-00	21-100-00-01 21-100-00-02	W-21-105-00-01 W-21-105-00-02	CLEAN/INSP	Cabin Pressure Control Outflow Valves
21-105-00	21-105-00	21-105-00-01 21-105-00-02	W-21-100-00-01 W-21-100-00-02	INSPECTION - GEN VISUAL	Cabin Pressure Control Outflow Valves
21-110-00	21-110-00	21-110-00-01 21-110-00-02	R-21-110-00-01 P-21-110-00-02	FUNCTIONAL	Cabin Positive Pressure Relief Valves
21-120-00	21-120-00	21-120-00-01		REPLACE	Cabin Positive Pressure Relief Filters
21-130-00	21-130-00	21-130-00-01		OPERATIONAL	AFT and Bulk Cargo Temperature Selector Switches
21-131-00	21-131-00	21-131-00-01		FUNCTIONAL	AFT/Bulk Cargo Overheat Protection Switch & Relay
21-132-00	21-132-00	21-132-00-01		OPERATIONAL	AFT Cargo Temperature Selector Switch
21-133-00	21-133-00	21-133-00-01		OPERATIONAL	Aft Cargo Air Conditioning (ACAC)/Aft Lower Cargo Temperature Selector Switch
21-134-00	21-134-00	21-134-00-01		FUNCTIONAL	Aft Cargo Overheat Protection Switch & Relay
21-140-00	21-140-00	21-140-00-01		OPERATIONAL	AC Pack Flow Sensors
21-150-00	21-150-00	21-150-00-01	W-21-170-00-01	CLEAN	AC Pack Heat Exchangers
21-160-00	21-160-00	21-160-00-01		FUNCTIONAL	AC Pack Heat Exchangers
21-170-00	21-170-00	21-170-00-01	W-21-150-00-01	INSPECTION - DETAILED	AC Pack Fan Bypass Check Valve
21-180-00	21-180-00	21-180-00-01 21-180-00-02		INSPECTION - DETAILED	AC Pack Conditioned Air Check Valves
21-190-00	21-190-00	21-190-00-01		OPERATIONAL	AC Pack Condenser Low Limit Valves



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
21-200-00	21-200-00	21-200-00-01		OPERATIONAL	AC Pack 2nd Stage Turbine Bypass Valves
21-210-00	21-210-00	21-210-00-01		OPERATIONAL	AC Pack Secondary Heat Exchangers Outlet Temperature Sensor
21-220-00	21-220-00	21-220-00-01		OPERATIONAL	Cabin Air Conditioning and Temperature Controllers
21-230-00	21-230-00	21-230-00-01		CLEAN	Ozone Converters
21-240-00	21-240-00	21-240-00-01		CLEAN	Ozone Converters
21-250-00	21-250-00	21-250-00-01		INSPECTION - GEN VISUAL	E/E Equipment Cooling Override Duct
21-260-00	21-260-00	21-260-00-01		INSPECTION - DETAILED	Lower Recirculation Air Fan Check Valves
22-040-00	22-040-00	22-040-00-01		OPERATIONAL	Take-Off/ Go-Around (TO/GA) Switch
23-010-00	23-010-00	23-010-00-01 23-010-00-02		FUNCTIONAL	Passenger Address System
23-020-00	23-020-00	23-020-00-01		OPERATIONAL	Passenger Address System
23-030-00	23-030-00	23-030-00-01		OPERATIONAL	Passenger Address System
23-040-00	23-040-00	23-040-00-01		OPERATIONAL	Cabin Interphone System Alternate Channel
23-050-00	23-050-00	23-050-00-01		OPERATIONAL	Flight Interphone System - Audio Transfer
23-060-00	23-060-00	23-060-00-01		INSPECTION - GEN VISUAL	Static Dischargers
23-070-00	23-070-00	23-070-00-01		OPERATIONAL	Voice Recorder System
23-080-00	23-080-00	23-080-00-01		FUNCTIONAL	Voice Recorder System - Four Channel Operation
23-085-00	23-085-00	23-085-00-01		FUNCTIONAL	Voice recorder back up power system
23-090-00	23-090-00	23-090-00-01 23-090-00-02		REPLACE	Voice Recorder - Underwater Locator Beacon
23-100-00	23-100-00	23-100-00-01 23-100-00-02		OPERATIONAL	Voice Recorder System - Under Water Locator Beacon



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
23-110-00	23-110-00	23-110-00-01 23-110-00-02 23-110-00-03 23-110-00-04 23-110-00-05		OPERATIONAL	Emergency Locator Transmitter
23-120-00	23-120-00	23-120-00-01 23-120-00-02 23-120-00-03 23-120-00-04		REPLACE	Emergency Locator Transmitter
23-180-00	23-180-00	23-180-00-01		OPERATIONAL	Low Frequency Underwater Locator Device
23-190-00	23-190-00	23-190-00-01		DISCARD	Low Frequency Underwater Locator Device Battery
24-010-00	24-010-00	24-010-00-01 24-010-00-02		SERVICE	IDG Oil Servicing
24-011-00	24-011-00	24-011-00-01 24-011-00-02		SERVICE	IDG OIL Servicing
24-012-00	24-012-00	24-012-00-01 24-012-00-02		SERVICE	IDG Oil Servicing
24-030-00	24-030-00	24-030-00-01 24-030-00-02		SERVICE	VSCF Backup Generator Oil Servicing
24-040-00	24-040-00	24-040-00-01 24-040-00-02	W-24-070-00-01 W-24-070-00-02	SERVICE	IDG Oil Change
24-041-00	24-041-00	24-041-00-01 24-041-00-02	W-24-071-00-01 W-24-071-00-02	SERVICE	IDG Oil Change
24-042-00	24-042-00	24-042-00-01 24-042-00-02	W-24-072-00-01 W-24-072-00-02	SERVICE	IDG Oil Change
24-050-00	24-050-00	24-050-00-01 24-050-00-02 24-050-00-03 24-050-00-04 24-050-00-05 24-050-00-06		SERVICE	VSCF Backup Generator Oil and Filter Change



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
24-060-00	24-060-00	24-060-00-01 24-060-00-02	W-24-040-00-01 W-24-040-00-02 W-24-075-00-01 W-24-075-00-02	OPERATIONAL	Generator Drive Disconnect
24-061-00	24-061-00	24-061-00-01 24-061-00-02		OPERATIONAL	Generator Drive Disconnect
24-062-00	24-062-00	24-062-00-01 24-062-00-02		OPERATIONAL	Generator Drive Disconnect
24-070-00	24-070-00	24-070-00-01 24-070-00-02		REPLACE	IDG Oil Filter
24-071-00	24-071-00	24-071-00-01 24-071-00-02		REPLACE	IDG Oil Filter
24-072-00	24-072-00	24-072-00-01 24-072-00-02		REPLACE	IDG Oil Filter
24-080-00	24-080-00	24-080-00-01 24-080-00-02		INSPECTION - GEN VISUAL	IDG Oil Filter Element
24-090-00	24-090-00	24-090-00-01 24-090-00-02		FUNCTIONAL	IDG QAD Coupler
24-091-00	24-091-00	24-091-00-01 24-091-00-02		FUNCTIONAL	IDG QAD Coupler
24-092-00	24-092-00	24-092-00-01 24-092-00-02		FUNCTIONAL	IDG QAD Coupler



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
24-100-00	24-100-00	24-100-00-01 24-100-00-02 24-100-00-03 24-100-00-04 24-100-00-05 24-100-00-06 24-100-00-07		CLEAN	IDG and Backup Generator (VSCF) Heat Exchangers
24-120-00	24-120-00	24-120-00-01 24-120-00-02		CHECK/INSP	VSCF Backup Generator Differential Pressure Switch
24-160-00	24-160-00	24-160-00-01		FUNCTIONAL	APU Battery Charge Capacity
24-160-01	24-160-01	24-160-01-01		RESTORE	APU Battery Charge Capacity
24-170-00	24-170-00	24-170-00-01		FUNCTIONAL	Main Battery Charge Capacity
24-170-01	24-170-01	24-170-01-01		RESTORE	Main Battery Charge Capacity
24-190-00	24-190-00	24-190-00-01		RESTORE	Flight Control DC Power Battery
24-200-00	24-200-00	24-200-00-01		FUNCTIONAL	External Power Receptacles (Wear Check)
24-210-00	24-210-00	24-210-00-01		INSPECTION - DETAILED	External Power Receptacles (Inspection)
25-010-00	25-010-00	25-010-00-01		INSPECTION - DETAILED	Crew Seat Attachments
25-020-00	25-020-00	25-020-00-01		OPERATIONAL	Crew Seat Lock Mechanism
25-020-02	25-020-02	25-020-02-01 25-020-02-02		OPERATIONAL	Flight Crew Seat Manual Adjustments
25-020-04	25-020-04	25-020-04-01		INSPECTION - DETAILED	Flight Compartment Seat Harness
25-020-06	25-020-06	25-020-06-01		OPERATIONAL	Flight Compartment Seat Inertial Reel
25-030-00	25-030-00	25-030-00-01 25-030-00-02 25-030-00-03 25-030-00-04		VISUAL CHECK	Passenger Compartment Seats



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
25-040-00	25-040-00	25-040-00-01 25-040-00-02 25-040-00-03		OPERATIONAL	Passenger Seat Belts
25-045-00	25-045-00	25-045-00-01		OPERATIONAL	Crew and/or Attendant Rest Bunk Belts
25-050-00	25-050-00	25-050-00-01		OPERATIONAL	Passenger Compartment Seats
25-055-00	25-055-00	25-055-00-01		OPERATIONAL	Passenger Compartment Articulating Seats
25-056-00	25-056-00	25-056-00-01 25-056-00-02 25-056-00-03 25-056-00-04		OPERATIONAL	Inflatable Seat Restraint System
25-057-00	25-057-00	25-057-00-01		INSPECTION - DETAILED	Inflatable Seat Restraint System Seatbelt Airbag Assembly (SAA)
25-058-00	25-058-00	25-058-00-01 25-058-00-02 25-058-00-03		DISCARD	Inflatable Seat Restraint System Gas Generator Assembly (GGA)
25-059-00	25-059-00	25-059-00-01 25-059-00-02 25-059-00-03		RESTORE	Inflatable Seat Restraint System Electronic Module Assembly (EMA) Battery
25-060-00	25-060-00	25-060-00-01		OPERATIONAL	Attendant Seat Restraint
25-062-00	25-062-00	25-062-00-01		RESTORE	Life Raft
25-065-00	25-065-00	25-065-00-01		RESTORE	Off-Wing Emergency Escape Slide Assembly
25-066-00	25-066-00	25-066-00-01		VISUAL CHECK	Off-Wing Inflation Cylinder Pressure
25-067-00	25-067-00	25-067-00-01		OPERATIONAL	Off-Wing Slide Compartment Door Lock/Latch System
25-069-00	25-069-00	25-069-00-01		REPLACE	Off-Wing Slide Inflation Cylinder Squib Cartridges
25-070-00	25-070-00	25-070-00-01		INSPECTION - DETAILED	Lavatory Waste Compartment Doors & Flaps
25-071-00	25-071-00	25-071-00-01 25-071-00-02		DISCARD	Off - Wing Slide Reservoir



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
25-085-00	25-085-00	25-085-00-01		INSPECTION - DETAILED	Aux Fuel Tank Barrier Panel
25-090-00	25-090-00	25-090-00-01		VISUAL CHECK	Flight Deck Escape Rope
25-095-00	25-095-00	25-095-00-01 25-095-00-02		INSPECTION - DETAILED	Overwing Exit Door Lifeline
25-100-00	25-100-00	25-100-00-01		RESTORE	Survival Kit - Life Vests (Jackets)
25-105-00	25-105-00	25-105-00-01		VISUAL CHECK	Crash Axe
25-110-00	25-110-00	25-110-00-01 25-110-00-02		RESTORE	Life Vests (Jackets)
25-115-00	25-115-00	25-115-00-01 25-115-00-02		RESTORE	Flotation Cots
25-120-00	25-120-00	25-120-00-01		FUNCTIONAL	Emergency Locator Transmitters
25-125-00	25-125-00	25-125-00-01		DISCARD	Emergency Locator Transmitter (Batteries)
25-130-00	25-130-00	25-130-00-01		OPERATIONAL	Emergency Evacuation Signal System
25-135-00	25-135-00	25-135-00-01		VISUAL CHECK	First Aid Kits
25-140-00	25-140-00	25-140-00-01		RESTORE	Emergency Medical Kit
25-145-00	25-145-00	25-145-00-01		RESTORE	Automated External Defibrillator
25-150-00	25-150-00	25-150-00-01		VISUAL CHECK	Smokeyhoods
25-160-00	25-160-00	25-160-00-01		OPERATIONAL	Emergency Flashlights
25-170-00	25-170-00	25-170-00-01		REPLACE	Emergency Flashlight Batteries
25-180-00	25-180-00	25-180-00-01		REPLACE	Smokeyhoods
25-190-00	25-190-00	25-190-00-01		OPERATIONAL	Megaphones
25-200-00	25-200-00	25-200-00-01		REPLACE	Megaphone Batteries
25-210-00	25-210-00	25-210-00-01		RESTORE	Emergency Escape Slide/Rafts
25-230-00	25-230-00	25-230-00-01		VISUAL CHECK	Slide/Raft Inflation Cylinder Pressure





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
25-240-00	25-240-00	25-240-00-01 25-240-00-02		OPERATIONAL	Passenger Entry Door Emergency Escape Slide
25-250-00	25-250-00	25-250-00-01		INSPECTION - DETAILED	Overhead Flight Crew Rest (OFCR) Seat Assembly Lanyard
25-260-00	25-260-00	25-260-00-01 25-260-00-02		OPERATIONAL	Overhead Crew/Attendant Rests Secondary Egress System
25-270-00	25-270-00	25-270-00-01 25-270-00-02		INSPECTION - DETAILED	Overhead Crew/Attendant Rests Secondary Egress Grab Bar
25-290-00	25-290-00	25-290-00-01		FUNCTIONAL	Tip Alarm System (TAS)
25-320-00	25-320-00	25-320-00-01		INSPECTION - DETAILED	Rigid Cargo Barrier Sliding Door Seal
26-010-00	26-010-00	26-010-00-01		OPERATIONAL	Engine Fire/Overheat Detection
26-014-01	26-014-01	26-014-01-01		OPERATIONAL	Passenger Cabin, High Wall Suites Smoke Detector System
26-014-02	26-014-02	26-014-02-01		OPERATIONAL	Passenger Cabin, High Wall Suites Smoke Detectors System
26-014-03	26-014-03	26-014-03-01		RESTORE	Passenger Cabin, High Wall Suites Smoke Detector System
26-015-00	26-015-00	26-015-00-01		OPERATIONAL	APU Fire Detection Control Cards
26-020-00	26-020-00	26-020-00-01		OPERATIONAL	Duct Leak & Overheat Detection Control Card
26-030-00	26-030-00	26-030-00-01 26-030-00-02 26-030-00-03		OPERATIONAL	Lavatory and Overhead Cross-Aisle Stowage (If Installed) Smoke Detector Circuitry
26-035-00	26-035-00	26-035-00-01 26-035-00-04 26-035-00-05 26-035-00-06		OPERATIONAL	OFCR/OFAR Smoke Detector System
26-040-00	26-040-00	26-040-00-01 26-040-00-02 26-040-00-03		OPERATIONAL	Lavatory and Overhead Cross-Aisle Stowage (If Installed) Smoke Detectors



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
26-045-00	26-045-00	26-045-00-01 26-045-00-04 26-045-00-05 26-045-00-06		OPERATIONAL	OFCCR/OFAR Smoke Detector System
26-050-00	26-050-00	26-050-00-01	W-26-060-00-01	OPERATIONAL	Wheel Well Fire Detection Sensing Element
26-060-00	26-060-00	26-060-00-01	W-26-050-00-01	OPERATIONAL	Duct Leak and Overheat Detection Sensing Element
26-061-00	26-061-00	26-061-00-01		OPERATIONAL	Lower Lobe Attendant Rest (LLAR) Smoke Detection System
26-062-00	26-062-00	26-062-00-01		OPERATIONAL	Lower Lobe Attendant Rest Smoke Detection System
26-064-00	26-064-00	26-064-00-01		FUNCTIONAL	Lower Lobe Attendant Rest (LLAR) Smoke Detection System
26-066-00	26-066-00	26-066-00-01 26-066-00-02		FUNCTIONAL	Cargo Smoke Detector Water Separators
26-067-00	26-067-00	26-067-00-01 26-067-00-02		FUNCTIONAL	Cargo Compartment Smoke Detector Heaters and Controllers
26-068-00	26-068-00	26-068-00-01 26-068-00-02 26-068-00-03		OPERATIONAL	Flight Crew Rest (FCR) or Main Deck Crew Rest (MDCR) Smoke Detection System
26-069-00	26-069-00	26-069-00-01 26-069-00-02 26-069-00-03		FUNCTIONAL	Flight Crew Rest (FCR) or Main Deck Crew Rest (MDCR) Smoke Detection System
26-070-00	26-070-00	26-070-00-01 26-070-00-02 26-070-00-03		OPERATIONAL	Engine Fire Extinguishing Bottle Pressure Switches
26-090-00	26-090-00	26-090-00-01 26-090-00-02 26-090-00-03		OPERATIONAL	Engine Fire Switches
26-100-00	26-100-00	26-100-00-01 26-100-00-02 26-100-00-03		FUNCTIONAL	Engine Fire Extinguishing Distribution Lines
26-120-00	26-120-00	26-120-00-01		FUNCTIONAL	Engine Fire Bottle Extinguishing Bottle Pressure Switches



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
26-130-00	26-130-00	26-130-00-01		REPLACE	Engine Fire Bottle Squib Cartridges
26-140-00	26-140-00	26-140-00-01		OPERATIONAL	APU Fire Extinguishing Bottle Pressure Switch
26-150-00	26-150-00	26-150-00-01		FUNCTIONAL	APU Fire Switch
26-170-00	26-170-00	26-170-00-01		FUNCTIONAL	APU Fire Extinguishing Bottle Pressure Switch
26-180-00	26-180-00	26-180-00-01		REPLACE	APU Fire Bottle Squib Cartridges
26-190-00	26-190-00	26-190-00-01		OPERATIONAL	Cargo Fire Extinguishing Bottle Pressure Switches
26-200-00	26-200-00	26-200-00-01		OPERATIONAL	Cargo Fire Extinguishing Arm & Discharge Switches
26-201-00	26-201-00	26-201-00-01		OPERATIONAL	Main Deck Cargo Fire Extinguishing ARM and DEPRESSURIZATION Switches
26-210-00	26-210-00	26-210-00-01		FUNCTIONAL	Cargo Fire Extinguishing Tubing
26-220-00	26-220-00	26-220-00-01		FUNCTIONAL	Cargo Fire Extinguishing Bottle Pressure Switches
26-240-00	26-240-00	26-240-00-01		REPLACE	Cargo Compartment Fire Extinguishing Bottle SQUIB Cartridges
26-250-00	26-250-00	26-250-00-01		RESTORE	Cargo Fire Extinguishing System Filter/Regulator
26-260-00	26-260-00	26-260-00-01		REPLACE	Cargo Fire Extinguishing Flow Valve Squib Cartridges
26-270-00	26-270-00	26-270-00-01 26-270-00-02		INSPECTION - DETAILED	Lavatory Waste Compartment Fire Extinguisher Bottles
26-272-00	26-272-00	26-272-00-01		OPERATIONAL	Lower Lobe Attendant Rest Fire Extinguishing System
26-274-00	26-274-00	26-274-00-01		REPLACE	Lower Lobe Attendant Rest Fire Extinguishing System
26-276-00	26-276-00	26-276-00-01		VISUAL CHECK	LLAR Fire Extinguishing Tubing
26-277-00	26-277-00	26-277-00-01		OPERATIONAL	Lower Lobe Attendant Rest Fire Extinguishing System
26-278-00	26-278-00	26-278-00-01		FUNCTIONAL	Lower Lobe Attendant Rest Fire Extinguishing System
26-290-00	26-290-00	26-290-00-01 26-290-00-02		INSPECTION - DETAILED	Portable Halon Fire Extinguishers
26-300-00	26-300-00	26-300-00-01 26-300-00-02		INSPECTION - DETAILED	Portable Water Fire Extinguishers
27-010-00	27-010-00	27-010-00-01		SERVICE	Stabilizer Primary Brake Housing



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-020-00	27-020-00	27-020-00-01		SERVICE	Slat Power Drive Unit and Slat Electric Motor
27-030-00	27-030-00	27-030-00-01 27-030-00-02		SERVICE	Left and Right Inboard and Outboard Leading Edge No-Back Brake Offset Gearbox
27-040-00	27-040-00	27-040-00-01		SERVICE	Flap Power Drive Unit and Flap Electric Motor
27-050-00	27-050-00	27-050-00-01 27-050-00-02		SERVICE	Left and Right Inboard and Outboard Flap Transmissions
27-055-00	27-055-00	27-055-00-01		OPERATIONAL	Flap Transmission No Back Brakes
27-060-00	27-060-00	27-060-00-01 27-060-00-02		SERVICE	Left and Right Flap Skewed Roller No-Back Brakes
27-140-00	27-140-00	27-140-00-01		OPERATIONAL	Primary Flight Computers (PFC)
27-150-00	27-150-00	27-150-00-01		OPERATIONAL	Primary Flight Computer Disconnect Switch
27-160-00	27-160-00	27-160-00-01		OPERATIONAL	Actuator Control Electronics (ACE)
27-170-00	27-170-00	27-170-00-01 27-170-00-02 27-170-00-03		FUNCTIONAL	Wing Aileron and Flaperon System Hydraulic Fuses
27-180-00	27-180-00	27-180-00-01		FUNCTIONAL	Rudder Check Valve
27-190-00	27-190-00	27-190-00-01		OPERATIONAL	Wheel Jam Breakout Mechanism
27-200-00	27-200-00	27-200-00-01		FUNCTIONAL	Rudder Power Control Units
27-210-00	27-210-00	27-210-00-01		OPERATIONAL	Control Column Breakout Mechanism
27-220-00	27-220-00	27-220-00-01		OPERATIONAL	Elevator Power Control Units
27-230-00	27-230-00	27-230-00-01		FUNCTIONAL	Column Force Transducer
27-240-00	27-240-00	27-240-00-01		FUNCTIONAL	Elevator Power Control Unit Bearings
27-250-00	27-250-00	27-250-00-01		OPERATIONAL	Alternate Stabilizer Trim Control System
27-260-00	27-260-00	27-260-00-01		OPERATIONAL	Stabilizer Cutout Switches
27-270-00	27-270-00	27-270-00-01		OPERATIONAL	Stabilizer Secondary Brakes



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-280-00	27-280-00	27-280-00-01		FUNCTIONAL	Stabilizer Trim Limit Switches
27-290-00	27-290-00	27-290-00-01		INSPECTION - DETAILED	Stabilizer Ballscrew Safety Rod
27-300-00	27-300-00	27-300-00-01		INSPECTION - DETAILED	Stabilizer Trim Actuator Gimbals
27-310-00	27-310-00	27-310-00-01		OPERATIONAL	High Lift System Alternate Control Switches
27-320-00	27-320-00	27-320-00-01 27-320-00-02		FUNCTIONAL	Wing TE Flap No-Back Brakes - Left and Right
27-330-00	27-330-00	27-330-00-01		OPERATIONAL	Auto Speedbrake Function
27-340-00	27-340-00	27-340-00-01 27-340-00-02		OPERATIONAL	Leading Edge Slat No-Back Brakes - Left and Right
27-350-00	27-350-00	27-350-00-01		OPERATIONAL	Autoslat Priority Valves - Main Landing Gear
27-360-00	27-360-00	27-360-00-01 27-360-00-02		OPERATIONAL	Leading Edge Slat Skew/Loss Cable - Left and Right
27-370-00	27-370-00	27-370-00-01		REPLACE	Spoiler Auxiliary Retract Device (SARD) Pyrotechnic Cartridge
27-380-00	27-380-00	27-380-00-01		OPERATIONAL	Spoiler Auxiliary Retract Device (SARD) Operational Check
27-400-00	27-400-00	27-400-00-01		OPERATIONAL	Aileron Trim Inhibit Operational Check
27-410-00	27-410-00	27-410-00-01		FUNCTIONAL	Nose Gear Pressure Switch
27-415-00	27-415-00	27-415-00-01		FUNCTIONAL	Nose Gear Pressure Transducer
27-420-00	27-420-00	27-420-00-01		OPERATIONAL	Rudder Pedal Pogo
27-430-00	27-430-00	27-430-00-01		FUNCTIONAL	Rudder Power Control Unit
27-440-00	27-440-00	27-440-00-01		FUNCTIONAL	Stabilizer Freeplay
27-450-00	27-450-00	27-450-00-01		INSPECTION - DETAILED	Stabilizer Trim Ballscrew, Ballnut, and Ballnut Return Tubes
27-460-00	27-460-00	27-460-00-01		FUNCTIONAL	TRAILING EDGE FLAP SUPPORT LINKAGE PIN FREEPLAY
27-460-01	27-460-01	27-460-01-01		FUNCTIONAL	TRAILING EDGE FLAP SUPPORT LINKAGE PIN FREEPLAY



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
28-010-00	28-010-00	28-010-00-01		OPERATIONAL	Fuel Vent Float Valves
28-011-00	28-011-00	28-011-00-01 28-011-00-02		FUNCTIONAL	Hydraulic Tube Spar Penetration (SFAR 88)
28-012-00	28-012-00	28-012-00-01		VISUAL CHECK	Interspace drain valves (AUX TANK)
28-013-20	28-013-20	28-013-20-01 28-013-20-02		FUNCTIONAL	Pressure Relief Valve (SFAR 88)
28-013-30	28-013-30	28-013-30-01 28-013-30-02		FUNCTIONAL	Overfill Float Switch. (SFAR 88)
28-013-40	28-013-40	28-013-40-01 28-013-40-02		FUNCTIONAL	Vent Scoop Upper Duct (SFAR 88)
28-015-00	28-015-00	28-015-00-01 28-015-00-02		INSPECTION - GEN VISUAL	Surge Tank Vent Flame Arrestor
28-015-20	28-015-20	28-015-20-01 28-015-20-02 28-015-20-03 28-015-20-04 28-015-20-05		FUNCTIONAL	Scavenge Jet Pumps (SFAR 88)
28-020-00	28-020-00	28-020-00-01		OPERATIONAL	Engine Fuel Suction Feed System
28-021-10	28-021-10	28-021-10-01 28-021-10-02 28-021-10-03 28-021-10-04 28-021-10-05 28-021-10-06		INSPECTION - DETAILED	In-tank Tubing and Equipment Static Ground Straps and Clamps (SFAR 88)
28-021-20	28-021-20	28-021-20-01 28-021-20-02		FUNCTIONAL	Fueling Shutoff Valve (SFAR 88)
28-021-30	28-021-30	28-021-30-01 28-021-30-02		FUNCTIONAL	Fueling Receptacle (SFAR 88)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
28-022-30	28-022-30	28-022-30-01 28-022-30-02 28-022-30-03		FUNCTIONAL	Pump Housing (SFAR 88)
28-022-40	28-022-40	28-022-40-01 28-022-40-02 28-022-40-03		FUNCTIONAL	Boost, Center Tank Override/Jettison Pumps and Main Tank Jettison Pumps. (SFAR 88)
28-022-50	28-022-50	28-022-50-01 28-022-50-02 28-022-50-03		FUNCTIONAL	Motor Operated Valve (SFAR 88)
28-022-60	28-022-60	28-022-60-01 28-022-60-02		OPERATIONAL	GFI Relay Check
28-023-00	28-023-00	28-023-00-01		REPLACE	Fuel Spar Valve Battery
28-024-00	28-024-00	28-024-00-01		FUNCTIONAL	Transfer tube penetration (AUX TANK)
28-025-00	28-025-00	28-025-00-01 28-025-00-03		OPERATIONAL	Engine Fuel Spar Valve
28-025-20	28-025-20	28-025-20-01		FUNCTIONAL	APU DC Fuel Pump (SFAR 88)
28-025-30	28-025-30	28-025-30-01		FUNCTIONAL	APU Fuel Shutoff Valve (SFAR 88)
28-025-40	28-025-40	28-025-40-01		FUNCTIONAL	APU Isolation Valve (SFAR 88)
28-026-10	28-026-10	28-026-10-01		FUNCTIONAL	Defuel Valve (SFAR 88)
28-030-00	28-030-00	28-030-00-01		FUNCTIONAL	APU Fuel Supply Line And Shroud
28-031-20	28-031-20	28-031-20-01 28-031-20-02		FUNCTIONAL	Jettison Nozzle Valve (SFAR 88)
28-031-30	28-031-30	28-031-30-01 28-031-30-02		FUNCTIONAL	Jettison Isolation Valve (SFAR 88)
28-031-40	28-031-40	28-031-40-01 28-031-40-02		FUNCTIONAL	Jettison Nozzle Manifold (SFAR 88)
28-040-00	28-040-00	28-040-00-01		OPERATIONAL	Defuel Valve Actuator



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
28-041-10	28-041-10	28-041-10-01 28-041-10-02 28-041-10-03 28-041-10-04	W-28-070-00-01 W-28-060-00-01	INSPECTION - DETAILED	FQIS Wiring (SFAR 88)
28-041-20	28-041-20	28-041-20-01 28-041-20-02 28-041-20-03 28-041-20-04		INSPECTION - DETAILED	FQIS Equipment (SFAR 88)
28-041-30	28-041-30	28-041-30-01		FUNCTIONAL	FQIS - Out Tank Wiring (SFAR 88)
28-045-00	28-045-00	28-045-00-01		OPERATIONAL	EFLI tank circuits (AUX TANK)
28-045-10	28-045-10	28-045-10-01		OPERATIONAL	EFLI tank unit (AUX TANK)
28-045-20	28-045-20	28-045-20-01		OPERATIONAL	EFLI Processor Display Unit (AUX TANK)
28-050-00	28-050-00	28-050-00-01		OPERATIONAL	Fuel Jettison System
28-050-10	28-050-10	28-050-10-01		FUNCTIONAL	Fuel Scavenge System
28-060-00	28-060-00	28-060-00-01		OPERATIONAL	Densitometers of Fuel Quantity Indicating System
28-070-00	28-070-00	28-070-00-01		OPERATIONAL	Tank Units of Fuel Quantity Indicating System
28-080-00	28-080-00	28-080-00-01		OPERATIONAL	Fuel Quantity Processor Unit (FQPU)
29-010-00	29-010-00	29-010-00-01		SERVICE	Air Drive Unit
29-030-00	29-030-00	29-030-00-01		FUNCTIONAL	Hydraulic System Gross Internal Leakage
29-040-00	29-040-00	29-040-00-01 29-040-00-02 29-040-00-03		VISUAL CHECK	Center Hydraulic System Return Filter Module
29-050-00	29-050-00	29-050-00-01 29-050-00-02 29-050-00-03		CHECK/INSP	Hydraulic System Return Filter Module
29-060-00	29-060-00	29-060-00-01 29-060-00-02		CHECK/INSP	Hydraulic System EDP Pressure and Case Drain Filter Module





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE	
29-070-00	29-070-00	29-070-00-01 29-070-00-02		VISUAL CHECK	Hydraulic System EDP Pressure and Case Drain Filter Module	
29-080-00	29-080-00	29-080-00-01 29-080-00-02 29-080-00-03		CHECK/INSP	Hydraulic System ACMP Pressure and Case Drain Filter Module	
29-090-00	29-090-00	29-090-00-01 29-090-00-02 29-090-00-03		VISUAL CHECK	Hydraulic System ACMP Pressure and Case Drain Filter Module	
29-100-00	29-100-00	29-100-00-01		CHECK/INSP	ADP Pressure and Case Drain Filter Module	
29-110-00	29-110-00	29-110-00-01 29-110-00-02 29-110-00-03 29-110-00-04 29-110-00-05 29-110-00-06		VISUAL CHECK	ADP Pressure and Case Drain Filter Module	
29-120-00	29-120-00	29-120-00-01 29-120-00-02		FUNCTIONAL	Air Drive Unit (ADU) and ADU Heater System	
29-130-00	29-130-00	29-130-00-01		OPERATIONAL	Center Hydraulic Isolation System	
29-140-00	29-140-00	29-140-00-01 29-140-00-02 29-140-00-03		RESTORE	Hydraulic System Reservoir Pressurization Module	
29-150-00	29-150-00	29-150-00-01		B-29-160-00-01	OPERATIONAL	Ram Air Turbine
29-160-00	29-160-00	29-160-00-01		A-29-150-00-01	INSPECTION - GEN VISUAL	Ram Air Turbine
29-170-00	29-170-00	29-170-00-01		VISUAL CHECK	Ram Air Turbine	
29-180-00	29-180-00	29-180-00-01 29-180-00-02		FUNCTIONAL	Hydraulic Accumulators	
30-010-00	30-010-00	30-010-00-01		OPERATIONAL	Flight Compartment No. 1 Window Backup Anti-Fog	



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
31-010-00	31-010-00	31-010-00-01 31-010-00-02 31-010-00-03 31-010-00-04 31-010-00-05 31-010-00-06		FUNCTIONAL	Flight Data Recorder System
31-020-00	31-020-00	31-020-00-01 31-020-00-02		REPLACE	Flight Data Recorder System
31-030-00	31-030-00	31-030-00-01 31-030-00-02 31-030-00-03		OPERATIONAL	Flight Data Recorder Underwater Locator Beacon (ULB)
31-040-00	31-040-00	31-040-00-01		OPERATIONAL	Airplane Information Management System
31-050-00	31-050-00	31-050-00-01		OPERATIONAL	Airplane Information Management System - Coaxial Splitter
31-060-00	31-060-00	31-060-00-01		OPERATIONAL	Warning Electronic System
31-070-00	31-070-00	31-070-00-01		OPERATIONAL	Primary Display System - Inboard Select Switching
31-080-00	31-080-00	31-080-00-01		OPERATIONAL	Primary Display System - Instrument Source Select Switching
31-090-00	31-090-00	31-090-00-01		OPERATIONAL	Primary Display System - Display Control Switches
32-010-00	32-010-00	32-010-00-01		SERVICE	Tires
32-011-00	32-011-00	32-011-00-01		FUNCTIONAL	Tire Pressure Indication System (TPIS)
32-012-00	32-012-00	32-012-00-01		FUNCTIONAL	Tire and Brake Monitoring System (TBMS)
32-020-00	32-020-00	32-020-00-01		FUNCTIONAL	Brake Accumulator
32-120-00	32-120-00	32-120-00-01		OPERATIONAL	Landing Gear Alternate Extension System
32-130-00	32-130-00	32-130-00-01		OPERATIONAL	Landing Gear Downlock Springs and Gear Release Hooks
32-140-00	32-140-00	32-140-00-01		OPERATIONAL	Alternate Source Select Valve
32-150-00	32-150-00	32-150-00-01		OPERATIONAL	Accumulator Isolation Valve
32-160-00	32-160-00	32-160-00-01		FUNCTIONAL	Brake Accumulator
32-170-00	32-170-00	32-170-00-01		FUNCTIONAL	Normal and Alternate Brake Systems



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
32-180-00	32-180-00	32-180-00-01 32-180-00-02	P-32-260-00-01 R-32-250-00-01	FUNCTIONAL	Main Landing Gear Antiskid Module Hydraulic Fuses - Left and Right
32-190-00	32-190-00	32-190-00-01		INSPECTION - GEN VISUAL	Wheels
32-200-00	32-200-00	32-200-00-01		INSPECTION - GEN VISUAL	Tires
32-210-00	32-210-00	32-210-00-01		INSPECTION - GEN VISUAL	Brakes
32-220-00	32-220-00	32-220-00-01		RESTORE	Main Landing Gear
32-230-00	32-230-00	32-230-00-01		RESTORE	Nose Landing Gear
32-240-00	32-240-00	32-240-00-01		VISUAL CHECK	Tail Skid
32-250-00	32-250-00	32-250-00-01		SERVICE	Main Landing Gear Shock Strut Servicing
32-260-00	32-260-00	32-260-00-01		FUNCTIONAL	Main Landing Gear Shock Strut Dimension "A"
32-270-00	32-270-00	32-270-00-01		VISUAL CHECK	Nose Landing Gear Pressure Gage
32-280-00	32-280-00	32-280-00-01		SERVICE	Nose Landing Gear Shock Strut Servicing
32-300-00	32-300-00	32-300-00-01 32-300-00-02		INSPECTION - GEN VISUAL	Main Landing Gear Mechanisms
32-310-00	32-310-00	32-310-00-01 32-310-00-02		INSPECTION - GEN VISUAL	Main Landing Gear Door Mechanisms
32-320-00	32-320-00	32-320-00-01		INSPECTION - GEN VISUAL	Nose Landing Gear Mechanisms
32-330-00	32-330-00	32-330-00-01		INSPECTION - GEN VISUAL	Nose Landing Gear Door Mechanisms
32-800-00	32-800-00	32-800-00-01		ZONAL (GV)	Nose Landing Gear and Landing Gear Doors - From the Ground
32-802-00	32-802-00	32-802-00-01		ZONAL (GV)	Nose Landing Gear and Landing Gear Doors
32-804-01	32-804-01	32-804-01-01		ZONAL (GV)	Left Main Landing Gear and Landing Gear Doors - From the Ground
32-806-01	32-806-01	32-806-01-01		ZONAL (GV)	Left Main Landing Gear and Landing Gear Doors



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
32-808-02	32-808-02	32-808-02-01		ZONAL (GV)	Right Main Landing Gear and Landing Gear Doors - From the Ground
32-810-02	32-810-02	32-810-02-01		ZONAL (GV)	Right Main Landing Gear and Landing Gear Doors
33-010-00	33-010-00	33-010-00-01		OPERATIONAL	Flight Compartment Panel Flood Lights
33-020-00	33-020-00	33-020-00-01		OPERATIONAL	Integral Panel Lights
33-030-00	33-030-00	33-030-00-01		OPERATIONAL	Integral Panel Lights
33-040-00	33-040-00	33-040-00-01		OPERATIONAL	Indicator Lights DIM/BRT Relays
33-060-00	33-060-00	33-060-00-01		OPERATIONAL	Emergency Lights
33-070-00	33-070-00	33-070-00-01		OPERATIONAL	Emergency Lights
33-075-00	33-075-00	33-075-00-01		INSPECTION - GEN VISUAL	Photoluminescent floor proximity lighting.
33-076-00	33-076-00	33-076-00-01		FUNCTIONAL	Cabin ceiling lighting intensity
33-080-00	33-080-00	33-080-00-01		FUNCTIONAL	Emergency Lights Battery Packs
33-090-00	33-090-00	33-090-00-01		RESTORE	Emergency Lights Battery Packs
33-095-00	33-095-00	33-095-00-01 33-095-00-02 33-095-00-03 33-095-00-04 33-095-00-05 33-095-00-06		RESTORE	OFAR/OFAR Backup Lighting Power Supply Battery Packs
33-100-00	33-100-00	33-100-00-01		OPERATIONAL	Lower Lobe Attendant Rest (LLAR) Back-up Lighting System
33-105-00	33-105-00	33-105-00-01 33-105-00-02 33-105-00-03 33-105-00-04 33-105-00-05 33-105-00-06		OPERATIONAL	Overhead Flight Crew Rest and/or Overhead Flight Attendant Rest Backup Lights System
33-110-00	33-110-00	33-110-00-01		FUNCTIONAL	Lower Lobe Attendant Rest (LLAR) Back-up Lighting System



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
33-115-00	33-115-00	33-115-00-01 33-115-00-02 33-115-00-03 33-115-00-04 33-115-00-05 33-115-00-06		FUNCTIONAL	OFCR/OFAR Back-up Lighting Power Packs
33-120-00	33-120-00	33-120-00-01		RESTORE	Lower Lobe Attendant Rest (LLAR) Back-up Lighting System
35-020-00	35-020-00	35-020-00-01		CHECK/INSP	Crew Oxygen System
35-040-00	35-040-00	35-040-00-01		OPERATIONAL	Crew Oxygen Mask, Diluter Demand Regulator, and Microphone
35-050-00	35-050-00	35-050-00-01		INSPECTION - DETAILED	Crew Oxygen Masks
35-060-00	35-060-00	35-060-00-01 35-060-00-02 35-060-00-03 35-060-00-04		OPERATIONAL	Passenger Oxygen System Door Latch/Actuator
35-070-00	35-070-00	35-070-00-01 35-070-00-02 35-070-00-03		VISUAL CHECK	Passenger Chemical Oxygen Generators
35-071-00	35-071-00	35-071-00-01		VISUAL CHECK	Lavatory Constant Dispensing (CDS) oxygen System
35-080-00	35-080-00	35-080-00-01 35-080-00-02 35-080-00-03 35-080-00-04		DISCARD	Passenger Chemical Oxygen Generators
35-081-00	35-081-00	35-081-00-01		DISCARD	Lavatory oxygen Constant Dispensing System (CDS) cylinder discard.
35-090-00	35-090-00	35-090-00-01 35-090-00-02 35-090-00-03 35-090-00-04 35-090-00-05 35-090-00-06 35-090-00-07		INSPECTION - DETAILED	Passenger Oxygen Masks



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
35-110-00	35-110-00	35-110-00-01 35-110-00-02	W-35-161-00-01 W-35-160-00-01	OPERATIONAL	Passenger Gaseous Oxygen System Pressure Lines
35-120-00	35-120-00	35-120-00-01 35-120-00-02		OPERATIONAL	Passenger/ Supernumerary Gaseous Oxygen System Pressure Regulator
35-130-00	35-130-00	35-130-00-01		OPERATIONAL	Therapeutic Oxygen System
35-140-00	35-140-00	35-140-00-01 35-140-00-02		OPERATIONAL	Passenger/ Supernumerary Gaseous Oxygen System Flow Control Units
35-160-00	35-160-00	35-160-00-01		CHECK/INSP	Portable Oxygen Equipment Pressure
35-161-00	35-161-00	35-161-00-01		INSPECTION - GEN VISUAL	Portable oxygen disposable type masks
35-162-00	35-162-00	35-162-00-01		INSPECTION - DETAILED	Portable oxygen non-disposable type masks
35-163-00	35-163-00	35-163-00-01		DISCARD	Portable oxygen cylinders
35-164-00	35-164-00	35-164-00-01		DISCARD	Crew Oxygen Cylinders
35-220-00	35-220-00	35-220-00-01		FUNCTIONAL	Supernumerary Oxygen System Pressure Decay
35-230-00	35-230-00	35-230-00-01 35-230-00-02		INSPECTION - GEN VISUAL	Supernumerary Oxygen System Pressure Indications
35-240-00	35-240-00	35-240-00-01		OPERATIONAL	Supernumerary Cylinder Pressure Regulator
35-250-00	35-250-00	35-250-00-01		OPERATIONAL	Supernumerary System Pressure Regulator
35-260-00	35-260-00	35-260-00-01		OPERATIONAL	Supernumerary Stowage Box and Mask Regulator
35-270-00	35-270-00	35-270-00-01		OPERATIONAL	Supernumerary Oxygen Mask and Diluter Demand Regulator
35-280-00	35-280-00	35-280-00-01		VISUAL CHECK	Supernumerary Oxygen Masks
36-010-00	36-010-00	36-010-00-01		FUNCTIONAL	Engine Air Supply Manifold
36-020-00	36-020-00	36-020-00-01 36-020-00-02		FUNCTIONAL	Engine Air Supply IP Check Valve - Left and Right



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
36-022-00	36-022-00	36-022-00-01 36-022-00-02 36-022-00-03 36-022-00-04		FUNCTIONAL	Engine Air Supply IP Check Valve - Left and Right
36-024-00	36-024-00	36-024-00-01 36-024-00-02		FUNCTIONAL	Engine Air Supply IP Check Valve - Left and Right
36-030-00	36-030-00	36-030-00-01		OPERATIONAL	Air Supply Manifold Dual Temperature Sensor
38-010-00	38-010-00	38-010-00-01		DISINFECT	Potable Water Supply System
38-020-00	38-020-00	38-020-00-01		OPERATIONAL	Potable Water Isolation Valves and Cables
38-030-00	38-030-00	38-030-00-01 38-030-00-02 38-030-00-03 38-030-00-04		FUNCTIONAL	Waste Drain Ball Valve & Fitting Seals
38-050-00	38-050-00	38-050-00-01 38-050-00-02 38-050-00-03		RESTORE	Waste Tank Liquid Separators
38-070-00	38-070-00	38-070-00-01 38-070-00-02		RESTORE	Vacuum Blower Air Filter
38-080-00	38-080-00	38-080-00-01 38-080-00-02		OPERATIONAL	Waste Tank Quantity Indication System
38-090-00	38-090-00	38-090-00-01		OPERATIONAL	Waste Tank Quantity Indication
38-100-00	38-100-00	38-100-00-01		REPLACE	Compressor Inlet Filter
38-110-00	38-110-00	38-110-00-01		REPLACE	APU Duct Bleed Air Inline Filter
38-120-00	38-120-00	38-120-00-01		OPERATIONAL	Potable Water Pressure Relief Valve
38-130-00	38-130-00	38-130-00-01		OPERATIONAL	Potable Water System Pressure Limit Switch and Relay Circuit
38-140-00	38-140-00	38-140-00-01		RESTORE	Fill Line Water Filter of Pump Based Potable Water System
47-100-00	47-100-00	47-100-00-01		RESTORE	Restore the Ozone Converter (off-aircraft).
47-110-00	47-110-00	47-110-00-01		RESTORE	Clean the Primary Heat Exchanger (off-aircraft).



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
47-120-00	47-120-00	47-120-00-01		FUNCTIONAL	Functionally check the Regenerative Heat Exchanger (off-aircraft).
47-130-00	47-130-00	47-130-00-01		FUNCTIONAL	Functionally Check the Filter Differential Pressure Sensor Switch (off-aircraft).
47-140-00	47-140-00	47-140-00-01		VISUAL CHECK	Visually Check for Fluid Accumulation Through the Drain Valve or Drain Cap.
47-150-00	47-150-00	47-150-00-01		INSPECTION - DETAILED	Inspect (detailed) the Nitrogen Enriched Air (NEA) distribution lines
47-160-00	47-160-00	47-160-00-01		OPERATIONAL	Operationally check the center tank vent cross flow check valve.
49-010-00	49-010-00	49-010-00-01		SERVICE	APU and Generator Lubrication System
49-020-00	49-020-00	49-020-00-01		REPLACE	APU 1st & 2ND Stage Compressor Impellers
49-030-00	49-030-00	49-030-00-01		REPLACE	APU Turbine Wheels
49-040-00	49-040-00	49-040-00-01		REPLACE	APU Load Compressor Impeller
49-060-00	49-060-00	49-060-00-01		FUNCTIONAL	APU Combustor Drain Valve
52-009-00	52-009-00	52-009-00-01		INSPECTION - DETAILED	Main Deck Cargo Door seals.
52-009-10	52-009-10	52-009-10-01		INSPECTION - DETAILED	Main Deck Cargo vent door seal
52-010-00	52-010-00	52-010-00-01		INSPECTION - DETAILED	Passenger Entry Door Seals and Vent Door Seals
52-015-00	52-015-00	52-015-00-01		INSPECTION - DETAILED	No. 3 Over-Wing Door Seals and Vent Door Seals
52-020-00	52-020-00	52-020-00-01		INSPECTION - DETAILED	Forward Large Cargo Door Seals and Vent Door Seals
52-025-00	52-025-00	52-025-00-01		INSPECTION - DETAILED	AFT Large Cargo Door Seals and Vent Door Seals
52-030-00	52-030-00	52-030-00-01		INSPECTION - DETAILED	AFT Small Cargo Door Seals and Vent Door Seals
52-032-00	52-032-00	52-032-00-01		LUBRICATE	Main Deck Cargo Door mechanism.
52-032-10	52-032-10	52-032-10-01		LUBRICATE	Main Deck Cargo Door hinge pin.





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-032-20	52-032-20	52-032-20-01		OPERATIONAL	Manual drive mechanism of Main Deck Cargo Door.
52-032-30	52-032-30	52-032-30-01		FUNCTIONAL	Lock control switches.
52-032-40	52-032-40	52-032-40-01		LUBRICATE	Main Deck Cargo Door Latch Pins and Cam Latches
52-040-00	52-040-00	52-040-00-01		INSPECTION - DETAILED	Bulk Cargo Door Seals
52-050-00	52-050-00	52-050-00-01		INSPECTION - DETAILED	Forward Access Door Seal
52-060-00	52-060-00	52-060-00-01		INSPECTION - DETAILED	Main Equipment Center Door Seals
52-070-00	52-070-00	52-070-00-01		REPLACE	Passenger Entry Door EPAS SQUIBS
52-070-01	52-070-01	52-070-01-01		REPLACE	Passenger Entry Door EPAS SQUIBS
52-070-02	52-070-02	52-070-02-01		DISCARD	Passenger Entry Door EPAS SQUIBS
52-075-00	52-075-00	52-075-00-01		REPLACE	No. 3 Over-Wing Door EPAS Squibs
52-090-00	52-090-00	52-090-00-01 52-090-00-02 52-090-00-03		OPERATIONAL	Passenger Entry Door EPAS Battery
52-090-01	52-090-01	52-090-01-01 52-090-01-02		OPERATIONAL	Passenger Entry Door EPAS Battery
52-090-02	52-090-02	52-090-02-01		OPERATIONAL	Passenger Entry Door EPAS Battery
52-091-00	52-091-00	52-091-00-01 52-091-00-02		RESTORE	Passenger Entry Door EPAS Battery
52-091-01	52-091-01	52-091-01-01 52-091-01-02		RESTORE	Passenger Entry Door EPAS Battery
52-091-02	52-091-02	52-091-02-01		RESTORE	Passenger Entry Door EPAS Battery
52-095-00	52-095-00	52-095-00-01		OPERATIONAL	No. 3 Over-wing Door EPAS/Backup Battery
52-096-00	52-096-00	52-096-00-01		RESTORE	No. 3 Over-Wing Door EPAS/Backup Battery
52-100-00	52-100-00	52-100-00-01		VISUAL CHECK	Passenger Entry Door Girt Bar Floor Fittings



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-100-01	52-100-01	52-100-01-01		VISUAL CHECK	Passenger Entry Door Girt Bar Floor Fittings
52-100-02	52-100-02	52-100-02-01		VISUAL CHECK	Passenger Entry Door Girt Bar Floor Fittings
52-110-00	52-110-00	52-110-00-01		VISUAL CHECK	Passenger Entry Door EPAS Pressure Gauge
52-110-01	52-110-01	52-110-01-01		VISUAL CHECK	Passenger Entry Door EPAS Pressure Gauge
52-110-02	52-110-02	52-110-02-01		VISUAL CHECK	Passenger Entry Door EPAS Pressure Gauge
52-115-00	52-115-00	52-115-00-01		VISUAL CHECK	No. 3 Over-Wing Door EPAS Pressure Gauge
52-120-00	52-120-00	52-120-00-01		INSPECTION - DETAILED	Passenger Entry Door Flight Lock Mechanism
52-120-01	52-120-01	52-120-01-01		INSPECTION - DETAILED	Passenger Entry Door Flight Lock Mechanism
52-120-02	52-120-02	52-120-02-01		INSPECTION - DETAILED	Passenger Entry Door Flight Lock Mechanism
52-125-00	52-125-00	52-125-00-01		INSPECTION - DETAILED	No. 3 Over-Wing Door Flight Lock Mechanism
52-130-00	52-130-00	52-130-00-01		INSPECTION - DETAILED	Passenger Entry Door Girt Bar Mechanism Interlock
52-130-01	52-130-01	52-130-01-01		INSPECTION - DETAILED	Passenger Entry Door Girt Bar Mechanism Interlock
52-130-02	52-130-02	52-130-02-01		INSPECTION - DETAILED	Passenger Entry Door Girt Bar Mechanism Interlock
52-135-00	52-135-00	52-135-00-01		INSPECTION - DETAILED	No. 3 Over-Wing Door Latch Torque Tube Interlock
52-140-00	52-140-00	52-140-00-01		INSPECTION - DETAILED	Passenger Entry Door Mode Select Mechanism and Cables
52-140-01	52-140-01	52-140-01-01		INSPECTION - DETAILED	Passenger Entry Door Mode Select Mechanism and Cables
52-140-02	52-140-02	52-140-02-01		INSPECTION - DETAILED	Passenger Entry Door Mode Select Mechanism and Cables



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-145-00	52-145-00	52-145-00-01	W-52-167-00-01 W-52-167-00-02	INSPECTION - DETAILED	No. 3 Over-Wing Doors Mode Select Mechanism and Pull Cable
52-150-00	52-150-00	52-150-00-01		INSPECTION - DETAILED	Passenger Entry Door EPAS Tubing
52-150-01	52-150-01	52-150-01-01		INSPECTION - DETAILED	Passenger Entry Door EPAS Tubing
52-150-02	52-150-02	52-150-02-01		INSPECTION - DETAILED	Passenger Entry Door EPAS Tubing
52-155-00	52-155-00	52-155-00-01		INSPECTION - DETAILED	No. 3 Over-Wing Doors EPAS Tubing
52-160-00	52-160-00	52-160-00-01 52-160-00-02 52-160-00-03 52-160-00-04		FUNCTIONAL	Passenger Entry Door EPAS Circuitry
52-165-00	52-165-00	52-165-00-01 52-165-00-02		FUNCTIONAL	No. 3 Over-Wing Door Circuitry
52-166-00	52-166-00	52-166-00-01		FUNCTIONAL	No. 3 Over-Wing Door EPAS Battery Circuitry
52-167-00	52-167-00	52-167-00-01 52-167-00-02		FUNCTIONAL	No. 3 Over-Wing Door Backup Battery Circuitry
52-170-00	52-170-00	52-170-00-01		FUNCTIONAL	Passenger Entry Door Mechanisms
52-170-01	52-170-01	52-170-01-01		FUNCTIONAL	Passenger Entry Door Mechanisms
52-170-02	52-170-02	52-170-02-01		FUNCTIONAL	Passenger Entry Door Mechanisms
52-175-00	52-175-00	52-175-00-01		FUNCTIONAL	No. 3 Over-Wing Door Mechanisms
52-180-00	52-180-00	52-180-00-01		OPERATIONAL	Forward Large Cargo Door Manual Drive Mechanism & Lift PDU Brake
52-185-00	52-185-00	52-185-00-01		OPERATIONAL	AFT Large Cargo Door Manual Drive Mechanism & Lift PDU Brake
52-190-00	52-190-00	52-190-00-01		OPERATIONAL	Forward Large Cargo Door Rotary Actuator No-Back
52-195-00	52-195-00	52-195-00-01		OPERATIONAL	AFT Large Cargo Door Rotary Actuator No-Back
52-200-00	52-200-00	52-200-00-01		FUNCTIONAL	Forward Large Cargo Door Lock Handle Load Limiter



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-205-00	52-205-00	52-205-00-01		FUNCTIONAL	AFT Large Cargo Door Lock Handle Load Limiter
52-210-00	52-210-00	52-210-00-01		OPERATIONAL	Forward Large Cargo Door Ditching Interlock Mechanism
52-215-00	52-215-00	52-215-00-01		OPERATIONAL	AFT Large Cargo Door Ditching Interlock Mechanism
52-220-00	52-220-00	52-220-00-01		OPERATIONAL	AFT Small Cargo Door Hinge Power Drive Unit and Manual Drive Mechanism
52-230-00	52-230-00	52-230-00-01		OPERATIONAL	AFT Small Cargo Door Rotary Actuator
52-240-00	52-240-00	52-240-00-01		INSPECTION - DETAILED	Bulk Cargo Door Latch Mechanism
52-250-00	52-250-00	52-250-00-01		INSPECTION - DETAILED	Equipment Compartment Exterior Door Latch Mechanisms
52-255-00	52-255-00	52-255-00-01		OPERATIONAL	Lower Lobe Attendant Rest Emergency Exit Hatch
52-260-00	52-260-00	52-260-00-01		OPERATIONAL	Passenger Entry Door Closed Proximity Sensors
52-265-00	52-265-00	52-265-00-01		OPERATIONAL	No. 3 Over-Wing Doors Closed Proximity Sensors
52-305-00	52-305-00	52-305-00-01		INSPECTION - DETAILED	Flight Deck Door Decompression Panel Latches and Hinges
52-310-00	52-310-00	52-310-00-01		OPERATIONAL	Flight Deck Door Pressure Sensor
52-315-00	52-315-00	52-315-00-01		VISUAL CHECK	FLIGHT DECK DOOR SEALS AND BREAKAWAY PANEL SEAL
52-320-00	52-320-00	52-320-00-01		VISUAL CHECK	Flight Deck Door Decompression Panel Trim Ring Seals
52-501-00	52-501-00	52-501-00-01		GENERAL VISUAL	Forward Large Cargo Door
52-502-00	52-502-00	52-502-00-01		DETAILED	Forward Large Cargo Door
52-503-00	52-503-00	52-503-00-01		DETAILED	Forward Large Cargo Door
52-504-00	52-504-00	52-504-00-01		DETAILED	Forward Large Cargo Door
52-505-00	52-505-00	52-505-00-01		DETAILED	Forward Large Cargo Door
52-506-00	52-506-00	52-506-00-01		GENERAL VISUAL	Aft Small Cargo Door



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-507-00	52-507-00	52-507-00-01		GENERAL VISUAL	Bulk Cargo Door
52-508-00	52-508-00	52-508-00-01		GENERAL VISUAL	Bulk Cargo Door
52-509-00	52-509-00	52-509-00-01		GENERAL VISUAL	Aft Large Cargo Door
52-510-00	52-510-00	52-510-00-01		DETAILED	Aft Large Cargo Door
52-511-00	52-511-00	52-511-00-01		DETAILED	Aft Large Cargo Door
52-512-00	52-512-00	52-512-00-01		DETAILED	Aft Large Cargo Door
52-513-00	52-513-00	52-513-00-01		DETAILED	Aft Large Cargo Door
52-520-01	52-520-01	52-520-01-01		GENERAL VISUAL	Left #1 Entry Door
52-521-01	52-521-01	52-521-01-01		GENERAL VISUAL	Left #2 Passenger Entry Door
52-522-01	52-522-01	52-522-01-01		GENERAL VISUAL	Left #3 Overwing Door
52-523-01	52-523-01	52-523-01-01		GENERAL VISUAL	Left #3 Passenger Entry Door
52-524-01	52-524-01	52-524-01-01		GENERAL VISUAL	Left #4 Passenger Entry Door
52-525-01	52-525-01	52-525-01-01		GENERAL VISUAL	Left #4 Passenger Entry Door
52-526-01	52-526-01	52-526-01-01		GENERAL VISUAL	Left #5 Passenger Entry Door
52-527-01	52-527-01	52-527-01-01		DETAILED	Left #1 Entry Door
52-528-01	52-528-01	52-528-01-01		DETAILED	Left #2 Passenger Entry Door
52-529-01	52-529-01	52-529-01-01		DETAILED	Left #3 Overwing Door
52-530-01	52-530-01	52-530-01-01		DETAILED	Left #3 Passenger Entry Door



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-531-01	52-531-01	52-531-01-01		DETAILED	Left #4 Passenger Entry Door
52-532-01	52-532-01	52-532-01-01		DETAILED	Left #4 Passenger Entry Door
52-533-01	52-533-01	52-533-01-01		DETAILED	Left #5 Passenger Entry Door
52-535-02	52-535-02	52-535-02-01		GENERAL VISUAL	Right #1 Entry Door
52-536-02	52-536-02	52-536-02-01		GENERAL VISUAL	Right #2 Passenger Entry Door
52-537-02	52-537-02	52-537-02-01		GENERAL VISUAL	Right #3 Overwing Door
52-538-02	52-538-02	52-538-02-01		GENERAL VISUAL	Right #3 Passenger Entry Door
52-539-02	52-539-02	52-539-02-01		GENERAL VISUAL	Right #4 Passenger Entry Door
52-540-02	52-540-02	52-540-02-01		GENERAL VISUAL	Right #4 Passenger Entry Door
52-541-02	52-541-02	52-541-02-01		GENERAL VISUAL	Right #5 Passenger Entry Door
52-542-02	52-542-02	52-542-02-01		DETAILED	Right #1 Entry Door
52-543-02	52-543-02	52-543-02-01		DETAILED	Right #2 Passenger Entry Door
52-544-02	52-544-02	52-544-02-01		DETAILED	Right #3 Overwing Door
52-545-02	52-545-02	52-545-02-01		DETAILED	Right #3 Passenger Entry Door
52-546-02	52-546-02	52-546-02-01		DETAILED	Right #4 Passenger Entry Door
52-547-02	52-547-02	52-547-02-01		DETAILED	Right #4 Passenger Entry Door
52-548-02	52-548-02	52-548-02-01		DETAILED	Right #5 Passenger Entry Door
52-549-00	52-549-00	52-549-00-01		GENERAL VISUAL	Main Deck Cargo Door
52-550-00	52-550-00	52-550-00-01		DETAILED	Main Deck Cargo Door



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-551-00	52-551-00	52-551-00-01		DETAILED	Main Deck Cargo Door
52-552-00	52-552-00	52-552-00-01		DETAILED	Main Deck Cargo Door
52-553-00	52-553-00	52-553-00-01		GENERAL VISUAL	Main Deck Cargo Door
52-554-00	52-554-00	52-554-00-01		DETAILED	Main Deck Cargo Door
52-730-00	52-730-00	52-730-00-01		GENERAL VISUAL	Flight Deck Security Door
52-802-00	52-802-00	52-802-00-01		ZONAL (GV)	Forward Large Cargo Door
52-804-00	52-804-00	52-804-00-01		ZONAL (GV)	Forward Large Cargo Door
52-806-00	52-806-00	52-806-00-01		ZONAL (GV)	Aft Small Cargo Door
52-808-00	52-808-00	52-808-00-01		ZONAL (GV)	Aft Small Cargo Door
52-810-00	52-810-00	52-810-00-01		ZONAL (GV)	Aft Large Cargo Door
52-812-00	52-812-00	52-812-00-01		ZONAL (GV)	Aft Large Cargo Door
52-814-00	52-814-00	52-814-00-01		ZONAL (GV)	Bulk Cargo Door
52-816-01	52-816-01	52-816-01-01		ZONAL (GV)	Left No. 1 Passenger/Crew Entry Door - Section 41
52-818-01	52-818-01	52-818-01-01		ZONAL (GV)	Left No. 1 Passenger/Crew Entry Door - Section 41
52-820-01	52-820-01	52-820-01-01		ZONAL (GV)	Left No. 2 Passenger Entry Door - Section 43
52-822-01	52-822-01	52-822-01-01		ZONAL (GV)	Left No. 2 Passenger Entry Door - Section 43
52-824-01	52-824-01	52-824-01-01		ZONAL (GV)	Left No. 3 Overwing Door - Section 44
52-825-01	52-825-01	52-825-01-01		ZONAL (GV)	Left No. 3 Overwing Door - Section 44
52-826-01	52-826-01	52-826-01-01		ZONAL (GV)	Left No. 3 Passenger Entry Door - Section 46
52-827-01	52-827-01	52-827-01-01		ZONAL (GV)	Left No. 4 Passenger Entry Door - Section 46
52-828-01	52-828-01	52-828-01-01		ZONAL (GV)	Left No. 3 Passenger Entry Door - Section 46
52-829-01	52-829-01	52-829-01-01		ZONAL (GV)	Left No. 4 Passenger Entry Door - Section 46



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-830-01	52-830-01	52-830-01-01		ZONAL (GV)	Left No. 4 Passenger Entry Door - Section 47
52-831-01	52-831-01	52-831-01-01		ZONAL (GV)	Left No. 5 Passenger Entry Door - Section 47
52-832-01	52-832-01	52-832-01-01		ZONAL (GV)	Left No. 4 Passenger Entry Door - Section 47
52-833-01	52-833-01	52-833-01-01		ZONAL (GV)	Left No. 5 Passenger Entry Door - Section 47
52-834-02	52-834-02	52-834-02-01		ZONAL (GV)	Right No. 1 Passenger/Crew Entry Door - Section 41
52-836-02	52-836-02	52-836-02-01		ZONAL (GV)	Right No. 1 Passenger/Crew Entry Door - Section 41
52-840-02	52-840-02	52-840-02-01		ZONAL (GV)	Right No. 2 Passenger Entry Door - Section 43
52-842-02	52-842-02	52-842-02-01		ZONAL (GV)	Right No. 2 Passenger Entry Door - Section 43
52-844-02	52-844-02	52-844-02-01		ZONAL (GV)	Right No. 3 Overwing Door - Section 44
52-846-02	52-846-02	52-846-02-01		ZONAL (GV)	Right No. 3 Overwing Door - Section 44
52-848-02	52-848-02	52-848-02-01		ZONAL (GV)	Right No. 3 Passenger Entry Door - Section 46
52-849-02	52-849-02	52-849-02-01		ZONAL (GV)	Right No. 4 Passenger Entry Door - Section 46
52-850-02	52-850-02	52-850-02-01		ZONAL (GV)	Right No. 3 Passenger Entry Door - Section 46
52-851-02	52-851-02	52-851-02-01		ZONAL (GV)	Right No. 4 Passenger Entry Door - Section 46
52-852-02	52-852-02	52-852-02-01		ZONAL (GV)	Right No. 4 Passenger Entry Door - Section 47
52-853-02	52-853-02	52-853-02-01		ZONAL (GV)	Right No. 5 Passenger Entry Door - Section 47
52-854-02	52-854-02	52-854-02-01		ZONAL (GV)	Right No. 4 Passenger Entry Door - Section 47
52-855-02	52-855-02	52-855-02-01		ZONAL (GV)	Right No. 5 Passenger Entry Door - Section 47
52-856-00	52-856-00	52-856-00-01		ZONAL (GV)	Main Deck Cargo Door
52-858-00	52-858-00	52-858-00-01		ZONAL (GV)	Main Deck Cargo Door
53-501-00	53-501-00	53-501-00-01		GENERAL VISUAL	Area Forward of Nose Landing Gear Wheel Well and Forward Access Door
53-502-00	53-502-00	53-502-00-01		GENERAL VISUAL	Area Outboard and Above Nose Landing Gear Wheel Well
53-503-00	53-503-00	53-503-00-01		DETAILED	Left Area Outboard and Above Nose Landing Gear Wheel Well





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-504-00	53-504-00	53-504-00-01		DETAILED	Right Area Outboard and Above Nose Landing Gear Wheel Well
53-505-00	53-505-00	53-505-00-01		GENERAL VISUAL	Main Equipment Center and Main Equipment Center Access Door
53-506-00	53-506-00	53-506-00-01		DETAILED	Main Equipment Center
53-507-00	53-507-00	53-507-00-01		DETAILED	Main Equipment Center
53-508-00	53-508-00	53-508-00-01		GENERAL VISUAL	Main Equipment Center
53-509-00	53-509-00	53-509-00-01		GENERAL VISUAL	Forward Cargo Compartment
53-509-01	53-509-01	53-509-01-01		GENERAL VISUAL	Forward Cargo Compartment
53-511-00	53-511-00	53-511-00-01		DETAILED	Forward Cargo Compartment
53-512-00	53-512-00	53-512-00-01 53-512-00-02 53-512-00-03 53-512-00-04 53-512-00-05		DETAILED	Forward Cargo Compartment
53-512-01	53-512-01	53-512-01-01		DETAILED	Forward Cargo Compartment
53-513-00	53-513-00	53-513-00-01		GENERAL VISUAL	Area Below Forward Cargo Compartment
53-514-00	53-514-00	53-514-00-01		GENERAL VISUAL	Area Below Forward Cargo Compartment
53-515-00	53-515-00	53-515-00-01 53-515-00-02 53-515-00-03 53-515-00-04 53-515-00-05 53-515-00-06		DETAILED	Area Below Forward Cargo Compartment
53-516-00	53-516-00	53-516-00-01		GENERAL VISUAL	Area Aft of Forward Cargo Compartment - Body Station 998 to 1035



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-516-01	53-516-01	53-516-01-01		GENERAL VISUAL	Area Aft of Forward Cargo Compartment - Body Station 998 to 1035
53-517-00	53-517-00	53-517-00-01		GENERAL VISUAL	Forward Cargo Compartment Lower Lobe
53-518-00	53-518-00	53-518-00-01		DETAILED	Main Landing Gear Wheel Well, Left
53-519-00	53-519-00	53-519-00-01		DETAILED	Main Landing Gear Wheel Well, Right
53-520-00	53-520-00	53-520-00-01		GENERAL VISUAL	Area Above Main Landing Gear Wheel Well
53-520-01	53-520-01	53-520-01-01		GENERAL VISUAL	Area Above Main Landing Gear Wheel Well
53-521-00	53-521-00	53-521-00-01		GENERAL VISUAL	Aft Cargo Compartment
53-522-00	53-522-00	53-522-00-01		GENERAL VISUAL	Aft Cargo Compartment
53-522-01	53-522-01	53-522-01-01		GENERAL VISUAL	Aft Cargo Compartment
53-523-00	53-523-00	53-523-00-01		GENERAL VISUAL	Aft Cargo Compartment
53-523-01	53-523-01	53-523-01-01		GENERAL VISUAL	Aft Cargo Compartment
53-524-00	53-524-00	53-524-00-01		DETAILED	Aft Cargo Compartment
53-525-00	53-525-00	53-525-00-01		DETAILED	Aft Cargo Compartment
53-526-00	53-526-00	53-526-00-01		DETAILED	Aft Cargo Compartment
53-526-01	53-526-01	53-526-01-01		DETAILED	Aft Cargo Compartment
53-527-00	53-527-00	53-527-00-01		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-528-00	53-528-00	53-528-00-01		GENERAL VISUAL	Area Below Aft Cargo Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-529-00	53-529-00	53-529-00-01		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-529-01	53-529-01	53-529-01-01		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-530-00	53-530-00	53-530-00-01		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-530-01	53-530-01	53-530-01-01		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-532-00	53-532-00	53-532-00-01		DETAILED	Area Below Aft Cargo Compartment
53-532-01	53-532-01	53-532-01-01		DETAILED	Area Below Aft Cargo Compartment
53-533-00	53-533-00	53-533-00-01		DETAILED	Area Below Aft Cargo Compartment
53-533-01	53-533-01	53-533-01-01		DETAILED	Area Below Aft Cargo Compartment
53-534-00	53-534-00	53-534-00-01		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-535-00	53-535-00	53-535-00-01		GENERAL VISUAL	Bulk Cargo Compartment
53-536-00	53-536-00	53-536-00-01		DETAILED	Bulk Cargo Compartment
53-537-00	53-537-00	53-537-00-01 53-537-00-02 53-537-00-03 53-537-00-04 53-537-00-05		DETAILED	Bulk Cargo Compartment
53-537-01	53-537-01	53-537-01-01		DETAILED	Bulk Cargo Compartment
53-538-00	53-538-00	53-538-00-01		DETAILED	Area Below Bulk Cargo Compartment
53-539-00	53-539-00	53-539-00-01		DETAILED	Area Aft of Bulk Cargo Compartment
53-540-00	53-540-00	53-540-00-01		DETAILED	Area Aft of Bulk Cargo Compartment
53-541-00	53-541-00	53-541-00-01		GENERAL VISUAL	Aft Cargo Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-542-00	53-542-00	53-542-00-01		GENERAL VISUAL	Bulk Cargo Compartment
53-543-00	53-543-00	53-543-00-01		GENERAL VISUAL	Overwing Wing-To-Body Fairings, Left
53-544-00	53-544-00	53-544-00-01		GENERAL VISUAL	Overwing Wing-To-Body Fairings, Right
53-545-01	53-545-01	53-545-01-01		DETAILED	Forward Wing-To-Body Fairings - Left
53-545-02	53-545-02	53-545-02-01		DETAILED	Forward Wing-To-Body Fairings - Right
53-546-01	53-546-01	53-546-01-01		GENERAL VISUAL	Overwing Wing-To-Body Fairings - Left
53-546-02	53-546-02	53-546-02-01		GENERAL VISUAL	Overwing Wing-To-Body Fairings - Right
53-547-01	53-547-01	53-547-01-01		DETAILED	Aft Wing-To-Body Fairings - Left
53-547-02	53-547-02	53-547-02-01		DETAILED	Aft Wing-To-Body Fairings - Right
53-547-03	53-547-03	53-547-03-01		DETAILED	Aft Wing-To-Body Fairings - Left
53-547-04	53-547-04	53-547-04-01		DETAILED	Aft Wing-To-Body Fairings - Right
53-548-00	53-548-00	53-548-00-01		SPECIAL DETAILED	Flight Compartment
53-549-00	53-549-00	53-549-00-01		DETAILED	Flight Compartment
53-550-00	53-550-00	53-550-00-01		GENERAL VISUAL	Flight Compartment
53-551-00	53-551-00	53-551-00-01		GENERAL VISUAL	Passenger Compartment - Left
53-551-01	53-551-01	53-551-01-01		GENERAL VISUAL	Supernumerary Cabin - Left
53-552-00	53-552-00	53-552-00-01		GENERAL VISUAL	Passenger Compartment - Right



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-552-01	53-552-01	53-552-01-01		GENERAL VISUAL	Supernumerary Cabin - Right
53-553-00	53-553-00	53-553-00-01		GENERAL VISUAL	Passenger Compartment - Left
53-553-01	53-553-01	53-553-01-01		GENERAL VISUAL	Supernumerary Cabin - Left
53-554-00	53-554-00	53-554-00-01		GENERAL VISUAL	Passenger Compartment - Right
53-554-01	53-554-01	53-554-01-01		GENERAL VISUAL	Supernumerary Cabin - Right
53-557-00	53-557-00	53-557-00-01		GENERAL VISUAL	Main Deck Compartment
53-558-00	53-558-00	53-558-00-01		GENERAL VISUAL	Main Deck Compartment
53-559-00	53-559-00	53-559-00-01		DETAILED	Main Deck Compartment
53-560-00	53-560-00	53-560-00-01		DETAILED	Main Deck Compartment
53-561-00	53-561-00	53-561-00-01		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-562-00	53-562-00	53-562-00-01		GENERAL VISUAL	Passenger Compartment - Left
53-563-00	53-563-00	53-563-00-01		GENERAL VISUAL	Passenger Compartment - Right
53-564-00	53-564-00	53-564-00-01		GENERAL VISUAL	Passenger Compartment - Left
53-565-00	53-565-00	53-565-00-01		GENERAL VISUAL	Passenger Compartment - Right



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-568-00	53-568-00	53-568-00-01 53-568-00-02 53-568-00-03 53-568-00-04 53-568-00-05		GENERAL VISUAL	Passenger Compartment - Left
53-568-01	53-568-01	53-568-01-01		GENERAL VISUAL	Main Deck Cargo Compartment - Left
53-569-00	53-569-00	53-569-00-01 53-569-00-02 53-569-00-03 53-569-00-04 53-569-00-05		GENERAL VISUAL	Passenger Compartment - Right
53-569-01	53-569-01	53-569-01-01		GENERAL VISUAL	Main Deck Cargo Compartment - Right
53-570-00	53-570-00	53-570-00-01		DETAILED	Passenger Compartment - Left
53-571-00	53-571-00	53-571-00-01		DETAILED	Passenger Compartment - Right
53-572-00	53-572-00	53-572-00-01		GENERAL VISUAL	Passenger Compartment - Left
53-572-01	53-572-01	53-572-01-01		GENERAL VISUAL	Main Deck Cargo Compartment - Left
53-573-00	53-573-00	53-573-00-01		GENERAL VISUAL	Passenger Compartment - Right
53-573-01	53-573-01	53-573-01-01		GENERAL VISUAL	Main Deck Cargo Compartment - Right
53-574-00	53-574-00	53-574-00-01		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-575-00	53-575-00	53-575-00-01		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-576-00	53-576-00	53-576-00-01 53-576-00-02 53-576-00-03 53-576-00-04 53-576-00-05 53-576-00-06		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-577-00	53-577-00	53-577-00-01 53-577-00-02 53-577-00-03 53-577-00-04 53-577-00-05 53-577-00-06		GENERAL VISUAL	Main Deck Compartment
53-578-00	53-578-00	53-578-00-01 53-578-00-02 53-578-00-03 53-578-00-04 53-578-00-05 53-578-00-06		GENERAL VISUAL	Main Deck Compartment
53-579-00	53-579-00	53-579-00-01		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-580-00	53-580-00	53-580-00-01		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-581-00	53-581-00	53-581-00-01		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-582-00	53-582-00	53-582-00-01		GENERAL VISUAL	Passenger Compartment
53-583-00	53-583-00	53-583-00-01		GENERAL VISUAL	Passenger Compartment
53-584-00	53-584-00	53-584-00-01		GENERAL VISUAL	Passenger Compartment
53-585-00	53-585-00	53-585-00-01		GENERAL VISUAL	Passenger Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-586-00	53-586-00	53-586-00-01		GENERAL VISUAL	Passenger Compartment
53-586-01	53-586-01	53-586-01-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-587-00	53-587-00	53-587-00-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-588-00	53-588-00	53-588-00-01		GENERAL VISUAL	Upper Cargo Compartment
53-589-00	53-589-00	53-589-00-01		GENERAL VISUAL	Passenger Compartment
53-590-00	53-590-00	53-590-00-01		GENERAL VISUAL	Passenger Compartment
53-591-00	53-591-00	53-591-00-01 53-591-00-02 53-591-00-03 53-591-00-04 53-591-00-05		GENERAL VISUAL	Passenger Compartment
53-591-01	53-591-01	53-591-01-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-592-00	53-592-00	53-592-00-01		DETAILED	Passenger Compartment
53-593-00	53-593-00	53-593-00-01		DETAILED	Passenger Compartment
53-594-00	53-594-00	53-594-00-01 53-594-00-02 53-594-00-03 53-594-00-04 53-594-00-05		DETAILED	Passenger Compartment
53-594-01	53-594-01	53-594-01-01		DETAILED	Main Deck Cargo Compartment
53-595-00	53-595-00	53-595-00-01		GENERAL VISUAL	Area above Main Deck Compartment Ceiling





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-596-00	53-596-00	53-596-00-01		GENERAL VISUAL	Area above Main Deck Compartment Ceiling
53-597-00	53-597-00	53-597-00-01 53-597-00-02 53-597-00-03 53-597-00-04 53-597-00-05 53-597-00-06		GENERAL VISUAL	Area above Main Deck Compartment Ceiling
53-598-00	53-598-00	53-598-00-01		GENERAL VISUAL	Area above Main Deck Compartment Ceiling
53-599-00	53-599-00	53-599-00-01		GENERAL VISUAL	Passenger Compartment
53-601-00	53-601-00	53-601-00-01		GENERAL VISUAL	Passenger Compartment
53-602-00	53-602-00	53-602-00-01		GENERAL VISUAL	Passenger Compartment
53-603-00	53-603-00	53-603-00-01		GENERAL VISUAL	Passenger Compartment
53-606-00	53-606-00	53-606-00-01		GENERAL VISUAL	Passenger Compartment
53-607-00	53-607-00	53-607-00-01		GENERAL VISUAL	Passenger Compartment
53-608-00	53-608-00	53-608-00-01		DETAILED	Passenger Compartment
53-609-00	53-609-00	53-609-00-01		DETAILED	Passenger Compartment
53-610-00	53-610-00	53-610-00-01 53-610-00-02		DETAILED	Area above Wing Center Section
53-611-00	53-611-00	53-611-00-01		GENERAL VISUAL	Area above Wing Center Section
53-612-00	53-612-00	53-612-00-01		GENERAL VISUAL	Passenger Compartment Left and Right



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-613-00	53-613-00	53-613-00-01		GENERAL VISUAL	Area above Passenger Compartment Ceiling
53-614-00	53-614-00	53-614-00-01 53-614-00-02		GENERAL VISUAL	Passenger Compartment
53-615-00	53-615-00	53-615-00-01 53-615-00-02		GENERAL VISUAL	Passenger Compartment Left and Right
53-616-00	53-616-00	53-616-00-01 53-616-00-02		DETAILED	Passenger Compartment Left and Right
53-617-00	53-617-00	53-617-00-01 53-617-00-02		GENERAL VISUAL	Passenger Compartment Left and Right
53-618-00	53-618-00	53-618-00-01		GENERAL VISUAL	Passenger Compartment Left and Right
53-619-00	53-619-00	53-619-00-01 53-619-00-02		GENERAL VISUAL	Area above Passenger Compartment Ceiling
53-620-00	53-620-00	53-620-00-01 53-620-00-02		DETAILED	Forward Wing-To-Body Fairings
53-621-00	53-621-00	53-621-00-01 53-621-00-02		DETAILED	Aft Wing-To-Body Fairings
53-623-00	53-623-00	53-623-00-01		DETAILED	Main Deck Compartment Ceiling
53-624-00	53-624-00	53-624-00-01		SPECIAL DETAILED	Main Deck Compartment Ceiling
53-625-00	53-625-00	53-625-00-01		GENERAL VISUAL	Main Deck Compartment Ceiling
53-626-00	53-626-00	53-626-00-01		DETAILED	Auxiliary Body Fuel Tanks
53-627-00	53-627-00	53-627-00-01		DETAILED	Auxiliary Body Fuel Tank Attach Fittings, Links and Pins
53-628-00	53-628-00	53-628-00-01		GENERAL VISUAL	Area Above Main Landing Gear Wheel Well
53-629-00	53-629-00	53-629-00-01		GENERAL VISUAL	Supernumerary Area



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-631-00	53-631-00	53-631-00-01		SPECIAL DETAILED	Main Deck Cargo Compartment
53-632-00	53-632-00	53-632-00-01		DETAILED	Main Deck Cargo Compartment
53-633-00	53-633-00	53-633-00-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-634-00	53-634-00	53-634-00-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-635-00	53-635-00	53-635-00-01		SPECIAL DETAILED	Main Deck Cargo Compartment
53-637-00	53-637-00	53-637-00-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-638-00	53-638-00	53-638-00-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-639-00	53-639-00	53-639-00-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-640-00	53-640-00	53-640-00-01		GENERAL VISUAL	Aft Cargo Compartment
53-641-00	53-641-00	53-641-00-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-645-00	53-645-00	53-645-00-01		DETAILED	Aft Cargo Compartment
53-646-00	53-646-00	53-646-00-01		DETAILED	Main Deck Cargo Compartment
53-647-00	53-647-00	53-647-00-01		DETAILED	Main Deck Cargo Compartment
53-648-00	53-648-00	53-648-00-01		DETAILED	Area Above Main Deck Cargo Compartment
53-671-00	53-671-00	53-671-00-01		GENERAL VISUAL	Lower Fuselage - Subzone 150 and 160
53-673-00	53-673-00	53-673-00-01 53-673-00-02		GENERAL VISUAL	Underwing Wing-To-Body Fairing
53-674-01	53-674-01	53-674-01-01		GENERAL VISUAL	Supernumerary Cabin



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-675-00	53-675-00	53-675-00-01		GENERAL VISUAL	Subzone 220 BS 246 to 655 (Section 41)
53-675-01	53-675-01	53-675-01-01		GENERAL VISUAL	Subzone 220 BS 388 to 655
53-676-00	53-676-00	53-676-00-01		GENERAL VISUAL	Subzone 230 BS 655 to 1035 (Section 43)
53-677-00	53-677-00	53-677-00-01		GENERAL VISUAL	Subzone 240 BS 1035 to 1434 (Section 44)
53-678-00	53-678-00	53-678-00-01		GENERAL VISUAL	Subzone 250 BS 1434 to 1832 (Section 46)
53-679-00	53-679-00	53-679-00-01		GENERAL VISUAL	Subzone 260 BS 1832 to 2195.75 (Section 47)
53-800-00	53-800-00	53-800-00-01 53-800-00-02 53-800-00-03 53-800-00-04 53-800-00-05 53-800-00-06 53-800-00-07 53-800-00-08 53-800-00-09 53-800-00-10 53-800-00-11 53-800-00-12		ZONAL (GV)	Fuselage Lower Half
53-804-00	53-804-00	53-804-00-01 53-804-00-02 53-804-00-03 53-804-00-04 53-804-00-05 53-804-00-06		ZONAL (GV)	Radome
53-806-00	53-806-00	53-806-00-01		ZONAL (GV)	Area Forward of Nose Landing Gear Wheel Well
53-808-00	53-808-00	53-808-00-01		ZONAL (GV)	Nose Gear Wheel Well - from the ground



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-810-00	53-810-00	53-810-00-01		ZONAL (GV)	Nose Gear Wheel Well (Inspection Accomplished from Within Wheel Well)
53-812-00	53-812-00	53-812-00-01		ZONAL (GV)	Area Above and Outboard of the Nose Landing Gear Wheel Well
53-814-00	53-814-00	53-814-00-01		ZONAL (GV)	Main Equipment Center
53-816-00	53-816-00	53-816-00-01		ZONAL (GV)	Forward Cargo Compartment
53-818-00	53-818-00	53-818-00-01		ZONAL (GV)	Forward Cargo Compartment
53-820-00	53-820-00	53-820-00-01		ZONAL (GV)	Forward Cargo Compartment
53-822-00	53-822-00	53-822-00-01		ZONAL (GV)	Area Below Forward Cargo Compartment
53-824-00	53-824-00	53-824-00-01 53-824-00-02 53-824-00-03 53-824-00-04 53-824-00-05 53-824-00-06		ZONAL (GV)	Area Below Forward Cargo Compartment
53-826-00	53-826-00	53-826-00-01		ZONAL (GV)	Area Aft of Forward Cargo Compartment
53-828-00	53-828-00	53-828-00-01		ZONAL (GV)	Area Above Wing Center Section
53-830-00	53-830-00	53-830-00-01 53-830-00-02		ZONAL (GV)	Environmental Control Systems Bay
53-832-00	53-832-00	53-832-00-01 53-832-00-02 53-832-00-03 53-832-00-04 53-832-00-05 53-832-00-06		ZONAL (GV)	Forward Keel Beam
53-834-00	53-834-00	53-834-00-01		ZONAL (GV)	Area Above Main Landing Gear Wheel Well
53-836-00	53-836-00	53-836-00-01		ZONAL (GV)	Left Main Landing Gear Wheel Well - From the Ground
53-838-00	53-838-00	53-838-00-01		ZONAL (GV)	Left Main Landing Gear Wheel Well (Inspection accomplished within WW)
53-840-00	53-840-00	53-840-00-01		ZONAL (GV)	Right Main Landing Gear Wheel Well - From the Ground
53-842-00	53-842-00	53-842-00-01		ZONAL (GV)	Right Main Landing Gear Wheel Well (Inspection accomplished Within WW)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-844-00	53-844-00	53-844-00-01 53-844-00-02 53-844-00-03 53-844-00-04 53-844-00-05 53-844-00-06		ZONAL (GV)	Aft Keel Beam
53-846-00	53-846-00	53-846-00-01		ZONAL (GV)	Aft Cargo Compartment
53-848-00	53-848-00	53-848-00-01		ZONAL (GV)	Aft Cargo Compartment
53-850-00	53-850-00	53-850-00-01		ZONAL (GV)	Aft Cargo Compartment Lower Lobe Attendant Rest
53-852-00	53-852-00	53-852-00-01		ZONAL (GV)	Aft Cargo Compartment
53-852-01	53-852-01	53-852-01-01		ZONAL (GV)	Aft Cargo Compartment
53-854-00	53-854-00	53-854-00-01		ZONAL (GV)	Aft Cargo Compartment
53-856-00	53-856-00	53-856-00-01		ZONAL (GV)	Aft Cargo Compartment
53-858-00	53-858-00	53-858-00-01		ZONAL (GV)	Aft Cargo Compartment
53-860-00	53-860-00	53-860-00-01		ZONAL (GV)	Area Below Aft Cargo Compartment
53-862-00	53-862-00	53-862-00-01 53-862-00-02 53-862-00-03 53-862-00-04 53-862-00-05 53-862-00-06		ZONAL (GV)	Area Below Aft Cargo Compartment
53-864-00	53-864-00	53-864-00-01		ZONAL (GV)	Area Below Aft Cargo Compartment
53-866-00	53-866-00	53-866-00-01		ZONAL (GV)	Area Below Aft Cargo Compartment
53-868-00	53-868-00	53-868-00-01		ZONAL (GV)	Bulk Cargo Compartment
53-870-00	53-870-00	53-870-00-01		ZONAL (GV)	Bulk Cargo Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-872-00	53-872-00	53-872-00-01 53-872-00-02 53-872-00-03 53-872-00-04 53-872-00-05 53-872-00-06		ZONAL (GV)	Bulk Cargo Compartment
53-874-00	53-874-00	53-874-00-01		ZONAL (GV)	Area Below Bulk Cargo Compartment
53-876-00	53-876-00	53-876-00-01 53-876-00-02 53-876-00-03 53-876-00-04 53-876-00-05 53-876-00-06		ZONAL (GV)	Area Aft of the Bulk Cargo Compartment
53-878-00	53-878-00	53-878-00-01 53-878-00-02 53-878-00-03 53-878-00-04 53-878-00-05 53-878-00-06		ZONAL (GV)	Area Aft of the Bulk Cargo Compartment
53-880-00	53-880-00	53-880-00-01		ZONAL (GV)	Forward Wing-To-Body Fairings - Left
53-882-00	53-882-00	53-882-00-01		ZONAL (GV)	Forward Wing-To-Body Fairings - Right
53-884-00	53-884-00	53-884-00-01		ZONAL (GV)	Overwing Wing-To-Body Fairing - Left
53-886-00	53-886-00	53-886-00-01		ZONAL (GV)	Overwing Wing-To-Body Fairings - Right
53-888-00	53-888-00	53-888-00-01		ZONAL (GV)	Underwing Wing-to-Body Fairings - Left
53-890-00	53-890-00	53-890-00-01		ZONAL (GV)	Underwing Wing-To-Body Fairings - Right
53-892-00	53-892-00	53-892-00-01		ZONAL (GV)	Aft Wing-to-Body Fairings - Left
53-894-00	53-894-00	53-894-00-01		ZONAL (GV)	Aft Wing-To-Body Fairings - Right



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-896-00	53-896-00	53-896-00-01 53-896-00-02 53-896-00-03 53-896-00-04 53-896-00-05 53-896-00-06		ZONAL (GV)	Upper Fuselage - Left and Right - Section 41 through 47 - BS 246 to BS 2150
53-898-00	53-898-00	53-898-00-01 53-898-00-02		ZONAL (GV)	Upper Fuselage - Flight Compartment - BS 92.5 to 246
53-900-00	53-900-00	53-900-00-01 53-900-00-02 53-900-00-03 53-900-00-04 53-900-00-05 53-900-00-06		ZONAL (GV)	Flight Compartment
53-902-00	53-902-00	53-902-00-01 53-902-00-02 53-902-00-03 53-902-00-04 53-902-00-05 53-902-00-06		ZONAL (GV)	Flight Compartment
53-904-00	53-904-00	53-904-00-01		ZONAL (GV)	Passenger Compartment - Section 41
53-906-00	53-906-00	53-906-00-01 53-906-00-02 53-906-00-03 53-906-00-04 53-906-00-05		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 41
53-907-00	53-907-00	53-907-00-01		ZONAL (GV)	Overhead Flight Crew Rest (OFCR) Compartment
53-908-00	53-908-00	53-908-00-01		ZONAL (GV)	Passenger Compartment - Section 43
53-910-00	53-910-00	53-910-00-01 53-910-00-02 53-910-00-03 53-910-00-04 53-910-00-05		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 43





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-912-00	53-912-00	53-912-00-01		ZONAL (GV)	Passenger Compartment - Section 44
53-914-00	53-914-00	53-914-00-01 53-914-00-02 53-914-00-03 53-914-00-04 53-914-00-05		ZONAL (GV)	Area Above Passenger Compartment - Section 44
53-916-00	53-916-00	53-916-00-01		ZONAL (GV)	Passenger Compartment - Section 46
53-918-00	53-918-00	53-918-00-01 53-918-00-02 53-918-00-03 53-918-00-04 53-918-00-05		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 46
53-919-00	53-919-00	53-919-00-01		ZONAL (GV)	Overhead Flight Attendant Rest (OFAR) Compartment(s)
53-920-00	53-920-00	53-920-00-01		ZONAL (GV)	Passenger Compartment - Section 47
53-922-00	53-922-00	53-922-00-01 53-922-00-02 53-922-00-03 53-922-00-04 53-922-00-05		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 47
53-924-00	53-924-00	53-924-00-01 53-924-00-02		ZONAL (GV)	Body Section 48 - BS 2150 to BS 2570
53-926-00	53-926-00	53-926-00-01		ZONAL (GV)	Fuselage Area Aft of Bulkhead - Inspection Accomplished within Fuselage
53-928-00	53-928-00	53-928-00-01		ZONAL (GV)	APU Compartment
53-930-00	53-930-00	53-930-00-01		ZONAL (GV)	APU Compartment - As visible with APU Removed
53-932-00	53-932-00	53-932-00-01		ZONAL (GV)	Upper Fuselage - Left and Right - Section 43
53-934-00	53-934-00	53-934-00-01		ZONAL (GV)	Area Above Supernumerary Cabin - Left and Right
53-936-00	53-936-00	53-936-00-01		ZONAL (GV)	Supernumerary Cabin - Left and Right
53-937-00	53-937-00	53-937-00-01		ZONAL (GV)	Area Above Main Deck Cargo Compartment Ceiling - Left and Right Sides - BS STA 388 to Aft Pressure Bulkhead



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-938-00	53-938-00	53-938-00-01		ZONAL (GV)	Main Deck Cargo Compartment - Section 41, 43, 44, 46, 47 - Left And Right Sides - BS STA 388 To Aft Pressure Bulkhead
54-005-01	54-005-01	54-005-01-01 54-005-01-02		FUNCTIONAL	Left Strut AFT Upper Spar Drain and AFT Strut Fairing Drain
54-005-02	54-005-02	54-005-02-01 54-005-02-02		FUNCTIONAL	Right Strut AFT Upper Spar Drain and AFT Strut Fairing Drain
54-205-01	54-205-01	54-205-01-01		FUNCTIONAL	Left Strut AFT Upper Spar Drain and AFT Strut Fairing Drain
54-205-02	54-205-02	54-205-02-01		FUNCTIONAL	Right Strut AFT Upper Spar Drain and AFT Strut Fairing Drain
54-210-01	54-210-01	54-210-01-01		FUNCTIONAL	Left Forward Engine Strut Drain.
54-210-02	54-210-02	54-210-02-01		FUNCTIONAL	Right Forward Engine Strut Drain.
54-350-01	54-350-01	54-350-01-01		FUNCTIONAL	Left Strut AFT Upper Spar Drain and AFT Strut Fairing Drain
54-350-02	54-350-02	54-350-02-01		FUNCTIONAL	Right Strut AFT Upper Spar Drain and AFT Strut Fairing Drain
54-501-01	54-501-01	54-501-01-01		GENERAL VISUAL	Powerplant - Left
54-502-01	54-502-01	54-502-01-01		DETAILED	Powerplant - Left
54-504-02	54-504-02	54-504-02-01		GENERAL VISUAL	Powerplant - Right
54-505-02	54-505-02	54-505-02-01		DETAILED	Powerplant - Right
54-507-01	54-507-01	54-507-01-01		DETAILED	Left Nacelle Strut
54-508-01	54-508-01	54-508-01-01		SPECIAL DETAILED	Left Nacelle Strut
54-509-01	54-509-01	54-509-01-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut
54-510-01	54-510-01	54-510-01-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut
54-511-01	54-511-01	54-511-01-01		GENERAL VISUAL	AFT Torque Box - Left Nacelle Strut



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-512-01	54-512-01	54-512-01-01		DETAILED	AFT Torque Box - Left Nacelle Strut
54-513-01	54-513-01	54-513-01-01		DETAILED	Strut Forward Torque Box
54-514-01	54-514-01	54-514-01-01		GENERAL VISUAL	AFT Torque Box - Left Nacelle Strut
54-515-02	54-515-02	54-515-02-01		DETAILED	Right Nacelle Strut
54-516-02	54-516-02	54-516-02-01		SPECIAL DETAILED	Right Nacelle Strut
54-517-02	54-517-02	54-517-02-01		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut
54-518-02	54-518-02	54-518-02-01		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut
54-519-02	54-519-02	54-519-02-01		GENERAL VISUAL	AFT Torque Box - Right Nacelle Strut
54-520-02	54-520-02	54-520-02-01		DETAILED	AFT Torque Box - Right Nacelle Strut
54-521-02	54-521-02	54-521-02-01		DETAILED	Strut Forward Torque Box
54-522-02	54-522-02	54-522-02-01		GENERAL VISUAL	AFT Torque Box - Right Nacelle Strut
54-530-01	54-530-01	54-530-01-01		GENERAL VISUAL	Powerplant - Left
54-531-01	54-531-01	54-531-01-01		DETAILED	Powerplant - Left
54-533-02	54-533-02	54-533-02-01		GENERAL VISUAL	Powerplant - Right
54-534-02	54-534-02	54-534-02-01		DETAILED	Powerplant - Right
54-536-01	54-536-01	54-536-01-01		DETAILED	Left Nacelle Strut
54-537-01	54-537-01	54-537-01-01		SPECIAL DETAILED	Left Nacelle Strut
54-538-01	54-538-01	54-538-01-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-539-01	54-539-01	54-539-01-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut
54-540-01	54-540-01	54-540-01-01		GENERAL VISUAL	AFT Torque Box - Left Nacelle Strut
54-541-01	54-541-01	54-541-01-01 54-541-01-02		DETAILED	AFT Torque Box - Left Nacelle Strut
54-542-01	54-542-01	54-542-01-01 54-542-01-02		DETAILED	Strut Forward Torque Box
54-543-01	54-543-01	54-543-01-01 54-543-01-02		GENERAL VISUAL	AFT Torque Box - Left Nacelle Strut
54-544-02	54-544-02	54-544-02-01		DETAILED	Right Nacelle Strut
54-545-02	54-545-02	54-545-02-01		SPECIAL DETAILED	Right Nacelle Strut
54-546-02	54-546-02	54-546-02-01		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut
54-547-02	54-547-02	54-547-02-01		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut
54-548-02	54-548-02	54-548-02-01		GENERAL VISUAL	AFT Torque Box - Right Nacelle Strut
54-549-02	54-549-02	54-549-02-01 54-549-02-02		DETAILED	AFT Torque Box - Right Nacelle Strut
54-550-02	54-550-02	54-550-02-01 54-550-02-02		DETAILED	Strut Forward Torque Box
54-551-02	54-551-02	54-551-02-01 54-551-02-02		GENERAL VISUAL	AFT Torque Box - Right Nacelle Strut
54-560-01	54-560-01	54-560-01-01		GENERAL VISUAL	Powerplant - Left
54-561-01	54-561-01	54-561-01-01		DETAILED	Powerplant - Left



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-563-02	54-563-02	54-563-02-01		GENERAL VISUAL	Powerplant - Right
54-564-02	54-564-02	54-564-02-01		DETAILED	Powerplant - Right
54-566-01	54-566-01	54-566-01-01		DETAILED	Left Nacelle Strut
54-567-01	54-567-01	54-567-01-01		SPECIAL DETAILED	Left Nacelle Strut
54-568-01	54-568-01	54-568-01-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut
54-569-01	54-569-01	54-569-01-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut
54-570-01	54-570-01	54-570-01-01		GENERAL VISUAL	Aft Torque Box - Left Nacelle Strut
54-571-01	54-571-01	54-571-01-01		DETAILED	Aft Torque Box - Left Nacelle Strut
54-572-01	54-572-01	54-572-01-01		DETAILED	Strut Forward - Left Torque Box
54-573-01	54-573-01	54-573-01-01		GENERAL VISUAL	Aft Torque Box - Left Nacelle Strut
54-574-02	54-574-02	54-574-02-01		DETAILED	Right Nacelle Strut
54-575-02	54-575-02	54-575-02-01		SPECIAL DETAILED	Right Nacelle Strut
54-576-02	54-576-02	54-576-02-01		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut
54-577-02	54-577-02	54-577-02-01		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut
54-578-02	54-578-02	54-578-02-01		GENERAL VISUAL	Aft Torque Box - Right Nacelle Strut
54-579-02	54-579-02	54-579-02-01		DETAILED	Aft Torque Box - Right Nacelle Strut
54-580-02	54-580-02	54-580-02-01		DETAILED	Strut Forward - Right Torque Box



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-581-02	54-581-02	54-581-02-01		GENERAL VISUAL	Aft Torque Box - Right Nacelle Strut
54-582-01	54-582-01	54-582-01-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut
54-583-02	54-583-02	54-583-02-01		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut
54-800-01	54-800-01	54-800-01-01		ZONAL (GV)	Left Nacelle Strut
54-802-01	54-802-01	54-802-01-01		ZONAL (GV)	Forward Strut Fairing - Left Nacelle Strut
54-804-01	54-804-01	54-804-01-01		ZONAL (GV)	Forward and Aft Torque Box - Left Nacelle Strut
54-806-01	54-806-01	54-806-01-01		ZONAL (GV)	Forward and Aft Torque Box - Left Nacelle Strut
54-808-01	54-808-01	54-808-01-01		ZONAL (GV)	Aft Strut Fairing - Left Nacelle Strut
54-810-02	54-810-02	54-810-02-01		ZONAL (GV)	Right Nacelle Strut
54-812-02	54-812-02	54-812-02-01		ZONAL (GV)	Forward Strut Fairing - Right Nacelle Strut
54-814-02	54-814-02	54-814-02-01		ZONAL (GV)	Forward and Aft Torque Box - Right Nacelle Strut
54-816-02	54-816-02	54-816-02-01		ZONAL (GV)	Forward and Aft Torque Box - Right Nacelle Strut
54-818-02	54-818-02	54-818-02-01		ZONAL (GV)	Aft Strut Fairing - Right Nacelle Strut
54-820-01	54-820-01	54-820-01-01		ZONAL (GV)	Left Nacelle Strut
54-822-01	54-822-01	54-822-01-01		ZONAL (GV)	Forward Strut Fairing - Left Nacelle Strut
54-824-01	54-824-01	54-824-01-01		ZONAL (GV)	Forward and Aft Torque Box - Left Nacelle Strut - Cowls Opened
54-826-01	54-826-01	54-826-01-01		ZONAL (GV)	Forward and Aft Torque Box - Left Nacelle Strut
54-828-01	54-828-01	54-828-01-01		ZONAL (GV)	Aft Strut Fairing - Left Nacelle Strut
54-830-02	54-830-02	54-830-02-01		ZONAL (GV)	Right Nacelle Strut
54-832-02	54-832-02	54-832-02-01		ZONAL (GV)	Forward Strut Fairing - Right Nacelle Strut
54-834-02	54-834-02	54-834-02-01		ZONAL (GV)	Forward and Aft Torque Box - Right Nacelle Strut - Fan Cowls Opened
54-836-02	54-836-02	54-836-02-01		ZONAL (GV)	Forward and Aft Torque Box - Right Nacelle Strut



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-838-02	54-838-02	54-838-02-01		ZONAL (GV)	Aft Strut Fairing - Right Nacelle Strut
54-840-01	54-840-01	54-840-01-01		ZONAL (GV)	Left Nacelle Strut
54-842-01	54-842-01	54-842-01-01		ZONAL (GV)	Forward Strut Fairing - Left Nacelle Strut
54-844-01	54-844-01	54-844-01-01		ZONAL (GV)	Forward and Aft Torque Box - Left Nacelle Strut - Cowls Opened
54-846-01	54-846-01	54-846-01-01		ZONAL (GV)	Forward and Aft Torque Box - Left Nacelle Strut
54-848-01	54-848-01	54-848-01-01		ZONAL (GV)	Aft Strut Fairing - Left Nacelle Strut
54-850-02	54-850-02	54-850-02-01		ZONAL (GV)	Right Nacelle Strut
54-852-02	54-852-02	54-852-02-01		ZONAL (GV)	Forward Strut Fairing - Right Nacelle Strut
54-854-02	54-854-02	54-854-02-01		ZONAL (GV)	Forward and Aft Torque Box - Right Nacelle Strut - Fan Cowls Opened
54-856-02	54-856-02	54-856-02-01		ZONAL (GV)	Forward and Aft Torque Box - Right Nacelle Strut
54-858-02	54-858-02	54-858-02-01		ZONAL (GV)	Aft Strut Fairing - Right Nacelle Strut
55-501-00	55-501-00	55-501-00-01		DETAILED	Horizontal Stabilizer Center Section
55-502-00	55-502-00	55-502-00-01		DETAILED	Horizontal Stabilizer Center Section
55-503-00	55-503-00	55-503-00-01		DETAILED	Area Aft of Bulkhead
55-504-00	55-504-00	55-504-00-01		DETAILED	Area Aft of Bulkhead Stabilizer Torsion Box Compartment
55-505-00	55-505-00	55-505-00-01		DETAILED	Stabilizer Torsion Box Compartment
55-507-00	55-507-00	55-507-00-01		GENERAL VISUAL	Fuselage - BS 2150-2570.3 (Section 48)
55-508-00	55-508-00	55-508-00-01		SPECIAL DETAILED	Fuselage - BS 2150-2570.3 (Section 48)
55-509-00	55-509-00	55-509-00-01	W-55-511-00-01	DETAILED	Vertical Stabilizer - Auxiliary Spar to Front Spar
55-510-00	55-510-00	55-510-00-01 55-510-00-02	W-55-514-00-01	DETAILED	Vertical Stabilizer - Auxiliary Spar to Front Spar
55-511-00	55-511-00	55-511-00-01	W-55-509-00-01	DETAILED	Vertical Stabilizer - Front Spar to Rear Spar



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-512-00	55-512-00	55-512-00-01	W-55-510-00-01 W-55-510-00-02	GENERAL VISUAL	Vertical Stabilizer - Front Spar to Rear Spar
55-513-00	55-513-00	55-513-00-01		DETAILED	Vertical Stabilizer - Front Spar to Rear Spar
55-513-01	55-513-01	55-513-01-01		DETAILED	Vertical Stabilizer - Front Spar to Rear Spar
55-514-00	55-514-00	55-514-00-01		DETAILED	Vertical Stabilizer - Front Spar to Rear Spar
55-514-01	55-514-01	55-514-01-01	W-55-518-00-01	DETAILED	Vertical Stabilizer - Front Spar to Rear Spar
55-515-00	55-515-00	55-515-00-01		DETAILED	Vertical Stabilizer - Rear Spar to Trailing Edge
55-515-01	55-515-01	55-515-01-01		DETAILED	Vertical Stabilizer - Rear Spar to Trailing Edge
55-516-00	55-516-00	55-516-00-01		DETAILED	Vertical Stabilizer - Rear Spar to Trailing Edge
55-516-01	55-516-01	55-516-01-01	W-55-515-00-01	DETAILED	Vertical Stabilizer - Rear Spar to Trailing Edge
55-517-00	55-517-00	55-517-00-01		GENERAL VISUAL	Vertical Stabilizer - Rear Spar to Trailing Edge
55-517-01	55-517-01	55-517-01-01		GENERAL VISUAL	Vertical Stabilizer - Rear Spar to Trailing Edge
55-518-00	55-518-00	55-518-00-01		DETAILED	Vertical Stabilizer - Rear Spar to Trailing Edge
55-518-01	55-518-01	55-518-01-01		DETAILED	Vertical Stabilizer - Rear Spar to Trailing Edge
55-519-00	55-519-00	55-519-00-01 55-519-00-02		GENERAL VISUAL	Rudder
55-520-00	55-520-00	55-520-00-01		DETAILED	Rudder
55-520-01	55-520-01	55-520-01-01		DETAILED	Rudder
55-521-00	55-521-00	55-521-00-01		GENERAL VISUAL	Rudder Tab
55-522-00	55-522-00	55-522-00-01 55-522-00-02		DETAILED	Rudder Tab
55-523-00	55-523-00	55-523-00-01		DETAILED	Rudder Tab
55-524-00	55-524-00	55-524-00-01		DETAILED	Vertical Stabilizer Leading Edge





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-524-01	55-524-01	55-524-01-01		DETAILED	Vertical Stabilizer Leading Edge
55-525-00	55-525-00	55-525-00-01		DETAILED	Vertical Stabilizer - Auxiliary Spar to Front Spar
55-525-01	55-525-01	55-525-01-01		DETAILED	Vertical Stabilizer - Auxiliary Spar to Front Spar
55-526-00	55-526-00	55-526-00-01		GENERAL VISUAL	Vertical Stabilizer - Front Spar to Rear Spar
55-527-01	55-527-01	55-527-01-01	W-55-538-02-01	DETAILED	Left Horizontal Stabilizer Center Section
55-528-01	55-528-01	55-528-01-01	W-55-539-02-01	DETAILED	Left Horizontal Stabilizer Center Section
55-528-03	55-528-03	55-528-03-01	W-55-539-04-01	DETAILED	Left Horizontal Stabilizer Center Section
55-528-05	55-528-05	55-528-05-01	W-55-539-06-01	DETAILED	Left Horizontal Stabilizer Center Section
55-529-01	55-529-01	55-529-01-01		DETAILED	Left Horizontal Stabilizer Center Section
55-530-01	55-530-01	55-530-01-01		GENERAL VISUAL	Left Horizontal Stabilizer Center Section
55-531-01	55-531-01	55-531-01-01		DETAILED	Left Horizontal Stabilizer Center Section
55-532-01	55-532-01	55-532-01-01		GENERAL VISUAL	Left Horizontal Stabilizer - Front Spar to Rear Spar
55-533-01	55-533-01	55-533-01-01		DETAILED	Left Horizontal Stabilizer - Front Spar to Rear Spar
55-534-01	55-534-01	55-534-01-01		DETAILED	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-534-03	55-534-03	55-534-03-01		DETAILED	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-535-01	55-535-01	55-535-01-01		DETAILED	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-535-03	55-535-03	55-535-03-01		DETAILED	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-536-01	55-536-01	55-536-01-01		DETAILED	Left Elevator
55-536-03	55-536-03	55-536-03-01		DETAILED	Left Elevator
55-537-01	55-537-01	55-537-01-01		GENERAL VISUAL	Left Horizontal Stabilizer Tip
55-538-02	55-538-02	55-538-02-01	W-55-527-01-01	DETAILED	Right Horizontal Stabilizer Center Section



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-539-02	55-539-02	55-539-02-01	W-55-528-01-01	DETAILED	Right Horizontal Stabilizer Center Section
55-539-04	55-539-04	55-539-04-01	W-55-528-03-01	DETAILED	Right Horizontal Stabilizer Center Section
55-539-06	55-539-06	55-539-06-01	W-55-528-05-01	DETAILED	Right Horizontal Stabilizer Center Section
55-540-02	55-540-02	55-540-02-01		DETAILED	Right Horizontal Stabilizer Center Section
55-541-02	55-541-02	55-541-02-01		GENERAL VISUAL	Right Horizontal Stabilizer Center Section
55-542-02	55-542-02	55-542-02-01		DETAILED	Right Horizontal Stabilizer Center Section
55-543-02	55-543-02	55-543-02-01		GENERAL VISUAL	Right Horizontal Stabilizer - Front Spar to Rear Spar
55-544-02	55-544-02	55-544-02-01		DETAILED	Right Horizontal Stabilizer - Front Spar to Rear Spar
55-545-02	55-545-02	55-545-02-01		DETAILED	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-545-04	55-545-04	55-545-04-01		DETAILED	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-546-02	55-546-02	55-546-02-01		DETAILED	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-546-04	55-546-04	55-546-04-01		DETAILED	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-547-02	55-547-02	55-547-02-01		DETAILED	Right Elevator
55-547-04	55-547-04	55-547-04-01		DETAILED	Right Elevator
55-548-02	55-548-02	55-548-02-01		GENERAL VISUAL	Right Horizontal Stabilizer Tip
55-549-00	55-549-00	55-549-00-01		SPECIAL DETAILED	Area Aft of Bulkhead and Stabilizer Torsion Box Compartment
55-550-00	55-550-00	55-550-00-01		DETAILED	Vertical Stabilizer - Front Spar to Rear Spar
55-550-01	55-550-01	55-550-01-01		GENERAL VISUAL	Vertical Stabilizer - Front Spar to Rear Spar
55-551-00	55-551-00	55-551-00-01		DETAILED	Left Horizontal Stabilizer Tip
55-552-00	55-552-00	55-552-00-01		DETAILED	Right Horizontal Stabilizer Tip



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-656-01	55-656-01	55-656-01-01	W-55-814-00-01 W-55-822-00-01 W-55-824-00-01	GENERAL VISUAL	Left Horizontal Stabilizer Leading Edge
55-660-02	55-660-02	55-660-02-01		GENERAL VISUAL	Right Horizontal Stabilizer Leading Edge
55-800-00	55-800-00	55-800-00-01		ZONAL (GV)	Stabilizer Torsion Box Compartment - Left and Right Sides (Internal of Fuselage)
55-804-00	55-804-00	55-804-00-01		ZONAL (GV)	Vertical Stabilizer Leading Edge
55-806-00	55-806-00	55-806-00-01		ZONAL (GV)	Vertical Stabilizer Leading Edge
55-808-00	55-808-00	55-808-00-01		ZONAL (GV)	Vertical Stabilizer - Auxiliary Spar to Rear Spar
55-810-00	55-810-00	55-810-00-01		ZONAL (GV)	Vertical Stabilizer - Auxiliary Spar to Front Spar
55-811-00	55-811-00	55-811-00-01		ZONAL (GV)	Vertical Stabilizer - Auxiliary Spar / Front Spar
55-812-00	55-812-00	55-812-00-01		ZONAL (GV)	Vertical Stabilizer - Front Spar to Rear Spar - Between Ribs 8 and 9
55-814-00	55-814-00	55-814-00-01		ZONAL (GV)	Vertical Stabilizer - Rear Spar to Trailing Edge
55-816-00	55-816-00	55-816-00-01	W-55-804-00-01 W-55-820-00-01 W-55-822-00-01	ZONAL (GV)	Vertical Stabilizer - Rear Spar to Trailing Edge
55-817-00	55-817-00	55-817-00-01		ZONAL (GV)	Vertical Stabilizer - Rear Spar to Trailing Edge
55-818-00	55-818-00	55-818-00-01		ZONAL (GV)	Vertical Stabilizer - Rear Spar to Trailing Edge
55-819-00	55-819-00	55-819-00-01		ZONAL (GV)	Vertical Stabilizer - Rear Spar to Trailing Edge
55-820-00	55-820-00	55-820-00-01		ZONAL (GV)	Rudder
55-822-00	55-822-00	55-822-00-01		ZONAL (GV)	Rudder Tab
55-824-00	55-824-00	55-824-00-01		ZONAL (GV)	Vertical Stabilizer Forward Tip



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-826-00	55-826-00	55-826-00-01		ZONAL (GV)	Vertical Stabilizer Forward Tip
55-828-01	55-828-01	55-828-01-01	W-55-848-02-01	ZONAL (GV)	Left Horizontal Stabilizer - Center Section
55-830-01	55-830-01	55-830-01-01	W-55-838-01-01 W-55-844-01-01 W-55-846-01-01	ZONAL (GV)	Left Horizontal Stabilizer - Leading Edge
55-832-01	55-832-01	55-832-01-01		ZONAL (GV)	Left Horizontal Stabilizer - Auxiliary Spar to Rear Spar
55-834-01	55-834-01	55-834-01-01		ZONAL (GV)	Left Horizontal Stabilizer - Auxiliary Spar to Front Spar
55-836-01	55-836-01	55-836-01-01		ZONAL (GV)	Left Horizontal Stabilizer - Front Spar to Rear Spar
55-838-01	55-838-01	55-838-01-01	W-55-830-01-01 W-55-844-01-01 W-55-846-01-01	ZONAL (GV)	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-838-03	55-838-03	55-838-03-02		ZONAL (GV)	Left Horizontal Stabilizer - Front Spar to Rear Spar
55-840-01	55-840-01	55-840-01-01		ZONAL (GV)	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-841-00	55-841-00	55-841-00-01		ZONAL (GV)	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-842-01	55-842-01	55-842-01-01		ZONAL (GV)	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-843-00	55-843-00	55-843-00-01		ZONAL (GV)	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-844-01	55-844-01	55-844-01-01	W-55-830-01-01 W-55-838-01-01	ZONAL (GV)	Left Elevator
55-846-01	55-846-01	55-846-01-01	W-55-830-01-01 W-55-838-01-01	ZONAL (GV)	Left Horizontal Stabilizer Tip
55-848-02	55-848-02	55-848-02-01	W-55-828-01-01	ZONAL (GV)	Right Horizontal Stabilizer Center Section
55-850-02	55-850-02	55-850-02-01	W-55-858-02-01 W-55-864-02-01 W-55-866-02-01	ZONAL (GV)	Right Horizontal Stabilizer - Leading Edge
55-852-02	55-852-02	55-852-02-01		ZONAL (GV)	Right Horizontal Stabilizer - Auxiliary Spar to Rear Spar
55-854-02	55-854-02	55-854-02-01		ZONAL (GV)	Right Horizontal Stabilizer Auxiliary Spar to Front Spar
55-856-02	55-856-02	55-856-02-01		ZONAL (GV)	Right Horizontal Stabilizer - Front Spar to Rear Spar



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-856-04	55-856-04	55-856-04-01	W-55-850-02-01 W-55-866-02-01	ZONAL (GV)	Right Horizontal Stabilizer - Front Spar to Rear Spar
55-858-02	55-858-02	55-858-02-01		ZONAL (GV)	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-860-02	55-860-02	55-860-02-01		ZONAL (GV)	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-861-00	55-861-00	55-861-00-01		ZONAL (GV)	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-862-02	55-862-02	55-862-02-01		ZONAL (GV)	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-863-00	55-863-00	55-863-00-01	W-55-850-02-01 W-55-858-02-01	ZONAL (GV)	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-864-02	55-864-02	55-864-02-01		ZONAL (GV)	Right Elevator
55-866-02	55-866-02	55-866-02-01		ZONAL (GV)	Right Horizontal Stabilizer Tip
56-010-00	56-010-00	56-010-00-01		OPERATIONAL	Flight Deck #2 Windows MICROSWITCH
56-020-00	56-020-00	56-020-00-01		LUBRICATE	Flight Deck Number 2 Windows Guide Bearings
56-030-00	56-030-00	56-030-00-01		OPERATIONAL	Flight Deck Number 2 Windows Open/Close Function
57-501-00	57-501-00	57-501-00-01		DETAILED	Wing Center Section
57-502-01	57-502-01	57-502-01-01		GENERAL VISUAL	Slat Number 7
57-503-01	57-503-01	57-503-01-01		GENERAL VISUAL	Slat Number 7
57-504-01	57-504-01	57-504-01-01		GENERAL VISUAL	Slats Number 1 Through 6
57-505-01	57-505-01	57-505-01-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17
57-506-01	57-506-01	57-506-01-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17
57-507-01	57-507-01	57-507-01-01		GENERAL VISUAL	Wing Inspar Area (Fuel Tanks) - Rib 17 to Wing Tip
57-508-01	57-508-01	57-508-01-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Rib 17 to Rib 34
57-509-01	57-509-01	57-509-01-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Rib 34 to Wing Tip



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-510-01	57-510-01	57-510-01-01		SPECIAL DETAILED	Main Tank - Rib 17 to Rib 32 - Left Wing
57-511-01	57-511-01	57-511-01-01		DETAILED	Main Tank - Rib 17 to Rib 32 - Left Wing
57-512-00	57-512-00	57-512-00-01		DETAILED	Slats Number 1 Through 6 Cove Skin
57-514-00	57-514-00	57-514-00-01		SPECIAL DETAILED	Wing Inboard and Outboard Main Flap Attach Bolts
57-515-01	57-515-01	57-515-01-01		DETAILED	Left Wing Inboard Main Flap
57-516-01	57-516-01	57-516-01-01		GENERAL VISUAL	Left Wing Inboard Main Flap
57-517-01	57-517-01	57-517-01-01		DETAILED	Left Wing Inboard Main Flap
57-518-01	57-518-01	57-518-01-01		GENERAL VISUAL	Left Wing Inboard Aft Flap
57-519-01	57-519-01	57-519-01-01		GENERAL VISUAL	Left Wing Flaperon
57-520-01	57-520-01	57-520-01-01		DETAILED	Left Wing Flaperon
57-521-00	57-521-00	57-521-00-01 57-521-00-02		DETAILED	Wing Inboard Trailing Edge Flap Torque Tube
57-523-01	57-523-01	57-523-01-01		GENERAL VISUAL	Left Wing Outboard Flap
57-524-01	57-524-01	57-524-01-01		DETAILED	Left Wing Outboard Flap
57-530-01	57-530-01	57-530-01-01		SPECIAL DETAILED	Left Wing Flap Support Fairing Number 4
57-531-01	57-531-01	57-531-01-01		GENERAL VISUAL	Inboard Flap Center Track Fairing - Left Wing
57-532-01	57-532-01	57-532-01-01		SPECIAL DETAILED	Left Wing Flap Support Fairing Number 3
57-533-01	57-533-01	57-533-01-01		GENERAL VISUAL	Outboard Flaperon Support Fairing - Left Wing



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-535-02	57-535-02	57-535-02-01		GENERAL VISUAL	Slat Number 8
57-536-02	57-536-02	57-536-02-01		GENERAL VISUAL	Slat Number 8
57-538-02	57-538-02	57-538-02-01		GENERAL VISUAL	Slats Number 9 Through 14
57-539-00	57-539-00	57-539-00-01		DETAILED	Slats Number 9 Through 14 Cove Skin
57-540-02	57-540-02	57-540-02-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17
57-541-02	57-541-02	57-541-02-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17
57-542-02	57-542-02	57-542-02-01		GENERAL VISUAL	Wing Inspar Area (Fuel Tanks) - Rib 17 to Wing Tip
57-543-02	57-543-02	57-543-02-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Rib 17 to Rib 34
57-544-02	57-544-02	57-544-02-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Rib 34 to Wing Tip
57-545-02	57-545-02	57-545-02-01		SPECIAL DETAILED	Main Tank - Rib17 to Rib 32 - Right Wing
57-546-02	57-546-02	57-546-02-01		DETAILED	Main Tank - Rib 17 to Rib 32 - Right Wing
57-550-02	57-550-02	57-550-02-01		DETAILED	Right Wing Inboard Main Flap
57-551-02	57-551-02	57-551-02-01		GENERAL VISUAL	Right Wing Inboard Main Flap
57-552-02	57-552-02	57-552-02-01		DETAILED	Right Wing Inboard Main Flap
57-553-02	57-553-02	57-553-02-01		GENERAL VISUAL	Right Wing Inboard Aft Flap
57-554-02	57-554-02	57-554-02-01		GENERAL VISUAL	Right Wing Flaperon
57-555-02	57-555-02	57-555-02-01		DETAILED	Right Wing Flaperon
57-556-02	57-556-02	57-556-02-01		GENERAL VISUAL	Right Wing Outboard Flap



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-557-02	57-557-02	57-557-02-01		DETAILED	Right Wing Outboard Flap
57-560-02	57-560-02	57-560-02-01		SPECIAL DETAILED	Right Wing Flap Support Fairing Number 5
57-561-02	57-561-02	57-561-02-01		GENERAL VISUAL	Inboard Flap Center Track Fairing - Right Wing
57-562-02	57-562-02	57-562-02-01		SPECIAL DETAILED	Right Wing Flap Support Fairing Number 6
57-563-02	57-563-02	57-563-02-01		GENERAL VISUAL	Outboard Flaperon Support Fairing - Right Wing
57-606-00	57-606-00	57-606-00-01 57-606-00-02 57-606-00-03		GENERAL VISUAL	Lower Fuselage - Subzone 130
57-607-01	57-607-01	57-607-01-01		GENERAL VISUAL	Left Wing
57-608-01	57-608-01	57-608-01-01		GENERAL VISUAL	Left Wing
57-620-02	57-620-02	57-620-02-01		GENERAL VISUAL	Right Wing
57-621-02	57-621-02	57-621-02-01		GENERAL VISUAL	Right Wing
57-630-00	57-630-00	57-630-00-01		GENERAL VISUAL	Area Above Wing Center Section
57-800-00	57-800-00	57-800-00-01		ZONAL (GV)	Wing Center Section
57-802-00	57-802-00	57-802-00-01		ZONAL (GV)	Wing Center Section
57-804-01	57-804-01	57-804-01-01		ZONAL (GV)	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing
57-806-01	57-806-01	57-806-01-01		ZONAL (GV)	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing
57-808-01	57-808-01	57-808-01-01		ZONAL (GV)	Slat No. 7
57-810-01	57-810-01	57-810-01-01		ZONAL (GV)	Krueger Seal Flap/Nacelle Gap Cover Area - Left Wing





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-812-01	57-812-01	57-812-01-01		ZONAL (GV)	Krueger Seal Flap/Nacelle Gap Cover Area - Left Wing
57-814-01	57-814-01	57-814-01-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
57-816-01	57-816-01	57-816-01-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
57-817-01	57-817-01	57-817-01-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
57-818-01	57-818-01	57-818-01-01		ZONAL (GV)	Left Wing Outboard Leading Edge Slats Number 1 through 6
57-820-01	57-820-01	57-820-01-01		ZONAL (GV)	Slat Number 6
57-822-01	57-822-01	57-822-01-01		ZONAL (GV)	Slat Number 5
57-824-01	57-824-01	57-824-01-01		ZONAL (GV)	Slat Number 4
57-826-01	57-826-01	57-826-01-01		ZONAL (GV)	Slat Number 3
57-828-01	57-828-01	57-828-01-01		ZONAL (GV)	Slat Number 2
57-830-01	57-830-01	57-830-01-01		ZONAL (GV)	Slat Number 1
57-831-01	57-831-01	57-831-01-01		ZONAL (GV)	Slat Number 1
57-832-01	57-832-01	57-832-01-01 57-832-01-02		ZONAL (GV)	Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17 - Left Wing
57-834-01	57-834-01	57-834-01-01		ZONAL (GV)	Center Fuel Tank - Rib 1 to Rib 8 - Left Wing
57-836-01	57-836-01	57-836-01-01		ZONAL (GV)	Left Wing Dry Bay
57-838-01	57-838-01	57-838-01-01		ZONAL (GV)	Main Tank - Rib 8 to Rib 17 - Left Wing
57-840-01	57-840-01	57-840-01-01 57-840-01-02		ZONAL (GV)	Wing Inspar Area (Fuel Tanks) - Rib 17 to Wing Tip - Left Wing
57-842-01	57-842-01	57-842-01-01		ZONAL (GV)	Main Tank - Rib 17 to Rib 32 - Left Wing
57-844-01	57-844-01	57-844-01-01		ZONAL (GV)	Left Wing Surge Tank - Rib 32 to Rib 34
57-845-01	57-845-01	57-845-01-01		ZONAL (GV)	Main Tank Rib 32 to Rib 34 - Left Wing
57-846-01	57-846-01	57-846-01-01		ZONAL (GV)	Inspar Area - Rib 34 to Wing Tip - Left Wing
57-847-01	57-847-01	57-847-01-01		ZONAL (GV)	Main Tank, Surge Tank, and Inspar Area - Left Wing



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-848-01	57-848-01	57-848-01-01		ZONAL (GV)	Left Wing Tip
57-850-01	57-850-01	57-850-01-01		ZONAL (GV)	Left Wing Tip
57-851-01	57-851-01	57-851-01-01		ZONAL (GV)	Left Wing Tip
57-852-01	57-852-01	57-852-01-01		ZONAL (GV)	Left Wing Fixed T.E. - Aft of Rear Spar, Inbd of Outbd Support Fairing
57-854-01	57-854-01	57-854-01-01		ZONAL (GV)	Rear Spar to Landing Gear Support Beam - Left Wing
57-856-01	57-856-01	57-856-01-01		ZONAL (GV)	Landing Gear Support Beam and Rear Spar to Trailing Edge - Left Wing
57-858-01	57-858-01	57-858-01-01		ZONAL (GV)	Inboard Spoilers Numbers 6 and 7
57-860-01	57-860-01	57-860-01-01		ZONAL (GV)	Inboard Trailing Edge Flaps - Left Wing
57-862-01	57-862-01	57-862-01-01		ZONAL (GV)	Left Wing Flaperon
57-864-01	57-864-01	57-864-01-01		ZONAL (GV)	Rear Spar to Trailing Edge - Outboard of Flaperon - Left Wing
57-866-01	57-866-01	57-866-01-01		ZONAL (GV)	Rear Spar to Trailing Edge - Outboard of Flaperon - Left Wing
57-868-01	57-868-01	57-868-01-01		ZONAL (GV)	Outboard Spoilers Numbers 1 through 5
57-870-01	57-870-01	57-870-01-01		ZONAL (GV)	Left Wing Outboard Flap
57-872-01	57-872-01	57-872-01-01		ZONAL (GV)	Left Wing Aileron
57-874-01	57-874-01	57-874-01-01		ZONAL (GV)	Flap Support Fairing No. 4
57-876-01	57-876-01	57-876-01-01		ZONAL (GV)	Flap Support Fairing No. 4
57-878-01	57-878-01	57-878-01-01		ZONAL (GV)	Inboard Flap Center Track Fairing - Left Wing
57-880-01	57-880-01	57-880-01-01		ZONAL (GV)	Flap Support Fairing No. 3 and Inboard Flaperon Support Fairing
57-882-01	57-882-01	57-882-01-01		ZONAL (GV)	Flap Support Fairing No. 3 and Inboard Flaperon Support Fairing
57-884-01	57-884-01	57-884-01-01		ZONAL (GV)	Outboard Flaperon Support Fairing - Left Wing
57-886-01	57-886-01	57-886-01-01		ZONAL (GV)	Flap Support Fairing No. 2
57-888-01	57-888-01	57-888-01-01		ZONAL (GV)	Flap Support Fairing No. 2
57-890-01	57-890-01	57-890-01-01		ZONAL (GV)	Flap Support Fairing No. 1
57-892-01	57-892-01	57-892-01-01		ZONAL (GV)	Flap Support Fairing No. 1



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-894-01	57-894-01	57-894-01-01		ZONAL (GV)	Outboard Auxiliary Support Fairing - Left Wing
57-896-02	57-896-02	57-896-02-01		ZONAL (GV)	Leading Edge to Front Spar - Inboard of Nacelle Strut - Right Wing
57-898-02	57-898-02	57-898-02-01		ZONAL (GV)	Leading Edge to Front Spar - Inboard of Nacelle Strut - Right Wing
57-900-02	57-900-02	57-900-02-01		ZONAL (GV)	Slat No. 8
57-902-02	57-902-02	57-902-02-01		ZONAL (GV)	Krueger Seal Flap/Nacelle Gap Cover Area - Right Wing
57-904-02	57-904-02	57-904-02-01		ZONAL (GV)	Krueger Seal Flap/Nacelle Gap Cover Area - Right Wing
57-906-02	57-906-02	57-906-02-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Right Wing
57-908-02	57-908-02	57-908-02-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Right Wing
57-909-02	57-909-02	57-909-02-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Right Wing
57-910-02	57-910-02	57-910-02-01		ZONAL (GV)	Outboard Leading Edge Slats Number 9 through 14
57-912-02	57-912-02	57-912-02-01		ZONAL (GV)	Slat Number 9
57-914-02	57-914-02	57-914-02-01		ZONAL (GV)	Slat Number 10
57-916-02	57-916-02	57-916-02-01		ZONAL (GV)	Slat Number 11
57-918-02	57-918-02	57-918-02-01		ZONAL (GV)	Slat Number 12
57-920-02	57-920-02	57-920-02-01		ZONAL (GV)	Slat Number 13
57-922-02	57-922-02	57-922-02-01		ZONAL (GV)	Slat Number 14
57-923-02	57-923-02	57-923-02-01		ZONAL (GV)	Slat Number 14
57-924-02	57-924-02	57-924-02-01 57-924-02-02		ZONAL (GV)	Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17 - Right Wing
57-926-02	57-926-02	57-926-02-01		ZONAL (GV)	Center Fuel Tank - Rib 1 to Rib 8 - Right Wing
57-928-02	57-928-02	57-928-02-01		ZONAL (GV)	Right Wing Dry Bay
57-930-02	57-930-02	57-930-02-01		ZONAL (GV)	Main Tank - Rib 8 to Rib 17 - Right Wing
57-932-02	57-932-02	57-932-02-01 57-932-02-02		ZONAL (GV)	Wing Inspar Area (Fuel Tanks) - Rib 17 to Wing Tip - Right Wing



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-934-02	57-934-02	57-934-02-01		ZONAL (GV)	Main Tank - Rib 17 to Rib 32 - Right Wing
57-936-02	57-936-02	57-936-02-01		ZONAL (GV)	Right Wing Surge Tank - Rib 32 to Rib 34
57-937-02	57-937-02	57-937-02-01		ZONAL (GV)	Main Tank - Rib 32 to Rib 34 - Right Wing
57-938-02	57-938-02	57-938-02-01		ZONAL (GV)	Inspar Area - Rib 34 to Wing Tip - Right Wing
57-939-02	57-939-02	57-939-02-01		ZONAL (GV)	Main Tank, Surge Tank, and Inspar Area - Right Wing
57-940-02	57-940-02	57-940-02-01		ZONAL (GV)	Right Wing Tip
57-942-02	57-942-02	57-942-02-01		ZONAL (GV)	Right Wing Tip
57-943-02	57-943-02	57-943-02-01		ZONAL (GV)	Right Wing Tip
57-944-02	57-944-02	57-944-02-01		ZONAL (GV)	Right Wing Fixed T.E. - Aft of Rear Spar, Inbd of Outbd Support Fairing
57-946-02	57-946-02	57-946-02-01		ZONAL (GV)	Rear Spar to Landing Gear Support Beam - Right Wing
57-948-02	57-948-02	57-948-02-01		ZONAL (GV)	Landing Gear Support Beam and Rear Spar to Trailing Edge - Right Wing
57-950-02	57-950-02	57-950-02-01		ZONAL (GV)	Inboard Spoilers Numbers 8 and 9
57-952-02	57-952-02	57-952-02-01		ZONAL (GV)	Inboard Trailing Edge Flaps - Right Wing
57-954-02	57-954-02	57-954-02-01		ZONAL (GV)	Right Wing Flaperon
57-956-02	57-956-02	57-956-02-01		ZONAL (GV)	Rear Spar to Trailing Edge - Outboard of Flaperon - Right Wing
57-958-02	57-958-02	57-958-02-01		ZONAL (GV)	Rear Spar to Trailing Edge - Outboard of Flaperon - Right Wing
57-960-02	57-960-02	57-960-02-01		ZONAL (GV)	Outboard Spoilers Numbers 10 through 14
57-962-02	57-962-02	57-962-02-01		ZONAL (GV)	Right Wing Outboard Flap
57-964-02	57-964-02	57-964-02-01		ZONAL (GV)	Right Wing Aileron
57-966-02	57-966-02	57-966-02-01		ZONAL (GV)	Flap Support Fairing No. 5
57-968-02	57-968-02	57-968-02-01		ZONAL (GV)	Flap Support Fairing No. 5
57-970-02	57-970-02	57-970-02-01		ZONAL (GV)	Inboard Flap Center Track Fairing - Right Wing
57-972-02	57-972-02	57-972-02-01		ZONAL (GV)	Flap Support Fairing No. 6 and Inbd Flaperon Support Fairing
57-974-02	57-974-02	57-974-02-01		ZONAL (GV)	Flap Support Fairing No. 6 and Inbd Flaperon Support Fairing



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-976-02	57-976-02	57-976-02-01		ZONAL (GV)	Outboard Flaperon Support Fairing - Right Wing
57-978-02	57-978-02	57-978-02-01		ZONAL (GV)	Flap Support Fairing No. 7
57-980-02	57-980-02	57-980-02-01		ZONAL (GV)	Flap Support Fairing No. 7
57-982-02	57-982-02	57-982-02-01		ZONAL (GV)	Flap Support Fairing No. 8
57-984-02	57-984-02	57-984-02-01		ZONAL (GV)	Flap Support Fairing No. 8
57-986-02	57-986-02	57-986-02-01		ZONAL (GV)	Outboard Auxiliary Support Fairing - Right Wing
71-205-01	71-205-01	71-205-01-01		INSPECTION - DETAILED	Inspection of the Forward Mount
71-205-02	71-205-02	71-205-02-01		INSPECTION - DETAILED	Inspection of the Forward Mount
71-210-01	71-210-01	71-210-01-01		INSPECTION - DETAILED	Inspection of the Aft Lower Mount
71-210-02	71-210-02	71-210-02-01		INSPECTION - DETAILED	Inspection of the Aft Lower Mount
71-350-01	71-350-01	71-350-01-01		INSPECTION - DETAILED	Inspection of the Forward Mount
71-350-02	71-350-02	71-350-02-01		INSPECTION - DETAILED	Inspection of the Forward Mount
71-355-01	71-355-01	71-355-01-01		INSPECTION - DETAILED	Inspection of the AFT Engine Mount
71-355-02	71-355-02	71-355-02-01		INSPECTION - DETAILED	Inspection of the AFT Engine Mount
71-800-01	71-800-01	71-800-01-01		ZONAL (GV)	Left Powerplant
71-802-01	71-802-01	71-802-01-01		ZONAL (GV)	Left Engine
71-804-01	71-804-01	71-804-01-01		ZONAL (GV)	Inlet Cowl - Left Engine
71-806-01	71-806-01	71-806-01-01		ZONAL (GV)	Left Engine Fan Cowls
71-808-01	71-808-01	71-808-01-01		ZONAL (GV)	Left Engine Thrust Reversers



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
71-810-01	71-810-01	71-810-01-01		ZONAL (GV)	Left Engine Thrust Reversers
71-812-02	71-812-02	71-812-02-01		ZONAL (GV)	Right Powerplant
71-814-02	71-814-02	71-814-02-01		ZONAL (GV)	Right Engine
71-816-02	71-816-02	71-816-02-01		ZONAL (GV)	Inlet Cowl - Right Engine
71-818-02	71-818-02	71-818-02-01		ZONAL (GV)	Right Engine Fan Cowl
71-820-02	71-820-02	71-820-02-01		ZONAL (GV)	Right Engine Thrust Reversers
71-822-02	71-822-02	71-822-02-01		ZONAL (GV)	Right Engine Thrust Reversers
71-830-01	71-830-01	71-830-01-01		ZONAL (GV)	Left Powerplant - From the Ground
71-832-01	71-832-01	71-832-01-01		ZONAL (GV)	Left Powerplant
71-834-01	71-834-01	71-834-01-01		ZONAL (GV)	Left Engine
71-836-01	71-836-01	71-836-01-01		ZONAL (GV)	Inlet Cowl - Left Engine
71-838-01	71-838-01	71-838-01-01		ZONAL (GV)	Left Engine Fan Cowl
71-840-01	71-840-01	71-840-01-01		ZONAL (GV)	Left Engine Thrust Reversers
71-842-01	71-842-01	71-842-01-01		ZONAL (GV)	Left Engine Thrust Reversers
71-844-02	71-844-02	71-844-02-01		ZONAL (GV)	Right Powerplant - From the Ground
71-846-02	71-846-02	71-846-02-01		ZONAL (GV)	Right Powerplant
71-848-02	71-848-02	71-848-02-01		ZONAL (GV)	Right Engine
71-850-02	71-850-02	71-850-02-01		ZONAL (GV)	Inlet Cowl - Right Engine
71-852-02	71-852-02	71-852-02-01		ZONAL (GV)	Right Engine Fan Cowl
71-854-02	71-854-02	71-854-02-01		ZONAL (GV)	Right Engine Thrust Reversers
71-856-02	71-856-02	71-856-02-01		ZONAL (GV)	Right Engine Thrust Reversers
71-860-01	71-860-01	71-860-01-01		ZONAL (GV)	Left Powerplant - From the Ground
71-862-01	71-862-01	71-862-01-01		ZONAL (GV)	Left Powerplant
71-864-01	71-864-01	71-864-01-01		ZONAL (GV)	Left Engine



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
71-866-01	71-866-01	71-866-01-01		ZONAL (GV)	Inlet Cowl - Left Engine
71-868-01	71-868-01	71-868-01-01		ZONAL (GV)	Left Engine Fan Cowls
71-870-01	71-870-01	71-870-01-01		ZONAL (GV)	Left Engine Thrust Reversers
71-872-01	71-872-01	71-872-01-01		ZONAL (GV)	Left Engine Thrust Reversers
71-874-02	71-874-02	71-874-02-01		ZONAL (GV)	Right Powerplant - From the Ground
71-876-02	71-876-02	71-876-02-01		ZONAL (GV)	Right Powerplant
71-878-02	71-878-02	71-878-02-01		ZONAL (GV)	Right Engine
71-880-02	71-880-02	71-880-02-01		ZONAL (GV)	Inlet Cowl - Right Engine
71-882-02	71-882-02	71-882-02-01		ZONAL (GV)	Right Engine Fan Cowls
71-884-02	71-884-02	71-884-02-01		ZONAL (GV)	Right Engine Thrust Reversers
71-886-02	71-886-02	71-886-02-01		ZONAL (GV)	Right Engine Thrust Reversers
72-001-00	72-001-00	72-001-00-01 72-001-00-02		CLEAN	Engine Gas Path
72-005-01	72-005-01	72-005-01-01 72-005-01-03		INSPECTION - DETAILED	Fan Blade Inspection - Left
72-005-02	72-005-02	72-005-02-02 72-005-02-04		INSPECTION - DETAILED	Fan Blade Inspection - Right
72-010-00	72-010-00	72-010-00-01 72-010-00-02		REPLACE	Discard Fan Disk and Booster Spool
72-015-00	72-015-00	72-015-00-01 72-015-00-02		REPLACE	Discard Fan Shaft
72-020-01	72-020-01	72-020-01-01 72-020-01-02		INSPECTION - DETAILED	Check for Bearing and Gear Degradation - Left
72-020-02	72-020-02	72-020-02-01 72-020-02-02		INSPECTION - DETAILED	Check for Bearing and Gear Degradation - Right
72-021-01	72-021-01	72-021-01-01		INSPECTION - DETAILED	Check for Bearing and Gear Degradation - Left



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-021-02	72-021-02	72-021-02-01		INSPECTION - DETAILED	Check for Bearing and Gear Degradation - Right
72-025-01	72-025-01	72-025-01-01 72-025-01-03		INSPECTION - DETAILED	Inspection of the forward Mount - Left
72-025-02	72-025-02	72-025-02-02 72-025-02-04		INSPECTION - DETAILED	Inspection of the forward Mount - Right
72-030-01	72-030-01	72-030-01-01 72-030-01-03		INSPECTION - GEN VISUAL	General Visual Inspection of the Fan Area - Left
72-030-02	72-030-02	72-030-02-02 72-030-02-04		INSPECTION - GEN VISUAL	General Visual Inspection of the Fan Area - Right
72-035-00	72-035-00	72-035-00-01 72-035-00-02		REPLACE	Discard HPC Stage 1 Disk/Shaft
72-040-00	72-040-00	72-040-00-01 72-040-00-02		REPLACE	Discard HPC Stage 2 thru 6 Spool
72-045-00	72-045-00	72-045-00-01 72-045-00-02		REPLACE	Discard HPC Stage 7 Disk
72-050-00	72-050-00	72-050-00-01 72-050-00-02		REPLACE	Discard HPC Stage 8 thru 10 Spool
72-055-00	72-055-00	72-055-00-01 72-055-00-02		REPLACE	Discard CDP Seal
72-060-01	72-060-01	72-060-01-01 72-060-01-03		SPECIAL DETAILED	Borescope Inspection of the Combustor - Left
72-060-02	72-060-02	72-060-02-02 72-060-02-04		SPECIAL DETAILED	Borescope Inspection of the Combustor - Right
72-065-01	72-065-01	72-065-01-01 72-065-01-03		SPECIAL DETAILED	Borescope Inspection of the 1 St. & 2 ND. Stage Turbine Blades - Left
72-065-02	72-065-02	72-065-02-02 72-065-02-04		SPECIAL DETAILED	Borescope Inspection of the 1 St. & 2 ND. Stage Turbine Blades - Right





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

<b>MRB ITEM NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>TASK CARD NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
72-070-00	72-070-00	72-070-00-01 72-070-00-02		REPLACE	Discard HPT Stage 1 and 2 Disks and Seals
72-075-00	72-075-00	72-075-00-01 72-075-00-02		REPLACE	Discard LPT Shaft, LPT Cone Shaft and LPT Stage 1 thru 6 Disks
72-080-01	72-080-01	72-080-01-01		INSPECTION - DETAILED	Detailed Inspection of TRF AFT Engine Mount Lugs- Left
72-080-02	72-080-02	72-080-02-02		INSPECTION - DETAILED	Detailed Inspection of TRF AFT Engine Mount Lugs - Right
72-083-01	72-083-01	72-083-01-01		INSPECTION - DETAILED	Detailed Inspection of TRF AFT Engine Mount Lugs- Left
72-083-02	72-083-02	72-083-02-01		INSPECTION - DETAILED	Detailed Inspection of TRF AFT Engine Mount Lugs - Right
72-090-01	72-090-01	72-090-01-01 72-090-01-03		INSPECTION - DETAILED	Detailed Inspection ACC GB. and Fittings - Left
72-090-02	72-090-02	72-090-02-02 72-090-02-04		INSPECTION - DETAILED	Detailed Inspection ACC GB. and Fittings - Right
72-206-01	72-206-01	72-206-01-01		INSPECTION - DETAILED	Turbine Section - Left
72-206-02	72-206-02	72-206-02-01		INSPECTION - DETAILED	Turbine Section - Right
72-207-01	72-207-01	72-207-01-01		INSPECTION - DETAILED	Turbine Section - Left
72-207-02	72-207-02	72-207-02-01		INSPECTION - DETAILED	Turbine Section - Right
72-211-01	72-211-01	72-211-01-01		INSPECTION - DETAILED	Diffuser Case Section - Left
72-211-02	72-211-02	72-211-02-01		INSPECTION - DETAILED	Diffuser Case Section - Right
72-212-01	72-212-01	72-212-01-01		INSPECTION - DETAILED	Diffuser Case Section - Left



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-212-02	72-212-02	72-212-02-01		INSPECTION - DETAILED	Diffuser Case Section - Right
72-220-01	72-220-01	72-220-01-01		INSPECTION - DETAILED	Low Pressure Compressor Section - Left
72-220-02	72-220-02	72-220-02-01		INSPECTION - DETAILED	Low Pressure Compressor Section - Right
72-225-00	72-225-00	72-225-00-01		REPLACE	Discard Fan Hub & LPC Drum Rotor
72-235-01	72-235-01	72-235-01-01		CHECK/INSP	Fan Case Section - Left
72-235-02	72-235-02	72-235-02-01		CHECK/INSP	Fan Case Section - Right
72-240-01	72-240-01	72-240-01-01		INSPECTION - GEN VISUAL	Kevlar Inspection on Fan Case - Left
72-240-02	72-240-02	72-240-02-01		INSPECTION - GEN VISUAL	Kevlar Inspection on Fan Case - Right
72-245-01	72-245-01	72-245-01-01 72-245-01-02 72-245-01-04 72-245-01-05 72-245-01-06		INSPECTION - DETAILED	Fan Case Section - Left
72-245-02	72-245-02	72-245-02-01 72-245-02-02 72-245-02-04 72-245-02-05 72-245-02-06		INSPECTION - DETAILED	Fan Case Section - Right
72-250-00	72-250-00	72-250-00-01		REPLACE	Discard Front HUB, 5th Disk, Drum Rotor/Drive Turbine Shaft
72-255-00	72-255-00	72-255-00-01		REPLACE	Discard HUBS, ROTATING AIRSEAL, AND BLADE RETAINING PLATES
72-260-00	72-260-00	72-260-00-01		REPLACE	Discard LPC/LPT COUPLING
72-265-00	72-265-00	72-265-00-01		REPLACE	Discard Disks, Rotating Airseals and Shafts
72-270-01	72-270-01	72-270-01-01		INSPECTION - DETAILED	Lubrication and Scavage System - Left



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-270-02	72-270-02	72-270-02-01		INSPECTION - DETAILED	Lubrication and Scavage System - Right
72-280-01	72-280-01	72-280-01-01		INSPECTION - DETAILED	Inspection of the Turbine Exhaust Case Rail Mount (AFT Eng Mount) - Left
72-280-02	72-280-02	72-280-02-01		INSPECTION - DETAILED	Inspection of the Turbine Exhaust Case Rail Mount (AFT Eng Mount) - Right
72-350-01	72-350-01	72-350-01-01		INSPECTION - DETAILED	Fan Blade Inspection
72-350-02	72-350-02	72-350-02-01		INSPECTION - DETAILED	Fan Blade Inspection
72-355-00	72-355-00	72-355-00-01		REPLACE	Discard LPC Disk
72-360-00	72-360-00	72-360-00-01		REPLACE	Discard LPC Shaft
72-365-00	72-365-00	72-365-00-01		REPLACE	Discard Fan Shaft
72-370-01	72-370-01	72-370-01-01		INSPECTION - DETAILED	Inspection of the Lugs
72-370-02	72-370-02	72-370-02-01		INSPECTION - DETAILED	Inspection of the Lugs
72-375-01	72-375-01	72-375-01-01		INSPECTION - DETAILED	MCD Inspection
72-375-02	72-375-02	72-375-02-01		INSPECTION - DETAILED	MCD Inspection
72-376-01	72-376-01	72-376-01-01		RESTORE	Restore (Clean) Master Electric Chip Detector (active DMS) Left Engine
72-376-02	72-376-02	72-376-02-01		RESTORE	Restore (Clean) Master Electric Chip Detector (active DMS) Right Engine
72-377-01	72-377-01	72-377-01-01		FUNCTIONAL	Functionally Check Master Electric Chip Detector (active DMS) Left Engine
72-377-02	72-377-02	72-377-02-01		FUNCTIONAL	Functionally Check Master Electric Chip Detector (active DMS) Right Engine
72-380-00	72-380-00	72-380-00-01		REPLACE	Discard IPC Rear Stubshaft
72-385-01	72-385-01	72-385-01-01		INSPECTION - DETAILED	Inspect Detailed Kevlar



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-385-02	72-385-02	72-385-02-01		INSPECTION - DETAILED	Inspect Detailed Kevlar
72-390-01	72-390-01	72-390-01-01		INSPECTION - GEN VISUAL	General Visual of the Splitter Fairing
72-390-02	72-390-02	72-390-02-01		INSPECTION - GEN VISUAL	General Visual of the Splitter Fairing
72-400-01	72-400-01	72-400-01-01		INSPECTION - GEN VISUAL	General Visual of OGV's
72-400-02	72-400-02	72-400-02-01		INSPECTION - GEN VISUAL	General Visual of OGV's
72-405-00	72-405-00	72-405-00-01		REPLACE	Discard HPC Shaft/Assemblies
72-410-01	72-410-01	72-410-01-01		INSPECTION - DETAILED	Borescope Combustor
72-410-02	72-410-02	72-410-02-01		INSPECTION - DETAILED	Borescope Combustor
72-415-01	72-415-01	72-415-01-01		INSPECTION - DETAILED	Borescope Turbine Blades
72-415-02	72-415-02	72-415-02-01		INSPECTION - DETAILED	Borescope Turbine Blades
72-420-00	72-420-00	72-420-00-01		REPLACE	Discard HPT Disk
72-425-00	72-425-00	72-425-00-01		REPLACE	Discard IPT Disk
72-430-00	72-430-00	72-430-00-01		REPLACE	Discard IPT Shaft
72-435-00	72-435-00	72-435-00-01		REPLACE	Discard IPT Disks
72-440-00	72-440-00	72-440-00-01		REPLACE	Discard LPT Shaft
72-445-01	72-445-01	72-445-01-01		INSPECTION - DETAILED	Borescope Nozzle Guide Vanes
72-445-02	72-445-02	72-445-02-01		INSPECTION - DETAILED	Borescope Nozzle Guide Vanes



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
73-010-01	73-010-01	73-010-01-01 73-010-01-03		OPERATIONAL	Restore All C2 Messages - Left
73-010-02	73-010-02	73-010-02-02 73-010-02-04		OPERATIONAL	Restore All C2 Messages - Right
73-011-00	73-011-00	73-011-00-01 73-011-00-02 73-011-00-03 73-011-00-04		RESTORE	Engine Fuel
73-055-01	73-055-01	73-055-01-01 73-055-01-03		INSPECTION - DETAILED	Inspect Detailed Fuel Filter
73-055-02	73-055-02	73-055-02-02 73-055-02-04		INSPECTION - DETAILED	Inspect Detailed Fuel Filter
73-210-01	73-210-01	73-210-01-01		REPLACE	Fuel Pump Filter Element - Left
73-210-02	73-210-02	73-210-02-01		REPLACE	Fuel Pump Filter Element - Right
73-350-01	73-350-01	73-350-01-01		DISCARD	Discard LP Fuel Filter
73-350-02	73-350-02	73-350-02-01		DISCARD	Discard LP Fuel Filter
77-005-01	77-005-01	77-005-01-01 77-005-01-03		INSPECTION - DETAILED	Inspect for EGT System Degradation - Left
77-005-02	77-005-02	77-005-02-02 77-005-02-04		INSPECTION - DETAILED	Inspect for EGT System Degradation - Right
78-005-01	78-005-01	78-005-01-01 78-005-01-03		INSPECTION - GEN VISUAL	Inspect General Visual Exhaust Sleeve/Center Body - Left
78-005-02	78-005-02	78-005-02-02 78-005-02-04		INSPECTION - GEN VISUAL	Inspect General Visual Exhaust Sleeve/Center Body - Right
78-010-01	78-010-01	78-010-01-01 78-010-01-03		INSPECTION - DETAILED	Inspect Detailed T/R Blocker Door Hinges, Drag Links and Attachments - Left
78-010-02	78-010-02	78-010-02-02 78-010-02-04		INSPECTION - DETAILED	Inspect Detailed T/R Blocker Door Hinges, Drag Links and Attachments - Right



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
78-015-01	78-015-01	78-015-01-01 78-015-01-03		INSPECTION - DETAILED	Thrust Reverser Bullnose Seal
78-015-02	78-015-02	78-015-02-02 78-015-02-04		INSPECTION - DETAILED	Thrust Reverser Bullnose Seal
78-020-01	78-020-01	78-020-01-01 78-020-01-03		OPERATIONAL	Thrust Reverser Locks - Left
78-020-02	78-020-02	78-020-02-02 78-020-02-04		OPERATIONAL	Thrust Reverser Locks - Right
78-025-01	78-025-01	78-025-01-01 78-025-01-03		OPERATIONAL	Thrust Reverser Sync Lock- Left
78-025-02	78-025-02	78-025-02-02 78-025-02-04		OPERATIONAL	Thrust Reverser Sync Lock - Right
78-030-01	78-030-01	78-030-01-01 78-030-01-03		OPERATIONAL	Operationally Check DCV and Locking Sensors - Left
78-030-02	78-030-02	78-030-02-02 78-030-02-04		OPERATIONAL	Operationally Check DCV and Locking Sensors - Right
78-205-01	78-205-01	78-205-01-01		INSPECTION - GEN VISUAL	Thrust Reverser Bullnose Seal - Left
78-205-02	78-205-02	78-205-02-01		INSPECTION - GEN VISUAL	Thrust Reverser Bullnose Seal - Right
78-210-01	78-210-01	78-210-01-01		OPERATIONAL	Thrust Reverser System
78-210-02	78-210-02	78-210-02-01		OPERATIONAL	Thrust Reverser System
78-215-01	78-215-01	78-215-01-01		OPERATIONAL	Thrust Reverser System
78-215-02	78-215-02	78-215-02-01		OPERATIONAL	Thrust Reverser System
78-220-01	78-220-01	78-220-01-01		OPERATIONAL	Operationally Check Sync Lock on Thrust Reverser
78-220-02	78-220-02	78-220-02-01		OPERATIONAL	Operationally Check Sync Lock on Thrust Reverser
78-225-01	78-225-01	78-225-01-01		INSPECTION - DETAILED	Inspect Detailed T/R Blocker Door Hinge and Drag Link Attachments - Left



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
78-225-02	78-225-02	78-225-02-01		INSPECTION - DETAILED	Inspect Detailed T/R Blocker Door Hinge and Drag Link Attachments - Right
78-350-01	78-350-01	78-350-01-01		INSPECTION - DETAILED	Inspect Detailed Thrust Reverser Blocker Door Hinge and Drag Link Attachments
78-350-02	78-350-02	78-350-02-01		INSPECTION - DETAILED	Inspect Detailed Thrust Reverser Blocker Door Hinge and Drag Link Attachments
78-355-01	78-355-01	78-355-01-01		INSPECTION - DETAILED	Thrust Reverser Bullnose Seal
78-355-02	78-355-02	78-355-02-01		INSPECTION - DETAILED	Thrust Reverser Bullnose Seal
78-360-01	78-360-01	78-360-01-01		OPERATIONAL	Thrust Reverser Locks
78-360-02	78-360-02	78-360-02-01		OPERATIONAL	Thrust Reverser Locks
78-365-01	78-365-01	78-365-01-01		OPERATIONAL	Thrust Reverser Sync Lock
78-365-02	78-365-02	78-365-02-01		OPERATIONAL	Thrust Reverser Sync Lock
78-370-01	78-370-01	78-370-01-01		OPERATIONAL	Thrust Reverser Sensor Checks
78-370-02	78-370-02	78-370-02-01		OPERATIONAL	Thrust Reverser Sensor Checks
78-375-01	78-375-01	78-375-01-01		INSPECTION - GEN VISUAL	Inspect Fire Seal
78-375-02	78-375-02	78-375-02-01		INSPECTION - GEN VISUAL	Inspect Fire Seal
78-380-01	78-380-01	78-380-01-01		INSPECTION - GEN VISUAL	Inspect Thrust Reverser Hinges
78-380-02	78-380-02	78-380-02-01		INSPECTION - GEN VISUAL	Inspect Thrust Reverser Hinges
78-385-01	78-385-01	78-385-01-01		VISUAL CHECK	Thrust Reverser Thermal Protection System
78-385-02	78-385-02	78-385-02-01		VISUAL CHECK	Thrust Reverser Thermal Protection System
79-010-01	79-010-01	79-010-01-01 79-010-01-03		INSPECTION - DETAILED	Inspect Oil Filter Scavenge Screen - Left



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
79-010-02	79-010-02	79-010-02-02 79-010-02-04		INSPECTION - DETAILED	Inspect Oil Filter Scavenge Screen - Right
79-385-01	79-385-01	79-385-01-01		RESTORE	Restore Oil Pressure Filter
79-385-02	79-385-02	79-385-02-01		RESTORE	Restore Oil Pressure Filter
79-390-01	79-390-01	79-390-01-01		REPLACE	Replace Scavenge Oil Filter
79-390-02	79-390-02	79-390-02-01		REPLACE	Replace Scavenge Oil Filter
80-005-01	80-005-01	80-005-01-01 80-005-01-03		INSPECTION - DETAILED	Inspect Starter Chip Detector - Left
80-005-02	80-005-02	80-005-02-02 80-005-02-04		INSPECTION - DETAILED	Inspect Starter Chip Detector - Right
80-205-01	80-205-01	80-205-01-01		SERVICE	Starter Oil
80-205-02	80-205-02	80-205-02-01		SERVICE	Starter Oil
80-210-01	80-210-01	80-210-01-01		INSPECTION - DETAILED	Starter Chip Detector
80-210-02	80-210-02	80-210-02-01		INSPECTION - DETAILED	Starter Chip Detector
80-350-01	80-350-01	80-350-01-01		SERVICE	Starter Oil
80-350-02	80-350-02	80-350-02-01		SERVICE	Starter Oil
80-355-01	80-355-01	80-355-01-01		INSPECTION - DETAILED	Starter Chip Detector
80-355-02	80-355-02	80-355-02-01		INSPECTION - DETAILED	Starter Chip Detector





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
12-002-01-01	12-002-01	12-002-01		LUBRICATE	Left Elevator Power Control Actuators and Elevator Hinges
12-002-01-02	12-002-01	12-002-01		LUBRICATE	Right Elevator Power Control Actuators and Elevator Hinges
12-004-00-01	12-004-00	12-004-00		LUBRICATE	RUDDER PCU'S, RUDDER AND TAB HINGES
12-006-00-01	12-006-00	12-006-00		LUBRICATE	HORIZONTAL STABILIZER BALLSCREW ACTUATOR
12-008-00-01	12-008-00	12-008-00		LUBRICATE	Left Wing Inboard Leading Edge Torque Tube Supports and Couplings
12-008-00-02	12-008-00	12-008-00		LUBRICATE	Right Wing Inboard Leading Edge Torque Tube Supports and Couplings
12-008-00-11	12-008-00	12-008-00		LUBRICATE	Left Wing Outboard Leading Edge Torque Tube Supports and Couplings
12-008-00-12	12-008-00	12-008-00		LUBRICATE	Right Wing Outboard Leading Edge Torque Tube Supports and Couplings
12-008-01-01	12-008-01	12-008-01		LUBRICATE	Forward Cargo Compartment Torque Tube Supports and Couplings
12-008-01-02	12-008-01	12-008-01		LUBRICATE	Forward Cargo Compartment Torque Tube Supports and Couplings
12-008-01-03	12-008-01	12-008-01		LUBRICATE	Forward Cargo Compartment Torque Tube Supports and Couplings
12-008-01-04	12-008-01	12-008-01		LUBRICATE	Forward Cargo Compartment Torque Tube Supports and Couplings
12-008-01-05	12-008-01	12-008-01		LUBRICATE	Forward Cargo Compartment Torque Tube Supports and Couplings
12-008-01-06	12-008-01	12-008-01		LUBRICATE	Forward Cargo Compartment Torque Tube Supports and Couplings
12-010-00-01	12-010-00	12-010-00		LUBRICATE	Left Wing Inboard Slat Main Tracks
12-010-00-02	12-010-00	12-010-00		LUBRICATE	Right Wing Inboard Slat Main Tracks
12-012-00-01	12-012-00	12-012-00		LUBRICATE	Left Wing Outboard Slats Main Tracks
12-012-00-02	12-012-00	12-012-00		LUBRICATE	Right Wing Outboard Slats Main Tracks
12-014-00-01	12-014-00	12-014-00		LUBRICATE	Left Wing Inboard Slat Track Rollers and Pinion Bearings
12-014-00-02	12-014-00	12-014-00		LUBRICATE	Right Wing Inboard Slat Track Rollers and Pinion Bearings
12-014-00-11	12-014-00	12-014-00		LUBRICATE	Left Wing Outboard Slat Main Track Rollers & Pinion Bearings
12-014-00-12	12-014-00	12-014-00		LUBRICATE	Right Wing Outboard Slat Main Track Rollers & Pinion Bearings
12-018-00-01	12-018-00	12-018-00		LUBRICATE	Left Wing Krueger Flap Drive Arm Bearing
12-018-00-02	12-018-00	12-018-00		LUBRICATE	Right Wing Krueger Flap Drive Arm Bearing



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
12-020-00-01	12-020-00	12-020-00		LUBRICATE	Left Wing Inboard Spoiler Hinges and PCU'S
12-020-00-02	12-020-00	12-020-00		LUBRICATE	Right Wing Inboard Spoiler Hinges and PCU'S
12-022-00-01	12-022-00	12-022-00		LUBRICATE	Left Wing Outboard Spoiler Hinges and PCU'S
12-022-00-02	12-022-00	12-022-00		LUBRICATE	Right Wing Outboard Spoiler Hinges and PCU'S
12-024-00-01	12-024-00	12-024-00		LUBRICATE	Left Wing Aileron Power Control Units (PCUs) and Hinges
12-024-00-02	12-024-00	12-024-00		LUBRICATE	Right Wing Aileron Power Control Units (PCUs) and Hinges
12-026-00-01	12-026-00	12-026-00		LUBRICATE	Left Wing Flaperon Power Control Units (PCU's) and Hinges
12-026-00-02	12-026-00	12-026-00		LUBRICATE	Right Wing Flaperon Power Control Units (PCU's) and Hinges
12-030-00-01	12-030-00	12-030-00		LUBRICATE	Left Wing Trailing Edge Torque Tube and Torque Tube Supports
12-030-00-02	12-030-00	12-030-00		LUBRICATE	Right Wing Trailing Edge Torque Tube and Torque Tube Supports
12-034-00-01	12-034-00	12-034-00		LUBRICATE	Left Wing Inboard Flap Transmission No. 4, Ballscrew and Gimbal
12-034-00-02	12-034-00	12-034-00		LUBRICATE	Right Wing Inboard Flap Transmission No. 5, Ballscrew and Gimbal
12-034-00-11	12-034-00	12-034-00		LUBRICATE	Left Wing Inboard Flap No. 3 Transmission, Ballscrew and Gimbal
12-034-00-12	12-034-00	12-034-00		LUBRICATE	Right Wing Inboard Flap No. 6 Transmission, Ballscrew and Gimbal
12-034-00-21	12-034-00	12-034-00	W-12-034-00-31	LUBRICATE	Left Wing Outboard Flap Transmissions No. 1 Ballscrew and Gimbal
12-034-00-22	12-034-00	12-034-00	W-12-034-00-32	LUBRICATE	Right Wing Outboard Flap Transmission No. 8, Ballscrew and Gimbal
12-034-00-31	12-034-00	12-034-00	W-12-034-00-21	LUBRICATE	Left Wing Outboard Flap Transmission No. 2, Ballscrew and Gimbal
12-034-00-32	12-034-00	12-034-00	W-12-034-00-22	LUBRICATE	Right Wing Outboard Flap Transmission No. 7, Ballscrew and Gimbal
12-050-00-01	12-050-00	12-050-00		LUBRICATE	Left Wing Inboard Flap, Inboard Flap Support No. 4 Support Mechanisms
12-050-00-02	12-050-00	12-050-00		LUBRICATE	Right Wing Inboard Flap, Inboard Flap Support No. 5 Support Mechanisms
12-050-00-03	12-050-00	12-050-00		LUBRICATE	Left Wing Inboard Flap, Outboard Flap Support No. 3 Mechanisms
12-050-00-04	12-050-00	12-050-00		LUBRICATE	Right Wing Inboard Flap, Outboard Flap Support No. 6 Mechanisms
12-050-00-11	12-050-00	12-050-00		LUBRICATE	Left Wing Inboard Aft Flap Track Rollers
12-050-00-12	12-050-00	12-050-00		LUBRICATE	Right Wing Inboard Aft Flap Track Rollers



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
12-050-00-21	12-050-00	12-050-00	W-12-050-00-31	LUBRICATE	Left Wing Outboard Flap, Outboard Support No. 1 Mechanisms
12-050-00-22	12-050-00	12-050-00	W-12-050-00-32	LUBRICATE	Right Wing Outboard Flap, Outboard Support No. 8 Mechanisms
12-050-00-31	12-050-00	12-050-00	W-12-050-00-21	LUBRICATE	Left Wing Outboard Flap, Inboard Support No. 2 Support Mechanisms
12-050-00-32	12-050-00	12-050-00	W-12-050-00-22	LUBRICATE	Right Wing Outboard Flap, Inboard Support No. 7 Support Mechanisms
12-050-00-41	12-050-00	12-050-00		LUBRICATE	Left Wing Outbd Flap, Inboard Auxiliary Support Tracks and Carriage
12-050-00-42	12-050-00	12-050-00		LUBRICATE	Right Wing Outbd Flap, Inboard Auxiliary Support Tracks and Carriages
12-050-00-51	12-050-00	12-050-00		LUBRICATE	Left Wing Outbd Flap, Outboard Auxiliary Support Tracks and Carriages
12-050-00-52	12-050-00	12-050-00		LUBRICATE	Right Wing Outbd Flap, Outboard Auxiliary Support Tracks and Carriages
12-070-00-01	12-070-00	12-070-00		LUBRICATE	Nose Landing Gear Steering and Actuating Components - Upper End
12-070-00-10	12-070-00	12-070-00		LUBRICATE	Nose Landing Gear Steering and Actuating Components - Lower End
12-074-00-01	12-074-00	12-074-00		LUBRICATE	Nose Landing Gear Doors and Actuating Mechanisms
12-080-00-01	12-080-00	12-080-00	W-12-082-00-01	LUBRICATE	Left Main Landing Gear and Actuating Mechanisms - Upper End
12-080-00-02	12-080-00	12-080-00	W-12-082-00-02	LUBRICATE	Right Main Landing Gear and Actuating Mechanisms - Upper End
12-080-00-03	12-080-00	12-080-00	W-12-082-00-03	LUBRICATE	Left Main Landing Gear and Actuating Mechanisms - Upper End (Applicable to 300ER, 200LR and 777F)
12-080-00-04	12-080-00	12-080-00	W-12-082-00-04	LUBRICATE	Right Main Landing Gear and Actuating Mechanisms - Upper End (Applicable to 300ER, 200LR and 777F)
12-080-00-05	12-080-00	12-080-00		LUBRICATE	Left Main Landing Gear and Actuating Mechanisms - Lower End (Applicable to 200LR and 777F)
12-080-00-06	12-080-00	12-080-00		LUBRICATE	Right Main Landing Gear and Actuating Mechanisms - Lower End (Applicable to 200LR and 777F)
12-080-00-11	12-080-00	12-080-00		LUBRICATE	Left Main Landing Gear and Actuating Mechanisms - Lower End
12-080-00-12	12-080-00	12-080-00		LUBRICATE	Right Main Landing Gear and Actuating Mechanisms - Lower End
12-080-00-13	12-080-00	12-080-00		LUBRICATE	Left Main Landing Gear and Actuating Mechanisms - Lower End (Applicable to 300ER)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
12-080-00-14	12-080-00	12-080-00		LUBRICATE	Right Main Landing Gear and Actuating Mechanisms - Lower End (Applicable to 300ER)
12-081-00-01	12-081-00	12-081-00		LUBRICATE	Main Landing Gear Truck Beam and Inner Cylinder Pivot Joints
12-081-00-02	12-081-00	12-081-00		LUBRICATE	Main Landing Gear Truck Beam and Inner Cylinder Pivot Joints
12-082-00-01	12-082-00	12-082-00	W-12-080-00-01	LUBRICATE	Main Landing Gear Forward Trunnion Bearing Housing and Retract Arm Assembly
12-082-00-02	12-082-00	12-082-00	W-12-080-00-02	LUBRICATE	Main Landing Gear Forward Trunnion Bearing Housing and Retract Arm Assembly
12-082-00-03	12-082-00	12-082-00	W-12-080-00-03	LUBRICATE	Main Landing Gear Forward Trunnion Bearing Housing and Retract Arm Assembly
12-082-00-04	12-082-00	12-082-00	W-12-080-00-04	LUBRICATE	Main Landing Gear Forward Trunnion Bearing Housing and Retract Arm Assembly
12-086-00-01	12-086-00	12-086-00		LUBRICATE	Left Main Landing Gear Doors and Actuating Mechanisms
12-086-00-02	12-086-00	12-086-00		LUBRICATE	Right Main Landing Gear Doors and Actuating Mechanisms
12-086-00-03	12-086-00	12-086-00		LUBRICATE	Left Main Landing Gear Doors and Actuating Mechanisms
12-086-00-04	12-086-00	12-086-00		LUBRICATE	Right Main Landing Gear Doors and Actuating Mechanisms
12-088-00-01	12-088-00	12-088-00		LUBRICATE	Left Main Landing Gear Support Beam
12-088-00-02	12-088-00	12-088-00		LUBRICATE	Right Main Landing Gear Support Beam
12-088-00-03	12-088-00	12-088-00		LUBRICATE	Left Main Landing Gear Support Beam
12-088-00-04	12-088-00	12-088-00		LUBRICATE	Right Main Landing Gear Support Beam
12-090-00-01	12-090-00	12-090-00		LUBRICATE	Forward Large Cargo Door Hinge Pins
12-092-00-01	12-092-00	12-092-00		LUBRICATE	Aft Large Cargo Door Hinge Pins
12-094-00-01	12-094-00	12-094-00		LUBRICATE	Forward Large Cargo Door, Door to Cutout Mating Surfaces
12-096-00-01	12-096-00	12-096-00		LUBRICATE	Aft Large Cargo Door, Door to Cutout Mating Surfaces
12-100-00-01	12-100-00	12-100-00		LUBRICATE	Forward Large Cargo Door, Door Mechanisms
12-102-00-01	12-102-00	12-102-00		LUBRICATE	Aft Large Cargo Door, Door Mechanisms



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
12-104-00-01	12-104-00	12-104-00		LUBRICATE	Aft Small Cargo Door Hinge Arms and Adjustment Rods
12-106-00-01	12-106-00	12-106-00		LUBRICATE	Passenger Entry Door Mechanisms
12-106-00-03	12-106-00	12-106-00		LUBRICATE	Crew Entry Door Mechanisms
12-106-00-04	12-106-00	12-106-00		LUBRICATE	Passenger Entry Door Mechanisms
12-108-00-01	12-108-00	12-108-00		LUBRICATE	Bulk Cargo Door Probe Support Fittings
12-110-00-01	12-110-00	12-110-00		LUBRICATE	Forward Access Door Latch Pin
12-110-00-02	12-110-00	12-110-00		LUBRICATE	Forward Access Door Latch Pin
12-110-00-03	12-110-00	12-110-00		LUBRICATE	Forward Access Door Latch Pin
12-110-00-04	12-110-00	12-110-00		LUBRICATE	Forward Access Door Latch Pin
12-110-00-05	12-110-00	12-110-00		LUBRICATE	Forward Access Door Latch Pin
12-110-00-06	12-110-00	12-110-00		LUBRICATE	Forward Access Door Latch Pin
12-112-00-01	12-112-00	12-112-00		LUBRICATE	Main Equipment Center Access Door Latch Pin
12-114-00-01	12-114-00	12-114-00		LUBRICATE	Ram Air Turbine (RAT) Actuator, Strut and Door Actuation Link
12-118-00-01	12-118-00	12-118-00		LUBRICATE	Left Wing Nacelle Attach Fittings (For PW 4000 engines only)
12-118-00-02	12-118-00	12-118-00		LUBRICATE	Right Wing Nacelle Attach Fittings (For PW 4000 engines only)
12-118-00-03	12-118-00	12-118-00		LUBRICATE	Left Wing Nacelle Attach Fittings (For GE90 engines only)
12-118-00-04	12-118-00	12-118-00		LUBRICATE	Right Wing Nacelle Attach Fittings (For GE90 engines only)
12-118-00-05	12-118-00	12-118-00		LUBRICATE	Left Wing Nacelle Attach Fittings (For Trent engines only)
12-118-00-06	12-118-00	12-118-00		LUBRICATE	Right Wing Nacelle Attach Fittings (For Trent engines only)
12-122-00-01	12-122-00	12-122-00		LUBRICATE	No. 2 Left and Right Flight Compartment Window Drive Tracks
20-010-00-01	20-010-00	20-010-00		INSPECTION - DETAILED	Primary Flight Control and Brake Control Cables Turns
20-010-00-02	20-010-00	20-010-00		INSPECTION - DETAILED	Primary Flight Control and Brake Control Cables



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
20-010-00-03	20-010-00	20-010-00		INSPECTION - DETAILED	Primary Flight Control and Brake Control Cable Turns
20-010-00-04	20-010-00	20-010-00		INSPECTION - DETAILED	Primary Flight Control Cable Turns
20-010-00-05	20-010-00	20-010-00		INSPECTION - DETAILED	Primary Flight Control Cable Turns
20-012-00-01	20-012-00			INSPECTION - DETAILED	Nose Gear Steering Control Cable Turns
20-012-00-02	20-012-00			INSPECTION - DETAILED	Nose Gear Steering Control Cable Turns
20-015-00-01	20-015-00	20-015-00		INSPECTION - DETAILED	Primary Flight Control and Brake Control Cables - straight runs
20-015-00-02	20-015-00	20-015-00		INSPECTION - DETAILED	Primary Flight Control and Brake Control Cables - straight runs
20-015-00-03	20-015-00	20-015-00		INSPECTION - DETAILED	Primary Flight Control and Brake Control Cables - Straight Runs
20-015-00-04	20-015-00	20-015-00		INSPECTION - DETAILED	Primary Flight Control and Brake Control Cables - Straight Runs
20-015-00-05	20-015-00	20-015-00		INSPECTION - DETAILED	Primary Flight Control and Brake Control Cable - Straight Runs
20-015-00-06	20-015-00	20-015-00		INSPECTION - DETAILED	Primary Flight Control and Brake Control Cable - Straight Runs
20-015-00-07	20-015-00	20-015-00		INSPECTION - DETAILED	Primary Flight Control Cables - Straight Runs
20-015-00-08	20-015-00	20-015-00		INSPECTION - DETAILED	Primary Flight Control Cables - Straight Runs
20-015-00-09	20-015-00	20-015-00		INSPECTION - DETAILED	Primary Flight Control Cables in Fuselage - Straight Runs
20-018-00-01	20-018-00			INSPECTION - DETAILED	Nose Gear Steering Control Cables - straight runs



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
20-018-00-02	20-018-00			INSPECTION - DETAILED	Nose Gear Steering Control Cables - straight runs
20-070-00-01	20-070-00	20-070-00		INSPECTION - DETAILED	Exposed, Unprotected Brake Control Cables in the Wheel Well
20-070-00-02	20-070-00	20-070-00		INSPECTION - DETAILED	Exposed, Unprotected Brake Control Cables in the Wheel Well
20-110-00-01	20-110-00	20-110-00		INSPECTION - DETAILED	Primary Flight Control Cables - Protected Unpressurized Areas
20-110-00-02	20-110-00	20-110-00		INSPECTION - DETAILED	Primary Flight Control Cables - Protected Unpressurized Areas
20-110-00-03	20-110-00	20-110-00		INSPECTION - DETAILED	Primary Flight Control Cables - Protected Unpressurized Areas
20-110-00-04	20-110-00	20-110-00		INSPECTION - DETAILED	Primary Flight Control Cables - Protected Unpressurized Areas
20-110-00-05	20-110-00	20-110-00		INSPECTION - DETAILED	Primary Flight Control Cables - PROTECTED/UNPROTECTED UNPRESSURIZED AREAS
20-200-00-01	20-200-00	20-200-00		FUNCTIONAL	HIRF/L AFDC Task for ILS, RA, AIMS, Backdrive and Cross Channel
20-250-10-01	20-250-10	20-250-10		INSPECTION - DETAILED	FOIL/MESH PANELS; ENGINE COWLS, STRUT, LEADING EDGE
20-250-20-01	20-250-20	20-250-20		INSPECTION - DETAILED	FOIL/MESH PANELS; ENGINE COWLS, STRUT, LEADING EDGE
20-251-10-01	20-251-10	20-251-10		INSPECTION - DETAILED	FOIL/MESH PANELS; ENGINE COWLS, STRUT, LEADING EDGE
20-251-20-01	20-251-20	20-251-20		INSPECTION - DETAILED	FOIL/MESH PANELS; ENGINE COWLS, STRUT, LEADING EDGE
20-252-10-01	20-252-10	20-252-10		INSPECTION - DETAILED	FOIL/MESH PANELS; ENGINE COWLS, STRUT, LEADING EDGE
20-252-20-01	20-252-20	20-252-20		INSPECTION - DETAILED	FOIL/MESH PANELS; ENGINE COWLS, STRUT, LEADING EDGE
20-260-00-01	20-260-00	20-260-00		FUNCTIONAL	Ram Air Turbine (RAT) Wire Shielding Functional Check



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-270-01-01	20-270-01	20-270-01		FUNCTIONAL	PFCS Wire Shielding Functional Check - Left Wing
20-270-02-01	20-270-02	20-270-02		FUNCTIONAL	PFCS Wire Shielding Functional Check - Right Wing
20-280-00-01	20-280-00	20-280-00		FUNCTIONAL	PFCS Wire Shielding Functional Check - Empennage
20-290-00-01	20-290-00	20-290-00		FUNCTIONAL	HIRF/Lightning Ace Wire Bundle Shielding
20-300-00-01	20-300-00	20-300-00		FUNCTIONAL	HIRF/Arlinc 629 Buses for Flight Controls, Couplers to EE Racks
20-310-01-01	20-310-01	20-310-01		FUNCTIONAL	Functional Check Wire Bundle Inspection Left Flaps, Slats, Skew Sensors
20-310-02-01	20-310-02	20-310-02		FUNCTIONAL	Functional Check Wire Bundle Right Flaps, Slats, Skew Sensors
20-320-00-01	20-320-00	20-320-00		FUNCTIONAL	Gust Suppression Transducers Wire Shielding Functional Check
20-330-00-01	20-330-00	20-330-00		FUNCTIONAL	HIRF/Lightning ACE Disconnects to Modal Suppression Transducers
20-340-00-01	20-340-00	20-340-00		FUNCTIONAL	HIRF/lightning ACE disconnects to pitch rate sensors
20-400-00-01	20-400-00	20-400-00		FUNCTIONAL	HIRF/Lightning Glide Slope and Localizer Antenna Coax
20-410-00-01	20-410-00	20-410-00		INSPECTION - DETAILED	Radome Diverter Strips Detailed Visual Inspection
20-420-00-01	20-420-00	20-420-00		FUNCTIONAL	HIRF/Lightning Localizer Tracking, VOR/Localizer Antenna COAX
20-430-00-01	20-430-00	20-430-00		FUNCTIONAL	HIRF/Lightning Glide Slope Tracking Antenna COAX
20-440-00-01	20-440-00	20-440-00		FUNCTIONAL	HIRF/Lightning VOR/Localizer Capture Antenna COAX
20-445-00-01	20-445-00	20-445-00		INSPECTION - DETAILED	Fin Tip Diverter Strip
20-450-00-01	20-450-00	20-450-00		FUNCTIONAL	HIRF/Lightning Radio Altimeter Antenna to Transceiver Coax
20-451-00-01	20-451-00	20-451-00		FUNCTIONAL	HIRF/Lightning Radio Altimeter Antenna to Transceiver Coax
20-460-00-01	20-460-00	20-460-00		FUNCTIONAL	HIRF/Lightning GPS Antenna to Left and Right MMR
20-470-00-01	20-470-00	20-470-00		FUNCTIONAL	HIRF/Lightning Protection - Air Supply Isolation Valves
20-471-00-01	20-471-00	20-471-00		FUNCTIONAL	HIRF/Lightning Protection - Main Landing Gear (MLG) Selector/Bypass Valve Module
20-472-00-01	20-472-00	20-472-00		FUNCTIONAL	HIRF/Lightning Protection - Center Hydraulic System Quantity Transmitter





## 777-200/300 MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-473-01-01	20-473-01	20-473-01		FUNCTIONAL	HIRF/Lightning Protection - Flight Control Shutoff Valves - LH Wing & LH MLG W/W
20-473-02-01	20-473-02	20-473-02		FUNCTIONAL	HIRF/Lightning Protection - Flight Control Shutoff Valves - RH Wing & RH MLG W/W
20-474-01-01	20-474-01	20-474-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Crossfeed and Isolation Valves - LH Wing & LH MLG W/W
20-474-02-01	20-474-02	20-474-02		FUNCTIONAL	HIRF/Lightning Protection - Fuel Crossfeed and Isolation Valves - RH Wing & RH MLG W/W
20-475-00-01	20-475-00	20-475-00		FUNCTIONAL	HIRF/Lightning Protection - Center Override Jettison Fuel Pumps - MLG W/W
20-476-01-01	20-476-01	20-476-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Boost Pumps - LH Wing & LH MLG W/W
20-476-02-01	20-476-02	20-476-02		FUNCTIONAL	HIRF/Lightning Protection - Fuel Boost Pumps - RH Wing & RH MLG W/W
20-477-01-01	20-477-01	20-477-01		FUNCTIONAL	HIRF/Lightning Protection - Main Tank Fuel Jettison Pump - LH Wing
20-477-02-01	20-477-02	20-477-02		FUNCTIONAL	HIRF/Lightning Protection - Main Tank Fuel Jettison Pump - RH Wing
20-478-01-01	20-478-01	20-478-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Jettison Nozzle Valves - LH Wing
20-478-02-01	20-478-02	20-478-02		FUNCTIONAL	HIRF/Lightning Protection - Fuel Jettison Nozzle Valves - RH Wing
20-479-01-01	20-479-01	20-479-01		FUNCTIONAL	HIRF/Lightning Protection - Fuel Jettison Nozzle Valves - LH Wing
20-479-02-01	20-479-02	20-479-02		FUNCTIONAL	HIRF/Lightning Protection - Fuel Jettison Nozzle Valves - RH Wing
20-500-01-01	20-500-01	20-500-01		INSPECTION - DETAILED	GE90 FADEC Control System Wires Detail Inspection
20-500-02-01	20-500-02	20-500-02		INSPECTION - DETAILED	GE90 FADEC Control System Wires Detail Inspection
20-520-01-01	20-520-01	20-520-01		INSPECTION - DETAILED	PW4000 Electronic Engine Control System Wire Run
20-520-02-01	20-520-02	20-520-02		INSPECTION - DETAILED	PW4000 Electronic Engine Control System Wire Run
20-540-01-01	20-540-01	20-540-01		INSPECTION - DETAILED	Trent Electronic Engine Control System Wire Runs



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
20-540-02-01	20-540-02	20-540-02		INSPECTION - DETAILED	Trent Electronic Engine Control System Wire Runs
20-560-01-01	20-560-01	20-560-01		FUNCTIONAL	HIRF/ L Functional Test for FQIS, Left Side
20-560-02-01	20-560-02	20-560-02		FUNCTIONAL	HIRF/ L Functional Test for FQIS, Right Side
20-600-00-01	20-600-00	20-600-00		INSPECTION - DETAILED	Power Feeders connected to P100 and P200 Power Panels
20-602-00-01	20-602-00	20-602-00		RESTORE	Area Above Nose Landing Gear Wheel Well
20-640-10-01	20-640-10	20-640-10		INSPECTION - DETAILED	Wing Center Section Fuel Tank (SFAR 88)
20-641-00-01	20-641-00	20-641-00		INSPECTION - GEN VISUAL	ECS Bay Installed EWIS
20-642-00-01	20-642-00	20-642-00		INSPECTION - GEN VISUAL	Forward Bulkhead Left Main Landing Gear Wheel Well
20-644-00-01	20-644-00	20-644-00		INSPECTION - GEN VISUAL	Forward Bulkhead Right Main Landing Gear Wheel Well
20-648-00-01	20-648-00	20-648-00		INSPECTION - GEN VISUAL	Forward Cargo Power Drive Unit Wire Bundles
20-650-00-01	20-650-00	20-650-00		RESTORE	Areas Behind the FWD Cargo Compartment Sidewalls
20-650-00-02	20-650-00	20-650-00		RESTORE	Areas Behind the FWD Cargo Compartment Sidewalls
20-650-00-03	20-650-00	20-650-00		RESTORE	Areas Behind the FWD Cargo Compartment Sidewalls
20-650-00-04	20-650-00	20-650-00		RESTORE	Areas Behind the FWD Cargo Compartment Sidewalls
20-650-00-05	20-650-00	20-650-00		RESTORE	Areas Behind the FWD Cargo Compartment Sidewalls
20-651-00-01	20-651-00	20-651-00		RESTORE	Areas Below the AFT Cargo Compartment
20-652-00-01	20-652-00	20-652-00		INSPECTION - GEN VISUAL	Forward Cargo Compartment Power Feeders
20-652-00-02	20-652-00	20-652-00		INSPECTION - GEN VISUAL	Forward Cargo Compartment Power Feeders



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
20-652-00-03	20-652-00	20-652-00		INSPECTION - GEN VISUAL	Forward Cargo Compartment Power Feeders
20-652-00-04	20-652-00	20-652-00		INSPECTION - GEN VISUAL	Forward Cargo Compartment Power Feeders
20-652-00-05	20-652-00	20-652-00		INSPECTION - GEN VISUAL	Forward Cargo Compartment Power Feeders
20-652-00-06	20-652-00	20-652-00		INSPECTION - GEN VISUAL	Forward Cargo Compartment Power Feeders
20-654-00-01	20-654-00	20-654-00		RESTORE	Areas Behind the FWD Cargo Compartment Sidewalls
20-656-00-01	20-656-00	20-656-00		RESTORE	Areas Below the FWD Cargo Compartment
20-656-00-02	20-656-00	20-656-00		RESTORE	Areas Below the FWD Cargo Compartment
20-656-00-03	20-656-00	20-656-00		RESTORE	Areas Below the FWD Cargo Compartment
20-656-00-04	20-656-00	20-656-00		RESTORE	Areas Below the FWD Cargo Compartment
20-656-00-05	20-656-00	20-656-00		RESTORE	Areas Below the FWD Cargo Compartment
20-656-00-06	20-656-00	20-656-00		RESTORE	Areas Below the FWD Cargo Compartment
20-658-00-01	20-658-00	20-658-00		RESTORE	Area Behind the Forward Cargo Compartment
20-658-00-02	20-658-00	20-658-00		RESTORE	Area Behind the Forward Cargo Compartment
20-658-00-03	20-658-00	20-658-00		RESTORE	Area Behind the Forward Cargo Compartment
20-658-00-04	20-658-00	20-658-00		RESTORE	Area Behind the Forward Cargo Compartment
20-658-00-05	20-658-00	20-658-00		RESTORE	Area Behind the Forward Cargo Compartment
20-658-00-06	20-658-00	20-658-00		RESTORE	Area Behind the Forward Cargo Compartment
20-659-00-01	20-659-00	20-659-00		INSPECTION - GEN VISUAL	Area Behind the Forward Cargo Compartment
20-659-00-02	20-659-00	20-659-00		INSPECTION - GEN VISUAL	Area Behind the Forward Cargo Compartment
20-659-00-03	20-659-00	20-659-00		INSPECTION - GEN VISUAL	Area Behind the Forward Cargo Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
20-659-00-04	20-659-00	20-659-00		INSPECTION - GEN VISUAL	Area Behind the Forward Cargo Compartment
20-659-00-05	20-659-00	20-659-00		INSPECTION - GEN VISUAL	Area Behind the Forward Cargo Compartment
20-659-00-06	20-659-00	20-659-00		INSPECTION - GEN VISUAL	Area Behind the Forward Cargo Compartment
20-660-00-01	20-660-00	20-660-00		INSPECTION - GEN VISUAL	Aft Cargo Compartment Power Feeders
20-660-00-02	20-660-00	20-660-00		INSPECTION - GEN VISUAL	Aft Cargo Compartment Power Feeders
20-660-00-03	20-660-00	20-660-00		INSPECTION - GEN VISUAL	Aft Cargo Compartment Power Feeders
20-660-00-04	20-660-00	20-660-00		INSPECTION - GEN VISUAL	Aft Cargo Compartment Power Feeders
20-660-00-05	20-660-00	20-660-00		INSPECTION - GEN VISUAL	Aft Cargo Compartment Power Feeders
20-660-00-06	20-660-00	20-660-00		INSPECTION - GEN VISUAL	Aft Cargo Compartment Power Feeders
20-662-00-01	20-662-00	20-662-00		RESTORE	Areas Behind the Aft Cargo Compartment Sidewalls
20-664-00-01	20-664-00	20-664-00		RESTORE	Areas Behind the Aft Cargo Compartment Sidewalls
20-665-00-01	20-665-00	20-665-00		INSPECTION - GEN VISUAL	Aft Cargo Power Drive Unit Wire Bundles
20-668-00-01	20-668-00	20-668-00		INSPECTION - GEN VISUAL	APU Battery Installation and Power Feeders
20-670-00-01	20-670-00	20-670-00		RESTORE	Area Behind the Bulk Cargo Compartment Sidewalls
20-672-00-01	20-672-00	20-672-00		RESTORE	Area Behind the Bulk Cargo Compartment
20-700-00-01	20-700-00	20-700-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-700-00-02	20-700-00	20-700-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
20-700-00-03	20-700-00	20-700-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-700-00-04	20-700-00	20-700-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-700-00-05	20-700-00	20-700-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-701-00-01	20-701-00	20-701-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-701-00-02	20-701-00	20-701-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-701-00-03	20-701-00	20-701-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-701-00-04	20-701-00	20-701-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-701-00-05	20-701-00	20-701-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-702-00-01	20-702-00	20-702-00		INSPECTION - DETAILED	APU and RAT Power Feeders, and Galley and Cabin Power Feeders
20-702-00-02	20-702-00	20-702-00		INSPECTION - DETAILED	APU and RAT Power Feeders, and Galley and Cabin Power Feeders
20-704-00-01	20-704-00	20-704-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-705-00-01	20-705-00	20-705-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-706-00-01	20-706-00	20-706-00		INSPECTION - DETAILED	APU, RAT, Galley and Cabin Power Feeders in Passenger Compartment
20-708-00-01	20-708-00	20-708-00		RESTORE	Upper Surface of Ceiling Panels, Bins and Modules
20-708-00-02	20-708-00	20-708-00		RESTORE	Upper Surface of Ceiling Panels, Bins and Modules
20-708-00-03	20-708-00	20-708-00		RESTORE	Upper Surface of Ceiling Panels, Bins and Modules
20-708-00-04	20-708-00	20-708-00		RESTORE	Upper Surface of Ceiling Panels, Bins and Modules
20-708-00-05	20-708-00	20-708-00		RESTORE	Upper Surface of Ceiling Panels, Bins and Modules
20-712-00-01	20-712-00	20-712-00		INSPECTION - GEN VISUAL	Flight Deck EWIS
20-712-00-02	20-712-00	20-712-00		INSPECTION - GEN VISUAL	Flight Deck EWIS



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
20-712-00-03	20-712-00	20-712-00		INSPECTION - GEN VISUAL	Flight Deck EWIS
20-712-00-04	20-712-00	20-712-00		INSPECTION - GEN VISUAL	Flight Deck EWIS
20-712-00-05	20-712-00	20-712-00		INSPECTION - GEN VISUAL	Flight Deck EWIS
20-712-00-06	20-712-00	20-712-00		INSPECTION - GEN VISUAL	Flight Deck EWIS
20-714-00-01	20-714-00	20-714-00		RESTORE	Flight Deck
20-716-00-01	20-716-00	20-716-00		RESTORE	Area Around the Video Control Center
20-716-00-02	20-716-00	20-716-00		RESTORE	Area Around the Video Control Center
20-724-00-01	20-724-00	20-724-00		INSPECTION - DETAILED	Rat Cabin and Galley Power Feeders in the Passenger Compartment
20-728-00-01	20-728-00	20-728-00		INSPECTION - DETAILED	Rat and Cabin Power Feeder Bundles in Passenger Compartment
20-730-00-01	20-730-00	20-730-00		RESTORE	Equipment Racks in Main Equipment Center.
20-732-00-01	20-732-00	20-732-00		INSPECTION - DETAILED	APU, IDG, BAT. & CHGR and Ground Power Feeders in the Main Equipment Center
20-734-00-01	20-734-00	20-734-00		INSPECTION - GEN VISUAL	External Power Receptacle in the Main Equipment Center.
20-736-00-01	20-736-00	20-736-00		INSPECTION - DETAILED	APU Power Feeders in Main Deck Cargo Compartment
20-737-00-01	20-737-00	20-737-00		CLEAN	Main Deck Cargo Compartment Air Grilles
20-738-00-01	20-738-00	20-738-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-738-00-02	20-738-00	20-738-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-738-00-03	20-738-00	20-738-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-740-00-01	20-740-00	20-740-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
20-740-00-02	20-740-00	20-740-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-740-00-03	20-740-00	20-740-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-742-00-01	20-742-00	20-742-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-742-00-02	20-742-00	20-742-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-744-00-01	20-744-00	20-744-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-744-00-02	20-744-00	20-744-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-746-00-01	20-746-00	20-746-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-746-00-02	20-746-00	20-746-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-746-00-03	20-746-00	20-746-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-748-00-01	20-748-00	20-748-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-748-00-02	20-748-00	20-748-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-748-00-03	20-748-00	20-748-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-750-00-01	20-750-00	20-750-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-750-00-02	20-750-00	20-750-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-752-00-01	20-752-00	20-752-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-752-00-02	20-752-00	20-752-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-754-00-01	20-754-00	20-754-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-754-00-02	20-754-00	20-754-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
20-754-00-03	20-754-00	20-754-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-754-00-04	20-754-00	20-754-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-754-00-05	20-754-00	20-754-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-756-00-01	20-756-00	20-756-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-756-00-02	20-756-00	20-756-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-756-00-03	20-756-00	20-756-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-756-00-04	20-756-00	20-756-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-756-00-05	20-756-00	20-756-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-758-00-01	20-758-00	20-758-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-758-00-02	20-758-00	20-758-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-758-00-03	20-758-00	20-758-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-758-00-04	20-758-00	20-758-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-758-00-05	20-758-00	20-758-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-760-00-01	20-760-00	20-760-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-760-00-02	20-760-00	20-760-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-760-00-03	20-760-00	20-760-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-760-00-04	20-760-00	20-760-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-760-00-05	20-760-00	20-760-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
20-762-00-01	20-762-00	20-762-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-762-00-02	20-762-00	20-762-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-762-00-03	20-762-00	20-762-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-764-00-01	20-764-00	20-764-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-764-00-02	20-764-00	20-764-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-764-00-03	20-764-00	20-764-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-766-00-01	20-766-00	20-766-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-766-00-02	20-766-00	20-766-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-768-00-01	20-768-00	20-768-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-768-00-02	20-768-00	20-768-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-770-00-01	20-770-00	20-770-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-770-00-02	20-770-00	20-770-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-770-00-03	20-770-00	20-770-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-772-00-01	20-772-00	20-772-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-772-00-02	20-772-00	20-772-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-772-00-03	20-772-00	20-772-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-774-00-01	20-774-00	20-774-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-774-00-02	20-774-00	20-774-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-776-00-01	20-776-00	20-776-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
20-776-00-02	20-776-00	20-776-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-778-00-01	20-778-00	20-778-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-778-00-02	20-778-00	20-778-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-778-00-03	20-778-00	20-778-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-778-00-04	20-778-00	20-778-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-778-00-05	20-778-00	20-778-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-780-00-01	20-780-00	20-780-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-780-00-02	20-780-00	20-780-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-780-00-03	20-780-00	20-780-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-780-00-04	20-780-00	20-780-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-780-00-05	20-780-00	20-780-00		RESTORE	Areas Behind the Passenger Compartment Air Grilles
20-782-00-01	20-782-00	20-782-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-782-00-02	20-782-00	20-782-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-782-00-03	20-782-00	20-782-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-782-00-04	20-782-00	20-782-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-782-00-05	20-782-00	20-782-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-784-00-01	20-784-00	20-784-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-784-00-02	20-784-00	20-784-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-784-00-03	20-784-00	20-784-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
20-784-00-04	20-784-00	20-784-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-784-00-05	20-784-00	20-784-00		INSPECTION - GEN VISUAL	Wiring Behind Passenger Compartment Air Grilles
20-790-00-01	20-790-00	20-790-00		INSPECTION - GEN VISUAL	APU and APU Starter Power Feeders
20-792-00-01	20-792-00	20-792-00		INSPECTION - GEN VISUAL	APU and APU Starter Power Feeders
20-794-00-01	20-794-00	20-794-00		INSPECTION - DETAILED	APU and APU Starter Power Feeders
20-796-00-01	20-796-00	20-796-00		RESTORE	Main Deck Entry Doors
20-800-00-01	20-800-00	20-800-00		INSPECTION - DETAILED	ENGINE IDG AND BACKUP GENERATOR POWER FEEDERS - LEFT ENGINE
20-802-00-01	20-802-00	20-802-00		INSPECTION - DETAILED	ENGINE IDG AND BACKUP GENERATOR POWER FEEDERS - RIGHT ENGINE
20-840-01-01	20-840-01	20-840-01		INSPECTION - GEN VISUAL	IDG and Backup Power Feeders - Left Wing
20-840-02-01	20-840-02	20-840-02		INSPECTION - GEN VISUAL	IDG and Backup Power Feeders - Right Wing
20-842-00-01	20-842-00	20-842-00		INSPECTION - GEN VISUAL	EWIS within Nacelle Gap - Left
20-842-00-02	20-842-00	20-842-00		INSPECTION - GEN VISUAL	EWIS within Nacelle Gap - Right
20-844-00-01	20-844-00	20-844-00		INSPECTION - GEN VISUAL	IDG and Backup Power Feeders - Left Wing
20-844-00-02	20-844-00	20-844-00		INSPECTION - GEN VISUAL	IDG and Backup Power Feeders - Right Wing
20-850-00-01	20-850-00	20-850-00		INSPECTION - GEN VISUAL	Wing Leading Edge Wiring - Left Wing



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
20-851-00-01	20-851-00	20-851-00		INSPECTION - GEN VISUAL	Wing Leading Edge Wiring - Right Wing
20-852-00-01	20-852-00	20-852-00		INSPECTION - DETAILED	FQIS Wiring in the Wing Main Tank - Left
20-852-00-02	20-852-00	20-852-00		INSPECTION - DETAILED	FQIS Wiring in the Wing Main Tank - Right
20-856-11-01	20-856-11	20-856-11		INSPECTION - DETAILED	Center Fuel Tank (Rib 1 to Rib 8) - Left Wing (SFAR 88)
20-856-12-01	20-856-12	20-856-12		INSPECTION - DETAILED	Center Fuel Tank (Rib 1 to Rib 8) - Right Wing (SFAR 88)
20-858-11-01	20-858-11	20-858-11		INSPECTION - DETAILED	Main Tank (Rib 8 to Rib 17) - Left Wing (SFAR 88)
20-858-12-01	20-858-12	20-858-12		INSPECTION - DETAILED	Main Tank (Rib 8 to Rib 17) - Right Wing (SFAR 88)
20-860-11-01	20-860-11	20-860-11		INSPECTION - DETAILED	Main Tank (Rib 17 to Rib 32) - Left Wing (SFAR 88)
20-860-12-01	20-860-12	20-860-12		INSPECTION - DETAILED	Main Tank (Rib 17 to Rib 32) - Right Wing (SFAR 88)
20-866-00-01	20-866-00	20-866-00		INSPECTION - GEN VISUAL	Flap Support No. 3
20-868-00-01	20-868-00	20-868-00		INSPECTION - GEN VISUAL	Flap Support No. 6
21-010-00-01	21-010-00	21-010-00		REPLACE	Upper Recirculation Air Filters
21-020-00-01	21-020-00	21-020-00		REPLACE	Lower Recirculation Air Filters
21-030-00-01	21-030-00	21-030-00		REPLACE	Galley Ventilation Filters
21-033-00-01	21-033-00	21-033-00		OPERATIONAL	Main Deck Alerting System
21-034-00-01	21-034-00	21-034-00		OPERATIONAL	Alternate Ventilation System (AVS)
21-036-00-01	21-036-00	21-036-00		INSPECTION - DETAILED	Lavatory/Galley and Alternate Ventilation System (LGVS and AVS)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
21-037-00-01	21-037-00	21-037-00		RESTORE	Lav/Galley Ventilation System (LGVS)
21-048-00-01	21-048-00	21-048-00		OPERATIONAL	E/E Cooling System Override Switch
21-050-00-01	21-050-00	21-050-00		CLEAN	Equipment Cooling Air Filter
21-052-00-01	21-052-00	21-052-00		INSPECTION - DETAILED	IFE Cooling Smoke Detector
21-054-00-01	21-054-00	21-054-00		INSPECTION - DETAILED	IFE Cooling System Air Supply Multi-holed Orifices
21-055-00-01	21-055-00	21-055-00		FUNCTIONAL	Condenser/Reheater
21-060-00-01	21-060-00	21-060-00	W-21-070-00-01	INSPECTION - DETAILED	E11 Rack Satcom Backup Fan Check Valves
21-065-00-01	21-065-00	21-065-00	W-21-075-00-01	INSPECTION - DETAILED	E13 Rack Satcom Backup Fan Check Valves
21-070-00-01	21-070-00	21-070-00	W-21-060-00-01	INSPECTION - DETAILED	E11 Rack Satcom Backup Cooling Check Valve
21-075-00-01	21-075-00	21-075-00	W-21-065-00-01	INSPECTION - DETAILED	E13 Rack Satcom Backup Cooling Check Valve
21-080-00-01	21-080-00	21-080-00		OPERATIONAL	Outflow Valve Manual Control
21-090-00-01	21-090-00	21-090-00		OPERATIONAL	Landing Altitude Manual Select Switch
21-100-00-01	21-100-00	21-100-00	W-21-105-00-01	CLEAN/INSP	Cabin Pressure Control Outflow Valves
21-100-00-02	21-100-00	21-100-00	W-21-105-00-02	CLEAN/INSP	Cabin Pressure Control Outflow Valves
21-105-00-01	21-105-00	21-105-00	W-21-100-00-01	INSPECTION - GEN VISUAL	Cabin Pressure Control Outflow Valves
21-105-00-02	21-105-00	21-105-00	W-21-100-00-02	INSPECTION - GEN VISUAL	Cabin Pressure Control Outflow Valves
21-110-00-01	21-110-00	21-110-00	P-21-110-00-02	FUNCTIONAL	Cabin Positive Pressure Relief Valves - On-aircraft
21-110-00-02	21-110-00	21-110-00	R-21-110-00-01	FUNCTIONAL	Cabin Positive Pressure Relief Valves - Off-aircraft
21-120-00-01	21-120-00	21-120-00		REPLACE	Cabin Positive Pressure Relief Filters



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
21-130-00-01	21-130-00	21-130-00		OPERATIONAL	AFT and Bulk Cargo Temperature Selector Switches
21-131-00-01	21-131-00	21-131-00		FUNCTIONAL	AFT/Bulk Cargo Overheat Protection Switch & Relay
21-132-00-01	21-132-00	21-132-00		OPERATIONAL	AFT Cargo Temperature Selector Switch
21-133-00-01	21-133-00	21-133-00		OPERATIONAL	Aft Cargo Air Conditioning (ACAC)/Aft Lower Cargo Temperature Selector Switch
21-134-00-01	21-134-00	21-134-00		FUNCTIONAL	Aft Cargo Overheat Protection Switch & Relay
21-140-00-01	21-140-00	21-140-00	W-21-170-00-01	OPERATIONAL	AC Pack Flow Sensors
21-150-00-01	21-150-00	21-150-00		CLEAN	AC Pack Heat Exchangers
21-160-00-01	21-160-00	21-160-00		FUNCTIONAL	AC Pack Heat Exchangers
21-170-00-01	21-170-00	21-170-00		INSPECTION - DETAILED	AC Pack Fan Bypass Check Valve
21-180-00-01	21-180-00	21-180-00		INSPECTION - DETAILED	AC Pack Conditioned Air Check Valves
21-180-00-02	21-180-00	21-180-00	W-21-150-00-01	INSPECTION - DETAILED	AC Pack Conditioned Air Check Valves
21-190-00-01	21-190-00	21-190-00		OPERATIONAL	AC Pack Condenser Low Limit Valves
21-200-00-01	21-200-00	21-200-00		OPERATIONAL	AC Pack 2nd Stage Turbine Bypass Valves
21-210-00-01	21-210-00	21-210-00		OPERATIONAL	AC Pack Secondary Heat Exchangers Outlet Temperature Sensor
21-220-00-01	21-220-00	21-220-00		OPERATIONAL	Cabin Air Conditioning and Temperature Controllers
21-230-00-01	21-230-00	21-230-00		CLEAN	Ozone Converters
21-240-00-01	21-240-00	21-240-00		CLEAN	Ozone Converters
21-250-00-01	21-250-00	21-250-00		INSPECTION - GEN VISUAL	E/E Equipment Cooling Override Duct
21-260-00-01	21-260-00	21-260-00		INSPECTION - DETAILED	Lower Recirculation Air Fan Check Valves
22-040-00-01	22-040-00	22-040-00		OPERATIONAL	Take-Off/ Go-Around (TO/GA) Switch
23-010-00-01	23-010-00	23-010-00		FUNCTIONAL	Passenger Address System



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
23-010-00-02	23-010-00	23-010-00		FUNCTIONAL	Personnel Address System
23-020-00-01	23-020-00	23-020-00		OPERATIONAL	Passenger Address System
23-030-00-01	23-030-00	23-030-00		OPERATIONAL	Passenger Address System
23-040-00-01	23-040-00	23-040-00		OPERATIONAL	Cabin Interphone System Alternate Channel
23-050-00-01	23-050-00	23-050-00		OPERATIONAL	Flight Interphone System - Audio Transfer
23-060-00-01	23-060-00	23-060-00		INSPECTION - GEN VISUAL	Static Dischargers
23-070-00-01	23-070-00	23-070-00		OPERATIONAL	Voice Recorder System
23-080-00-01	23-080-00	23-080-00		FUNCTIONAL	Voice Recorder System - Four Channel Operation
23-085-00-01	23-085-00	23-085-00		FUNCTIONAL	Voice recorder back up power system
23-090-00-01	23-090-00	23-090-00		REPLACE	Voice Recorder - Underwater Locator Beacon
23-090-00-02	23-090-00	23-090-00		REPLACE	Voice Recorder - Underwater Locator Beacon
23-100-00-01	23-100-00	23-100-00		OPERATIONAL	Voice Recorder System - Under Water Locator Beacon
23-100-00-02	23-100-00	23-100-00		OPERATIONAL	Voice Recorder System - Under Water Locator Beacon
23-110-00-01	23-110-00	23-110-00		OPERATIONAL	Emergency Locator Transmitter (For A/C Equipped with Artex ELTs)
23-110-00-02	23-110-00	23-110-00		OPERATIONAL	Emergency Locator Transmitter (For A/C equipped with Honeywell ELTs)
23-110-00-03	23-110-00	23-110-00		OPERATIONAL	Emergency Locator Transmitter (For A/C Equipped with CEIS ELTs)
23-110-00-04	23-110-00	23-110-00		OPERATIONAL	Emergency Locator Transmitter (For A/C Equipped with CEIS/ELTA ELTs)
23-110-00-05	23-110-00	23-110-00		OPERATIONAL	Emergency Locator Transmitter (For A/C Equipped with Artex ELTs)
23-120-00-01	23-120-00	23-120-00		REPLACE	Emergency Locator Transmitter (For A/C equipped with Artex ELTs)
23-120-00-02	23-120-00	23-120-00		REPLACE	Emergency Locator Transmitter (For A/C equipped with Honeywell ELTs)
23-120-00-03	23-120-00	23-120-00		REPLACE	Emergency Locator Transmitter (For A/C equipped with CEIS ELTs)
23-120-00-04	23-120-00	23-120-00		REPLACE	Emergency Locator Transmitter (For A/C equipped with CEIS/ELTA ELTs)
23-180-00-01	23-180-00	23-180-00		OPERATIONAL	Low Frequency Underwater Locator Device



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
23-190-00-01	23-190-00	23-190-00		DISCARD	Low Frequency Underwater Locator Device Battery
24-010-00-01	24-010-00	24-010-00		SERVICE	IDG Oil Servicing - Left
24-010-00-02	24-010-00	24-010-00		SERVICE	IDG Oil Servicing - Right
24-011-00-01	24-011-00	24-011-00		SERVICE	IDG Oil Servicing - Left
24-011-00-02	24-011-00	24-011-00		SERVICE	IDG Oil Servicing - Right
24-012-00-01	24-012-00	24-012-00		SERVICE	IDG Oil Servicing -Left
24-012-00-02	24-012-00	24-012-00		SERVICE	IDG Oil Servicing -Right
24-030-00-01	24-030-00	24-030-00		SERVICE	VSCF Backup Generator Oil Servicing - Left
24-030-00-02	24-030-00	24-030-00		SERVICE	VSCF Backup Generator Oil Servicing - Right
24-040-00-01	24-040-00	24-040-00	W-24-070-00-01	SERVICE	Change IDG Oil - Left
24-040-00-02	24-040-00	24-040-00	W-24-070-00-02	SERVICE	Change IDG Oil - Right
24-041-00-01	24-041-00	24-041-00	W-24-071-00-01	SERVICE	Change IDG OIL - Left
24-041-00-02	24-041-00	24-041-00	W-24-071-00-02	SERVICE	Change IDG OIL - Right
24-042-00-01	24-042-00	24-042-00	W-24-072-00-01	SERVICE	IDG Oil Change - Left
24-042-00-02	24-042-00	24-042-00	W-24-072-00-02	SERVICE	IDG Oil Change - Right
24-050-00-01	24-050-00	24-050-00		SERVICE	VSCF Backup Generator Oil and Filter Change
24-050-00-02	24-050-00	24-050-00		SERVICE	VSCF Backup Generator Oil and Filter Change
24-050-00-03	24-050-00	24-050-00		SERVICE	VSCF Backup Generator Oil and Filter Change - Left
24-050-00-04	24-050-00	24-050-00		SERVICE	VSCF Backup Generator Oil and Filter Change - Right
24-050-00-05	24-050-00	24-050-00		SERVICE	VSCF Backup Generator Oil Change - Left
24-050-00-06	24-050-00	24-050-00		SERVICE	VSCF Backup Generator Oil Change - Right
24-060-00-01	24-060-00	24-060-00		OPERATIONAL	Generator Drive Disconnect - Left
24-060-00-02	24-060-00	24-060-00		OPERATIONAL	Generator Drive Disconnect - Right
24-061-00-01	24-061-00	24-061-00		OPERATIONAL	Generator Drive Disconnect - Left





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
24-061-00-02	24-061-00	24-061-00		OPERATIONAL	Generator Drive Disconnect - Right
24-062-00-01	24-062-00	24-062-00		OPERATIONAL	Generator Drive Disconnect - Left
24-062-00-02	24-062-00	24-062-00		OPERATIONAL	Generator Drive Disconnect - Right
24-070-00-01	24-070-00	24-070-00	W-24-040-00-01 W-24-075-00-01	REPLACE	IDG Oil Filter - Left
24-070-00-02	24-070-00	24-070-00	W-24-040-00-02 W-24-075-00-02	REPLACE	IDG Oil Filter - Right
24-071-00-01	24-071-00	24-071-00	W-24-041-00-01 W-24-075-00-01	REPLACE	IDG Oil Filter - Left
24-071-00-02	24-071-00	24-071-00	W-24-041-00-02 W-24-075-00-02	REPLACE	IDG Oil Filter - Right
24-072-00-01	24-072-00	24-072-00	W-24-042-00-01 W-24-075-00-01	REPLACE	IDG Oil Filter - Left
24-072-00-02	24-072-00	24-072-00	W-24-042-00-02 W-24-075-00-02	REPLACE	IDG Oil Filter - Right
24-075-00-01	24-075-00		W-24-070-00-01 W-24-071-00-01 W-24-072-00-01	VISUAL CHECK	IDG Oil Filter - Left
24-075-00-02	24-075-00		W-24-070-00-02 W-24-071-00-02 W-24-072-00-02	VISUAL CHECK	IDG Oil Filter - Right
24-080-00-01	24-080-00	24-080-00		INSPECTION - GEN VISUAL	IDG Oil Filter Bypass - Left
24-080-00-02	24-080-00	24-080-00		INSPECTION - GEN VISUAL	IDG Oil Filter Bypass - Right
24-090-00-01	24-090-00	24-090-00		FUNCTIONAL	IDG QAD Coupler - Left
24-090-00-02	24-090-00	24-090-00		FUNCTIONAL	IDG QAD Coupler - Right
24-091-00-01	24-091-00	24-091-00		FUNCTIONAL	IDG QAD Coupler - Left
24-091-00-02	24-091-00	24-091-00		FUNCTIONAL	IDG QAD Coupler - Right



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
24-092-00-01	24-092-00	24-092-00		FUNCTIONAL	IDG QAD Coupler - Left
24-092-00-02	24-092-00	24-092-00		FUNCTIONAL	IDG QAD Coupler - Right
24-100-00-01	24-100-00	24-100-00		CLEAN	IDG and Backup Generator (VSCF) Heat Exchangers (for GE90-70/80/90 series engine only)
24-100-00-02	24-100-00	24-100-00		CLEAN	IDG and Backup Generator (VSCF) Heat Exchangers (for GE90-100 series engine only)
24-100-00-03	24-100-00	24-100-00		CLEAN	IDG and Backup Generator (VSCF) Heat Exchangers
24-100-00-04	24-100-00	24-100-00		CLEAN	Engine 1 IDG/Backup Generator (VSCF) Heat Exchangers
24-100-00-05	24-100-00	24-100-00		CLEAN	Engine 2 IDG/Backup Generator (VSCF) Heat Exchangers
24-100-00-06	24-100-00	24-100-00		CLEAN	Engine 1 IDG/Backup Generator (VSCF) Heat Exchangers
24-100-00-07	24-100-00	24-100-00		CLEAN	Engine 2 IDG/Backup Generator (VSCF) Heat Exchangers
24-120-00-01	24-120-00	24-120-00		CHECK/INSP	VSCF Backup Generator Differential Pressure Switch - Left
24-120-00-02	24-120-00	24-120-00		CHECK/INSP	VSCF Backup Generator Differential Pressure Switch -Right
24-160-00-01	24-160-00	24-160-00		FUNCTIONAL	APU Battery Charge Capacity
24-160-01-01	24-160-01	24-160-01		RESTORE	APU Battery Charge Capacity
24-170-00-01	24-170-00	24-170-00		FUNCTIONAL	Main Battery Charge Capacity
24-170-01-01	24-170-01	24-170-01		RESTORE	Main Battery Charge Capacity
24-190-00-01	24-190-00	24-190-00		RESTORE	Flight Control DC Power Battery
24-200-00-01	24-200-00	24-200-00		FUNCTIONAL	External Power Receptacles (Wear Check)
24-201-00-01	24-201-00			FUNCTIONAL	Airplane External Power Receptacle Neutral Pin Continuity to Airframe Ground
24-210-00-01	24-210-00	24-210-00		INSPECTION - DETAILED	External Power Receptacles (Inspection)
25-010-00-01	25-010-00	25-010-00		INSPECTION - DETAILED	Crew Seat Attachments
25-020-00-01	25-020-00	25-020-00		OPERATIONAL	Crew Seat Lock Mechanism



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
25-020-02-01	25-020-02	25-020-02		OPERATIONAL	Flight Crew Seat Manual Adjustments
25-020-02-02	25-020-02	25-020-02		OPERATIONAL	Flight Crew Seat Manual Adjustments
25-020-04-01	25-020-04	25-020-04		INSPECTION - DETAILED	Flight Compartment Seat Harness
25-020-06-01	25-020-06	25-020-06		OPERATIONAL	Flight Compartment Seat Inertial Reel
25-030-00-01	25-030-00	25-030-00		VISUAL CHECK	Passenger Compartment Seats
25-030-00-02	25-030-00	25-030-00		VISUAL CHECK	CREW REST COMPARTMENT SEATS
25-030-00-03	25-030-00	25-030-00		VISUAL CHECK	Supernumerary Compartment Seats
25-030-00-04	25-030-00	25-030-00		VISUAL CHECK	Flight Attendant Seats
25-040-00-01	25-040-00	25-040-00		OPERATIONAL	Passenger Seat Belts
25-040-00-02	25-040-00	25-040-00		OPERATIONAL	CREW REST SEAT BELTS
25-040-00-03	25-040-00	25-040-00		OPERATIONAL	Supernumerary Seat Belts
25-045-00-01	25-045-00	25-045-00		OPERATIONAL	Crew and/or Attendant Rest Bunk Belts
25-050-00-01	25-050-00	25-050-00		OPERATIONAL	Passenger Compartment Seats
25-055-00-01	25-055-00	25-055-00		OPERATIONAL	Passenger Compartment Articulating Seats
25-056-00-01	25-056-00	25-056-00		OPERATIONAL	Inflatable Seat Restraint System
25-056-00-02	25-056-00	25-056-00		OPERATIONAL	Inflatable Seat Restraint System
25-056-00-03	25-056-00	25-056-00		OPERATIONAL	Inflatable Seat Restraint System
25-056-00-04	25-056-00	25-056-00		OPERATIONAL	Inflatable Seat Restraint System
25-057-00-01	25-057-00	25-057-00		INSPECTION - DETAILED	Inflatable Seat Restraint System Seatbelt Airbag Assembly (SAA)
25-058-00-01	25-058-00	25-058-00		DISCARD	Inflatable Seat Restraint System Gas Generator Assembly (GGA)
25-058-00-02	25-058-00	25-058-00		DISCARD	Inflatable Seat Restraint System Gas Generator Assembly (GGA)
25-058-00-03	25-058-00	25-058-00		DISCARD	Inflatable Seat Restraint System Gas Generator Assembly (GGA)
25-059-00-01	25-059-00	25-059-00		RESTORE	Inflatable Seat Restraint System Electronic Module Assembly (EMA) Battery



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
25-059-00-02	25-059-00	25-059-00		RESTORE	Inflatable Seat Restraint System Electronic Module Assembly (EMA) Battery
25-059-00-03	25-059-00	25-059-00		RESTORE	Inflatable Seat Restraint System Electronic Module Assembly (EMA) Battery
25-060-00-01	25-060-00	25-060-00		OPERATIONAL	Attendant Seat Restraint
25-062-00-01	25-062-00	25-062-00		RESTORE	Life Raft
25-065-00-01	25-065-00	25-065-00		RESTORE	Off-Wing Emergency Escape Slide Assembly
25-066-00-01	25-066-00	25-066-00		VISUAL CHECK	Off-Wing Inflation Cylinder Pressure
25-067-00-01	25-067-00	25-067-00		OPERATIONAL	Off-Wing Slide Compartment Door Lock/Latch System
25-069-00-01	25-069-00	25-069-00		REPLACE	Off-Wing Slide Inflation Cylinder Squib Cartridges
25-070-00-01	25-070-00	25-070-00		INSPECTION - DETAILED	Lavatory Waste Compartment Doors & Flaps
25-071-00-01	25-071-00	25-071-00		DISCARD	Off - Wing Slide Reservoir
25-071-00-02	25-071-00	25-071-00		DISCARD	Off - Wing Slide Reservoir
25-085-00-01	25-085-00	25-085-00		INSPECTION - DETAILED	Aux Fuel Tank Barrier Panel
25-090-00-01	25-090-00	25-090-00		VISUAL CHECK	Flight Deck Escape Rope
25-095-00-01	25-095-00	25-095-00		INSPECTION - DETAILED	Left Overwing Exit Door Lifeline
25-095-00-02	25-095-00	25-095-00		INSPECTION - DETAILED	Right Overwing Exit Door Lifeline
25-100-00-01	25-100-00	25-100-00		RESTORE	Survival Kit - Life Vests (Jackets)
25-105-00-01	25-105-00	25-105-00		VISUAL CHECK	Crash Axe
25-110-00-01	25-110-00	25-110-00		RESTORE	Life Vests (Jackets)
25-110-00-02	25-110-00	25-110-00		RESTORE	Life Vests (Jackets)
25-115-00-01	25-115-00	25-115-00		RESTORE	Flotation Cots
25-115-00-02	25-115-00	25-115-00		RESTORE	Flotation Cots



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
25-120-00-01	25-120-00	25-120-00		FUNCTIONAL	Emergency Locator Transmitters
25-125-00-01	25-125-00	25-125-00		DISCARD	Emergency Locator Transmitter (Batteries)
25-130-00-01	25-130-00	25-130-00		OPERATIONAL	Emergency Evacuation Signal System
25-135-00-01	25-135-00	25-135-00		VISUAL CHECK	First Aid Kits
25-140-00-01	25-140-00	25-140-00		RESTORE	Emergency Medical Kit
25-145-00-01	25-145-00	25-145-00		RESTORE	Automated External Defibrillator
25-150-00-01	25-150-00	25-150-00		VISUAL CHECK	Smokehoods
25-160-00-01	25-160-00	25-160-00		OPERATIONAL	Emergency Flashlights
25-170-00-01	25-170-00	25-170-00		REPLACE	Emergency Flashlight Batteries
25-180-00-01	25-180-00	25-180-00		REPLACE	Smokehoods
25-190-00-01	25-190-00	25-190-00		OPERATIONAL	Megaphones
25-200-00-01	25-200-00	25-200-00		REPLACE	Megaphone Batteries
25-210-00-01	25-210-00	25-210-00		RESTORE	Emergency Escape Slide/Rafts
25-230-00-01	25-230-00	25-230-00		VISUAL CHECK	Slide/Raft Inflation Cylinder Pressure
25-240-00-01	25-240-00	25-240-00		OPERATIONAL	Passenger Entry Door Emergency Escape Slide
25-240-00-02	25-240-00	25-240-00		OPERATIONAL	Overwing Door Emergency Escape Slide
25-250-00-01	25-250-00	25-250-00		INSPECTION - DETAILED	Overhead Flight Crew Rest (OFCR) Seat Assembly Lanyard
25-260-00-01	25-260-00	25-260-00		OPERATIONAL	Overhead Crew Rest Secondary Egress System
25-260-00-02	25-260-00	25-260-00		OPERATIONAL	Overhead Attendant Rests Secondary Egress System
25-270-00-01	25-270-00	25-270-00		INSPECTION - DETAILED	Overhead Crew Rest Secondary Egress Grab Bar
25-270-00-02	25-270-00	25-270-00		INSPECTION - DETAILED	Overhead Attendant Rest Secondary Egress Grab Bar
25-290-00-01	25-290-00	25-290-00		FUNCTIONAL	Tip Alarm System (TAS)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
25-320-00-01	25-320-00	25-320-00		INSPECTION - DETAILED	Rigid Cargo Barrier Sliding Door Seal
26-010-00-01	26-010-00	26-010-00		OPERATIONAL	Engine Fire/Overheat Detection
26-014-01-01	26-014-01	26-014-01		OPERATIONAL	Passenger Cabin, High Wall Suites Smoke Detector System
26-014-02-01	26-014-02	26-014-02		OPERATIONAL	Passenger Cabin, High Wall Suites Smoke Detectors System
26-014-03-01	26-014-03	26-014-03		RESTORE	Passenger Cabin, High Wall Suites Smoke Detector System
26-015-00-01	26-015-00	26-015-00		OPERATIONAL	APU Fire Detection Control Cards
26-020-00-01	26-020-00	26-020-00		OPERATIONAL	Duct Leak & Overheat Detection Control Card
26-030-00-01	26-030-00	26-030-00		OPERATIONAL	Lavatory Smoke Detector Circuitry
26-030-00-02	26-030-00	26-030-00		OPERATIONAL	Overhead Cross-Aisle Stowage Smoke Detector Circuitry
26-030-00-03	26-030-00	26-030-00		OPERATIONAL	Lavatory Smoke Detector Circuitry
26-035-00-01	26-035-00	26-035-00		OPERATIONAL	OFAR SMOKE DETECTOR SYSTEM
26-035-00-04	26-035-00	26-035-00		OPERATIONAL	OFAR (DOOR 3) SMOKE DETECTOR SYSTEM
26-035-00-05	26-035-00	26-035-00		OPERATIONAL	OFAR SMOKE DETECTOR SYSTEM
26-035-00-06	26-035-00	26-035-00		OPERATIONAL	OFAR SMOKE DETECTOR SYSTEM
26-040-00-01	26-040-00	26-040-00		OPERATIONAL	Lavatory Smoke Detectors
26-040-00-02	26-040-00	26-040-00		OPERATIONAL	Overhead Cross-Aisle Stowage Smoke Detectors
26-040-00-03	26-040-00	26-040-00		OPERATIONAL	Lavatory Smoke Detectors
26-045-00-01	26-045-00	26-045-00		OPERATIONAL	OFAR Smoke Detector System
26-045-00-04	26-045-00	26-045-00		OPERATIONAL	OFAR (Door 3) Smoke Detector System
26-045-00-05	26-045-00	26-045-00		OPERATIONAL	OFAR Smoke Detector System
26-045-00-06	26-045-00	26-045-00		OPERATIONAL	OFAR Smoke Detector System
26-050-00-01	26-050-00	26-050-00	W-26-060-00-01	OPERATIONAL	Sensing Elements
26-060-00-01	26-060-00	26-060-00	W-26-050-00-01	OPERATIONAL	Sensing Elements



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
26-061-00-01	26-061-00	26-061-00		OPERATIONAL	Lower Lobe Attendant Rest (LLAR) Smoke Detection System
26-062-00-01	26-062-00	26-062-00		OPERATIONAL	Lower Lobe Attendant Rest Smoke Detection System
26-064-00-01	26-064-00	26-064-00		FUNCTIONAL	Lower Lobe Attendant Rest (LLAR) Smoke Detection System
26-066-00-01	26-066-00	26-066-00		FUNCTIONAL	Cargo Smoke Detector Water Separators (for 200, 200ER, and 200LR airplanes only)
26-066-00-02	26-066-00	26-066-00		FUNCTIONAL	Cargo Smoke Detector Water Separators (for 300 and 300ER airplanes only)
26-067-00-01	26-067-00	26-067-00		FUNCTIONAL	Cargo Compartment Smoke Detector Heaters and Controllers
26-067-00-02	26-067-00	26-067-00		FUNCTIONAL	Cargo Compartment Smoke Detector Heaters and Controllers
26-068-00-01	26-068-00	26-068-00		OPERATIONAL	Flight Crew Rest (FCR) Smoke Detection System
26-068-00-02	26-068-00	26-068-00		OPERATIONAL	Flight Crew Rest (FCR) Smoke Detection System
26-068-00-03	26-068-00	26-068-00		OPERATIONAL	Main Deck Crew Rest (MDCR) Smoke Detection System
26-069-00-01	26-069-00	26-069-00		FUNCTIONAL	Flight Crew Rest (FCR) Smoke Detection System
26-069-00-02	26-069-00	26-069-00		FUNCTIONAL	Flight Crew Rest (FCR) Smoke Detection System
26-069-00-03	26-069-00	26-069-00		FUNCTIONAL	Main Deck Crew Rest (MDCR) Smoke Detection System
26-070-00-01	26-070-00	26-070-00		OPERATIONAL	Engine Fire Extinguishing Bottle Pressure Switches
26-070-00-02	26-070-00	26-070-00		OPERATIONAL	Engine Fire Extinguishing Bottle Pressure Switches
26-070-00-03	26-070-00	26-070-00		OPERATIONAL	Engine Fire Extinguishing Bottle Pressure Switches
26-090-00-01	26-090-00	26-090-00		OPERATIONAL	Engine Fire Switches
26-090-00-02	26-090-00	26-090-00		OPERATIONAL	Engine Fire Switches
26-090-00-03	26-090-00	26-090-00		OPERATIONAL	Engine Fire Switches
26-100-00-01	26-100-00	26-100-00		FUNCTIONAL	Engine Fire Extinguishing Distribution Lines
26-100-00-02	26-100-00	26-100-00		FUNCTIONAL	Engine Fire Extinguishing Distribution Lines
26-100-00-03	26-100-00	26-100-00		FUNCTIONAL	Engine Fire Extinguishing Distribution Lines
26-120-00-01	26-120-00	26-120-00		FUNCTIONAL	Engine Fire Bottle Extinguishing Bottle Pressure Switches



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
26-130-00-01	26-130-00	26-130-00		REPLACE	Engine Fire Bottle Squib Cartridges
26-140-00-01	26-140-00	26-140-00		OPERATIONAL	APU Fire Extinguishing Bottle Pressure Switch
26-150-00-01	26-150-00	26-150-00		FUNCTIONAL	APU Fire Switch
26-170-00-01	26-170-00	26-170-00		FUNCTIONAL	APU Fire Extinguishing Bottle Pressure Switch
26-180-00-01	26-180-00	26-180-00		REPLACE	APU Fire Bottle Squib Cartridges
26-190-00-01	26-190-00	26-190-00		OPERATIONAL	Cargo Fire Extinguishing Bottle Pressure Switches
26-200-00-01	26-200-00	26-200-00		OPERATIONAL	Cargo Fire Extinguishing Arm & Discharge Switches
26-201-00-01	26-201-00	26-201-00		OPERATIONAL	Main Deck Cargo Fire Extinguishing ARM and DEPRESSURIZATION Switches
26-210-00-01	26-210-00	26-210-00		FUNCTIONAL	Cargo Fire Extinguishing Tubing
26-220-00-01	26-220-00	26-220-00		FUNCTIONAL	Cargo Fire Extinguishing Bottle Pressure Switches
26-235-00-01	26-235-00			INSPECTION - DETAILED	Cargo Fire Extinguishing Bottles
26-240-00-01	26-240-00	26-240-00		REPLACE	Cargo Compartment Fire Extinguishing Bottle SQUIB Cartridges
26-250-00-01	26-250-00	26-250-00		RESTORE	Cargo Fire Extinguishing System Filter/Regulator
26-260-00-01	26-260-00	26-260-00		REPLACE	Cargo Fire Extinguishing Flow Valve Squib Cartridges
26-270-00-01	26-270-00	26-270-00		INSPECTION - DETAILED	Lavatory Waste Compartment Fire Extinguisher Bottles
26-270-00-02	26-270-00	26-270-00		INSPECTION - DETAILED	Lavatory Linen Disposal Compartment Fire Extinguisher Bottles
26-272-00-01	26-272-00	26-272-00		OPERATIONAL	Lower Lobe Attendant Rest Fire Extinguishing System
26-274-00-01	26-274-00	26-274-00		REPLACE	Lower Lobe Attendant Rest Fire Extinguishing System
26-276-00-01	26-276-00	26-276-00		VISUAL CHECK	LLAR Fire Extinguishing Tubing
26-277-00-01	26-277-00	26-277-00		OPERATIONAL	Lower Lobe Attendant Rest Fire Extinguishing System
26-278-00-01	26-278-00	26-278-00		FUNCTIONAL	Lower Lobe Attendant Rest Fire Extinguishing System





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
26-290-00-01	26-290-00	26-290-00		INSPECTION - DETAILED	Portable Halon Fire Extinguishers
26-290-00-02	26-290-00	26-290-00		INSPECTION - DETAILED	Portable Halon Fire Extinguishers
26-300-00-01	26-300-00	26-300-00		INSPECTION - DETAILED	Portable Water Fire Extinguishers
26-300-00-02	26-300-00	26-300-00		INSPECTION - DETAILED	Portable Water Fire Extinguishers
27-010-00-01	27-010-00	27-010-00		SERVICE	Stabilizer Primary Brake Housing
27-020-00-01	27-020-00	27-020-00		SERVICE	Slat Power Drive Unit and Slat Electric Motor
27-030-00-01	27-030-00	27-030-00		SERVICE	Left Inboard and outboard Leading Edge No-Back Offset Gearbox
27-030-00-02	27-030-00	27-030-00		SERVICE	Right Inboard and outboard Leading Edge No-Back Offset Gearbox
27-040-00-01	27-040-00	27-040-00		SERVICE	Flap Power Drive Unit and Flap Electric Motor
27-050-00-01	27-050-00	27-050-00		SERVICE	Left Inboard and Outboard Flap Transmissions
27-050-00-02	27-050-00	27-050-00		SERVICE	Right Inboard and Outboard Flap Transmissions
27-055-00-01	27-055-00	27-055-00		OPERATIONAL	Flap Transmission No Back Brakes
27-060-00-01	27-060-00	27-060-00		SERVICE	Left Flap Skewed Roller No-Back Brakes
27-060-00-02	27-060-00	27-060-00		SERVICE	Right Flap Skewed Roller No-Back Brakes
27-140-00-01	27-140-00	27-140-00		OPERATIONAL	Primary Flight Computers (PFC)
27-150-00-01	27-150-00	27-150-00		OPERATIONAL	Primary Flight Computer Disconnect Switch
27-160-00-01	27-160-00	27-160-00		OPERATIONAL	Actuator Control Electronics (ACE)
27-170-00-01	27-170-00	27-170-00		FUNCTIONAL	Left Wing Aileron and Flaperon System Hydraulic Fuses
27-170-00-02	27-170-00	27-170-00		FUNCTIONAL	Right Wing Aileron and Flaperon System Hydraulic Fuses
27-170-00-03	27-170-00	27-170-00		FUNCTIONAL	Rudder System Hydraulic Fuse
27-180-00-01	27-180-00	27-180-00		FUNCTIONAL	Rudder Check Valve



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-190-00-01	27-190-00	27-190-00		OPERATIONAL	Wheel Jam Breakout Mechanism
27-200-00-01	27-200-00	27-200-00		FUNCTIONAL	Rudder Power Control Units
27-210-00-01	27-210-00	27-210-00		OPERATIONAL	Control Column Breakout Mechanism
27-220-00-01	27-220-00	27-220-00		OPERATIONAL	Elevator Power Control Units
27-230-00-01	27-230-00	27-230-00		FUNCTIONAL	Column Force Transducer
27-240-00-01	27-240-00	27-240-00		FUNCTIONAL	Elevator Power Control Unit Bearings
27-250-00-01	27-250-00	27-250-00		OPERATIONAL	Alternate Stabilizer Trim Control System
27-260-00-01	27-260-00	27-260-00		OPERATIONAL	Stabilizer Cutout Switches
27-270-00-01	27-270-00	27-270-00		OPERATIONAL	Stabilizer Secondary Brakes
27-280-00-01	27-280-00	27-280-00		FUNCTIONAL	Stabilizer Trim Limit Switches
27-290-00-01	27-290-00	27-290-00		INSPECTION - DETAILED	Stabilizer Ballscrew Safety Rod
27-300-00-01	27-300-00	27-300-00		INSPECTION - DETAILED	Stabilizer Trim Actuator Gimbals
27-305-00-01	27-305-00			INSPECTION - DETAILED	Stabilizer Trim Actuator - Karon Lined Bushings
27-310-00-01	27-310-00	27-310-00		OPERATIONAL	High Lift System Alternate Control Switches
27-320-00-01	27-320-00	27-320-00		FUNCTIONAL	Left Wing TE Flap No-Back Brakes
27-320-00-02	27-320-00	27-320-00		FUNCTIONAL	Right Wing TE Flap No-Back Brakes
27-330-00-01	27-330-00	27-330-00		OPERATIONAL	Auto Speedbrake Function
27-340-00-01	27-340-00	27-340-00		OPERATIONAL	Left Leading Edge Slat No-Back Brakes
27-340-00-02	27-340-00	27-340-00		OPERATIONAL	Right Leading Edge Slat No-Back Brakes
27-350-00-01	27-350-00	27-350-00		OPERATIONAL	Autoslat Priority Valves - Main Landing Gear
27-360-00-01	27-360-00	27-360-00		OPERATIONAL	Left Leading Edge Slat Skew/Loss Cable
27-360-00-02	27-360-00	27-360-00		OPERATIONAL	Right Leading Edge Slat Skew/Loss Cable



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
27-370-00-01	27-370-00	27-370-00		REPLACE	Spoiler Auxiliary Retract Device (SARD) Pyrotechnic Cartridge
27-380-00-01	27-380-00	27-380-00		OPERATIONAL	Spoiler Auxiliary Retract Device (SARD) Operational Check
27-400-00-01	27-400-00	27-400-00		OPERATIONAL	Aileron Trim Inhibit Operational Check
27-410-00-01	27-410-00	27-410-00		FUNCTIONAL	Nose Gear Pressure Switch
27-415-00-01	27-415-00	27-415-00		FUNCTIONAL	Nose Gear Pressure Transducer
27-420-00-01	27-420-00	27-420-00		OPERATIONAL	Rudder Pedal Pogo
27-430-00-01	27-430-00	27-430-00		FUNCTIONAL	Rudder Power Control Unit
27-440-00-01	27-440-00	27-440-00		FUNCTIONAL	Stabilizer Freeplay
27-450-00-01	27-450-00	27-450-00		INSPECTION - DETAILED	Stabilizer Trim Ballscrew, Ballnut, and Ballnut Return Tubes
27-460-00-01	27-460-00	27-460-00		FUNCTIONAL	TRAILING EDGE FLAP SUPPORT LINKAGE PIN FREEPLAY
27-460-01-01	27-460-01	27-460-01		FUNCTIONAL	TRAILING EDGE FLAP SUPPORT LINKAGE PIN FREEPLAY
27-701-01-01	27-701-01			SPECIAL DETAILED	Safety Rod, Horizontal Stabilizer Trim Actuator
28-010-00-01	28-010-00	28-010-00		OPERATIONAL	Fuel Vent Float Valves
28-011-00-01	28-011-00	28-011-00		FUNCTIONAL	Left Wing
28-011-00-02	28-011-00	28-011-00		FUNCTIONAL	Right Wing
28-012-00-01	28-012-00	28-012-00		VISUAL CHECK	Interspace drain valves (AUX TANK)
28-013-20-01	28-013-20	28-013-20		FUNCTIONAL	Left Wing Pressure Relief Valve (SFAR 88)
28-013-20-02	28-013-20	28-013-20		FUNCTIONAL	Right Wing Pressure Relief Valve (SFAR 88)
28-013-30-01	28-013-30	28-013-30		FUNCTIONAL	Left Wing Overfill Float Switch. (SFAR 88)
28-013-30-02	28-013-30	28-013-30		FUNCTIONAL	Right wing Overfill Float Switch. (SFAR 88)
28-013-40-01	28-013-40	28-013-40		FUNCTIONAL	Left Wing Vent Scoop Upper Duct. (SFAR 88)
28-013-40-02	28-013-40	28-013-40		FUNCTIONAL	Right Wing Vent Scoop Upper Duct. (SFAR 88)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
28-015-00-01	28-015-00	28-015-00		INSPECTION - GEN VISUAL	Left Fuel Surge Tank FLAME ARRESTORS. Zone 542
28-015-00-02	28-015-00	28-015-00		INSPECTION - GEN VISUAL	Right Fuel Surge Tank FLAME ARRESTORS. Zone 642
28-015-20-01	28-015-20	28-015-20		FUNCTIONAL	Left Wing Scavenge Jet Pumps. (SFAR 88)
28-015-20-02	28-015-20	28-015-20		FUNCTIONAL	Right Wing Scavenge Jet Pumps. (SFAR 88)
28-015-20-03	28-015-20	28-015-20		FUNCTIONAL	Wing Center Section Water Scavenge Jet Pumps. (SFAR 88)
28-015-20-04	28-015-20	28-015-20		FUNCTIONAL	Wing Center Section Fuel Scavenge Jet Pumps. (SFAR 88)
28-015-20-05	28-015-20	28-015-20		FUNCTIONAL	Wing Center Section Fuel Scavenge Jet Pumps. (SFAR 88)
28-020-00-01	28-020-00	28-020-00		OPERATIONAL	Engine Fuel Suction Feed System
28-021-10-01	28-021-10	28-021-10		INSPECTION - DETAILED	Left Wing in-Tank Tubing, Equipment Static Ground Straps and Clamps (SFAR 88)
28-021-10-02	28-021-10	28-021-10		INSPECTION - DETAILED	Right Wing in-Tank Tubing, Equipment Static Ground Straps and Clamps (SFAR 88)
28-021-10-03	28-021-10	28-021-10		INSPECTION - DETAILED	Center Main Tank tubing, equipment static ground straps and clamps. (SFAR 88)
28-021-10-04	28-021-10	28-021-10		INSPECTION - DETAILED	Auxiliary Tank Tubing and Equipment Static Ground Straps and Clamps
28-021-10-05	28-021-10	28-021-10		INSPECTION - DETAILED	Left Wing in-Tank Tubing, Equipment Static Ground Straps and Clamps (SFAR 88)
28-021-10-06	28-021-10	28-021-10		INSPECTION - DETAILED	Right Wing in-Tank Tubing, Equipment Static Ground Straps and Clamps (SFAR 88)
28-021-20-01	28-021-20	28-021-20		FUNCTIONAL	Left Wing Fueling Shutoff Valve
28-021-20-02	28-021-20	28-021-20		FUNCTIONAL	Right Wing Fueling Shutoff Valve
28-021-30-01	28-021-30	28-021-30		FUNCTIONAL	Left Wing Fueling Receptacle. (SFAR 88)
28-021-30-02	28-021-30	28-021-30		FUNCTIONAL	Right Wing Fueling Receptacle. (SFAR 88)
28-022-30-01	28-022-30	28-022-30		FUNCTIONAL	Left wing Pump Housing. (SFAR 88)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
28-022-30-02	28-022-30	28-022-30		FUNCTIONAL	Right wing Pump Housing. (SFAR 88)
28-022-30-03	28-022-30	28-022-30		FUNCTIONAL	Pump Housing (AUX TANK)
28-022-40-01	28-022-40	28-022-40		FUNCTIONAL	Left Wing Boost and Jettison Pumps. (SFAR 88)
28-022-40-02	28-022-40	28-022-40		FUNCTIONAL	Right Wing Boost and Jettison Pumps. (SFAR 88)
28-022-40-03	28-022-40	28-022-40		FUNCTIONAL	Wing Center Section Override/Jettison Pumps. (SFAR 88)
28-022-50-01	28-022-50	28-022-50		FUNCTIONAL	Left Wing Motor Operated Valve. (SFAR 88)
28-022-50-02	28-022-50	28-022-50		FUNCTIONAL	Right Wing Motor Operated Valve. (SFAR 88)
28-022-50-03	28-022-50	28-022-50		FUNCTIONAL	Motor Operated Valve (AUX TANK)
28-022-60-01	28-022-60	28-022-60		OPERATIONAL	GFI Relay Check
28-022-60-02	28-022-60	28-022-60		OPERATIONAL	GFI Relay Check
28-022-65-01	28-022-65			OPERATIONAL	AC Fuel Pump Ground Fault Interrupter (GFI) and Ground Fault Protector (GFP)
28-022-65-02	28-022-65			OPERATIONAL	AC Fuel Pump Ground Fault Interrupter (GFI) and Ground Fault Protector (GFP)
28-022-65-03	28-022-65			OPERATIONAL	AC Fuel Pump Ground Fault Interrupter (GFI) and Ground Fault Protector (GFP)
28-022-65-04	28-022-65			OPERATIONAL	AC Fuel Pump Ground Fault Interrupter (GFI) and Ground Fault Protector (GFP)
28-022-65-05	28-022-65			OPERATIONAL	AC Fuel Pump Ground Fault Interrupter (GFI) and Ground Fault Protector (GFP)
28-022-65-06	28-022-65			OPERATIONAL	AC Fuel Pump Ground Fault Interrupter (GFI) and Ground Fault Protector (GFP)
28-023-00-01	28-023-00	28-023-00		REPLACE	Fuel Spar Valve Battery
28-024-00-01	28-024-00	28-024-00		FUNCTIONAL	Transfer tube penetration (AUX TANK)
28-025-00-01	28-025-00	28-025-00		OPERATIONAL	Left Engine Fuel Spar Valve
28-025-00-03	28-025-00	28-025-00		OPERATIONAL	Right Engine Fuel Spar Valve
28-025-20-01	28-025-20	28-025-20		FUNCTIONAL	APU DC Fuel Pump (SFAR 88)
28-025-30-01	28-025-30	28-025-30		FUNCTIONAL	APU Fuel Shutoff Valve (SFAR 88)
28-025-40-01	28-025-40	28-025-40		FUNCTIONAL	APU Isolation Valve (SFAR 88)
28-026-10-01	28-026-10	28-026-10		FUNCTIONAL	Defuel Valve (SFAR 88)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
28-030-00-01	28-030-00	28-030-00		FUNCTIONAL	APU Fuel Supply Line And Shroud
28-031-20-01	28-031-20	28-031-20		FUNCTIONAL	Left Wing Jettison Nozzle Valve. (SFAR 88)
28-031-20-02	28-031-20	28-031-20		FUNCTIONAL	Right Wing Jettison Nozzle Valve. (SFAR 88)
28-031-30-01	28-031-30	28-031-30		FUNCTIONAL	Left Wing Jettison Isolation Valve. (SFAR 88)
28-031-30-02	28-031-30	28-031-30		FUNCTIONAL	Right Wing Jettison Isolation Valve. (SFAR 88)
28-031-40-01	28-031-40	28-031-40		FUNCTIONAL	Left Wing Jettison Nozzle Manifold. (SFAR 88)
28-031-40-02	28-031-40	28-031-40		FUNCTIONAL	Right Wing Jettison Nozzle Manifold. (SFAR 88)
28-040-00-01	28-040-00	28-040-00		OPERATIONAL	Defuel Valve Actuator
28-041-10-01	28-041-10	28-041-10		INSPECTION - DETAILED	Left Wing Main Tank FQIS Wiring. (SFAR 88)
28-041-10-02	28-041-10	28-041-10		INSPECTION - DETAILED	Right Wing Main Tank FQIS Wiring. (SFAR 88)
28-041-10-03	28-041-10	28-041-10		INSPECTION - DETAILED	Wing Center Tank FQIS Wiring. (SFAR 88)
28-041-10-04	28-041-10	28-041-10		INSPECTION - DETAILED	FQIS Wiring. (AUX TANK)
28-041-20-01	28-041-20	28-041-20		INSPECTION - DETAILED	Left Wing Main Tank FQIS Equipment. (SFAR 88)
28-041-20-02	28-041-20	28-041-20		INSPECTION - DETAILED	Right Wing Main Tank FQIS Equipment. (SFAR 88)
28-041-20-03	28-041-20	28-041-20		INSPECTION - DETAILED	Wing Center Tank FQIS Equipment. (SFAR 88)
28-041-20-04	28-041-20	28-041-20		INSPECTION - DETAILED	FQIS Equipment (AUX TANK)
28-041-30-01	28-041-30	28-041-30		FUNCTIONAL	Fuel Quantity Indicating System (FQIS) - Out Of Tank Wiring Lightning Shield to Ground Termination
28-045-00-01	28-045-00	28-045-00		OPERATIONAL	EFLI tank circuits (AUX TANK)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
28-045-10-01	28-045-10	28-045-10	W-28-070-00-01 W-28-060-00-01	OPERATIONAL	EFLI tank unit (AUX TANK)
28-045-20-01	28-045-20	28-045-20		OPERATIONAL	EFLI Processor Display Unit (AUX TANK)
28-050-00-01	28-050-00	28-050-00		OPERATIONAL	Fuel Jettison System
28-050-10-01	28-050-10	28-050-10		FUNCTIONAL	Fuel Scavenge System
28-060-00-01	28-060-00	28-060-00		OPERATIONAL	Densitometers of Fuel Quantity Indicating System
28-070-00-01	28-070-00	28-070-00		OPERATIONAL	Tank Units of Fuel Quantity Indicating System
28-080-00-01	28-080-00	28-080-00		OPERATIONAL	Fuel Quantity Processor Unit (FQPU)
28-085-00-01	28-085-00			CHECK/INSP	Center Wing Fuel Tank FQIS Wiring
28-090-00-01	28-090-00			CHECK/INSP	Fuel Tanks Microbial Growth
28-111-00-01	28-111-00			INSPECTION - DETAILED	External Wires Over Center Fuel Tank
28-112-00-01	28-112-00			OPERATIONAL	Auxiliary Fuel Tank AC Fuel Pump Uncommanded On/Auto Shutoff
28-113-00-01	28-113-00			INSPECTION - DETAILED	External Wires Over the Auxiliary Fuel Tank
28-120-00-01	28-120-00			INSPECTION - DETAILED	Out-of-Tank Wire Bundle Cushion Clamps and Teflon Sleeving
29-010-00-01	29-010-00	29-010-00		SERVICE	Air Drive Unit
29-030-00-01	29-030-00	29-030-00		FUNCTIONAL	Hydraulic System Gross Internal Leakage
29-040-00-01	29-040-00	29-040-00		VISUAL CHECK	Center Hydraulic System Return Filter Module
29-040-00-02	29-040-00	29-040-00		VISUAL CHECK	Left Hydraulic System Return Filter Module
29-040-00-03	29-040-00	29-040-00		VISUAL CHECK	Right Hydraulic System Return Filter Module
29-050-00-01	29-050-00	29-050-00		CHECK/INSP	Center Hydraulic System Return Filter Module
29-050-00-02	29-050-00	29-050-00		CHECK/INSP	Left Hydraulic System Return Filter Module.
29-050-00-03	29-050-00	29-050-00		CHECK/INSP	Right Hydraulic System Return Filter Module
29-060-00-01	29-060-00	29-060-00		CHECK/INSP	Left Hydraulic System EDP Pressure and Case Drain Filter Module



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
29-060-00-02	29-060-00	29-060-00		CHECK/INSP	Right Hydraulic System EDP Pressure and Case Drain Filter Module
29-070-00-01	29-070-00	29-070-00		VISUAL CHECK	Left Hydraulic System EDP Pressure and Case Drain Filter Module
29-070-00-02	29-070-00	29-070-00		VISUAL CHECK	Right Hydraulic System EDP Pressure and Case Drain Filter Module
29-080-00-01	29-080-00	29-080-00		CHECK/INSP	Center Hydraulic System ACMP Pressure and Case Drain Filter Module
29-080-00-02	29-080-00	29-080-00		CHECK/INSP	Left Hydraulic System ACMP Pressure and Case Drain Filter Module
29-080-00-03	29-080-00	29-080-00		CHECK/INSP	Right Hydraulic System ACMP Pressure and Case Drain Filter Module
29-090-00-01	29-090-00	29-090-00		VISUAL CHECK	Center Hydraulic System ACMP Pressure and Case Drain Filter Module
29-090-00-02	29-090-00	29-090-00		VISUAL CHECK	Left Hydraulic System ACMP Pressure and Case Drain Filter Module
29-090-00-03	29-090-00	29-090-00		VISUAL CHECK	Right Hydraulic System ACMP Pressure and Case Drain Filter Module
29-100-00-01	29-100-00	29-100-00		CHECK/INSP	ADP Pressure and Case Drain Filter Module
29-110-00-01	29-110-00	29-110-00		VISUAL CHECK	ADP Pressure and Case Drain Filter Module
29-110-00-02	29-110-00	29-110-00		VISUAL CHECK	ADP Pressure and Case Drain Filter Module
29-110-00-03	29-110-00	29-110-00		VISUAL CHECK	ADP Pressure and Case Drain Filter Module
29-110-00-04	29-110-00	29-110-00		VISUAL CHECK	ADP Pressure and Case Drain Filter Module
29-110-00-05	29-110-00	29-110-00		VISUAL CHECK	ADP Pressure and Case Drain Filter Module
29-110-00-06	29-110-00	29-110-00		VISUAL CHECK	ADP Pressure and Case Drain Filter Module
29-120-00-01	29-120-00	29-120-00		FUNCTIONAL	ADU and ADU Heater System (Airplanes without the MAT ground test only)
29-120-00-02	29-120-00	29-120-00		FUNCTIONAL	ADU and ADU Heater System (Airplanes with the MAT ground test only)
29-130-00-01	29-130-00	29-130-00		OPERATIONAL	Center Hydraulic Isolation System
29-140-00-01	29-140-00	29-140-00		RESTORE	Center Hydraulic System Reservoir Pressurization Module
29-140-00-02	29-140-00	29-140-00		RESTORE	Left Hydraulic System Reservoir Pressurization Module
29-140-00-03	29-140-00	29-140-00		RESTORE	Right Hydraulic System Reservoir Pressurization Module
29-150-00-01	29-150-00	29-150-00	B-29-160-00-01	OPERATIONAL	Ram Air Turbine





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
29-160-00-01	29-160-00	29-160-00	A-29-150-00-01	INSPECTION - GEN VISUAL	Ram Air Turbine
29-170-00-01	29-170-00	29-170-00		VISUAL CHECK	Ram Air Turbine
29-180-00-01	29-180-00	29-180-00		FUNCTIONAL	Hydraulic Accumulators
29-180-00-02	29-180-00	29-180-00		FUNCTIONAL	Hydraulic Accumulators
30-010-00-01	30-010-00	30-010-00		OPERATIONAL	Flight Compartment No. 1 Window Backup Anti-Fog
31-010-00-01	31-010-00	31-010-00		FUNCTIONAL	Flight Data Recorder System
31-010-00-02	31-010-00	31-010-00		FUNCTIONAL	Flight Data Recorder System
31-010-00-03	31-010-00	31-010-00		FUNCTIONAL	Flight Data Recorder System
31-010-00-04	31-010-00	31-010-00		FUNCTIONAL	Flight Data Recorder System
31-010-00-05	31-010-00	31-010-00		FUNCTIONAL	Flight Data Recorder System
31-010-00-06	31-010-00	31-010-00		FUNCTIONAL	Flight Data Recorder System
31-020-00-01	31-020-00	31-020-00		REPLACE	Flight Data Recorder System
31-020-00-02	31-020-00	31-020-00		REPLACE	Flight Data Recorder System
31-030-00-01	31-030-00	31-030-00		OPERATIONAL	Flight Data Recorder Underwater Locator Beacon (ULB)
31-030-00-02	31-030-00	31-030-00		OPERATIONAL	Flight Data Recorder Underwater Locator Beacon (ULB)
31-030-00-03	31-030-00	31-030-00		OPERATIONAL	Flight Data Recorder Underwater Locator Beacon (ULB)
31-040-00-01	31-040-00	31-040-00		OPERATIONAL	Airplane Information Management System
31-050-00-01	31-050-00	31-050-00		OPERATIONAL	Airplane Information Management System - Coaxial Splitter
31-060-00-01	31-060-00	31-060-00		OPERATIONAL	Warning Electronic System
31-070-00-01	31-070-00	31-070-00		OPERATIONAL	Primary Display System - Inboard Select Switching
31-080-00-01	31-080-00	31-080-00		OPERATIONAL	Primary Display System - Instrument Source Select Switching
31-090-00-01	31-090-00	31-090-00		OPERATIONAL	Primary Display System - Display Control Switches
31-100-00-01	31-100-00			OPERATIONAL	Fire Warning System



# 777-200/300 MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
32-010-00-01	32-010-00	32-010-00		SERVICE	Tires
32-011-00-01	32-011-00	32-011-00		FUNCTIONAL	Tire Pressure Indication System (TPIS)
32-012-00-01	32-012-00	32-012-00		FUNCTIONAL	Tire and Brake Monitoring System (TBMS)
32-020-00-01	32-020-00	32-020-00		FUNCTIONAL	Brake Accumulator
32-120-00-01	32-120-00	32-120-00		OPERATIONAL	Landing Gear Alternate Extension System
32-130-00-01	32-130-00	32-130-00		OPERATIONAL	Landing Gear Downlock Springs and Gear Release Hooks
32-140-00-01	32-140-00	32-140-00		OPERATIONAL	Alternate Source Select Valve
32-150-00-01	32-150-00	32-150-00		OPERATIONAL	Accumulator Isolation Valve
32-160-00-01	32-160-00	32-160-00		FUNCTIONAL	Brake Accumulator
32-170-00-01	32-170-00	32-170-00		FUNCTIONAL	Normal and Alternate Brake Systems
32-180-00-01	32-180-00	32-180-00		FUNCTIONAL	Left Main Landing Gear Antiskid Module Hydraulic Fuses
32-180-00-02	32-180-00	32-180-00		FUNCTIONAL	Right Main Landing Gear Antiskid Module Hydraulic Fuses
32-190-00-01	32-190-00	32-190-00		INSPECTION - GEN VISUAL	Wheels
32-200-00-01	32-200-00	32-200-00		INSPECTION - GEN VISUAL	Tires
32-210-00-01	32-210-00	32-210-00		INSPECTION - GEN VISUAL	Brakes
32-220-00-01	32-220-00	32-220-00		RESTORE	Main Landing Gear
32-230-00-01	32-230-00	32-230-00		RESTORE	Nose Landing Gear
32-240-00-01	32-240-00	32-240-00		VISUAL CHECK	Tail Skid
32-250-00-01	32-250-00	32-250-00	P-32-260-00-01	SERVICE	Main Landing Gear Shock Strut Servicing
32-260-00-01	32-260-00	32-260-00	R-32-250-00-01	FUNCTIONAL	Main Landing Gear Shock Strut Dimension "A"
32-270-00-01	32-270-00	32-270-00		VISUAL CHECK	Nose Landing Gear Pressure Gage
32-280-00-01	32-280-00	32-280-00		SERVICE	Nose Landing Gear Shock Strut Servicing



# 777-200/300 MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
32-300-00-01	32-300-00	32-300-00		INSPECTION - GEN VISUAL	Left Main Landing Gear Mechanisms
32-300-00-02	32-300-00	32-300-00		INSPECTION - GEN VISUAL	Right Main Landing Gear Mechanisms
32-310-00-01	32-310-00	32-310-00		INSPECTION - GEN VISUAL	Left Main Landing Gear Door Mechanisms
32-310-00-02	32-310-00	32-310-00		INSPECTION - GEN VISUAL	Right Main Landing Gear Door Mechanisms
32-320-00-01	32-320-00	32-320-00		INSPECTION - GEN VISUAL	Nose Landing Gear Mechanisms
32-330-00-01	32-330-00	32-330-00		INSPECTION - GEN VISUAL	Nose Landing Gear Door Mechanisms
32-800-00-01	32-800-00	32-800-00		ZONAL (GV)	Nose Landing Gear and Landing Gear Doors - From the Ground
32-802-00-01	32-802-00	32-802-00		ZONAL (GV)	Nose Landing Gear and Landing Gear Doors
32-804-01-01	32-804-01	32-804-01		ZONAL (GV)	Left Main Landing Gear and Landing Gear Doors - From the Ground
32-806-01-01	32-806-01	32-806-01		ZONAL (GV)	Left Main Landing Gear and Landing Gear Doors
32-808-02-01	32-808-02	32-808-02		ZONAL (GV)	Right Main Landing Gear and Landing Gear Doors - From the Ground
32-810-02-01	32-810-02	32-810-02		ZONAL (GV)	Right Main Landing Gear and Landing Gear Doors
33-010-00-01	33-010-00	33-010-00		OPERATIONAL	Flight Compartment Panel Flood Lights
33-020-00-01	33-020-00	33-020-00		OPERATIONAL	Integral Panel Lights
33-030-00-01	33-030-00	33-030-00		OPERATIONAL	Integral Panel Lights
33-040-00-01	33-040-00	33-040-00		OPERATIONAL	Indicator Lights DIM/BRT Relays
33-060-00-01	33-060-00	33-060-00		OPERATIONAL	Emergency Lights
33-070-00-01	33-070-00	33-070-00		OPERATIONAL	Emergency Lights
33-075-00-01	33-075-00	33-075-00		INSPECTION - GEN VISUAL	Photoluminescent floor proximity lighting.
33-076-00-01	33-076-00	33-076-00		FUNCTIONAL	Cabin ceiling lighting intensity



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
33-080-00-01	33-080-00	33-080-00		FUNCTIONAL	Emergency Lights Battery Packs
33-090-00-01	33-090-00	33-090-00		RESTORE	Emergency Lights Battery Packs
33-095-00-01	33-095-00	33-095-00		RESTORE	OFAR (BCAG Door 3) Backup Lighting Power Supply Battery Packs
33-095-00-02	33-095-00	33-095-00		RESTORE	OFAR (Door 5) Backup Lighting Power Supply Battery Packs
33-095-00-03	33-095-00	33-095-00		RESTORE	OFAR (Door 4) Backup Lighting Power Supply Battery Packs
33-095-00-04	33-095-00	33-095-00		RESTORE	OFAR (BAS Door 3) Backup Lighting Power Supply Battery Packs
33-095-00-05	33-095-00	33-095-00		RESTORE	OFCR (BAS Style) Backup Lighting Power Supply Battery Packs
33-095-00-06	33-095-00	33-095-00		RESTORE	OFCR (BCAG Style) Backup Lighting Power Supply Battery Packs
33-100-00-01	33-100-00	33-100-00		OPERATIONAL	Lower Lobe Attendant Rest (LLAR) Back-up Lighting System
33-105-00-01	33-105-00	33-105-00		OPERATIONAL	Overhead Flight Attendant Rest (BCAG Door 3) Backup Lights System
33-105-00-02	33-105-00	33-105-00		OPERATIONAL	Overhead Flight Attendant Rest (Door 5) Backup Lights System
33-105-00-03	33-105-00	33-105-00		OPERATIONAL	Overhead Flight Attendant Rest (Door 4) Backup Lights System
33-105-00-04	33-105-00	33-105-00		OPERATIONAL	Overhead Flight Attendant Rest (BAS Door 3) Backup Lights System
33-105-00-05	33-105-00	33-105-00		OPERATIONAL	Overhead Flight Crew Rest (BAS Style) Backup Lights System
33-105-00-06	33-105-00	33-105-00		OPERATIONAL	Overhead Flight Crew Rest (BCAG Style) Backup Lights System
33-110-00-01	33-110-00	33-110-00		FUNCTIONAL	Lower Lobe Attendant Rest (LLAR) Back-up Lighting System
33-115-00-01	33-115-00	33-115-00		FUNCTIONAL	OFAR (BCAG Door 3) Back-up Lighting Power Packs
33-115-00-02	33-115-00	33-115-00		FUNCTIONAL	OFAR (Door 5) Back-up Lighting Power Packs
33-115-00-03	33-115-00	33-115-00		FUNCTIONAL	OFAR (Door 4) Back-up Lighting Power Packs
33-115-00-04	33-115-00	33-115-00		FUNCTIONAL	OFAR (BAS Door 3) Back-up Lighting Power Packs
33-115-00-05	33-115-00	33-115-00		FUNCTIONAL	OFCR (BAS Style) Back-up Lighting Power Packs
33-115-00-06	33-115-00	33-115-00		FUNCTIONAL	OFCR (BCAG Style) Back-up Lighting Power Packs
33-120-00-01	33-120-00	33-120-00		RESTORE	Lower Lobe Attendant Rest (LLAR) Back-up Lighting System
34-020-00-01	34-020-00			FUNCTIONAL	ATC Transponder System



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
34-020-00-02	34-020-00			FUNCTIONAL	ATC Transponder System
34-020-00-04	34-020-00			FUNCTIONAL	ATC Transponder System
34-020-00-05	34-020-00			FUNCTIONAL	ATC Transponder System
35-020-00-01	35-020-00	35-020-00		CHECK/INSP	Crew Oxygen System
35-040-00-01	35-040-00	35-040-00		OPERATIONAL	Crew Oxygen Mask, Diluter Demand Regulator, and Microphone
35-050-00-01	35-050-00	35-050-00		INSPECTION - DETAILED	Crew Oxygen Masks
35-060-00-01	35-060-00	35-060-00		OPERATIONAL	Passenger Oxygen System Door Latch/Actuator
35-060-00-02	35-060-00	35-060-00		OPERATIONAL	Passenger Oxygen System Door Latch/Actuator
35-060-00-03	35-060-00	35-060-00		OPERATIONAL	Passenger Oxygen System Door Latch/Actuator
35-060-00-04	35-060-00	35-060-00		OPERATIONAL	Passenger Oxygen System Door Latch/Actuator
35-070-00-01	35-070-00	35-070-00		VISUAL CHECK	Passenger Chemical Oxygen Generators
35-070-00-02	35-070-00	35-070-00		VISUAL CHECK	Passenger Chemical Oxygen Generators
35-070-00-03	35-070-00	35-070-00		VISUAL CHECK	Passenger Chemical Oxygen Generators
35-071-00-01	35-071-00	35-071-00		VISUAL CHECK	Lavatory Constant Dispensing (CDS) oxygen System
35-080-00-01	35-080-00	35-080-00		DISCARD	Passenger Chemical Oxygen Generators
35-080-00-02	35-080-00	35-080-00		DISCARD	Passenger Chemical Oxygen Generators
35-080-00-03	35-080-00	35-080-00		DISCARD	Passenger Chemical Oxygen Generators
35-080-00-04	35-080-00	35-080-00		DISCARD	Passenger Chemical Oxygen Generators
35-081-00-01	35-081-00	35-081-00		DISCARD	Lavatory oxygen Constant Dispensing System (CDS) cylinder discard.
35-090-00-01	35-090-00	35-090-00		INSPECTION - DETAILED	Passenger Oxygen Masks
35-090-00-02	35-090-00	35-090-00		INSPECTION - DETAILED	Passenger Oxygen Masks



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
35-090-00-03	35-090-00	35-090-00		INSPECTION - DETAILED	Passenger Oxygen Masks
35-090-00-04	35-090-00	35-090-00		INSPECTION - DETAILED	Attendant/Lavatory/Main Cabin Oxygen Masks
35-090-00-05	35-090-00	35-090-00		INSPECTION - DETAILED	Overhead Crew/Flight Attendant Rest Oxygen Masks
35-090-00-06	35-090-00	35-090-00		INSPECTION - DETAILED	Passenger Oxygen Masks
35-090-00-07	35-090-00	35-090-00		INSPECTION - DETAILED	Passenger Oxygen Masks
35-110-00-01	35-110-00	35-110-00		OPERATIONAL	Passenger Gaseous Oxygen System Pressure Lines
35-110-00-02	35-110-00	35-110-00		OPERATIONAL	Passenger Gaseous Oxygen System Pressure Lines
35-120-00-01	35-120-00	35-120-00		OPERATIONAL	Passenger Gaseous Oxygen System Pressure Regulator
35-120-00-02	35-120-00	35-120-00		OPERATIONAL	Supernumerary Gaseous Oxygen System Pressure Regulator
35-130-00-01	35-130-00	35-130-00		OPERATIONAL	Therapeutic Oxygen System
35-140-00-01	35-140-00	35-140-00		OPERATIONAL	Passenger Gaseous Oxygen System Flow Control Units
35-140-00-02	35-140-00	35-140-00		OPERATIONAL	Supernumerary Gaseous Oxygen System Flow Control Units
35-160-00-01	35-160-00	35-160-00	W-35-161-00-01	CHECK/INSP	Portable Oxygen Equipment Pressure
35-161-00-01	35-161-00	35-161-00	W-35-160-00-01	INSPECTION - GEN VISUAL	Portable oxygen disposable type masks
35-162-00-01	35-162-00	35-162-00		INSPECTION - DETAILED	Portable oxygen non-disposable type masks
35-163-00-01	35-163-00	35-163-00		DISCARD	Portable oxygen cylinders
35-164-00-01	35-164-00	35-164-00		DISCARD	Crew Oxygen Cylinders
35-220-00-01	35-220-00	35-220-00		FUNCTIONAL	Supernumerary Oxygen System Pressure Decay
35-230-00-01	35-230-00	35-230-00		INSPECTION - GEN VISUAL	Supernumerary Oxygen System Pressure Indications



## 777-200/300 MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
35-230-00-02	35-230-00	35-230-00		INSPECTION - GEN VISUAL	Supernumerary Oxygen System Pressure Indications
35-240-00-01	35-240-00	35-240-00		OPERATIONAL	Supernumerary Cylinder Pressure Regulator
35-250-00-01	35-250-00	35-250-00		OPERATIONAL	Supernumerary System Pressure Regulator
35-260-00-01	35-260-00	35-260-00		OPERATIONAL	Supernumerary Stowage Box and Mask Regulator
35-270-00-01	35-270-00	35-270-00		OPERATIONAL	Supernumerary Oxygen Mask and Diluter Demand Regulator
35-280-00-01	35-280-00	35-280-00		VISUAL CHECK	Supernumerary Oxygen Masks
36-010-00-01	36-010-00	36-010-00		FUNCTIONAL	Engine Air Supply Manifold
36-020-00-01	36-020-00	36-020-00		FUNCTIONAL	Left Engine Air Supply IP Check Valve
36-020-00-02	36-020-00	36-020-00		FUNCTIONAL	Right Engine Air Supply IP Check Valve
36-022-00-01	36-022-00	36-022-00		FUNCTIONAL	Left Engine Air Supply IP Check Valve (for GE90-70/80/90 series engine only)
36-022-00-02	36-022-00	36-022-00		FUNCTIONAL	Right Engine Air Supply IP Check Valve (for GE90-70/80/90 series engine only)
36-022-00-03	36-022-00	36-022-00		FUNCTIONAL	Left Engine Air Supply IP Check Valve (for GE90-100 series engine only)
36-022-00-04	36-022-00	36-022-00		FUNCTIONAL	Right Engine Air Supply IP Check Valve (for GE90-100 series engine only)
36-024-00-01	36-024-00	36-024-00		FUNCTIONAL	Left Engine Air Supply IP Check Valve
36-024-00-02	36-024-00	36-024-00		FUNCTIONAL	Right Engine Air Supply IP Check Valve
36-030-00-01	36-030-00	36-030-00		OPERATIONAL	Air Supply Manifold Dual Temperature Sensor
38-010-00-01	38-010-00	38-010-00		DISINFECT	Potable Water Supply System
38-020-00-01	38-020-00	38-020-00		OPERATIONAL	Potable Water Isolation Valves and Cables
38-030-00-01	38-030-00	38-030-00		FUNCTIONAL	Waste Drain Ball Valve & Fitting Seals (Not applicable to the 777F)
38-030-00-02	38-030-00	38-030-00		FUNCTIONAL	Waste Drain Ball Valve & Fitting Seals (Applicable to the 777F only)
38-030-00-03	38-030-00	38-030-00		FUNCTIONAL	Waste Drain Ball Valve & Fitting Seals
38-030-00-04	38-030-00	38-030-00		FUNCTIONAL	Waste Drain Ball Valve & Fitting Seals
38-050-00-01	38-050-00	38-050-00		RESTORE	Waste Tank Liquid Separators (Not applicable to the 777F)



## 777-200/300 MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
38-050-00-02	38-050-00	38-050-00		RESTORE	Waste Tank Liquid Separators (Applicable to the 777F only)
38-050-00-03	38-050-00	38-050-00		RESTORE	Waste Tank Liquid Separators
38-070-00-01	38-070-00	38-070-00		RESTORE	Vacuum Blower Air Filter
38-070-00-02	38-070-00	38-070-00		RESTORE	Vacuum Blower Air Filter
38-080-00-01	38-080-00	38-080-00		OPERATIONAL	Waste Tank Quantity Indication System
38-080-00-02	38-080-00	38-080-00		OPERATIONAL	Waste Tank Quantity Indication
38-090-00-01	38-090-00	38-090-00		OPERATIONAL	Waste Tank Quantity Indication
38-100-00-01	38-100-00	38-100-00		REPLACE	Compressor Inlet Filter
38-110-00-01	38-110-00	38-110-00		REPLACE	APU Duct Bleed Air Inline Filter
38-120-00-01	38-120-00	38-120-00		OPERATIONAL	Potable Water Pressure Relief Valve
38-130-00-01	38-130-00	38-130-00		OPERATIONAL	Potable Water System Pressure Limit Switch and Relay Circuit
38-140-00-01	38-140-00	38-140-00		RESTORE	Fill Line Water Filter of Pump Based Potable Water System
47-100-00-01	47-100-00	47-100-00		RESTORE	Restore the Ozone Converter (off-aircraft).
47-110-00-01	47-110-00	47-110-00		RESTORE	Clean the Primary Heat Exchanger (off-aircraft).
47-120-00-01	47-120-00	47-120-00		FUNCTIONAL	Functionally check the Regenerative Heat Exchanger (off-aircraft).
47-130-00-01	47-130-00	47-130-00		FUNCTIONAL	Functionally Check the Filter Differential Pressure Sensor Switch (off-aircraft).
47-135-00-01	47-135-00			FUNCTIONAL	Functional Check of the NGS thermal switch
47-140-00-01	47-140-00	47-140-00		VISUAL CHECK	Visually Check for Fluid Accumulation Through the Drain Valve or Drain Cap.
47-150-00-01	47-150-00	47-150-00		INSPECTION - DETAILED	Inspect (detailed) the Nitrogen Enriched Air (NEA) distribution lines
47-160-00-01	47-160-00	47-160-00		OPERATIONAL	Operationally check the center tank vent cross flow check valve.
49-010-00-01	49-010-00	49-010-00		SERVICE	APU and Generator Lubrication System
49-020-00-01	49-020-00	49-020-00		REPLACE	APU 1st & 2ND Stage Compressor Impellers
49-030-00-01	49-030-00	49-030-00		REPLACE	APU Turbine Wheels





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
49-040-00-01	49-040-00	49-040-00		REPLACE	APU Load Compressor Impeller
49-060-00-01	49-060-00	49-060-00		FUNCTIONAL	APU Combustor Drain Valve
52-009-00-01	52-009-00	52-009-00		INSPECTION - DETAILED	Main Deck Cargo Door seals.
52-009-10-01	52-009-10	52-009-10		INSPECTION - DETAILED	Main Deck Cargo vent door seal
52-010-00-01	52-010-00	52-010-00		INSPECTION - DETAILED	Passenger Entry Door Seals and Vent Door Seals
52-015-00-01	52-015-00	52-015-00		INSPECTION - DETAILED	No. 3 Over-Wing Door Seals and Vent Door Seals
52-020-00-01	52-020-00	52-020-00		INSPECTION - DETAILED	Forward Large Cargo Door Seals and Vent Door Seals
52-025-00-01	52-025-00	52-025-00		INSPECTION - DETAILED	AFT Large Cargo Door Seals and Vent Door Seals
52-030-00-01	52-030-00	52-030-00		INSPECTION - DETAILED	AFT Small Cargo Door Seals and Vent Door Seals
52-032-00-01	52-032-00	52-032-00		LUBRICATE	Main Deck Cargo Door mechanism.
52-032-10-01	52-032-10	52-032-10		LUBRICATE	Main Deck Cargo Door hinge pin.
52-032-20-01	52-032-20	52-032-20		OPERATIONAL	Manual drive mechanism of Main Deck Cargo Door.
52-032-30-01	52-032-30	52-032-30		FUNCTIONAL	Lock control switches.
52-032-40-01	52-032-40	52-032-40		LUBRICATE	Main Deck Cargo Door Latch Pins and Cam Latches
52-040-00-01	52-040-00	52-040-00		INSPECTION - DETAILED	Bulk Cargo Door Seals
52-050-00-01	52-050-00	52-050-00		INSPECTION - DETAILED	Forward Access Door Seal
52-060-00-01	52-060-00	52-060-00		INSPECTION - DETAILED	Main Equipment Center Door Seals
52-070-00-01	52-070-00	52-070-00		REPLACE	Passenger Entry Door EPAS SQUIBS



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
52-070-01-01	52-070-01	52-070-01		REPLACE	Passenger Entry Door EPAS SQUIBS
52-070-02-01	52-070-02	52-070-02		DISCARD	Passenger Entry Door EPAS SQUIBS
52-075-00-01	52-075-00	52-075-00		REPLACE	No. 3 Over-Wing Door EPAS Squibs
52-090-00-01	52-090-00	52-090-00		OPERATIONAL	Passenger Entry Door EPAS Battery
52-090-00-02	52-090-00	52-090-00		OPERATIONAL	Passenger Entry Door EPAS Battery
52-090-00-03	52-090-00	52-090-00		OPERATIONAL	Passenger Entry Door EPAS Battery
52-090-01-01	52-090-01	52-090-01		OPERATIONAL	Passenger Entry Door EPAS Battery
52-090-01-02	52-090-01	52-090-01		OPERATIONAL	Passenger Entry Door EPAS Battery
52-090-02-01	52-090-02	52-090-02		OPERATIONAL	Passenger Entry Door EPAS Battery
52-091-00-01	52-091-00	52-091-00		RESTORE	Passenger Entry Door EPAS Battery
52-091-00-02	52-091-00	52-091-00		RESTORE	Passenger Entry Door EPAS Battery
52-091-01-01	52-091-01	52-091-01		RESTORE	Passenger Entry Door EPAS Battery
52-091-01-02	52-091-01	52-091-01		RESTORE	Passenger Entry Door EPAS Battery
52-091-02-01	52-091-02	52-091-02		RESTORE	Passenger Entry Door EPAS Battery
52-095-00-01	52-095-00	52-095-00		OPERATIONAL	No. 3 Over-wing Door EPAS/Backup Battery
52-096-00-01	52-096-00	52-096-00		RESTORE	No. 3 Over-Wing Door EPAS/Backup Battery
52-100-00-01	52-100-00	52-100-00		VISUAL CHECK	Passenger Entry Door Girt Bar Floor Fittings
52-100-01-01	52-100-01	52-100-01		VISUAL CHECK	Passenger Entry Door Girt Bar Floor Fittings
52-100-02-01	52-100-02	52-100-02		VISUAL CHECK	Passenger Entry Door Girt Bar Floor Fittings
52-110-00-01	52-110-00	52-110-00		VISUAL CHECK	Passenger Entry Door EPAS Pressure Gauge
52-110-01-01	52-110-01	52-110-01		VISUAL CHECK	Passenger Entry Door EPAS Pressure Gauge
52-110-02-01	52-110-02	52-110-02		VISUAL CHECK	Passenger Entry Door EPAS Pressure Gauge
52-115-00-01	52-115-00	52-115-00		VISUAL CHECK	No. 3 Over-Wing Door EPAS Pressure Gauge



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
52-120-00-01	52-120-00	52-120-00		INSPECTION - DETAILED	Passenger Entry Door Flight Lock Mechanism
52-120-01-01	52-120-01	52-120-01		INSPECTION - DETAILED	Passenger Entry Door Flight Lock Mechanism
52-120-02-01	52-120-02	52-120-02		INSPECTION - DETAILED	Passenger Entry Door Flight Lock Mechanism
52-125-00-01	52-125-00	52-125-00		INSPECTION - DETAILED	No. 3 Over-Wing Door Flight Lock Mechanism
52-130-00-01	52-130-00	52-130-00		INSPECTION - DETAILED	Passenger Entry Door Girt Bar Mechanism Interlock
52-130-01-01	52-130-01	52-130-01		INSPECTION - DETAILED	Passenger Entry Door Girt Bar Mechanism Interlock
52-130-02-01	52-130-02	52-130-02		INSPECTION - DETAILED	Passenger Entry Door Girt Bar Mechanism Interlock
52-135-00-01	52-135-00	52-135-00		INSPECTION - DETAILED	No. 3 Over-Wing Door Latch Torque Tube Interlock
52-140-00-01	52-140-00	52-140-00		INSPECTION - DETAILED	Passenger Entry Door Mode Select Mechanism and Cables
52-140-01-01	52-140-01	52-140-01		INSPECTION - DETAILED	Passenger Entry Door Mode Select Mechanism and Cables
52-140-02-01	52-140-02	52-140-02		INSPECTION - DETAILED	Passenger Entry Door Mode Select Mechanism and Cables
52-145-00-01	52-145-00	52-145-00		INSPECTION - DETAILED	No. 3 Over-Wing Doors Mode Select Mechanism and Pull Cable
52-150-00-01	52-150-00	52-150-00		INSPECTION - DETAILED	Passenger Entry Door EPAS Tubing
52-150-01-01	52-150-01	52-150-01		INSPECTION - DETAILED	Passenger Entry Door EPAS Tubing
52-150-02-01	52-150-02	52-150-02		INSPECTION - DETAILED	Passenger Entry Door EPAS Tubing



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-155-00-01	52-155-00	52-155-00		INSPECTION - DETAILED	No. 3 Over-Wing Doors EPAS Tubing
52-160-00-01	52-160-00	52-160-00		FUNCTIONAL	Passenger Entry Door EPAS Circuitry
52-160-00-02	52-160-00	52-160-00		FUNCTIONAL	Passenger Entry Door EPAS Circuitry
52-160-00-03	52-160-00	52-160-00		FUNCTIONAL	Passenger Entry Door EPAS Circuitry
52-160-00-04	52-160-00	52-160-00		FUNCTIONAL	Passenger Entry Door EPAS Circuitry
52-165-00-01	52-165-00	52-165-00		FUNCTIONAL	Left No. 3 Over-Wing Door Circuitry
52-165-00-02	52-165-00	52-165-00		FUNCTIONAL	Right No. 3 Over-Wing Door Circuitry
52-166-00-01	52-166-00	52-166-00		FUNCTIONAL	No. 3 Over-Wing Door EPAS Battery Circuitry
52-167-00-01	52-167-00	52-167-00	W-52-167-00-02	FUNCTIONAL	No. 3 Over-Wing Door Backup Battery Circuitry
52-167-00-02	52-167-00	52-167-00	W-52-167-00-01	FUNCTIONAL	No. 3 Over-Wing Door Backup Battery Circuitry
52-170-00-01	52-170-00	52-170-00		FUNCTIONAL	Passenger Entry Door Mechanisms
52-170-01-01	52-170-01	52-170-01		FUNCTIONAL	Passenger Entry Door Mechanisms
52-170-02-01	52-170-02	52-170-02		FUNCTIONAL	Passenger Entry Door Mechanisms
52-175-00-01	52-175-00	52-175-00		FUNCTIONAL	No. 3 Over-Wing Door Mechanisms
52-180-00-01	52-180-00	52-180-00		OPERATIONAL	Forward Large Cargo Door Manual Drive Mechanism & Lift PDU Brake
52-185-00-01	52-185-00	52-185-00		OPERATIONAL	AFT Large Cargo Door Manual Drive Mechanism & Lift PDU Brake
52-190-00-01	52-190-00	52-190-00		OPERATIONAL	Forward Large Cargo Door Rotary Actuator No-Back
52-195-00-01	52-195-00	52-195-00		OPERATIONAL	AFT Large Cargo Door Rotary Actuator No-Back
52-200-00-01	52-200-00	52-200-00		FUNCTIONAL	Forward Large Cargo Door Lock Handle Load Limiter
52-205-00-01	52-205-00	52-205-00		FUNCTIONAL	AFT Large Cargo Door Lock Handle Load Limiter
52-210-00-01	52-210-00	52-210-00		OPERATIONAL	Forward Large Cargo Door Ditching Interlock Mechanism
52-215-00-01	52-215-00	52-215-00		OPERATIONAL	AFT Large Cargo Door Ditching Interlock Mechanism
52-220-00-01	52-220-00	52-220-00		OPERATIONAL	AFT Small Cargo Door Hinge Power Drive Unit and Manual Drive Mechanism



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-230-00-01	52-230-00	52-230-00		OPERATIONAL	AFT Small Cargo Door Rotary Actuator
52-240-00-01	52-240-00	52-240-00		INSPECTION - DETAILED	Bulk Cargo Door Latch Mechanism
52-250-00-01	52-250-00	52-250-00		INSPECTION - DETAILED	Equipment Compartment Exterior Door Latch Mechanisms
52-255-00-01	52-255-00	52-255-00		OPERATIONAL	Lower Lobe Attendant Rest Emergency Exit Hatch
52-260-00-01	52-260-00	52-260-00		OPERATIONAL	Passenger Entry Door Closed Proximity Sensors
52-265-00-01	52-265-00	52-265-00		OPERATIONAL	No. 3 Over-Wing Doors Closed Proximity Sensors
52-301-00-01	52-301-00			DISCARD	Flight Deck Door Strike Assembly
52-305-00-01	52-305-00	52-305-00		INSPECTION - DETAILED	Flight Deck Door Decompression Panel Latches and Hinges
52-310-00-01	52-310-00	52-310-00		OPERATIONAL	Flight Deck Door Pressure Sensor
52-315-00-01	52-315-00	52-315-00		VISUAL CHECK	FLIGHT DECK DOOR SEALS AND BREAKAWAY PANEL SEAL
52-320-00-01	52-320-00	52-320-00		VISUAL CHECK	Flight Deck Door Decompression Panel Trim Ring Seals
52-501-00-01	52-501-00	52-501-00		GENERAL VISUAL	Forward Large Cargo Door
52-502-00-01	52-502-00	52-502-00		DETAILED	Forward Large Cargo Door
52-503-00-01	52-503-00	52-503-00		DETAILED	Forward Large Cargo Door
52-504-00-01	52-504-00	52-504-00		DETAILED	Forward Large Cargo Door
52-505-00-01	52-505-00	52-505-00		DETAILED	Forward Large Cargo Door
52-506-00-01	52-506-00	52-506-00		GENERAL VISUAL	Aft Small Cargo Door
52-507-00-01	52-507-00	52-507-00		GENERAL VISUAL	Bulk Cargo Door
52-508-00-01	52-508-00	52-508-00		GENERAL VISUAL	Bulk Cargo Door



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
52-509-00-01	52-509-00	52-509-00		GENERAL VISUAL	Aft Large Cargo Door
52-510-00-01	52-510-00	52-510-00		DETAILED	Aft Large Cargo Door
52-511-00-01	52-511-00	52-511-00		DETAILED	Aft Large Cargo Door
52-512-00-01	52-512-00	52-512-00		DETAILED	Aft Large Cargo Door
52-513-00-01	52-513-00	52-513-00		DETAILED	Aft Large Cargo Door
52-520-01-01	52-520-01	52-520-01		GENERAL VISUAL	Left #1 Entry Door
52-521-01-01	52-521-01	52-521-01		GENERAL VISUAL	Left #2 Passenger Entry Door
52-522-01-01	52-522-01	52-522-01		GENERAL VISUAL	Left #3 Overwing Door
52-523-01-01	52-523-01	52-523-01		GENERAL VISUAL	Left #3 Passenger Entry Door
52-524-01-01	52-524-01	52-524-01		GENERAL VISUAL	Left #4 Passenger Entry Door
52-525-01-01	52-525-01	52-525-01		GENERAL VISUAL	Left #4 Passenger Entry Door
52-526-01-01	52-526-01	52-526-01		GENERAL VISUAL	Left #5 Passenger Entry Door
52-527-01-01	52-527-01	52-527-01		DETAILED	Left #1 Entry Door
52-528-01-01	52-528-01	52-528-01		DETAILED	Left #2 Passenger Entry Door
52-529-01-01	52-529-01	52-529-01		DETAILED	Left #3 Overwing Door
52-530-01-01	52-530-01	52-530-01		DETAILED	Left #3 Passenger Entry Door
52-531-01-01	52-531-01	52-531-01		DETAILED	Left #4 Passenger Entry Door
52-532-01-01	52-532-01	52-532-01		DETAILED	Left #4 Passenger Entry Door
52-533-01-01	52-533-01	52-533-01		DETAILED	Left #5 Passenger Entry Door



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-535-02-01	52-535-02	52-535-02		GENERAL VISUAL	Right #1 Entry Door
52-536-02-01	52-536-02	52-536-02		GENERAL VISUAL	Right #2 Passenger Entry Door
52-537-02-01	52-537-02	52-537-02		GENERAL VISUAL	Right #3 Overwing Door
52-538-02-01	52-538-02	52-538-02		GENERAL VISUAL	Right #3 Passenger Entry Door
52-539-02-01	52-539-02	52-539-02		GENERAL VISUAL	Right #4 Passenger Entry Door
52-540-02-01	52-540-02	52-540-02		GENERAL VISUAL	Right #4 Passenger Entry Door
52-541-02-01	52-541-02	52-541-02		GENERAL VISUAL	Right #5 Passenger Entry Door
52-542-02-01	52-542-02	52-542-02		DETAILED	Right #1 Entry Door
52-543-02-01	52-543-02	52-543-02		DETAILED	Right #2 Passenger Entry Door
52-544-02-01	52-544-02	52-544-02		DETAILED	Right #3 Overwing Door
52-545-02-01	52-545-02	52-545-02		DETAILED	Right #3 Passenger Entry Door
52-546-02-01	52-546-02	52-546-02		DETAILED	Right #4 Passenger Entry Door
52-547-02-01	52-547-02	52-547-02		DETAILED	Right #4 Passenger Entry Door
52-548-02-01	52-548-02	52-548-02		DETAILED	Right #5 Passenger Entry Door
52-549-00-01	52-549-00	52-549-00		GENERAL VISUAL	Main Deck Cargo Door
52-550-00-01	52-550-00	52-550-00		DETAILED	Main Deck Cargo Door
52-551-00-01	52-551-00	52-551-00		DETAILED	Main Deck Cargo Door
52-552-00-01	52-552-00	52-552-00		DETAILED	Main Deck Cargo Door
52-553-00-01	52-553-00	52-553-00		GENERAL VISUAL	Main Deck Cargo Door



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-554-00-01	52-554-00	52-554-00		DETAILED	Main Deck Cargo Door
52-701-01-01	52-701-01			GENERAL VISUAL	Passenger Entry Doors - Outer Skin and Structure
52-701-03-01	52-701-03			DETAILED	Passenger Entry Doors - Outer Skin and Structure
52-702-01-01	52-702-01			SPECIAL DETAILED	Large Cargo Door Latch Support Frame Fittings
52-703-01-01	52-703-01			SPECIAL DETAILED	Large Cargo Door Latch Support Frame Fitting (135W1191)
52-704-01-01	52-704-01			SPECIAL DETAILED	Large Cargo Door Latch Frame Inner Chord
52-705-01-01	52-705-01			SPECIAL DETAILED	Large Cargo Door Outer Skin at Attachment to Main Hinges
52-706-01-01	52-706-01			SPECIAL DETAILED	Large Cargo Door Latch Support Frame Fittings
52-707-01-01	52-707-01			SPECIAL DETAILED	Large Cargo Door Latch Support Frame Fitting (135W1191)
52-708-01-01	52-708-01			SPECIAL DETAILED	Large Cargo Door Latch Frame Inner Chord
52-709-01-01	52-709-01			SPECIAL DETAILED	Large Cargo Door Outer Skin at Attachment to Main Hinges
52-730-00-01	52-730-00	52-730-00		GENERAL VISUAL	Flight Deck Security Door
52-802-00-01	52-802-00	52-802-00		ZONAL (GV)	Forward Large Cargo Door
52-804-00-01	52-804-00	52-804-00		ZONAL (GV)	Forward Large Cargo Door
52-806-00-01	52-806-00	52-806-00		ZONAL (GV)	Aft Small Cargo Door
52-808-00-01	52-808-00	52-808-00		ZONAL (GV)	Aft Small Cargo Door
52-810-00-01	52-810-00	52-810-00		ZONAL (GV)	Aft Large Cargo Door
52-812-00-01	52-812-00	52-812-00		ZONAL (GV)	Aft Large Cargo Door





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
52-814-00-01	52-814-00	52-814-00		ZONAL (GV)	Bulk Cargo Door
52-816-01-01	52-816-01	52-816-01		ZONAL (GV)	Left No. 1 Passenger Entry Door - Section 41
52-818-01-01	52-818-01	52-818-01		ZONAL (GV)	Left No. 1 Passenger/Crew Entry Door - Section 41
52-820-01-01	52-820-01	52-820-01		ZONAL (GV)	Left No. 2 Passenger Entry Door - Section 43
52-822-01-01	52-822-01	52-822-01		ZONAL (GV)	Left No. 2 Passenger Entry Door - Section 43
52-824-01-01	52-824-01	52-824-01		ZONAL (GV)	Left No. 3 Overwing Door - Section 44
52-825-01-01	52-825-01	52-825-01		ZONAL (GV)	Left No. 3 Overwing Door - Section 44
52-826-01-01	52-826-01	52-826-01		ZONAL (GV)	Left No. 3 Passenger Entry Door - Section 46
52-827-01-01	52-827-01	52-827-01		ZONAL (GV)	Left No. 4 Passenger Entry Door - Section 46
52-828-01-01	52-828-01	52-828-01		ZONAL (GV)	Left No. 3 Passenger Entry Door - Section 46
52-829-01-01	52-829-01	52-829-01		ZONAL (GV)	Left No. 4 Passenger Entry Door - Section 46
52-830-01-01	52-830-01	52-830-01		ZONAL (GV)	Left No. 4 Passenger Entry Door - Section 47
52-831-01-01	52-831-01	52-831-01		ZONAL (GV)	Left No. 5 Passenger Entry Door - Section 47
52-832-01-01	52-832-01	52-832-01		ZONAL (GV)	Left No. 4 Passenger Entry Door - Section 47
52-833-01-01	52-833-01	52-833-01		ZONAL (GV)	Left No. 5 Passenger Entry Door - Section 47
52-834-02-01	52-834-02	52-834-02		ZONAL (GV)	Right No. 1 Passenger/Crew Entry Door - Section 41
52-836-02-01	52-836-02	52-836-02		ZONAL (GV)	Right No. 1 Passenger/Crew Entry Door - Section 41
52-840-02-01	52-840-02	52-840-02		ZONAL (GV)	Right No. 2 Passenger Entry Door - Section 43
52-842-02-01	52-842-02	52-842-02		ZONAL (GV)	Right No. 2 Passenger Entry Door - Section 43
52-844-02-01	52-844-02	52-844-02		ZONAL (GV)	Right No. 3 Overwing Door - Section 44
52-846-02-01	52-846-02	52-846-02		ZONAL (GV)	Right No. 3 Overwing Door - Section 44
52-848-02-01	52-848-02	52-848-02		ZONAL (GV)	Right No. 3 Passenger Entry Door - Section 46
52-849-02-01	52-849-02	52-849-02		ZONAL (GV)	Right No. 4 Passenger Entry Door - Section 46
52-850-02-01	52-850-02	52-850-02		ZONAL (GV)	Right No. 3 Passenger Entry Door - Section 46



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-851-02-01	52-851-02	52-851-02		ZONAL (GV)	Right No. 4 Passenger Entry Door - Section 46
52-852-02-01	52-852-02	52-852-02		ZONAL (GV)	Right No. 4 Passenger Entry Door - Section 47
52-853-02-01	52-853-02	52-853-02		ZONAL (GV)	Right No. 5 Passenger Entry Door - Section 47
52-854-02-01	52-854-02	52-854-02		ZONAL (GV)	Right No. 4 Passenger Entry Door - Section 47
52-855-02-01	52-855-02	52-855-02		ZONAL (GV)	Right No. 5 Passenger Entry Door - Section 47
52-856-00-01	52-856-00	52-856-00		ZONAL (GV)	Main Deck Cargo Door
52-858-00-01	52-858-00	52-858-00		ZONAL (GV)	Main Deck Cargo Door
53-501-00-01	53-501-00	53-501-00		GENERAL VISUAL	Area Forward of Nose Landing Gear Wheel Well and Forward Access Door
53-502-00-01	53-502-00	53-502-00		GENERAL VISUAL	Area Outboard and Above Nose Landing Gear Wheel Well
53-503-00-01	53-503-00	53-503-00		DETAILED	Left Area Outboard and Above Nose Landing Gear Wheel Well
53-504-00-01	53-504-00	53-504-00		DETAILED	Right Area Outboard and Above Nose Landing Gear Wheel Well
53-505-00-01	53-505-00	53-505-00		GENERAL VISUAL	Main Equipment Center and Main Equipment Center Access Door
53-506-00-01	53-506-00	53-506-00		DETAILED	Main Equipment Center
53-507-00-01	53-507-00	53-507-00		DETAILED	Main Equipment Center
53-508-00-01	53-508-00	53-508-00		GENERAL VISUAL	Main Equipment Center
53-509-00-01	53-509-00	53-509-00		GENERAL VISUAL	Forward Cargo Compartment
53-509-01-01	53-509-01	53-509-01		GENERAL VISUAL	Forward Cargo Compartment
53-511-00-01	53-511-00	53-511-00		DETAILED	Forward Cargo Compartment
53-512-00-01	53-512-00	53-512-00		DETAILED	Forward Cargo Compartment
53-512-00-02	53-512-00	53-512-00		DETAILED	Forward Cargo Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-512-00-03	53-512-00	53-512-00		DETAILED	Forward Cargo Compartment
53-512-00-04	53-512-00	53-512-00		DETAILED	Forward Cargo Compartment
53-512-00-05	53-512-00	53-512-00		DETAILED	Forward Cargo Compartment
53-512-01-01	53-512-01	53-512-01		DETAILED	Forward Cargo Compartment
53-513-00-01	53-513-00	53-513-00		GENERAL VISUAL	Area Below Forward Cargo Compartment
53-514-00-01	53-514-00	53-514-00		GENERAL VISUAL	Area Below Forward Cargo Compartment
53-515-00-01	53-515-00	53-515-00		DETAILED	Area Below Forward Cargo Compartment
53-515-00-02	53-515-00	53-515-00		DETAILED	Area Below Forward Cargo Compartment
53-515-00-03	53-515-00	53-515-00		DETAILED	Area Below Forward Cargo Compartment
53-515-00-04	53-515-00	53-515-00		DETAILED	Area Below Forward Cargo Compartment
53-515-00-05	53-515-00	53-515-00		DETAILED	Area Below Forward Cargo Compartment
53-515-00-06	53-515-00	53-515-00		DETAILED	Area Below Forward Cargo Compartment
53-516-00-01	53-516-00	53-516-00		GENERAL VISUAL	Area Aft of Forward Cargo Compartment - Body Station 998 to 1035
53-516-01-01	53-516-01	53-516-01		GENERAL VISUAL	Area Aft of Forward Cargo Compartment - Body Station 998 to 1035
53-517-00-01	53-517-00	53-517-00		GENERAL VISUAL	Forward Cargo Compartment Lower Lobe
53-518-00-01	53-518-00	53-518-00		DETAILED	Main Landing Gear Wheel Well, Left
53-519-00-01	53-519-00	53-519-00		DETAILED	Main Landing Gear Wheel Well, Right
53-520-00-01	53-520-00	53-520-00		GENERAL VISUAL	Area Above Main Landing Gear Wheel Well
53-520-01-01	53-520-01	53-520-01		GENERAL VISUAL	Area Above Main Landing Gear Wheel Well



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-521-00-01	53-521-00	53-521-00		GENERAL VISUAL	Aft Cargo Compartment
53-522-00-01	53-522-00	53-522-00		GENERAL VISUAL	Aft Cargo Compartment
53-522-01-01	53-522-01	53-522-01		GENERAL VISUAL	Aft Cargo Compartment
53-523-00-01	53-523-00	53-523-00		GENERAL VISUAL	Aft Cargo Compartment
53-523-01-01	53-523-01	53-523-01		GENERAL VISUAL	Aft Cargo Compartment
53-524-00-01	53-524-00	53-524-00		DETAILED	Aft Cargo Compartment
53-525-00-01	53-525-00	53-525-00		DETAILED	Aft Cargo Compartment
53-526-00-01	53-526-00	53-526-00		DETAILED	Aft Cargo Compartment
53-526-01-01	53-526-01	53-526-01		DETAILED	Aft Cargo Compartment
53-527-00-01	53-527-00	53-527-00		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-528-00-01	53-528-00	53-528-00		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-529-00-01	53-529-00	53-529-00		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-529-01-01	53-529-01	53-529-01		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-530-00-01	53-530-00	53-530-00		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-530-01-01	53-530-01	53-530-01		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-532-00-01	53-532-00	53-532-00		DETAILED	Area Below Aft Cargo Compartment
53-532-01-01	53-532-01	53-532-01		DETAILED	Area Below Aft Cargo Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-533-00-01	53-533-00	53-533-00		DETAILED	Area Below Aft Cargo Compartment
53-533-01-01	53-533-01	53-533-01		DETAILED	Area Below Aft Cargo Compartment
53-534-00-01	53-534-00	53-534-00		GENERAL VISUAL	Area Below Aft Cargo Compartment
53-535-00-01	53-535-00	53-535-00		GENERAL VISUAL	Bulk Cargo Compartment
53-536-00-01	53-536-00	53-536-00		DETAILED	Bulk Cargo Compartment
53-537-00-01	53-537-00	53-537-00		DETAILED	Bulk Cargo Compartment
53-537-00-02	53-537-00	53-537-00		DETAILED	Bulk Cargo Compartment
53-537-00-03	53-537-00	53-537-00		DETAILED	Bulk Cargo Compartment
53-537-00-04	53-537-00	53-537-00		DETAILED	Bulk Cargo Compartment
53-537-00-05	53-537-00	53-537-00		DETAILED	Bulk Cargo Compartment
53-537-01-01	53-537-01	53-537-01		DETAILED	Bulk Cargo Compartment
53-538-00-01	53-538-00	53-538-00		DETAILED	Area Below Bulk Cargo Compartment
53-539-00-01	53-539-00	53-539-00		DETAILED	Area Aft of Bulk Cargo Compartment
53-540-00-01	53-540-00	53-540-00		DETAILED	Area Aft of Bulk Cargo Compartment
53-541-00-01	53-541-00	53-541-00		GENERAL VISUAL	Aft Cargo Compartment
53-542-00-01	53-542-00	53-542-00		GENERAL VISUAL	Bulk Cargo Compartment
53-543-00-01	53-543-00	53-543-00		GENERAL VISUAL	Overwing Wing-To-Body Fairings, Left
53-544-00-01	53-544-00	53-544-00		GENERAL VISUAL	Overwing Wing-To-Body Fairings, Right
53-545-01-01	53-545-01	53-545-01		DETAILED	Forward Wing-To-Body Fairings - Left
53-545-02-01	53-545-02	53-545-02		DETAILED	Forward Wing-To-Body Fairings - Right



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-546-01-01	53-546-01	53-546-01		GENERAL VISUAL	Overwing Wing-To-Body Fairings - Left
53-546-02-01	53-546-02	53-546-02		GENERAL VISUAL	Overwing Wing-To-Body Fairings - Right
53-547-01-01	53-547-01	53-547-01		DETAILED	Aft Wing-To-Body Fairings - Left
53-547-02-01	53-547-02	53-547-02		DETAILED	Aft Wing-To-Body Fairings - Right
53-547-03-01	53-547-03	53-547-03		DETAILED	Aft Wing-To-Body Fairings - Left
53-547-04-01	53-547-04	53-547-04		DETAILED	Aft Wing-To-Body Fairings - Right
53-548-00-01	53-548-00	53-548-00		SPECIAL DETAILED	Flight Compartment
53-549-00-01	53-549-00	53-549-00		DETAILED	Flight Compartment
53-550-00-01	53-550-00	53-550-00		GENERAL VISUAL	Flight Compartment
53-551-00-01	53-551-00	53-551-00		GENERAL VISUAL	Passenger Compartment - Left
53-551-01-01	53-551-01	53-551-01		GENERAL VISUAL	Supernumerary Cabin - Left
53-552-00-01	53-552-00	53-552-00		GENERAL VISUAL	Passenger Compartment - Right
53-552-01-01	53-552-01	53-552-01		GENERAL VISUAL	Supernumerary Cabin - Right
53-553-00-01	53-553-00	53-553-00		GENERAL VISUAL	Passenger Compartment - Left
53-553-01-01	53-553-01	53-553-01		GENERAL VISUAL	Supernumerary Cabin - Left
53-554-00-01	53-554-00	53-554-00		GENERAL VISUAL	Passenger Compartment - Right
53-554-01-01	53-554-01	53-554-01		GENERAL VISUAL	Supernumerary Cabin - Right



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-557-00-01	53-557-00	53-557-00		GENERAL VISUAL	Main Deck Compartment
53-558-00-01	53-558-00	53-558-00		GENERAL VISUAL	Main Deck Compartment
53-559-00-01	53-559-00	53-559-00		DETAILED	Main Deck Compartment
53-560-00-01	53-560-00	53-560-00		DETAILED	Main Deck Compartment
53-561-00-01	53-561-00	53-561-00		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-562-00-01	53-562-00	53-562-00		GENERAL VISUAL	Passenger Compartment - Left
53-563-00-01	53-563-00	53-563-00		GENERAL VISUAL	Passenger Compartment - Right
53-564-00-01	53-564-00	53-564-00		GENERAL VISUAL	Passenger Compartment - Left
53-565-00-01	53-565-00	53-565-00		GENERAL VISUAL	Passenger Compartment - Right
53-568-00-01	53-568-00	53-568-00		GENERAL VISUAL	Passenger Compartment - Left
53-568-00-02	53-568-00	53-568-00		GENERAL VISUAL	Passenger Compartment - Left
53-568-00-03	53-568-00	53-568-00		GENERAL VISUAL	Passenger Compartment - Left
53-568-00-04	53-568-00	53-568-00		GENERAL VISUAL	Passenger Compartment - Left
53-568-00-05	53-568-00	53-568-00		GENERAL VISUAL	Passenger Compartment - Left
53-568-01-01	53-568-01	53-568-01		GENERAL VISUAL	Main Deck Cargo Compartment - Left
53-569-00-01	53-569-00	53-569-00		GENERAL VISUAL	Passenger Compartment - Right



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-569-00-02	53-569-00	53-569-00		GENERAL VISUAL	Passenger Compartment - Right
53-569-00-03	53-569-00	53-569-00		GENERAL VISUAL	Passenger Compartment - Right
53-569-00-04	53-569-00	53-569-00		GENERAL VISUAL	Passenger Compartment - Right
53-569-00-05	53-569-00	53-569-00		GENERAL VISUAL	Passenger Compartment - Right
53-569-01-01	53-569-01	53-569-01		GENERAL VISUAL	Main Deck Cargo Compartment - Right
53-570-00-01	53-570-00	53-570-00		DETAILED	Passenger Compartment - Left
53-571-00-01	53-571-00	53-571-00		DETAILED	Passenger Compartment - Right
53-572-00-01	53-572-00	53-572-00		GENERAL VISUAL	Passenger Compartment - Left
53-572-01-01	53-572-01	53-572-01		GENERAL VISUAL	Main Deck Cargo Compartment - Left
53-573-00-01	53-573-00	53-573-00		GENERAL VISUAL	Passenger Compartment - Right
53-573-01-01	53-573-01	53-573-01		GENERAL VISUAL	Main Deck Cargo Compartment - Right
53-574-00-01	53-574-00	53-574-00		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-575-00-01	53-575-00	53-575-00		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-576-00-01	53-576-00	53-576-00		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-576-00-02	53-576-00	53-576-00		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-576-00-03	53-576-00	53-576-00		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-576-00-04	53-576-00	53-576-00		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-576-00-05	53-576-00	53-576-00		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-576-00-06	53-576-00	53-576-00		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-577-00-01	53-577-00	53-577-00		GENERAL VISUAL	Main Deck Compartment
53-577-00-02	53-577-00	53-577-00		GENERAL VISUAL	Main Deck Compartment
53-577-00-03	53-577-00	53-577-00		GENERAL VISUAL	Main Deck Compartment
53-577-00-04	53-577-00	53-577-00		GENERAL VISUAL	Main Deck Compartment
53-577-00-05	53-577-00	53-577-00		GENERAL VISUAL	Main Deck Compartment
53-577-00-06	53-577-00	53-577-00		GENERAL VISUAL	Main Deck Compartment
53-578-00-01	53-578-00	53-578-00		GENERAL VISUAL	Main Deck Compartment
53-578-00-02	53-578-00	53-578-00		GENERAL VISUAL	Main Deck Compartment
53-578-00-03	53-578-00	53-578-00		GENERAL VISUAL	Main Deck Compartment
53-578-00-04	53-578-00	53-578-00		GENERAL VISUAL	Main Deck Compartment
53-578-00-05	53-578-00	53-578-00		GENERAL VISUAL	Main Deck Compartment
53-578-00-06	53-578-00	53-578-00		GENERAL VISUAL	Main Deck Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-579-00-01	53-579-00	53-579-00		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-580-00-01	53-580-00	53-580-00		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-581-00-01	53-581-00	53-581-00		GENERAL VISUAL	Area Above Main Deck Compartment Ceiling
53-582-00-01	53-582-00	53-582-00		GENERAL VISUAL	Passenger Compartment
53-583-00-01	53-583-00	53-583-00		GENERAL VISUAL	Passenger Compartment
53-584-00-01	53-584-00	53-584-00		GENERAL VISUAL	Passenger Compartment
53-585-00-01	53-585-00	53-585-00		GENERAL VISUAL	Passenger Compartment
53-586-00-01	53-586-00	53-586-00		GENERAL VISUAL	Passenger Compartment
53-586-01-01	53-586-01	53-586-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-587-00-01	53-587-00	53-587-00		GENERAL VISUAL	Main Deck Cargo Compartment
53-588-00-01	53-588-00	53-588-00		GENERAL VISUAL	Upper Cargo Compartment
53-589-00-01	53-589-00	53-589-00		GENERAL VISUAL	Passenger Compartment
53-590-00-01	53-590-00	53-590-00		GENERAL VISUAL	Passenger Compartment
53-591-00-01	53-591-00	53-591-00		GENERAL VISUAL	Passenger Compartment
53-591-00-02	53-591-00	53-591-00		GENERAL VISUAL	Passenger Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-591-00-03	53-591-00	53-591-00		GENERAL VISUAL	Passenger Compartment
53-591-00-04	53-591-00	53-591-00		GENERAL VISUAL	Passenger Compartment
53-591-00-05	53-591-00	53-591-00		GENERAL VISUAL	Passenger Compartment
53-591-01-01	53-591-01	53-591-01		GENERAL VISUAL	Main Deck Cargo Compartment
53-592-00-01	53-592-00	53-592-00		DETAILED	Passenger Compartment
53-593-00-01	53-593-00	53-593-00		DETAILED	Passenger Compartment
53-594-00-01	53-594-00	53-594-00		DETAILED	Passenger Compartment
53-594-00-02	53-594-00	53-594-00		DETAILED	Passenger Compartment
53-594-00-03	53-594-00	53-594-00		DETAILED	Passenger Compartment
53-594-00-04	53-594-00	53-594-00		DETAILED	Passenger Compartment
53-594-00-05	53-594-00	53-594-00		DETAILED	Passenger Compartment
53-594-01-01	53-594-01	53-594-01		DETAILED	Main Deck Cargo Compartment
53-595-00-01	53-595-00	53-595-00		GENERAL VISUAL	Area above Main Deck Compartment Ceiling
53-596-00-01	53-596-00	53-596-00		GENERAL VISUAL	Area above Main Deck Compartment Ceiling
53-597-00-01	53-597-00	53-597-00		GENERAL VISUAL	Area above Main Deck Compartment Ceiling
53-597-00-02	53-597-00	53-597-00		GENERAL VISUAL	Area above Main Deck Compartment Ceiling
53-597-00-03	53-597-00	53-597-00		GENERAL VISUAL	Area above Main Deck Compartment Ceiling
53-597-00-04	53-597-00	53-597-00		GENERAL VISUAL	Area above Main Deck Compartment Ceiling



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-597-00-05	53-597-00	53-597-00		GENERAL VISUAL	Area above Main Deck Compartment Ceiling
53-597-00-06	53-597-00	53-597-00		GENERAL VISUAL	Area above Main Deck Compartment Ceiling
53-598-00-01	53-598-00	53-598-00		GENERAL VISUAL	Area above Main Deck Compartment Ceiling
53-599-00-01	53-599-00	53-599-00		GENERAL VISUAL	Passenger Compartment
53-601-00-01	53-601-00	53-601-00		GENERAL VISUAL	Passenger Compartment
53-602-00-01	53-602-00	53-602-00		GENERAL VISUAL	Passenger Compartment
53-603-00-01	53-603-00	53-603-00		GENERAL VISUAL	Passenger Compartment
53-606-00-01	53-606-00	53-606-00		GENERAL VISUAL	Passenger Compartment
53-607-00-01	53-607-00	53-607-00		GENERAL VISUAL	Passenger Compartment
53-608-00-01	53-608-00	53-608-00		DETAILED	Passenger Compartment
53-609-00-01	53-609-00	53-609-00		DETAILED	Passenger Compartment
53-610-00-01	53-610-00	53-610-00		DETAILED	Area above Wing Center Section
53-610-00-02	53-610-00	53-610-00		DETAILED	Area above Wing Center Section
53-611-00-01	53-611-00	53-611-00		GENERAL VISUAL	Area above Wing Center Section
53-612-00-01	53-612-00	53-612-00		GENERAL VISUAL	Passenger Compartment Left and Right
53-613-00-01	53-613-00	53-613-00		GENERAL VISUAL	Area above Passenger Compartment Ceiling



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-614-00-01	53-614-00	53-614-00		GENERAL VISUAL	Passenger Compartment Left
53-614-00-02	53-614-00	53-614-00		GENERAL VISUAL	Passenger Compartment Right
53-615-00-01	53-615-00	53-615-00		GENERAL VISUAL	Passenger Compartment Left and Right
53-615-00-02	53-615-00	53-615-00		GENERAL VISUAL	Passenger Compartment Left and Right
53-616-00-01	53-616-00	53-616-00		DETAILED	Passenger Compartment Left and Right
53-616-00-02	53-616-00	53-616-00		DETAILED	Passenger Compartment Left and Right
53-617-00-01	53-617-00	53-617-00		GENERAL VISUAL	Passenger Compartment - Left
53-617-00-02	53-617-00	53-617-00		GENERAL VISUAL	Passenger Compartment - Right
53-618-00-01	53-618-00	53-618-00		GENERAL VISUAL	Passenger Compartment Left and Right
53-619-00-01	53-619-00	53-619-00		GENERAL VISUAL	Area above Passenger Compartment Ceiling
53-619-00-02	53-619-00	53-619-00		GENERAL VISUAL	Area above Passenger Compartment Ceiling
53-620-00-01	53-620-00	53-620-00		DETAILED	Forward Wing-To-Body Fairings - Left
53-620-00-02	53-620-00	53-620-00		DETAILED	Forward Wing-To-Body Fairings - Right
53-621-00-01	53-621-00	53-621-00		DETAILED	Aft Wing-To-Body Fairings - Left
53-621-00-02	53-621-00	53-621-00		DETAILED	Aft Wing-To-Body Fairings - Right
53-623-00-01	53-623-00	53-623-00		DETAILED	Main Deck Compartment Ceiling
53-624-00-01	53-624-00	53-624-00		SPECIAL DETAILED	Main Deck Compartment Ceiling



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-625-00-01	53-625-00	53-625-00		GENERAL VISUAL	Main Deck Compartment Ceiling
53-626-00-01	53-626-00	53-626-00		DETAILED	Auxiliary Body Fuel Tanks
53-627-00-01	53-627-00	53-627-00		DETAILED	Auxiliary Body Fuel Tank Attach Fittings, Links and Pins
53-628-00-01	53-628-00	53-628-00		GENERAL VISUAL	Area Above Main Landing Gear Wheel Well
53-629-00-01	53-629-00	53-629-00		GENERAL VISUAL	Supernumerary Area
53-631-00-01	53-631-00	53-631-00		SPECIAL DETAILED	Main Deck Cargo Compartment
53-632-00-01	53-632-00	53-632-00		DETAILED	Main Deck Cargo Compartment
53-633-00-01	53-633-00	53-633-00		GENERAL VISUAL	Main Deck Cargo Compartment
53-634-00-01	53-634-00	53-634-00		GENERAL VISUAL	Main Deck Cargo Compartment
53-635-00-01	53-635-00	53-635-00		SPECIAL DETAILED	Main Deck Cargo Compartment
53-637-00-01	53-637-00	53-637-00		GENERAL VISUAL	Main Deck Cargo Compartment
53-638-00-01	53-638-00	53-638-00		GENERAL VISUAL	Main Deck Cargo Compartment
53-639-00-01	53-639-00	53-639-00		GENERAL VISUAL	Main Deck Cargo Compartment
53-640-00-01	53-640-00	53-640-00		GENERAL VISUAL	Aft Cargo Compartment
53-641-00-01	53-641-00	53-641-00		GENERAL VISUAL	Main Deck Cargo Compartment
53-645-00-01	53-645-00	53-645-00		DETAILED	Aft Cargo Compartment
53-646-00-01	53-646-00	53-646-00		DETAILED	Main Deck Cargo Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-647-00-01	53-647-00	53-647-00		DETAILED	Main Deck Cargo Compartment
53-648-00-01	53-648-00	53-648-00		DETAILED	Area Above Main Deck Cargo Compartment
53-671-00-01	53-671-00	53-671-00		GENERAL VISUAL	Lower Fuselage - Subzone 150 and 160
53-673-00-01	53-673-00	53-673-00		GENERAL VISUAL	Underwing Wing-To-Body Fairing - Left
53-673-00-02	53-673-00	53-673-00		GENERAL VISUAL	Underwing Wing-To-Body Fairing - Right
53-674-01-01	53-674-01	53-674-01		GENERAL VISUAL	Supernumerary Cabin
53-675-00-01	53-675-00	53-675-00		GENERAL VISUAL	Subzone 220 BS 246 to 655 (Section 41)
53-675-01-01	53-675-01	53-675-01		GENERAL VISUAL	Subzone 220 BS 388 to 655
53-676-00-01	53-676-00	53-676-00		GENERAL VISUAL	Subzone 230 BS 655 to 1035 (Section 43)
53-677-00-01	53-677-00	53-677-00		GENERAL VISUAL	Subzone 240 BS 1035 to 1434 (Section 44)
53-678-00-01	53-678-00	53-678-00		GENERAL VISUAL	Subzone 250 BS 1434 to 1832 (Section 46)
53-679-00-01	53-679-00	53-679-00		GENERAL VISUAL	Subzone 260 BS 1832 to 2195.75 (Section 47)
53-701-01-01	53-701-01			GENERAL VISUAL	Upper Lobe Skin Panels
53-702-01-01	53-702-01			GENERAL VISUAL	Lower Lobe Skin Panels
53-703-01-01	53-703-01			DETAILED	Upper and Lower Lobe Skin Panels
53-704-01-01	53-704-01			SPECIAL DETAILED	Crown Skin Antenna Installation - TCAS



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-705-01-01	53-705-01			SPECIAL DETAILED	ACL Installation External Doubler
53-706-01-01	53-706-01			SPECIAL DETAILED	ACL Installation External Doubler
53-707-01-01	53-707-01			GENERAL VISUAL	Crown Skin Production ACL Installation
53-708-01-01	53-708-01			DETAILED	Ground Maneuver Camera Installation
53-709-01-01	53-709-01			SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin
53-710-01-01	53-710-01			DETAILED	Longitudinal Skin Lap Splices Outer Skin
53-711-01-01	53-711-01			SPECIAL DETAILED	Passenger Entry Door #1 - Cutout
53-712-01-01	53-712-01			SPECIAL DETAILED	Passenger Entry Door #1 - Cutout
53-713-01-01	53-713-01			SPECIAL DETAILED	Passenger Entry Door #1 - Cutout
53-714-01-01	53-714-01			SPECIAL DETAILED	Passenger Entry Door #1 - Cutout
53-715-01-01	53-715-01			SPECIAL DETAILED	Forward Large Cargo Door - Cutout
53-716-01-01	53-716-01			SPECIAL DETAILED	FWD Large Cargo Door - Cutout Outer Chord - Upper Sill
53-717-01-01	53-717-01			SPECIAL DETAILED	Fwd Large Cargo Door - Cutout
53-718-01-01	53-718-01			SPECIAL DETAILED	Fwd Large Cargo Door - Cutout
53-719-01-01	53-719-01			SPECIAL DETAILED	Forward Equipment Bay Access Hatch Cutout Structure
53-720-01-01	53-720-01			SPECIAL DETAILED	E/E Bay Access Hatch Cutout Structure





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-721-01-01	53-721-01			DETAILED	No. 1 Crew Window Cutout Structure
53-722-01-01	53-722-01			SPECIAL DETAILED	No. 3 Crew Window Cutout Structure
53-723-01-01	53-723-01			SPECIAL DETAILED	NLG Well Top Panel
53-724-01-01	53-724-01			SPECIAL DETAILED	WL 152 Beam (C/L 1 to 40)
53-724-02-01	53-724-02			SPECIAL DETAILED	WL 152 Beam (C/L 41 and on)
53-725-01-01	53-725-01			DETAILED	Nose Wheel Well Cutout Structure (C/L 1 to 40)
53-725-02-01	53-725-02			SPECIAL DETAILED	Nose Wheel Well Cutout Structure (C/L 41 and on)
53-725-03-01	53-725-03			DETAILED	Nose Landing Gear Well Cutout (C/L 1 to 40)
53-725-04-01	53-725-04			SPECIAL DETAILED	Nose Landing Gear Well Cutout (C/L 1 to 40)
53-725-05-01	53-725-05			DETAILED	Nose Landing Gear Well Cutout (C/L 41 and on)
53-725-06-01	53-725-06			SPECIAL DETAILED	Nose Landing Gear Well Cutout (C/L 41 and on)
53-725-07-01	53-725-07			SPECIAL DETAILED	Nose Wheel Well Cutout Structure (L/N 1 to 40)
53-726-01-01	53-726-01			SPECIAL DETAILED	Nose Wheel Well Trunnion Support Fitting
53-726-02-01	53-726-02			SPECIAL DETAILED	Nose Wheel Well Trunnion Support Fitting (C/L 41 and on)
53-727-01-01	53-727-01			SPECIAL DETAILED	NLG Drag Brace Fitting - Lug and Bushing Interface
53-728-01-01	53-728-01			DETAILED	Crown Panel Skin/Stringer Under Radome
53-728-02-01	53-728-02			DETAILED	Longitudinal Skin Crack Under Radome



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-730-01-01	53-730-01			SPECIAL DETAILED	Longitudinal Skin Crack Under Antenna Attach Angle/Skin Lug Fittings
53-731-01-01	53-731-01			SPECIAL DETAILED	Fuselage Skin adjacent to Strakelet Attach Fitting (L/N 1-218)
53-731-02-01	53-731-02			SPECIAL DETAILED	Fuselage Skin adjacent to Strakelet Attach Fitting (L/N 219 and on)
53-733-01-01	53-733-01			SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice, BS 1035 (L/N 75 and on)
53-733-02-01	53-733-02			SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice, BS 1035 (L/N 75 and on)
53-733-03-01	53-733-03			SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice, BS 1035 (L/N 75 and on)
53-733-04-01	53-733-04			SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice, BS 1035
53-733-05-01	53-733-05			SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice, BS 1035
53-733-06-01	53-733-06			SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice, BS 1035
53-734-01-01	53-734-01			SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin (L/N 1-422)
53-734-02-01	53-734-02			SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin (L/N 423 and on)
53-734-03-01	53-734-03			SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin
53-735-01-01	53-735-01			DETAILED	Longitudinal Skin Lap Splices Outer Skin - Except Lower Row (S-45). Typical - All Section 43 Lap Splices.
53-736-01-01	53-736-01			SPECIAL DETAILED	Passenger Entry Door #2 - Cutout
53-737-01-01	53-737-01			SPECIAL DETAILED	Passenger Entry Door #2 - Cutout



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-739-01-01	53-739-01			SPECIAL DETAILED	Passenger Entry Door #2 - Cutout Upper Sill
53-740-01-01	53-740-01			SPECIAL DETAILED	Passenger Entry Door #2 - Cutout
53-741-01-01	53-741-01			SPECIAL DETAILED	Passenger Entry Door #2 - Cutout Door Stop Backup Fitting
53-742-01-01	53-742-01			SPECIAL DETAILED	Satcom Antenna - Circumferential Cracking with Broken Stringer
53-742-02-01	53-742-02			DETAILED	Skin and Stringer at SATCOM antenna installation
53-743-01-01	53-743-01			SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin (L/N 1-450)
53-743-02-01	53-743-02			SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin (L/N 451 and on)
53-743-03-01	53-743-03			SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin
53-743-04-01	53-743-04			SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin (L/N 1-450)
53-744-01-01	53-744-01			DETAILED	Longitudinal Skin Lap Splices Outer Skin
53-745-01-01	53-745-01			SPECIAL DETAILED	Front Spar Side Fitting Inner Chord Splice
53-746-01-01	53-746-01			SPECIAL DETAILED	Rear Spar Side Fitting Inner Chord Splice
53-746-02-01	53-746-02			SPECIAL DETAILED	Rear Spar Side Fitting
53-746-03-01	53-746-03			SPECIAL DETAILED	Rear Spar Side Fitting at Seat Track Attachment
53-747-01-01	53-747-01			SPECIAL DETAILED	Aft Wheel Well Bulkhead Inner Chord Splice
53-748-01-01	53-748-01			DETAILED	Passenger Entry Overwing Door #3 - Cutout



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-748-02-01	53-748-02			SPECIAL DETAILED	Passenger Entry Overwing Door #3 - Cutout
53-749-01-01	53-749-01			SPECIAL DETAILED	Passenger Entry Overwing Door #3 - Cutout
53-750-01-01	53-750-01			SPECIAL DETAILED	Passenger Entry Overwing Door #3 - Cutout
53-751-01-01	53-751-01			SPECIAL DETAILED	Passenger Entry Overwing Door #3 - Cutout
53-752-01-01	53-752-01			SPECIAL DETAILED	Passenger Entry Overwing Door #3 - Cutout Upper Main Sill
53-753-01-01	53-753-01			SPECIAL DETAILED	Aft Wheel Well Bulkhead Side Fitting Inner Chord Splice
53-753-02-01	53-753-02			SPECIAL DETAILED	Aft Wheel Well Bulkhead Side Fitting Outer Chord
53-753-03-01	53-753-03			SPECIAL DETAILED	Aft Wheel Well Bulkhead Side Fitting Outer Chord
53-753-04-01	53-753-04			DETAILED	Aft Wheel Well Bulkhead Side Fitting Outer Chord
53-753-05-01	53-753-05			SPECIAL DETAILED	Aft Wheel Well Bulkhead Side Fitting Outer Chord
53-753-06-01	53-753-06			SPECIAL DETAILED	Aft Wheel Well Bulkhead Horizontal Stiffeners
53-753-07-01	53-753-07			SPECIAL DETAILED	Aft Wheel Well Bulkhead Horizontal Stiffeners
53-754-01-01	53-754-01			SPECIAL DETAILED	Crown Panel, Skin and Stringer Section 46
53-754-02-01	53-754-02			SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice (L/N 75 and on)
53-754-03-01	53-754-03			SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice (L/N 75 and on)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-754-04-01	53-754-04			SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice
53-754-05-01	53-754-05			SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice
53-754-06-01	53-754-06			SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice
53-754-07-01	53-754-07			SPECIAL DETAILED	Fuselage Circumferential Skin/Stringer Splice
53-755-01-01	53-755-01			SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin (L/N 1-422)
53-755-02-01	53-755-02			SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin (L/N 423 and on)
53-755-03-01	53-755-03			SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin
53-756-01-01	53-756-01			DETAILED	Longitudinal Skin Lap Splices Outer Skin
53-757-01-01	53-757-01			SPECIAL DETAILED	Passenger Entry Door #3 (-200)
53-757-02-01	53-757-02			SPECIAL DETAILED	Passenger Entry Door #4 (-300)
53-757-03-01	53-757-03			SPECIAL DETAILED	Passenger Entry Door #3 (-200ER)
53-757-04-01	53-757-04			SPECIAL DETAILED	Passenger Entry Door #3 (-200ER)
53-758-01-01	53-758-01			SPECIAL DETAILED	Passenger Entry Door #3 (-200)/#4 (-300) Cutout
53-759-01-01	53-759-01			SPECIAL DETAILED	Passenger Entry Door #3 (-200)/#4 (-300) Cutout
53-760-01-01	53-760-01			SPECIAL DETAILED	Passenger Entry Door #3 (-200)/#4 (-300) - Cutout



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-761-01-01	53-761-01			SPECIAL DETAILED	Passenger Entry Door #3 (-200)/#4 (-300) - Cutout
53-762-01-01	53-762-01			SPECIAL DETAILED	Small Cargo Door - Cutout Lower Main Sill
53-763-01-01	53-763-01			SPECIAL DETAILED	Small Cargo Door - Cutout Upper Main Sill
53-764-01-01	53-764-01			SPECIAL DETAILED	Small Cargo Door - Cutout Inner Chord - Edge Frames STA 1678.5 & STA 1754.5
53-765-01-01	53-765-01			SPECIAL DETAILED	Small Cargo Door - Cutout Inner Chord - Edge Frames STA 1678.5 & STA 1754.5
53-766-01-01	53-766-01			SPECIAL DETAILED	Small Cargo Door - Cutout Outer Chord - Edge Frames STA 1678.5 & STA 1754.5
53-767-01-01	53-767-01			DETAILED	Small Cargo Door - Cutout
53-767-02-01	53-767-02			SPECIAL DETAILED	Small Cargo Door - Cutout
53-768-01-01	53-768-01			SPECIAL DETAILED	Aft Large Cargo Door - Cutout
53-769-01-01	53-769-01			SPECIAL DETAILED	Aft Large Cargo Door - Cutout Outer Chord - Upper Sill
53-770-01-01	53-770-01			SPECIAL DETAILED	Aft Large Cargo Door - Upper Main Sill
53-774-01-01	53-774-01			SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin (L/N 1-422)
53-774-02-01	53-774-02			SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin (L/N 423 and on)
53-774-03-01	53-774-03			SPECIAL DETAILED	Longitudinal Skin Lap Splices Inner Skin
53-775-01-01	53-775-01			DETAILED	Longitudinal Skin Lap Splices Outer Skin
53-776-01-01	53-776-01			SPECIAL DETAILED	Passenger Entry Door #4 (-200)/#5 (-300) - Cutout



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-777-01-01	53-777-01			SPECIAL DETAILED	Passenger Entry Door #4 (-200)/#5 (-300) - Cutout
53-778-01-01	53-778-01			SPECIAL DETAILED	Passenger Entry Door #4 (-200)/#5 (-300) - Cutout
53-779-01-01	53-779-01			SPECIAL DETAILED	Passenger Entry Door #4 (-200)/#5 (-300) - Cutout
53-780-01-01	53-780-01			SPECIAL DETAILED	Bulk Cargo Door - Cutout Edge Frames
53-781-01-01	53-781-01			SPECIAL DETAILED	Pressure Bulkhead at STA 2150; Sec 48 Lap Splice (L/N 1-3)
53-781-02-01	53-781-02			SPECIAL DETAILED	Pressure Bulkhead at STA 2150; Sec 48 Lap Splice (L/N 1-422)
53-781-03-01	53-781-03			DETAILED	Pressure Bulkhead at STA 2150; Sec 48 Lap Splice (L/N 1-422)
53-781-04-01	53-781-04			SPECIAL DETAILED	Pressure Bulkhead at STA 2150; Sec 48 Lap Splice (L/N 423 and on)
53-781-05-01	53-781-05			DETAILED	Pressure Bulkhead at STA 2150; Sec 48 Lap Splice (L/N 423 and on)
53-782-01-01	53-782-01			DETAILED	Pressure Bulkhead at STA 2150; Sec 48 Circumferential Crack in Web at Radial Stiffener
53-783-01-01	53-783-01			SPECIAL DETAILED	Pressure Bulkhead, STA 2150, Dome Web Attachment to Y-Ring (L/N 1-422)
53-783-02-01	53-783-02			SPECIAL DETAILED	Pressure Bulkhead, STA 2150, Dome Web Attachment to Y-Ring (L/N 423 and on)
53-784-01-01	53-784-01			SPECIAL DETAILED	Stabilizer Pivot Bulkhead STA 2370
53-785-01-01	53-785-01			DETAILED	Stabilizer Pivot Bulkhead STA 2370 - Vertical Stiffeners
53-786-01-01	53-786-01			SPECIAL DETAILED	Stabilizer Pivot Fitting Lug; Section 48
53-787-01-01	53-787-01			SPECIAL DETAILED	Jackscrew Support Fitting Lug



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-800-00-01	53-800-00	53-800-00		ZONAL (GV)	Left Fuselage Lower Half - Section 41 & 43 - STA 92.5 to STA 858
53-800-00-02	53-800-00	53-800-00		ZONAL (GV)	Right Fuselage Lower Half - Section 41 & 43 - STA 92.5 to STA 858
53-800-00-03	53-800-00	53-800-00		ZONAL (GV)	Lower Left Fuselage & Wing to Body Fairing - STA 858 to STA 1655
53-800-00-04	53-800-00	53-800-00		ZONAL (GV)	Lower Right Fuselage & Wing to Body Fairing - STA 858 to STA 1655
53-800-00-05	53-800-00	53-800-00		ZONAL (GV)	Lower Left Fuselage - STA 1655 to STA 2150
53-800-00-06	53-800-00	53-800-00		ZONAL (GV)	Lower Right Fuselage - STA 1655 to STA 2150
53-800-00-07	53-800-00	53-800-00		ZONAL (GV)	Left Fuselage Lower Half - Section 41 & 43 - STA 92.5 to STA 867
53-800-00-08	53-800-00	53-800-00		ZONAL (GV)	Right Fuselage Lower Half - Section 41 & 43 - STA 92.5 to STA 867
53-800-00-09	53-800-00	53-800-00		ZONAL (GV)	Lower Left Fuselage & Wing to Body Fairing - STA 858 to STA 1655
53-800-00-10	53-800-00	53-800-00		ZONAL (GV)	Lower Right Fuselage & Wing to Body Fairing - STA 858 to STA 1655
53-800-00-11	53-800-00	53-800-00		ZONAL (GV)	Lower Left Fuselage - STA 1655 to STA 2196
53-800-00-12	53-800-00	53-800-00		ZONAL (GV)	Lower Right Fuselage - STA 1655 to STA 2196
53-804-00-01	53-804-00	53-804-00		ZONAL (GV)	Radome
53-804-00-02	53-804-00	53-804-00		ZONAL (GV)	Radome
53-804-00-03	53-804-00	53-804-00		ZONAL (GV)	Radome
53-804-00-04	53-804-00	53-804-00		ZONAL (GV)	Radome
53-804-00-05	53-804-00	53-804-00		ZONAL (GV)	Radome
53-804-00-06	53-804-00	53-804-00		ZONAL (GV)	Radome
53-806-00-01	53-806-00	53-806-00		ZONAL (GV)	Area Forward of Nose Landing Gear Wheel Well
53-808-00-01	53-808-00	53-808-00		ZONAL (GV)	Nose Gear Wheel Well - from the ground
53-810-00-01	53-810-00	53-810-00		ZONAL (GV)	Nose Gear Wheel Well (Inspection Accomplished from Within Wheel Well)
53-812-00-01	53-812-00	53-812-00		ZONAL (GV)	Area Above and Outboard of the Nose Landing Gear Wheel Well
53-814-00-01	53-814-00	53-814-00		ZONAL (GV)	Main Equipment Center
53-816-00-01	53-816-00	53-816-00		ZONAL (GV)	Forward Cargo Compartment





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-818-00-01	53-818-00	53-818-00		ZONAL (GV)	Forward Cargo Compartment
53-820-00-01	53-820-00	53-820-00		ZONAL (GV)	Forward Cargo Compartment
53-822-00-01	53-822-00	53-822-00		ZONAL (GV)	Area Below Forward Cargo
53-824-00-01	53-824-00	53-824-00		ZONAL (GV)	Area Below Forward Cargo Compartment
53-824-00-02	53-824-00	53-824-00		ZONAL (GV)	Area Below Forward Cargo Compartment
53-824-00-03	53-824-00	53-824-00		ZONAL (GV)	Area Below Forward Cargo Compartment
53-824-00-04	53-824-00	53-824-00		ZONAL (GV)	Area Below Forward Cargo Compartment
53-824-00-05	53-824-00	53-824-00		ZONAL (GV)	Area Below Forward Cargo Compartment
53-824-00-06	53-824-00	53-824-00		ZONAL (GV)	Area Below Forward Cargo Compartment
53-826-00-01	53-826-00	53-826-00		ZONAL (GV)	Area Aft of Forward Cargo Compartment
53-828-00-01	53-828-00	53-828-00		ZONAL (GV)	Area Above Wing Center Section
53-830-00-01	53-830-00	53-830-00		ZONAL (GV)	Left Environmental Control Systems Bay
53-830-00-02	53-830-00	53-830-00		ZONAL (GV)	Right Environmental Control Systems Bay
53-832-00-01	53-832-00	53-832-00		ZONAL (GV)	Forward Keel Beam
53-832-00-02	53-832-00	53-832-00		ZONAL (GV)	Forward Keel Beam
53-832-00-03	53-832-00	53-832-00		ZONAL (GV)	Forward Keel Beam
53-832-00-04	53-832-00	53-832-00		ZONAL (GV)	Forward Keel Beam
53-832-00-05	53-832-00	53-832-00		ZONAL (GV)	Forward Keel Beam
53-832-00-06	53-832-00	53-832-00		ZONAL (GV)	Forward Keel Beam
53-834-00-01	53-834-00	53-834-00		ZONAL (GV)	Area Above Main Landing Gear Wheel Well
53-836-00-01	53-836-00	53-836-00		ZONAL (GV)	Left Main Landing Gear Wheel Well - From the Ground
53-838-00-01	53-838-00	53-838-00		ZONAL (GV)	Left Main Landing Gear Wheel Well (Inspection accomplished within WW)
53-840-00-01	53-840-00	53-840-00		ZONAL (GV)	Right Main Landing Gear Wheel Well - From the Ground
53-842-00-01	53-842-00	53-842-00		ZONAL (GV)	Right Main Landing Gear Wheel Well (Inspection accomplished Within WW)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-844-00-01	53-844-00	53-844-00		ZONAL (GV)	Aft Keel Beam
53-844-00-02	53-844-00	53-844-00		ZONAL (GV)	Aft Keel Beam
53-844-00-03	53-844-00	53-844-00		ZONAL (GV)	Aft Keel Beam
53-844-00-04	53-844-00	53-844-00		ZONAL (GV)	Aft Keel Beam
53-844-00-05	53-844-00	53-844-00		ZONAL (GV)	Aft Keel Beam
53-844-00-06	53-844-00	53-844-00		ZONAL (GV)	Aft Keel Beam
53-846-00-01	53-846-00	53-846-00		ZONAL (GV)	Aft Cargo Compartment
53-848-00-01	53-848-00	53-848-00		ZONAL (GV)	Aft Cargo Compartment
53-850-00-01	53-850-00	53-850-00		ZONAL (GV)	Aft Cargo Compartment Lower Lobe Attendant Rest
53-852-00-01	53-852-00	53-852-00		ZONAL (GV)	Aft Cargo Compartment
53-852-01-01	53-852-01	53-852-01		ZONAL (GV)	Aft Cargo Compartment
53-854-00-01	53-854-00	53-854-00		ZONAL (GV)	Aft Cargo Compartment
53-856-00-01	53-856-00	53-856-00		ZONAL (GV)	Aft Cargo Compartment
53-858-00-01	53-858-00	53-858-00		ZONAL (GV)	Aft Cargo Compartment
53-860-00-01	53-860-00	53-860-00		ZONAL (GV)	Area Below Aft Cargo Compartment
53-862-00-01	53-862-00	53-862-00		ZONAL (GV)	Area Below Aft Cargo Compartment
53-862-00-02	53-862-00	53-862-00		ZONAL (GV)	Area Below Aft Cargo Compartment
53-862-00-03	53-862-00	53-862-00		ZONAL (GV)	Area Below Aft Cargo Compartment
53-862-00-04	53-862-00	53-862-00		ZONAL (GV)	Area Below Aft Cargo Compartment
53-862-00-05	53-862-00	53-862-00		ZONAL (GV)	Area Below Aft Cargo Compartment
53-862-00-06	53-862-00	53-862-00		ZONAL (GV)	Area Below Aft Cargo Compartment
53-864-00-01	53-864-00	53-864-00		ZONAL (GV)	Area Below Aft Cargo Compartment
53-866-00-01	53-866-00	53-866-00		ZONAL (GV)	Area Below Aft Cargo Compartment
53-868-00-01	53-868-00	53-868-00		ZONAL (GV)	Bulk Cargo Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-870-00-01	53-870-00	53-870-00		ZONAL (GV)	Bulk Cargo Compartment
53-872-00-01	53-872-00	53-872-00		ZONAL (GV)	Bulk Cargo Compartment
53-872-00-02	53-872-00	53-872-00		ZONAL (GV)	Bulk Cargo Compartment
53-872-00-03	53-872-00	53-872-00		ZONAL (GV)	Bulk Cargo Compartment
53-872-00-04	53-872-00	53-872-00		ZONAL (GV)	Bulk Cargo Compartment
53-872-00-05	53-872-00	53-872-00		ZONAL (GV)	Bulk Cargo Compartment
53-872-00-06	53-872-00	53-872-00		ZONAL (GV)	Bulk Cargo Compartment
53-874-00-01	53-874-00	53-874-00		ZONAL (GV)	Area Below Bulk Cargo Compartment
53-876-00-01	53-876-00	53-876-00		ZONAL (GV)	Area Aft of the Bulk Cargo Compartment
53-876-00-02	53-876-00	53-876-00		ZONAL (GV)	Area Aft of the Bulk Cargo Compartment
53-876-00-03	53-876-00	53-876-00		ZONAL (GV)	Area Aft of the Bulk Cargo Compartment
53-876-00-04	53-876-00	53-876-00		ZONAL (GV)	Area Aft of the Bulk Cargo Compartment
53-876-00-05	53-876-00	53-876-00		ZONAL (GV)	Area Aft of the Bulk Cargo Compartment
53-876-00-06	53-876-00	53-876-00		ZONAL (GV)	Area Aft of the Bulk Cargo Compartment
53-878-00-01	53-878-00	53-878-00		ZONAL (GV)	Area Aft of the Bulk Cargo Compartment
53-878-00-02	53-878-00	53-878-00		ZONAL (GV)	Area Aft of the Bulk Cargo Compartment
53-878-00-03	53-878-00	53-878-00		ZONAL (GV)	Area Aft of the Bulk Cargo Compartment
53-878-00-04	53-878-00	53-878-00		ZONAL (GV)	Area Aft of the Bulk Cargo Compartment
53-878-00-05	53-878-00	53-878-00		ZONAL (GV)	Area Aft of the Bulk Cargo Compartment
53-878-00-06	53-878-00	53-878-00		ZONAL (GV)	Area Aft of the Bulk Cargo Compartment
53-880-00-01	53-880-00	53-880-00		ZONAL (GV)	Forward Wing-To-Body Fairings - Left
53-882-00-01	53-882-00	53-882-00		ZONAL (GV)	Forward Wing-To-Body Fairings - Right
53-884-00-01	53-884-00	53-884-00		ZONAL (GV)	Overwing Wing-To-Body Fairing - Left
53-886-00-01	53-886-00	53-886-00		ZONAL (GV)	Overwing Wing-To-Body Fairings - Right



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-888-00-01	53-888-00	53-888-00		ZONAL (GV)	Underwing Wing-to-Body Fairings - Left
53-890-00-01	53-890-00	53-890-00		ZONAL (GV)	Underwing Wing-To-Body Fairings - Right
53-892-00-01	53-892-00	53-892-00		ZONAL (GV)	Aft Wing-to-Body Fairings - Left
53-894-00-01	53-894-00	53-894-00		ZONAL (GV)	Aft Wing-To-Body Fairings - Right
53-896-00-01	53-896-00	53-896-00		ZONAL (GV)	Left Upper Fuselage - Body Sections 41 and 43 - STA 246 to STA 1035
53-896-00-02	53-896-00	53-896-00		ZONAL (GV)	Right Upper Fuselage - Body Sections 41 and 43 - STA 246 to STA 1035
53-896-00-03	53-896-00	53-896-00		ZONAL (GV)	Left Upper Fuselage - Body Section 44 - BS 1035 to 1434
53-896-00-04	53-896-00	53-896-00		ZONAL (GV)	Right Upper Fuselage - Body Section 44 - STA 1035 to STA 1434
53-896-00-05	53-896-00	53-896-00		ZONAL (GV)	Left Upper Fuselage - Body Section 46 and 47 - STA 1434 to STA 2150
53-896-00-06	53-896-00	53-896-00		ZONAL (GV)	Right Upper Fuselage - Body Sections 46 and 47 - STA 1434 to STA 2150
53-898-00-01	53-898-00	53-898-00		ZONAL (GV)	Left Upper Fuselage - Flight Compartment - STA 92.5 to STA 246
53-898-00-02	53-898-00	53-898-00		ZONAL (GV)	Right Upper Fuselage - Flight Compartment - STA 92.5 to STA 246
53-900-00-01	53-900-00	53-900-00		ZONAL (GV)	Flight Compartment
53-900-00-02	53-900-00	53-900-00		ZONAL (GV)	Flight Compartment
53-900-00-03	53-900-00	53-900-00		ZONAL (GV)	Flight Compartment
53-900-00-04	53-900-00	53-900-00		ZONAL (GV)	Flight Compartment
53-900-00-05	53-900-00	53-900-00		ZONAL (GV)	Flight Compartment
53-900-00-06	53-900-00	53-900-00		ZONAL (GV)	Flight Compartment
53-902-00-01	53-902-00	53-902-00		ZONAL (GV)	Flight Compartment
53-902-00-02	53-902-00	53-902-00		ZONAL (GV)	Flight Compartment
53-902-00-03	53-902-00	53-902-00		ZONAL (GV)	Flight Compartment
53-902-00-04	53-902-00	53-902-00		ZONAL (GV)	Flight Compartment
53-902-00-05	53-902-00	53-902-00		ZONAL (GV)	Flight Compartment
53-902-00-06	53-902-00	53-902-00		ZONAL (GV)	Flight Compartment



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-904-00-01	53-904-00	53-904-00		ZONAL (GV)	Passenger Compartment - Section 41
53-906-00-01	53-906-00	53-906-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 41
53-906-00-02	53-906-00	53-906-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 41
53-906-00-03	53-906-00	53-906-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 41
53-906-00-04	53-906-00	53-906-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 41
53-906-00-05	53-906-00	53-906-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 41
53-907-00-01	53-907-00	53-907-00		ZONAL (GV)	Overhead Flight Crew Rest (OFCR) Compartment
53-908-00-01	53-908-00	53-908-00		ZONAL (GV)	Passenger Compartment - Section 43
53-910-00-01	53-910-00	53-910-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 43
53-910-00-02	53-910-00	53-910-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 43
53-910-00-03	53-910-00	53-910-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 43
53-910-00-04	53-910-00	53-910-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 43
53-910-00-05	53-910-00	53-910-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 43
53-912-00-01	53-912-00	53-912-00		ZONAL (GV)	Passenger Compartment - Section 44
53-914-00-01	53-914-00	53-914-00		ZONAL (GV)	Area Above Passenger Compartment - Section 44
53-914-00-02	53-914-00	53-914-00		ZONAL (GV)	Area Above Passenger Compartment - Section 44
53-914-00-03	53-914-00	53-914-00		ZONAL (GV)	Area Above Passenger Compartment - Section 44
53-914-00-04	53-914-00	53-914-00		ZONAL (GV)	Area Above Passenger Compartment - Section 44
53-914-00-05	53-914-00	53-914-00		ZONAL (GV)	Area Above Passenger Compartment - Section 44
53-916-00-01	53-916-00	53-916-00		ZONAL (GV)	Passenger Compartment - Section 46
53-918-00-01	53-918-00	53-918-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 46
53-918-00-02	53-918-00	53-918-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 46
53-918-00-03	53-918-00	53-918-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 46
53-918-00-04	53-918-00	53-918-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 46



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-918-00-05	53-918-00	53-918-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 46
53-919-00-01	53-919-00	53-919-00		ZONAL (GV)	INTERNAL - ZONAL (GV): Overhead Flight Attendant Rest (OFAR) Compartment(s)
53-920-00-01	53-920-00	53-920-00		ZONAL (GV)	Passenger Compartment - Section 47
53-922-00-01	53-922-00	53-922-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 47
53-922-00-02	53-922-00	53-922-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 47
53-922-00-03	53-922-00	53-922-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 47
53-922-00-04	53-922-00	53-922-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 47
53-922-00-05	53-922-00	53-922-00		ZONAL (GV)	Area Above Passenger Compartment Ceiling - Section 47
53-924-00-01	53-924-00	53-924-00		ZONAL (GV)	Body Section 48 - BS2150 to BS 2570
53-924-00-02	53-924-00	53-924-00		ZONAL (GV)	Body Section 48 - BS2150 to BS 2570
53-926-00-01	53-926-00	53-926-00		ZONAL (GV)	Fuselage Area Aft of Bulkhead - Inspection Accomplished within Fuselage
53-928-00-01	53-928-00	53-928-00		ZONAL (GV)	APU Compartment
53-930-00-01	53-930-00	53-930-00		ZONAL (GV)	APU Compartment - As visible with APU Removed
53-932-00-01	53-932-00	53-932-00		ZONAL (GV)	Upper Fuselage - Left and Right - Section 43
53-934-00-01	53-934-00	53-934-00		ZONAL (GV)	Area Above Supernumerary Cabin - Left and Right
53-936-00-01	53-936-00	53-936-00		ZONAL (GV)	Supernumerary Cabin - Left and Right
53-937-00-01	53-937-00	53-937-00		ZONAL (GV)	Area Above Main Deck Cargo Compartment Ceiling - Left and Right Sides - BS STA 388 to Aft Pressure Bulkhead
53-938-00-01	53-938-00	53-938-00		ZONAL (GV)	Main Deck Cargo Compartment - Section 41, 43, 44, 46, 47 - Left And Right Sides - BS STA 388 To Aft Pressure Bulkhead
54-005-01-01	54-005-01	54-005-01		FUNCTIONAL	Left Strut AFT Upper Spar Drain and AFT Strut Fairing Drain (GE90-70/80/90)
54-005-01-02	54-005-01	54-005-01		FUNCTIONAL	Left Strut AFT Upper Spar Drain and AFT Strut Fairing Drain (GE90-100)
54-005-02-01	54-005-02	54-005-02		FUNCTIONAL	Right Strut AFT Upper Spar Drain and AFT Strut Fairing Drain (GE90-70/80/90)
54-005-02-02	54-005-02	54-005-02		FUNCTIONAL	Right Strut AFT Upper Spar Drain and AFT Strut Fairing Drain (GE90-100)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
54-205-01-01	54-205-01	54-205-01		FUNCTIONAL	Left Strut AFT Upper Spar Drain and AFT Strut Fairing Drain
54-205-02-01	54-205-02	54-205-02		FUNCTIONAL	Right Strut AFT Upper Spar Drain and AFT Strut Fairing Drain
54-210-01-01	54-210-01	54-210-01		FUNCTIONAL	Left Forward Engine Strut Drain.
54-210-02-01	54-210-02	54-210-02		FUNCTIONAL	Right Forward Engine Strut Drain.
54-350-01-01	54-350-01	54-350-01		FUNCTIONAL	Left Strut AFT Upper Spar Drain and AFT Strut Fairing Drain
54-350-02-01	54-350-02	54-350-02		FUNCTIONAL	Right Strut AFT Upper Spar Drain and AFT Strut Fairing Drain
54-501-01-01	54-501-01	54-501-01		GENERAL VISUAL	Powerplant - Left
54-502-01-01	54-502-01	54-502-01		DETAILED	Powerplant - Left
54-504-02-01	54-504-02	54-504-02		GENERAL VISUAL	Powerplant - Right
54-505-02-01	54-505-02	54-505-02		DETAILED	Powerplant - Right
54-507-01-01	54-507-01	54-507-01		DETAILED	Left Nacelle Strut
54-508-01-01	54-508-01	54-508-01		SPECIAL DETAILED	Left Nacelle Strut
54-509-01-01	54-509-01	54-509-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut
54-510-01-01	54-510-01	54-510-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut
54-511-01-01	54-511-01	54-511-01		GENERAL VISUAL	AFT Torque Box - Left Nacelle Strut
54-512-01-01	54-512-01	54-512-01		DETAILED	AFT Torque Box - Left Nacelle Strut
54-513-01-01	54-513-01	54-513-01		DETAILED	Strut Forward Torque Box
54-514-01-01	54-514-01	54-514-01		GENERAL VISUAL	AFT Torque Box - Left Nacelle Strut
54-515-02-01	54-515-02	54-515-02		DETAILED	Right Nacelle Strut





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
54-516-02-01	54-516-02	54-516-02		SPECIAL DETAILED	Right Nacelle Strut
54-517-02-01	54-517-02	54-517-02		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut
54-518-02-01	54-518-02	54-518-02		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut
54-519-02-01	54-519-02	54-519-02		GENERAL VISUAL	AFT Torque Box - Right Nacelle Strut
54-520-02-01	54-520-02	54-520-02		DETAILED	AFT Torque Box - Right Nacelle Strut
54-521-02-01	54-521-02	54-521-02		DETAILED	Strut Forward Torque Box
54-522-02-01	54-522-02	54-522-02		GENERAL VISUAL	AFT Torque Box - Right Nacelle Strut
54-530-01-01	54-530-01	54-530-01		GENERAL VISUAL	Powerplant - Left
54-531-01-01	54-531-01	54-531-01		DETAILED	Powerplant - Left
54-533-02-01	54-533-02	54-533-02		GENERAL VISUAL	Powerplant - Right
54-534-02-01	54-534-02	54-534-02		DETAILED	Powerplant - Right
54-536-01-01	54-536-01	54-536-01		DETAILED	Left Nacelle Strut
54-537-01-01	54-537-01	54-537-01		SPECIAL DETAILED	Left Nacelle Strut
54-538-01-01	54-538-01	54-538-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut
54-539-01-01	54-539-01	54-539-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut (For GE90-70/80/90 series engines only)
54-540-01-01	54-540-01	54-540-01		GENERAL VISUAL	AFT Torque Box - Left Nacelle Strut
54-541-01-01	54-541-01	54-541-01		DETAILED	AFT Torque Box - Left Nacelle Strut (For GE90 series engines)





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
54-541-01-02	54-541-01	54-541-01		DETAILED	AFT Torque Box - Left Nacelle Strut (For GE90-100 series engines only)
54-542-01-01	54-542-01	54-542-01		DETAILED	Strut Forward Torque Box (For GE90 series engines only)
54-542-01-02	54-542-01	54-542-01		DETAILED	Strut Forward Torque Box (For GE90-100 series engines only)
54-543-01-01	54-543-01	54-543-01		GENERAL VISUAL	AFT Torque Box - Left Nacelle Strut (GE90)
54-543-01-02	54-543-01	54-543-01		GENERAL VISUAL	AFT Torque Box - Left Nacelle Strut (GE90-100)
54-544-02-01	54-544-02	54-544-02		DETAILED	Right Nacelle Strut
54-545-02-01	54-545-02	54-545-02		SPECIAL DETAILED	Right Nacelle Strut
54-546-02-01	54-546-02	54-546-02		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut
54-547-02-01	54-547-02	54-547-02		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut (For GE90-70/80/90 series engines only)
54-548-02-01	54-548-02	54-548-02		GENERAL VISUAL	AFT Torque Box - Right Nacelle Strut
54-549-02-01	54-549-02	54-549-02		DETAILED	AFT Torque Box - Right Nacelle Strut (For GE90 series engines only)
54-549-02-02	54-549-02	54-549-02		DETAILED	AFT Torque Box - Right Nacelle Strut (For GE90-100 series engines only)
54-550-02-01	54-550-02	54-550-02		DETAILED	Strut Forward Torque Box (For GE90 series engines only)
54-550-02-02	54-550-02	54-550-02		DETAILED	Strut Forward Torque Box (For GE90-100 series engines only)
54-551-02-01	54-551-02	54-551-02		GENERAL VISUAL	AFT Torque Box - Right Nacelle Strut (GE90 Engine)
54-551-02-02	54-551-02	54-551-02		GENERAL VISUAL	AFT Torque Box - Right Nacelle Strut (GE90-100 Engine)
54-560-01-01	54-560-01	54-560-01		GENERAL VISUAL	Powerplant - Left
54-561-01-01	54-561-01	54-561-01		DETAILED	Powerplant - Left



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
54-563-02-01	54-563-02	54-563-02		GENERAL VISUAL	Powerplant - Right
54-564-02-01	54-564-02	54-564-02		DETAILED	Powerplant - Right
54-566-01-01	54-566-01	54-566-01		DETAILED	Left Nacelle Strut
54-567-01-01	54-567-01	54-567-01		SPECIAL DETAILED	Left Nacelle Strut
54-568-01-01	54-568-01	54-568-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut
54-569-01-01	54-569-01	54-569-01		GENERAL VISUAL	Forward Torque Box - Left Nacelle Strut
54-570-01-01	54-570-01	54-570-01		GENERAL VISUAL	Aft Torque Box - Left Nacelle Strut
54-571-01-01	54-571-01	54-571-01		DETAILED	Aft Torque Box - Left Nacelle Strut
54-572-01-01	54-572-01	54-572-01		DETAILED	Strut Forward - Left Torque Box
54-573-01-01	54-573-01	54-573-01		GENERAL VISUAL	Aft Torque Box - Left Nacelle Strut
54-574-02-01	54-574-02	54-574-02		DETAILED	Right Nacelle Strut
54-575-02-01	54-575-02	54-575-02		SPECIAL DETAILED	Right Nacelle Strut
54-576-02-01	54-576-02	54-576-02		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut
54-577-02-01	54-577-02	54-577-02		GENERAL VISUAL	Forward Torque Box - Right Nacelle Strut
54-578-02-01	54-578-02	54-578-02		GENERAL VISUAL	Aft Torque Box - Right Nacelle Strut
54-579-02-01	54-579-02	54-579-02		DETAILED	Aft Torque Box - Right Nacelle Strut
54-580-02-01	54-580-02	54-580-02		DETAILED	Strut Forward - Right Torque Box



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-581-02-01	54-581-02	54-581-02		GENERAL VISUAL	Aft Torque Box - Right Nacelle Strut
54-582-01-01	54-582-01	54-582-01		GENERAL VISUAL	FORWARD TORQUE BOX - LEFT NACELLE STRUT (GE90-100 Only)
54-583-02-01	54-583-02	54-583-02		GENERAL VISUAL	FORWARD TORQUE BOX - RIGHT NACELLE STRUT (GE90-100 Only)
54-701-02-01	54-701-02			SPECIAL DETAILED	Aft Upper Spar Chord Splice (PW)
54-702-02-01	54-702-02			SPECIAL DETAILED	Strut Upper Spar (PW)
54-702-03-01	54-702-03			SPECIAL DETAILED	Strut Upper Spar (PW)
54-702-04-01	54-702-04			SPECIAL DETAILED	Strut Upper Spar (PW)
54-703-02-01	54-703-02			SPECIAL DETAILED	Strut Side Skin (PW)
54-703-03-01	54-703-03			SPECIAL DETAILED	Strut Side Skin (PW)
54-703-04-01	54-703-04			SPECIAL DETAILED	Strut Side Skin (PW)
54-703-05-01	54-703-05			SPECIAL DETAILED	Strut Side Skin (PW)
54-704-02-01	54-704-02			SPECIAL DETAILED	Lower Spar Chord (PW)
54-704-03-01	54-704-03			SPECIAL DETAILED	Lower Spar Chord (PW)
54-704-04-01	54-704-04			SPECIAL DETAILED	Lower Spar Chord (PW)
54-705-01-01	54-705-01			SPECIAL DETAILED	Lower Spar (PW)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-705-03-01	54-705-03			SPECIAL DETAILED	Lower Spar (PW)
54-706-01-01	54-706-01			SPECIAL DETAILED	Lower Spar @ AEMB (PW)
54-706-03-01	54-706-03			SPECIAL DETAILED	Lower Spar @ AEMB (PW)
54-706-04-01	54-706-04			SPECIAL DETAILED	Strut Lower Spar (PW)
54-707-01-01	54-707-01			SPECIAL DETAILED	Forward Engine Mount Bulkhead (PW)
54-707-03-01	54-707-03			SPECIAL DETAILED	Forward Engine Mount Bulkhead (PW)
54-707-04-01	54-707-04			SPECIAL DETAILED	Forward Engine Mount Bulkhead (PW)
54-707-05-01	54-707-05			SPECIAL DETAILED	Strut Forward Engine Mount Bulkhead Assembly (PW)
54-708-01-01	54-708-01			SPECIAL DETAILED	Strut Aft Engine Mount Bulkhead Assembly (PW)
54-709-01-01	54-709-01			DETAILED	PW 4090 and PW 4098 Forward Engine Mount Assembly (PW)
54-710-02-01	54-710-02			SPECIAL DETAILED	Upper Spar Bay 3 (GE)
54-710-03-01	54-710-03			SPECIAL DETAILED	Upper Spar Bay 3 (GE)
54-710-04-01	54-710-04			SPECIAL DETAILED	Upper Spar Bay 3 (GE)
54-711-02-01	54-711-02			SPECIAL DETAILED	Strut Upper Spar Bay 5/6 at Cutout (GE)
54-711-03-01	54-711-03			SPECIAL DETAILED	Strut Upper Spar Bay 5/6 at Cutout (GE)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
54-711-04-01	54-711-04			SPECIAL DETAILED	Strut Upper Spar Bay 5/6 at Cutout (GE)
54-712-02-01	54-712-02			SPECIAL DETAILED	Strut Upper Spar Bay 5 at Cutout (GE)
54-712-03-01	54-712-03			SPECIAL DETAILED	Strut Upper Spar Bay 5 at Cutout (GE)
54-712-04-01	54-712-04			SPECIAL DETAILED	Strut Upper Spar Bay 5 at Cutout (GE)
54-713-02-01	54-713-02			SPECIAL DETAILED	Strut Upper Spar Bay 6 at Cutout (GE)
54-713-03-01	54-713-03			SPECIAL DETAILED	Strut Upper Spar Bay 6 at Cutout (GE)
54-713-04-01	54-713-04			SPECIAL DETAILED	Strut Upper Spar Bay 6 at Cutout (GE)
54-714-02-01	54-714-02			SPECIAL DETAILED	Upper Spar (GE)
54-714-03-01	54-714-03			SPECIAL DETAILED	Upper Spar (GE)
54-715-02-01	54-715-02			SPECIAL DETAILED	Upper Spar (GE)
54-716-01-01	54-716-01			SPECIAL DETAILED	Side Skin Cutout (GE)
54-716-02-01	54-716-02			SPECIAL DETAILED	Side Skin Cutout (GE)
54-716-03-01	54-716-03			SPECIAL DETAILED	Side Skin Cutout (GE)
54-717-02-01	54-717-02			SPECIAL DETAILED	Lower Spar Bay 3 (GE)
54-717-03-01	54-717-03			SPECIAL DETAILED	Lower Spar Bay 3 (GE)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
54-717-04-01	54-717-04			SPECIAL DETAILED	Lower Spar Bay 3 (GE)
54-718-02-01	54-718-02			SPECIAL DETAILED	Lower Outboard Spar Chord at Aft Engine Mount Bulkhead (GE)
54-719-02-01	54-719-02			SPECIAL DETAILED	Lower Spar at Cutout (GE)
54-720-01-01	54-720-01			SPECIAL DETAILED	Lower Spar (GE)
54-720-03-01	54-720-03			SPECIAL DETAILED	Lower Spar (GE)
54-721-01-01	54-721-01			SPECIAL DETAILED	Forward Engine Mount Bulkhead (GE)
54-773-01-01	54-773-01			SPECIAL DETAILED	Upper Spar Chord (RR)
54-774-01-01	54-774-01			SPECIAL DETAILED	Forward Upper Spar (RR)
54-775-01-01	54-775-01			SPECIAL DETAILED	Forward Upper Spar (RR)
54-776-01-01	54-776-01			SPECIAL DETAILED	Lower Chord (RR)
54-777-01-01	54-777-01			SPECIAL DETAILED	Aft Lower Chord at Aft Engine Mount Bulkhead (RR)
54-777-02-01	54-777-02			SPECIAL DETAILED	Aft Lower Chord at Aft Engine Mount Bulkhead (RR)
54-778-01-01	54-778-01			SPECIAL DETAILED	Forward Engine Mount Bulkhead (RR)
54-779-01-01	54-779-01			SPECIAL DETAILED	Aft Engine Mount Bulkhead (RR)
54-779-02-01	54-779-02			SPECIAL DETAILED	Aft Engine Mount Bulkhead (RR)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-779-03-01	54-779-03			SPECIAL DETAILED	Aft Engine Mount Bulkhead (RR)
54-780-01-01	54-780-01			SPECIAL DETAILED	Strut Aft Bulkhead (RR)
54-780-02-01	54-780-02			SPECIAL DETAILED	Aluminum Aft Strut Bulkhead (RR)
54-781-01-01	54-781-01			SPECIAL DETAILED	Aluminum Aft Strut Bulkhead (RR)
54-781-02-01	54-781-02			SPECIAL DETAILED	Aluminum Aft Strut Bulkhead (RR)
54-781-03-01	54-781-03			SPECIAL DETAILED	Aluminum Aft Strut Bulkhead (RR)
54-800-01-01	54-800-01	54-800-01		ZONAL (GV)	Left Nacelle Strut
54-802-01-01	54-802-01	54-802-01		ZONAL (GV)	Forward Strut Fairing - Left Nacelle Strut
54-804-01-01	54-804-01	54-804-01		ZONAL (GV)	Forward and Aft Torque Box - Left Nacelle Strut
54-806-01-01	54-806-01	54-806-01		ZONAL (GV)	Forward and Aft Torque Box - Left Nacelle Strut
54-808-01-01	54-808-01	54-808-01		ZONAL (GV)	Aft Strut Fairing - Left Nacelle Strut
54-810-02-01	54-810-02	54-810-02		ZONAL (GV)	Right Nacelle Strut
54-812-02-01	54-812-02	54-812-02		ZONAL (GV)	Forward Strut Fairing - Right Nacelle Strut
54-814-02-01	54-814-02	54-814-02		ZONAL (GV)	Forward and Aft Torque Box - Right Nacelle Strut
54-816-02-01	54-816-02	54-816-02		ZONAL (GV)	Forward and Aft Torque Box - Right Nacelle Strut
54-818-02-01	54-818-02	54-818-02		ZONAL (GV)	Aft Strut Fairing - Right Nacelle Strut
54-820-01-01	54-820-01	54-820-01		ZONAL (GV)	Left Nacelle Strut
54-822-01-01	54-822-01	54-822-01		ZONAL (GV)	Forward Strut Fairing - Left Nacelle Strut
54-824-01-01	54-824-01	54-824-01		ZONAL (GV)	Forward and Aft Torque Box - Left Nacelle Strut - Cowls Opened
54-826-01-01	54-826-01	54-826-01		ZONAL (GV)	Forward and Aft Torque Box - Left Nacelle Strut



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
54-828-01-01	54-828-01	54-828-01		ZONAL (GV)	Aft Strut Fairing - Left Nacelle Strut
54-830-02-01	54-830-02	54-830-02		ZONAL (GV)	Right Nacelle Strut
54-832-02-01	54-832-02	54-832-02		ZONAL (GV)	Forward Strut Fairing - Right Nacelle Strut
54-834-02-01	54-834-02	54-834-02		ZONAL (GV)	Forward and Aft Torque Box - Right Nacelle Strut - Fan Cowls Opened
54-836-02-01	54-836-02	54-836-02		ZONAL (GV)	Forward and Aft Torque Box - Right Nacelle Strut
54-838-02-01	54-838-02	54-838-02		ZONAL (GV)	Aft Strut Fairing - Right Nacelle Strut
54-840-01-01	54-840-01	54-840-01		ZONAL (GV)	Left Nacelle Strut
54-842-01-01	54-842-01	54-842-01		ZONAL (GV)	Forward Strut Fairing - Left Nacelle Strut
54-844-01-01	54-844-01	54-844-01		ZONAL (GV)	Forward and Aft Torque Box - Left Nacelle Strut - Cowls Opened
54-846-01-01	54-846-01	54-846-01		ZONAL (GV)	Forward and Aft Torque Box - Left Nacelle Strut
54-848-01-01	54-848-01	54-848-01		ZONAL (GV)	Aft Strut Fairing - Left Nacelle Strut
54-850-02-01	54-850-02	54-850-02		ZONAL (GV)	Right Nacelle Strut
54-852-02-01	54-852-02	54-852-02		ZONAL (GV)	Forward Strut Fairing - Right Nacelle Strut
54-854-02-01	54-854-02	54-854-02		ZONAL (GV)	Forward and Aft Torque Box - Right Nacelle Strut - Fan Cowls Opened
54-856-02-01	54-856-02	54-856-02		ZONAL (GV)	Forward and Aft Torque Box - Right Nacelle Strut
54-858-02-01	54-858-02	54-858-02		ZONAL (GV)	Aft Strut Fairing - Right Nacelle Strut
55-501-00-01	55-501-00	55-501-00		DETAILED	Horizontal Stabilizer Center Section
55-502-00-01	55-502-00	55-502-00		DETAILED	Horizontal Stabilizer Center Section
55-503-00-01	55-503-00	55-503-00		DETAILED	Area Aft of Bulkhead
55-504-00-01	55-504-00	55-504-00		DETAILED	Area Aft of Bulkhead Stabilizer Torsion Box Compartment
55-505-00-01	55-505-00	55-505-00		DETAILED	Stabilizer Torsion Box Compartment
55-507-00-01	55-507-00	55-507-00		GENERAL VISUAL	Fuselage - BS 2150-2570.3 (Section 48)
55-508-00-01	55-508-00	55-508-00		SPECIAL DETAILED	Fuselage - BS 2150-2570.3 (Section 48)





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-509-00-01	55-509-00	55-509-00	W-55-511-00-01	DETAILED	Vertical Stabilizer - Auxiliary Spar to Front Spar
55-510-00-01	55-510-00	55-510-00	W-55-514-00-01	DETAILED	Vertical Stabilizer - Auxiliary Spar to Front Spar
55-510-00-02	55-510-00	55-510-00	W-55-514-00-01	DETAILED	Vertical Stabilizer - Auxiliary Spar to Front Spar
55-511-00-01	55-511-00	55-511-00	W-55-509-00-01	DETAILED	Vertical Stabilizer - Front Spar to Rear Spar
55-512-00-01	55-512-00	55-512-00		GENERAL VISUAL	Vertical Stabilizer - Front Spar to Rear Spar
55-513-00-01	55-513-00	55-513-00		DETAILED	Vertical Stabilizer - Front Spar to Rear Spar
55-513-01-01	55-513-01	55-513-01		DETAILED	Vertical Stabilizer - Front Spar to Rear Spar
55-514-00-01	55-514-00	55-514-00	W-55-510-00-01 W-55-510-00-02	DETAILED	Vertical Stabilizer - Front Spar to Rear Spar
55-514-01-01	55-514-01	55-514-01		DETAILED	Vertical Stabilizer - Front Spar to Rear Spar
55-515-00-01	55-515-00	55-515-00	W-55-518-00-01	DETAILED	Vertical Stabilizer - Rear Spar to Trailing Edge
55-515-01-01	55-515-01	55-515-01		DETAILED	Vertical Stabilizer - Rear Spar to Trailing Edge
55-516-00-01	55-516-00	55-516-00		DETAILED	Vertical Stabilizer - Rear Spar to Trailing Edge
55-516-01-01	55-516-01	55-516-01		DETAILED	Vertical Stabilizer - Rear Spar to Trailing Edge
55-517-00-01	55-517-00	55-517-00		GENERAL VISUAL	Vertical Stabilizer - Rear Spar to Trailing Edge
55-517-01-01	55-517-01	55-517-01		GENERAL VISUAL	Vertical Stabilizer - Rear Spar to Trailing Edge
55-518-00-01	55-518-00	55-518-00	W-55-515-00-01	DETAILED	Vertical Stabilizer - Rear Spar to Trailing Edge
55-518-01-01	55-518-01	55-518-01		DETAILED	Vertical Stabilizer - Rear Spar to Trailing Edge
55-519-00-01	55-519-00	55-519-00		GENERAL VISUAL	Rudder
55-519-00-02	55-519-00	55-519-00		GENERAL VISUAL	Rudder
55-520-00-01	55-520-00	55-520-00		DETAILED	Rudder



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-520-01-01	55-520-01	55-520-01		DETAILED	Rudder
55-521-00-01	55-521-00	55-521-00		GENERAL VISUAL	Rudder Tab
55-522-00-01	55-522-00	55-522-00		DETAILED	Rudder Tab
55-522-00-02	55-522-00	55-522-00		DETAILED	Rudder Tab
55-523-00-01	55-523-00	55-523-00		DETAILED	Rudder Tab
55-524-00-01	55-524-00	55-524-00		DETAILED	Vertical Stabilizer Leading Edge
55-524-01-01	55-524-01	55-524-01		DETAILED	Vertical Stabilizer Leading Edge
55-525-00-01	55-525-00	55-525-00		DETAILED	Vertical Stabilizer - Auxiliary Spar to Front Spar
55-525-01-01	55-525-01	55-525-01		DETAILED	Vertical Stabilizer - Auxiliary Spar to Front Spar
55-526-00-01	55-526-00	55-526-00		GENERAL VISUAL	Vertical Stabilizer - Front Spar to Rear Spar
55-527-01-01	55-527-01	55-527-01	W-55-538-02-01	DETAILED	Left Horizontal Stabilizer Center Section
55-528-01-01	55-528-01	55-528-01	W-55-539-02-01	DETAILED	Left Horizontal Stabilizer Center Section
55-528-03-01	55-528-03	55-528-03	W-55-539-04-01	DETAILED	Left Horizontal Stabilizer Center Section
55-528-05-01	55-528-05	55-528-05	W-55-539-06-01	DETAILED	Left Horizontal Stabilizer Center Section
55-529-01-01	55-529-01	55-529-01		DETAILED	Left Horizontal Stabilizer Center Section
55-530-01-01	55-530-01	55-530-01		GENERAL VISUAL	Left Horizontal Stabilizer Center Section
55-531-01-01	55-531-01	55-531-01		DETAILED	Left Horizontal Stabilizer Center Section
55-532-01-01	55-532-01	55-532-01		GENERAL VISUAL	Left Horizontal Stabilizer - Front Spar to Rear Spar
55-533-01-01	55-533-01	55-533-01		DETAILED	Left Horizontal Stabilizer - Front Spar to Rear Spar
55-534-01-01	55-534-01	55-534-01		DETAILED	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-534-03-01	55-534-03	55-534-03		DETAILED	Left Horizontal Stabilizer - Rear Spar to Trailing Edge



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
55-535-01-01	55-535-01	55-535-01		DETAILED	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-535-03-01	55-535-03	55-535-03		DETAILED	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-536-01-01	55-536-01	55-536-01		DETAILED	Left Elevator
55-536-03-01	55-536-03	55-536-03		DETAILED	Left Elevator
55-537-01-01	55-537-01	55-537-01		GENERAL VISUAL	Left Horizontal Stabilizer Tip
55-538-02-01	55-538-02	55-538-02	W-55-527-01-01	DETAILED	Right Horizontal Stabilizer Center Section
55-539-02-01	55-539-02	55-539-02	W-55-528-01-01	DETAILED	Right Horizontal Stabilizer Center Section
55-539-04-01	55-539-04	55-539-04	W-55-528-03-01	DETAILED	Right Horizontal Stabilizer Center Section
55-539-06-01	55-539-06	55-539-06	W-55-528-05-01	DETAILED	Right Horizontal Stabilizer Center Section
55-540-02-01	55-540-02	55-540-02		DETAILED	Right Horizontal Stabilizer Center Section
55-541-02-01	55-541-02	55-541-02		GENERAL VISUAL	Right Horizontal Stabilizer Center Section
55-542-02-01	55-542-02	55-542-02		DETAILED	Right Horizontal Stabilizer Center Section
55-543-02-01	55-543-02	55-543-02		GENERAL VISUAL	Right Horizontal Stabilizer - Front Spar to Rear Spar
55-544-02-01	55-544-02	55-544-02		DETAILED	Right Horizontal Stabilizer - Front Spar to Rear Spar
55-545-02-01	55-545-02	55-545-02		DETAILED	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-545-04-01	55-545-04	55-545-04		DETAILED	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-546-02-01	55-546-02	55-546-02		DETAILED	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-546-04-01	55-546-04	55-546-04		DETAILED	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-547-02-01	55-547-02	55-547-02		DETAILED	Right Elevator
55-547-04-01	55-547-04	55-547-04		DETAILED	Right Elevator
55-548-02-01	55-548-02	55-548-02		GENERAL VISUAL	Right Horizontal Stabilizer Tip



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
55-549-00-01	55-549-00	55-549-00		SPECIAL DETAILED	Area Aft of Bulkhead and Stabilizer Torsion Box Compartment
55-550-00-01	55-550-00	55-550-00		DETAILED	Vertical Stabilizer - Front Spar to Rear Spar
55-550-01-01	55-550-01	55-550-01		GENERAL VISUAL	Vertical Stabilizer - Front Spar to Rear Spar
55-551-00-01	55-551-00	55-551-00		DETAILED	Left Horizontal Stabilizer Tip
55-552-00-01	55-552-00	55-552-00		DETAILED	Right Horizontal Stabilizer Tip
55-656-01-01	55-656-01	55-656-01		GENERAL VISUAL	Left Horizontal Stabilizer Leading Edge
55-660-02-01	55-660-02	55-660-02		GENERAL VISUAL	Right Horizontal Stabilizer Leading Edge
55-701-01-01	55-701-01			SPECIAL DETAILED	Upper Double Plus Chord Horizontal Stabilizer
55-702-01-01	55-702-01			SPECIAL DETAILED	Splice Fitting - Front Spar Upper Chord Horizontal Stabilizer
55-703-01-01	55-703-01			SPECIAL DETAILED	Pivot Fitting Lugs
55-704-01-01	55-704-01			SPECIAL DETAILED	Pivot Fitting Straps (Both Pairs - Upper and Lower) L/N 1-40
55-704-02-01	55-704-02			SPECIAL DETAILED	Pivot Fitting Straps (Both Pairs - Upper and Lower) L/N 1-40
55-704-03-01	55-704-03			SPECIAL DETAILED	Pivot Fitting Straps (Both Pairs - Upper and Lower) L/N 41 and on
55-704-04-01	55-704-04			SPECIAL DETAILED	Pivot Fitting Straps (Both Pairs - Upper and Lower) L/N 41 and on
55-705-01-01	55-705-01			SPECIAL DETAILED	Pivot Fitting Pins Outer Pin
55-706-01-01	55-706-01			SPECIAL DETAILED	Jackscrew Fitting Lugs DWG 182W7402



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-707-01-01	55-707-01			SPECIAL DETAILED	Elevator Actuator Fitting 183W1312 L/N 718 and on and all retrofitted airplanes.
55-800-00-01	55-800-00	55-800-00		ZONAL (GV)	Stabilizer Torsion Box Compartment - Left and Right Sides
55-804-00-01	55-804-00	55-804-00	W-55-814-00-01 W-55-822-00-01 W-55-824-00-01	ZONAL (GV)	Vertical Stabilizer Leading Edge
55-806-00-01	55-806-00	55-806-00		ZONAL (GV)	Vertical Stabilizer Leading Edge
55-808-00-01	55-808-00	55-808-00		ZONAL (GV)	Vertical Stabilizer - Auxiliary Spar to Rear Spar
55-810-00-01	55-810-00	55-810-00		ZONAL (GV)	Vertical Stabilizer - Auxiliary Spar to Front Spar
55-811-00-01	55-811-00	55-811-00		ZONAL (GV)	Vertical Stabilizer - Auxiliary Spar / Front Spar
55-812-00-01	55-812-00	55-812-00		ZONAL (GV)	Vertical Stabilizer - Front Spar to Rear Spar - Between Ribs 8 and 9
55-814-00-01	55-814-00	55-814-00	W-55-804-00-01 W-55-820-00-01 W-55-822-00-01	ZONAL (GV)	Vertical Stabilizer - Rear Spar to Trailing Edge
55-816-00-01	55-816-00	55-816-00		ZONAL (GV)	Vertical Stabilizer - Rear Spar to Trailing Edge
55-817-00-01	55-817-00	55-817-00		ZONAL (GV)	Vertical Stabilizer - Rear Spar to Trailing Edge
55-818-00-01	55-818-00	55-818-00		ZONAL (GV)	Vertical Stabilizer - Rear Spar to Trailing Edge
55-819-00-01	55-819-00	55-819-00		ZONAL (GV)	Vertical Stabilizer - Rear Spar to Trailing Edge
55-820-00-01	55-820-00	55-820-00	W-55-814-00-01 W-55-822-00-01 W-55-824-00-01	ZONAL (GV)	Rudder
55-822-00-01	55-822-00	55-822-00	W-55-804-00-01 W-55-814-00-01 W-55-820-00-01	ZONAL (GV)	Rudder Tab
55-824-00-01	55-824-00	55-824-00	W-55-804-00-01 W-55-820-00-01	ZONAL (GV)	Vertical Stabilizer Forward Tip
55-826-00-01	55-826-00	55-826-00		ZONAL (GV)	Vertical Stabilizer Forward Tip
55-828-01-01	55-828-01	55-828-01	W-55-848-02-01	ZONAL (GV)	Left Horizontal Stabilizer - Center Section



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-830-01-01	55-830-01	55-830-01	W-55-838-01-01 W-55-844-01-01 W-55-846-01-01	ZONAL (GV)	Left Horizontal Stabilizer - Leading Edge
55-832-01-01	55-832-01	55-832-01		ZONAL (GV)	Left Horizontal Stabilizer - Auxiliary Spar to Rear Spar
55-834-01-01	55-834-01	55-834-01		ZONAL (GV)	Left Horizontal Stabilizer - Auxiliary Spar to Front Spar
55-836-01-01	55-836-01	55-836-01		ZONAL (GV)	Left Horizontal Stabilizer - Front Spar to Rear Spar
55-838-01-01	55-838-01	55-838-01	W-55-830-01-01 W-55-844-01-01 W-55-846-01-01	ZONAL (GV)	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-838-03-02	55-838-03	55-838-03		ZONAL (GV)	Left Horizontal Stabilizer - Front Spar to Rear Spar
55-840-01-01	55-840-01	55-840-01		ZONAL (GV)	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-841-00-01	55-841-00	55-841-00		ZONAL (GV)	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-842-01-01	55-842-01	55-842-01		ZONAL (GV)	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-843-00-01	55-843-00	55-843-00		ZONAL (GV)	Left Horizontal Stabilizer - Rear Spar to Trailing Edge
55-844-01-01	55-844-01	55-844-01	W-55-830-01-01 W-55-838-01-01	ZONAL (GV)	Left Elevator
55-846-01-01	55-846-01	55-846-01	W-55-830-01-01 W-55-838-01-01	ZONAL (GV)	Left Horizontal Stabilizer Tip
55-848-02-01	55-848-02	55-848-02	W-55-828-01-01	ZONAL (GV)	Right Horizontal Stabilizer Center Section
55-850-02-01	55-850-02	55-850-02	W-55-858-02-01 W-55-864-02-01 W-55-866-02-01	ZONAL (GV)	Right Horizontal Stabilizer - Leading Edge
55-852-02-01	55-852-02	55-852-02		ZONAL (GV)	Right Horizontal Stabilizer - Auxiliary Spar to Rear Spar
55-854-02-01	55-854-02	55-854-02		ZONAL (GV)	Right Horizontal Stabilizer Auxiliary Spar to Front Spar
55-856-02-01	55-856-02	55-856-02		ZONAL (GV)	Right Horizontal Stabilizer - Front Spar to Rear Spar
55-856-04-01	55-856-04	55-856-04		ZONAL (GV)	Right Horizontal Stabilizer - Front Spar to Rear Spar
55-858-02-01	55-858-02	55-858-02	W-55-850-02-01 W-55-866-02-01	ZONAL (GV)	Right Horizontal Stabilizer - Rear Spar to Trailing Edge



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-860-02-01	55-860-02	55-860-02	W-55-850-02-01 W-55-850-02-01 W-55-858-02-01	ZONAL (GV)	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-861-00-01	55-861-00	55-861-00		ZONAL (GV)	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-862-02-01	55-862-02	55-862-02		ZONAL (GV)	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-863-00-01	55-863-00	55-863-00		ZONAL (GV)	Right Horizontal Stabilizer - Rear Spar to Trailing Edge
55-864-02-01	55-864-02	55-864-02		ZONAL (GV)	Right Elevator
55-866-02-01	55-866-02	55-866-02		ZONAL (GV)	Right Horizontal Stabilizer Tip
56-010-00-01	56-010-00	56-010-00		OPERATIONAL	Flight Deck #2 Windows MICROSWITCH
56-020-00-01	56-020-00	56-020-00		LUBRICATE	Flight Deck Number 2 Windows Guide Bearings
56-030-00-01	56-030-00	56-030-00		OPERATIONAL	Flight Deck Number 2 Windows Open/Close Function
57-501-00-01	57-501-00	57-501-00		DETAILED	Wing Center Section
57-502-01-01	57-502-01	57-502-01		GENERAL VISUAL	Slat Number 7
57-503-01-01	57-503-01	57-503-01		GENERAL VISUAL	Slat Number 7
57-504-01-01	57-504-01	57-504-01		GENERAL VISUAL	Slats Number 1 Through 6
57-505-01-01	57-505-01	57-505-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17
57-506-01-01	57-506-01	57-506-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17
57-507-01-01	57-507-01	57-507-01		GENERAL VISUAL	Wing Inspar Area (Fuel Tanks) - Rib 17 to Wing Tip
57-508-01-01	57-508-01	57-508-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Rib 17 to Rib 34
57-509-01-01	57-509-01	57-509-01		DETAILED	Wing Inspar Area (Fuel Tanks) - Rib 34 to Wing Tip
57-510-01-01	57-510-01	57-510-01		SPECIAL DETAILED	Main Tank - Rib 17 to Rib 32 - Left Wing
57-511-01-01	57-511-01	57-511-01		DETAILED	Main Tank - Rib 17 to Rib 32 - Left Wing



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
57-512-00-01	57-512-00	57-512-00		DETAILED	Slats Number 1 Through 6 Cove Skin
57-514-00-01	57-514-00	57-514-00		SPECIAL DETAILED	Wing Inboard and Outboard Main Flap Attach Bolts
57-515-01-01	57-515-01	57-515-01		DETAILED	Left Wing Inboard Main Flap
57-516-01-01	57-516-01	57-516-01		GENERAL VISUAL	Left Wing Inboard Main Flap
57-517-01-01	57-517-01	57-517-01		DETAILED	Left Wing Inboard Main Flap
57-518-01-01	57-518-01	57-518-01		GENERAL VISUAL	Left Wing Inboard Aft Flap
57-519-01-01	57-519-01	57-519-01		GENERAL VISUAL	Left Wing Flaperon
57-520-01-01	57-520-01	57-520-01		DETAILED	Left Wing Flaperon
57-521-00-01	57-521-00	57-521-00		DETAILED	Left Wing Inboard Trailing Edge Flap Torque Tube
57-521-00-02	57-521-00	57-521-00		DETAILED	Right Wing Inboard Trailing Edge Flap Torque Tube
57-523-01-01	57-523-01	57-523-01		GENERAL VISUAL	Left Wing Outboard Flap
57-524-01-01	57-524-01	57-524-01		DETAILED	Left Wing Outboard Flap
57-530-01-01	57-530-01	57-530-01		SPECIAL DETAILED	Flap Support Fairing Number 4
57-531-01-01	57-531-01	57-531-01		GENERAL VISUAL	Inboard Flap Center Track Fairing - Left Wing
57-532-01-01	57-532-01	57-532-01		SPECIAL DETAILED	Left Wing Flap Support Fairing Number 3
57-533-01-01	57-533-01	57-533-01		GENERAL VISUAL	Outboard Flaperon Support Fairing - Left Wing
57-535-02-01	57-535-02	57-535-02		GENERAL VISUAL	Slat Number 8





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
57-536-02-01	57-536-02	57-536-02		GENERAL VISUAL	Slat Number 8
57-538-02-01	57-538-02	57-538-02		GENERAL VISUAL	Slats Number 9 Through 14
57-539-00-01	57-539-00	57-539-00		DETAILED	Slats Number 9 Through 14 Cove Skin
57-540-02-01	57-540-02	57-540-02		DETAILED	Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17
57-541-02-01	57-541-02	57-541-02		DETAILED	Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17
57-542-02-01	57-542-02	57-542-02		GENERAL VISUAL	Wing Inspar Area (Fuel Tanks) - Rib 17 to Wing Tip
57-543-02-01	57-543-02	57-543-02		DETAILED	Wing Inspar Area (Fuel Tanks) - Rib 17 to Rib 34
57-544-02-01	57-544-02	57-544-02		DETAILED	Wing Inspar Area (Fuel Tanks) - Rib 34 to Wing Tip
57-545-02-01	57-545-02	57-545-02		SPECIAL DETAILED	Main Tank - Rib17 to Rib 32 - Right Wing
57-546-02-01	57-546-02	57-546-02		DETAILED	Main Tank - Rib 17 to Rib 32 - Right Wing
57-550-02-01	57-550-02	57-550-02		DETAILED	Right Wing Inboard Main Flap
57-551-02-01	57-551-02	57-551-02		GENERAL VISUAL	Right Wing Inboard Main Flap
57-552-02-01	57-552-02	57-552-02		DETAILED	Right Wing Inboard Main Flap
57-553-02-01	57-553-02	57-553-02		GENERAL VISUAL	Right Wing Inboard Aft Flap
57-554-02-01	57-554-02	57-554-02		GENERAL VISUAL	Right Wing Flaperon
57-555-02-01	57-555-02	57-555-02		DETAILED	Right Wing Flaperon
57-556-02-01	57-556-02	57-556-02		GENERAL VISUAL	Right Wing Outboard Flap
57-557-02-01	57-557-02	57-557-02		DETAILED	Right Wing Outboard Flap
57-560-02-01	57-560-02	57-560-02		SPECIAL DETAILED	Right Wing Flap Support Fairing Number 5



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
57-561-02-01	57-561-02	57-561-02		GENERAL VISUAL	Inboard Flap Center Track Fairing - Right Wing
57-562-02-01	57-562-02	57-562-02		SPECIAL DETAILED	Right Wing Flap Support Fairing Number 6
57-563-02-01	57-563-02	57-563-02		GENERAL VISUAL	Outboard Flaperon Support Fairing - Right Wing
57-606-00-01	57-606-00	57-606-00		GENERAL VISUAL	Left Side - Environmental Control Systems Bay and Underwing Fairings
57-606-00-02	57-606-00	57-606-00		GENERAL VISUAL	Lower Fuselage - Forward Keel Beam Area
57-606-00-03	57-606-00	57-606-00		GENERAL VISUAL	Right Side - Environmental Control Systems Bay and Underwing Fairings
57-607-01-01	57-607-01	57-607-01		GENERAL VISUAL	Left Wing
57-608-01-01	57-608-01	57-608-01		GENERAL VISUAL	Left Wing
57-620-02-01	57-620-02	57-620-02		GENERAL VISUAL	Right Wing
57-621-02-01	57-621-02	57-621-02		GENERAL VISUAL	Right Wing
57-630-00-01	57-630-00	57-630-00		GENERAL VISUAL	Area Above Wing Center Section
57-701-02-01	57-701-02			SPECIAL DETAILED	SOB Splice, Lower Surface, T-Chord
57-701-03-01	57-701-03			SPECIAL DETAILED	SOB Splice, Lower Surface, T-Chord
57-702-02-01	57-702-02			SPECIAL DETAILED	SOB Splice, Lower Surface, T-Chord
57-702-03-01	57-702-03			SPECIAL DETAILED	SOB Splice, Lower Surface, T-Chord



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-703-02-01	57-703-02			SPECIAL DETAILED	SOB Splice, Lower Surface, T-Chord
57-703-03-01	57-703-03			SPECIAL DETAILED	SOB Splice, Lower Surface, T-Chord
57-704-01-01	57-704-01			SPECIAL DETAILED	SOB Splice, Front Spar Chord
57-704-02-01	57-704-02			SPECIAL DETAILED	SOB Splice, Front Spar Chord
57-704-03-01	57-704-03			SPECIAL DETAILED	SOB Splice, Front Spar Chord
57-706-02-01	57-706-02			SPECIAL DETAILED	SOB Splice, Rear Spar Chord
57-706-03-01	57-706-03			SPECIAL DETAILED	SOB Splice, Rear Spar Chord
57-706-04-01	57-706-04			SPECIAL DETAILED	SOB Splice, Rear Spar Chord
57-708-02-01	57-708-02			SPECIAL DETAILED	Body Chord Inspection at Stringer 36 to 41
57-708-03-01	57-708-03			SPECIAL DETAILED	Body Chord Inspection at Splice Plate
57-709-02-01	57-709-02			GENERAL VISUAL	Wing Center Section, Lower Panel, Typical and Splice Stringer
57-709-03-01	57-709-03			DETAILED	Wing Center Section (WCS), Lower Panel, Typical Stringer
57-710-02-01	57-710-02			GENERAL VISUAL	Wing Center Section (WCS), Lower Panel, Splice Stringer
57-711-02-01	57-711-02			DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-03-01	57-711-03			DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-04-01	57-711-04			SPECIAL DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
57-711-05-01	57-711-05			SPECIAL DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-06-01	57-711-06			DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-07-01	57-711-07			SPECIAL DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-08-01	57-711-08			SPECIAL DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-09-01	57-711-09			DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-10-01	57-711-10			SPECIAL DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-11-01	57-711-11			SPECIAL DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-711-12-01	57-711-12			SPECIAL DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Chord
57-712-02-01	57-712-02			DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Skin
57-712-03-01	57-712-03			DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Skin
57-712-04-01	57-712-04			DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Skin
57-712-05-01	57-712-05			GENERAL VISUAL	Wing Center Section, Lower Rear Spar Chord, Lower Skin
57-712-06-01	57-712-06			SPECIAL DETAILED	Wing Center Section, Lower Rear Spar Chord, Lower Skin
57-713-02-01	57-713-02			DETAILED	Wing Center Section, Lower Panel Keel Beam Chord, Lower Skin
57-713-03-01	57-713-03			SPECIAL DETAILED	Wing Center Section, Lower Panel Keel Beam Chord, Lower Skin
57-713-04-01	57-713-04			SPECIAL DETAILED	Wing Center Section, Lower Panel Keel Beam Chord, Lower Skin
57-713-05-01	57-713-05			SPECIAL DETAILED	Wing Center Section, Lower Panel Keel Beam Chord, Lower Skin



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-714-02-01	57-714-02			SPECIAL DETAILED	Wing Center Section, Lower Panel Keel Beam Chord, Lower Chord
57-714-03-01	57-714-03			DETAILED	Wing Center Section, Lower Panel Keel Beam Chord, Lower Chord
57-716-02-01	57-716-02			SPECIAL DETAILED	Wing Outboard, Typical Rear Spar Attachment, Lower Chord
57-716-03-01	57-716-03			SPECIAL DETAILED	Wing Outboard, Typical Rear Spar Attachment, Lower Chord
57-716-04-01	57-716-04			SPECIAL DETAILED	Wing Outboard, Typical Rear Spar Attachment, Lower Chord
57-716-05-01	57-716-05			SPECIAL DETAILED	Wing Outboard, Typical Rear Spar Attachment, Lower Chord
57-719-02-01	57-719-02			SPECIAL DETAILED	Wing Outboard, Typical Splice Stringers
57-719-03-01	57-719-03			DETAILED	Wing Outboard, Typical Splice Stringers
57-719-04-01	57-719-04			DETAILED	Wing Outboard, Typical Splice Stringers
57-721-01-01	57-721-01			SPECIAL DETAILED	Wing Outboard, Typical Splice Stringer
57-721-02-01	57-721-02			SPECIAL DETAILED	Wing Outboard, Typical Splice Stringer
57-721-03-01	57-721-03			SPECIAL DETAILED	Wing Outboard, Typical Splice Stringer
57-722-01-01	57-722-01			SPECIAL DETAILED	Wing Outboard, Lower Panel Rear Spar Chord, Lower Chord
57-722-02-01	57-722-02			SPECIAL DETAILED	Wing Outboard, Lower Panel Rear Spar Chord, Lower Chord
57-722-03-01	57-722-03			SPECIAL DETAILED	Wing Outboard, Lower Panel Rear Spar Chord, Lower Chord
57-722-04-01	57-722-04			SPECIAL DETAILED	Wing Outboard, Lower Panel Rear Spar Chord, Lower Chord



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
57-722-05-01	57-722-05			SPECIAL DETAILED	Wing Outboard, Lower Panel Rear Spar Chord, Lower Chord
57-722-06-01	57-722-06			SPECIAL DETAILED	Wing Outboard, Lower Panel Rear Spar Chord, Lower Chord
57-722-07-01	57-722-07			SPECIAL DETAILED	Wing Outboard, Lower Panel Rear Spar Chord, Lower Chord
57-724-02-01	57-724-02			SPECIAL DETAILED	Wing Outboard, Lower Panel Front Spar Chord, Lower Chord
57-728-02-01	57-728-02			SPECIAL DETAILED	Wing Outboard, MLG Beam Support Fitting, Mid Rib Lower Skin
57-729-01-01	57-729-01			SPECIAL DETAILED	Wing Outboard, Typical Stringer Attachment at Nacelle Fitting
57-729-02-01	57-729-02			DETAILED	Wing Outboard, Typical Stringer Attachment at Nacelle Fitting
57-729-03-01	57-729-03			SPECIAL DETAILED	Wing Outboard, Typical Stringer Attachment at Nacelle Fitting
57-729-04-01	57-729-04			DETAILED	Wing Outboard, Typical Stringer Attachment at Nacelle Fitting
57-729-05-01	57-729-05			SPECIAL DETAILED	Wing Outboard, Typical Stringer Attachment at Nacelle Fitting
57-729-06-01	57-729-06			SPECIAL DETAILED	Wing Outboard, Typical Stringer Attachment at Nacelle Fitting
57-730-01-01	57-730-01			DETAILED	Wing Outboard, Stringer Attachment at Nacelle Fitting
57-734-01-01	57-734-01			SPECIAL DETAILED	Wing Outboard, Upper Panel, MLG Beam Support Fitting Upper Skin
57-735-01-01	57-735-01			DETAILED	Wing Outboard, Upper Panel, Front Spar Upper Chord
57-735-03-01	57-735-03			DETAILED	Wing Outboard, Upper Panel, Front Spar Upper Chord
57-735-04-01	57-735-04			DETAILED	Wing Outboard, Upper Panel, Front Spar Upper Chord
57-737-01-01	57-737-01			SPECIAL DETAILED	Wing Outboard Upper Panel, Rear Spar Upper Chord



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-737-03-01	57-737-03			SPECIAL DETAILED	Wing Outboard Upper Panel, Rear Spar Upper Chord
57-737-04-01	57-737-04			SPECIAL DETAILED	Wing Outboard Upper Panel, Rear Spar Upper Chord
57-737-05-01	57-737-05			SPECIAL DETAILED	Wing Outboard Upper Panel, Rear Spar Upper Chord
57-737-06-01	57-737-06			SPECIAL DETAILED	Wing Outboard Upper Panel, Rear Spar Upper Chord
57-739-01-01	57-739-01			DETAILED	Wing Outboard, Upper Panel, Rear Spar Upper Chord
57-739-03-01	57-739-03			DETAILED	Wing Outboard, Upper Panel, Rear Spar Upper Chord
57-739-04-01	57-739-04			DETAILED	Wing Outboard, Upper Panel, Rear Spar Upper Chord
57-740-01-01	57-740-01			DETAILED	Wing Outboard, Upper Skin Tab
57-743-01-01	57-743-01			SPECIAL DETAILED	Wing Outboard, Rear Spar Web at Forward Trunnion Fitting
57-743-03-01	57-743-03			SPECIAL DETAILED	Wing Outboard, Rear Spar Web at Forward Trunnion Fitting
57-751-01-01	57-751-01			SPECIAL DETAILED	Inboard Main Flap Outboard Closeout Rib
57-752-01-01	57-752-01			SPECIAL DETAILED	Inboard Main Flap Outboard Ribs
57-753-01-01	57-753-01			SPECIAL DETAILED	Inboard Main Flap Torque Tube
57-754-01-01	57-754-01			SPECIAL DETAILED	Inboard Main Flap Inboard Closeout Rib
57-755-01-01	57-755-01			SPECIAL DETAILED	Inboard Main Flap Inboard Closeout Rib
57-755-03-01	57-755-03			SPECIAL DETAILED	Inboard Main Flap Inboard Closeout Rib
57-755-04-01	57-755-04			DETAILED	Inboard Main Flap Inboard Closeout Rib



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-756-01-01	57-756-01			SPECIAL DETAILED	Inboard Main Flap Inboard Closeout Rib Fitting
57-757-01-01	57-757-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Underwing Fitting
57-758-01-01	57-758-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Underwing Fitting
57-759-01-01	57-759-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Underwing Fitting
57-760-01-01	57-760-01			DETAILED	No. 3 and No. 6 Inboard Flap Support Forward Tension Link
57-760-03-01	57-760-03			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Forward Tension Link
57-761-01-01	57-761-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Forward Tension Link
57-761-03-01	57-761-03			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Forward Tension Link
57-761-04-01	57-761-04			DETAILED	No. 3 and No. 6 Inboard Flap Support Forward Tension Link
57-762-01-01	57-762-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Forward Tension Link
57-763-01-01	57-763-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Aft Tension Beam
57-764-01-01	57-764-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Aft Tension Beam
57-764-03-01	57-764-03			DETAILED	No. 3 and No. 6 Inboard Flap Support Aft Tension Beam
57-765-01-01	57-765-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Aft Tension Beam
57-765-03-01	57-765-03			GENERAL VISUAL	No. 3 and No. 6 Inboard Flap Support Aft Tension Beam
57-765-04-01	57-765-04			DETAILED	No. 3 and No. 6 Inboard Flap Support Aft Tension Beam





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-766-01-01	57-766-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Pivot Link
57-767-01-01	57-767-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Pivot Link
57-768-01-01	57-768-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Drive Arm Assembly
57-768-03-01	57-768-03			GENERAL VISUAL	No. 3 and No. 6 Inboard Flap Support Drive Arm Assembly
57-769-01-01	57-769-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-769-03-01	57-769-03			DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-771-01-01	57-771-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-771-03-01	57-771-03			DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-772-01-01	57-772-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-773-01-01	57-773-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-774-01-01	57-774-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-775-01-01	57-775-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-776-01-01	57-776-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-777-01-01	57-777-01			SPECIAL DETAILED	No. 3 and No. 6 Inboard Flap Support Carrier Beam
57-778-01-01	57-778-01			SPECIAL DETAILED	No. 4 and No. 5 Inboard Flap Support Drive Arm
57-779-01-01	57-779-01			SPECIAL DETAILED	No. 4 and No. 5 Inboard Flap Support Drive Arm



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
57-780-01-01	57-780-01			SPECIAL DETAILED	No. 4 and No. 5 Inboard Flap Actuator Support Fitting
57-781-01-01	57-781-01			SPECIAL DETAILED	No. 4 and No. 5 Inboard Flap Actuator Support Fitting
57-782-01-01	57-782-01			SPECIAL DETAILED	No. 4 and No. 5 Inboard Flap Support Carrier Beam
57-783-01-01	57-783-01			SPECIAL DETAILED	No. 4 and No. 5 Inboard Flap Support Pillow Block
57-784-01-01	57-784-01			SPECIAL DETAILED	No. 4 and No. 5 Inboard Flap Support Pillow Block
57-785-01-01	57-785-01			SPECIAL DETAILED	No. 1, No. 2, No. 7 and No. 8 Outboard Flap Supports
57-786-01-01	57-786-01			SPECIAL DETAILED	MLG Forward Trunnion Sideload Fitting
57-787-01-01	57-787-01			DETAILED	MLG Forward Trunnion Sideload Straps
57-788-01-01	57-788-01			DETAILED	MLG Forward Trunnion Outboard Support Fitting
57-788-02-01	57-788-02			DETAILED	MLG Forward Trunnion Outboard Support Fitting
57-788-03-01	57-788-03			DETAILED	MLG Forward Trunnion Outboard Support Fitting
57-788-04-01	57-788-04			SPECIAL DETAILED	MLG Forward Trunnion Outboard Support Fitting
57-788-05-01	57-788-05			SPECIAL DETAILED	MLG Forward Trunnion Outboard Support Fitting
57-790-01-01	57-790-01			DETAILED	MLG Beam Outboard Support Fitting, Lower Skin Flange
57-790-02-01	57-790-02			GENERAL VISUAL	MLG Beam Outboard Support Fitting, Lower Skin Flange
57-790-03-01	57-790-03			SPECIAL DETAILED	MLG Beam Outboard Support Fitting, Lower Skin Flange
57-793-01-01	57-793-01			SPECIAL DETAILED	MLG Drag Brace Support Fitting



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-793-02-01	57-793-02			SPECIAL DETAILED	MLG Drag Brace Support Fitting
57-794-01-01	57-794-01			SPECIAL DETAILED	MLG Drag Brace Support Fitting, Base of Fitting
57-795-01-01	57-795-01			DETAILED	MLG Drag Brace Internal Backup Fitting
57-796-01-01	57-796-01			DETAILED	Retraction Actuator Support Fitting Attach Flange
57-800-00-01	57-800-00	57-800-00		ZONAL (GV)	Wing Center Section
57-802-00-01	57-802-00	57-802-00		ZONAL (GV)	Wing Center Section
57-804-01-01	57-804-01	57-804-01		ZONAL (GV)	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing
57-806-01-01	57-806-01	57-806-01		ZONAL (GV)	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing
57-808-01-01	57-808-01	57-808-01		ZONAL (GV)	Slat No. 7
57-810-01-01	57-810-01	57-810-01		ZONAL (GV)	Krueger Seal Flap/Nacelle Gap Cover Area - Left Wing
57-812-01-01	57-812-01	57-812-01		ZONAL (GV)	Krueger Seal Flap/Nacelle Gap Cover Area - Left Wing
57-814-01-01	57-814-01	57-814-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
57-816-01-01	57-816-01	57-816-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
57-817-01-01	57-817-01	57-817-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
57-818-01-01	57-818-01	57-818-01		ZONAL (GV)	Left Wing Outboard Leading Edge Slats Number 1 through 6
57-820-01-01	57-820-01	57-820-01		ZONAL (GV)	Slat Number 6
57-822-01-01	57-822-01	57-822-01		ZONAL (GV)	Slat Number 5
57-824-01-01	57-824-01	57-824-01		ZONAL (GV)	Slat Number 4
57-826-01-01	57-826-01	57-826-01		ZONAL (GV)	Slat Number 3
57-828-01-01	57-828-01	57-828-01		ZONAL (GV)	Slat Number 2
57-830-01-01	57-830-01	57-830-01		ZONAL (GV)	Slat Number 1
57-831-01-01	57-831-01	57-831-01		ZONAL (GV)	Slat Number 1
57-832-01-01	57-832-01	57-832-01		ZONAL (GV)	Lower Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17 - Left Wing



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-832-01-02	57-832-01	57-832-01		ZONAL (GV)	Upper Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17 - Left Wing
57-834-01-01	57-834-01	57-834-01		ZONAL (GV)	Center Fuel Tank - Rib 1 to Rib 8 - Left Wing
57-836-01-01	57-836-01	57-836-01		ZONAL (GV)	Left Wing Dry Bay
57-838-01-01	57-838-01	57-838-01		ZONAL (GV)	Main Tank - Rib 8 to Rib 17 - Left Wing
57-840-01-01	57-840-01	57-840-01		ZONAL (GV)	Wing Inspar Area - Rib 17 to Wing Tip - Left Wing Lower Surface
57-840-01-02	57-840-01	57-840-01		ZONAL (GV)	Wing Inspar Area - Rib 17 to Wing Tip - Left Wing Upper Surface
57-842-01-01	57-842-01	57-842-01		ZONAL (GV)	Main Tank - Rib 17 to Rib 32 - Left Wing
57-844-01-01	57-844-01	57-844-01		ZONAL (GV)	Left Wing Surge Tank - Rib 32 to Rib 34
57-845-01-01	57-845-01	57-845-01		ZONAL (GV)	Main Tank Rib 32 to Rib 34 - Left Wing
57-846-01-01	57-846-01	57-846-01		ZONAL (GV)	Inspar Area - Rib 34 to Wing Tip - Left Wing
57-847-01-01	57-847-01	57-847-01		ZONAL (GV)	Main Tank, Surge Tank, and Inspar Area - Left Wing
57-848-01-01	57-848-01	57-848-01		ZONAL (GV)	Left Wing Tip
57-850-01-01	57-850-01	57-850-01		ZONAL (GV)	Left Wing Tip
57-851-01-01	57-851-01	57-851-01		ZONAL (GV)	Left Wing Tip
57-852-01-01	57-852-01	57-852-01		ZONAL (GV)	Left Wing Fixed T.E. - Aft of Rear Spar, Inbd of Outbd Support Fairing
57-854-01-01	57-854-01	57-854-01		ZONAL (GV)	Rear Spar to Landing Gear Support Beam - Left Wing
57-856-01-01	57-856-01	57-856-01		ZONAL (GV)	Landing Gear Support Beam and Rear Spar to Trailing Edge - Left Wing
57-858-01-01	57-858-01	57-858-01		ZONAL (GV)	Inboard Spoilers Numbers 6 and 7
57-860-01-01	57-860-01	57-860-01		ZONAL (GV)	Inboard Trailing Edge Flaps - Left Wing
57-862-01-01	57-862-01	57-862-01		ZONAL (GV)	Left Wing Flaperon
57-864-01-01	57-864-01	57-864-01		ZONAL (GV)	Rear Spar to Trailing Edge - Outboard of Flaperon - Left Wing
57-866-01-01	57-866-01	57-866-01		ZONAL (GV)	Rear Spar to Trailing Edge - Outboard of Flaperon - Left Wing
57-868-01-01	57-868-01	57-868-01		ZONAL (GV)	Outboard Spoilers Numbers 1 through 5
57-870-01-01	57-870-01	57-870-01		ZONAL (GV)	Left Wing Outboard Flap



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
57-872-01-01	57-872-01	57-872-01		ZONAL (GV)	Left Wing Aileron
57-874-01-01	57-874-01	57-874-01		ZONAL (GV)	Flap Support Fairing No. 4
57-876-01-01	57-876-01	57-876-01		ZONAL (GV)	Flap Support Fairing No. 4
57-878-01-01	57-878-01	57-878-01		ZONAL (GV)	Inboard Flap Center Track Fairing - Left Wing
57-880-01-01	57-880-01	57-880-01		ZONAL (GV)	Flap Support Fairing No. 3 and Inboard Flaperon Support Fairing
57-882-01-01	57-882-01	57-882-01		ZONAL (GV)	Flap Support Fairing No. 3 and Inboard Flaperon Support Fairing
57-884-01-01	57-884-01	57-884-01		ZONAL (GV)	Outboard Flaperon Support Fairing - Left Wing
57-886-01-01	57-886-01	57-886-01		ZONAL (GV)	Flap Support Fairing No. 2
57-888-01-01	57-888-01	57-888-01		ZONAL (GV)	Flap Support Fairing No. 2
57-890-01-01	57-890-01	57-890-01		ZONAL (GV)	Flap Support Fairing No. 1
57-892-01-01	57-892-01	57-892-01		ZONAL (GV)	Flap Support Fairing No. 1
57-894-01-01	57-894-01	57-894-01		ZONAL (GV)	Outboard Auxiliary Support Fairing - Left Wing
57-896-02-01	57-896-02	57-896-02		ZONAL (GV)	Leading Edge to Front Spar - Inboard of Nacelle Strut - Right Wing
57-898-02-01	57-898-02	57-898-02		ZONAL (GV)	Leading Edge to Front Spar - Inboard of Nacelle Strut - Right Wing
57-900-02-01	57-900-02	57-900-02		ZONAL (GV)	Slat No. 8
57-902-02-01	57-902-02	57-902-02		ZONAL (GV)	Krueger Seal Flap/Nacelle Gap Cover Area - Right Wing
57-904-02-01	57-904-02	57-904-02		ZONAL (GV)	Krueger Seal Flap/Nacelle Gap Cover Area - Right Wing
57-906-02-01	57-906-02	57-906-02		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Right Wing
57-908-02-01	57-908-02	57-908-02		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Right Wing
57-909-02-01	57-909-02	57-909-02		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Right Wing
57-910-02-01	57-910-02	57-910-02		ZONAL (GV)	Outboard Leading Edge Slats Number 9 through 14
57-912-02-01	57-912-02	57-912-02		ZONAL (GV)	Slat Number 9
57-914-02-01	57-914-02	57-914-02		ZONAL (GV)	Slat Number 10
57-916-02-01	57-916-02	57-916-02		ZONAL (GV)	Slat Number 11



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-918-02-01	57-918-02	57-918-02		ZONAL (GV)	Slat Number 12
57-920-02-01	57-920-02	57-920-02		ZONAL (GV)	Slat Number 13
57-922-02-01	57-922-02	57-922-02		ZONAL (GV)	Slat Number 14
57-923-02-01	57-923-02	57-923-02		ZONAL (GV)	Slat Number 14
57-924-02-01	57-924-02	57-924-02		ZONAL (GV)	Lower Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17 - Right Wing
57-924-02-02	57-924-02	57-924-02		ZONAL (GV)	Upper Wing Inspar Area (Fuel Tanks) - Inboard of Wing Rib 17 - Right Wing
57-926-02-01	57-926-02	57-926-02		ZONAL (GV)	Center Fuel Tank - Rib 1 to Rib 8 - Right Wing
57-928-02-01	57-928-02	57-928-02		ZONAL (GV)	Right Wing Dry Bay
57-930-02-01	57-930-02	57-930-02		ZONAL (GV)	Main Tank - Rib 8 to Rib 17 - Right Wing
57-932-02-01	57-932-02	57-932-02		ZONAL (GV)	Wing Inspar Area (Fuel Tanks) - Rib 17 to Wing Tip - Right Wing Lower Surface
57-932-02-02	57-932-02	57-932-02		ZONAL (GV)	Wing Inspar Area (Fuel Tanks) - Rib 17 to Wing Tip - Right Wing Upper Surface
57-934-02-01	57-934-02	57-934-02		ZONAL (GV)	Main Tank - Rib 17 to Rib 32 - Right Wing
57-936-02-01	57-936-02	57-936-02		ZONAL (GV)	Right Wing Surge Tank - Rib 32 to Rib 34
57-937-02-01	57-937-02	57-937-02		ZONAL (GV)	Main Tank - Rib 32 to Rib 34 - Right Wing
57-938-02-01	57-938-02	57-938-02		ZONAL (GV)	Inspar Area - Rib 34 to Wing Tip - Right Wing
57-939-02-01	57-939-02	57-939-02		ZONAL (GV)	Main Tank, Surge Tank, and Inspar Area - Right Wing
57-940-02-01	57-940-02	57-940-02		ZONAL (GV)	Right Wing Tip
57-942-02-01	57-942-02	57-942-02		ZONAL (GV)	Right Wing Tip
57-943-02-01	57-943-02	57-943-02		ZONAL (GV)	Right Wing Tip
57-944-02-01	57-944-02	57-944-02		ZONAL (GV)	Right Wing Fixed T.E. - Aft of Rear Spar, Inbd of Outbd Support Fairing
57-946-02-01	57-946-02	57-946-02		ZONAL (GV)	Rear Spar to Landing Gear Support Beam - Right Wing
57-948-02-01	57-948-02	57-948-02		ZONAL (GV)	Landing Gear Support Beam and Rear Spar to Trailing Edge - Right Wing
57-950-02-01	57-950-02	57-950-02		ZONAL (GV)	Inboard Spoilers Numbers 8 and 9
57-952-02-01	57-952-02	57-952-02		ZONAL (GV)	Inboard Trailing Edge Flaps - Right Wing



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
57-954-02-01	57-954-02	57-954-02		ZONAL (GV)	Right Wing Flaperon
57-956-02-01	57-956-02	57-956-02		ZONAL (GV)	Rear Spar to Trailing Edge - Outboard of Flaperon - Right Wing
57-958-02-01	57-958-02	57-958-02		ZONAL (GV)	Rear Spar to Trailing Edge - Outboard of Flaperon - Right Wing
57-960-02-01	57-960-02	57-960-02		ZONAL (GV)	Outboard Spoilers Numbers 10 through 14
57-962-02-01	57-962-02	57-962-02		ZONAL (GV)	Right Wing Outboard Flap
57-964-02-01	57-964-02	57-964-02		ZONAL (GV)	Right Wing Aileron
57-966-02-01	57-966-02	57-966-02		ZONAL (GV)	Flap Support Fairing No. 5
57-968-02-01	57-968-02	57-968-02		ZONAL (GV)	Flap Support Fairing No. 5
57-970-02-01	57-970-02	57-970-02		ZONAL (GV)	Inboard Flap Center Track Fairing - Right Wing
57-972-02-01	57-972-02	57-972-02		ZONAL (GV)	Flap Support Fairing No. 6 and Inbd Flaperon Support Fairing
57-974-02-01	57-974-02	57-974-02		ZONAL (GV)	Flap Support Fairing No. 6 and Inbd Flaperon Support Fairing
57-976-02-01	57-976-02	57-976-02		ZONAL (GV)	Outboard Flaperon Support Fairing - Right Wing
57-978-02-01	57-978-02	57-978-02		ZONAL (GV)	Flap Support Fairing No. 7
57-980-02-01	57-980-02	57-980-02		ZONAL (GV)	Flap Support Fairing No. 7
57-982-02-01	57-982-02	57-982-02		ZONAL (GV)	Flap Support Fairing No. 8
57-984-02-01	57-984-02	57-984-02		ZONAL (GV)	Flap Support Fairing No. 8
57-986-02-01	57-986-02	57-986-02		ZONAL (GV)	Outboard Auxiliary Support Fairing - Right Wing
71-205-01-01	71-205-01	71-205-01		INSPECTION - DETAILED	Inspection of the Forward Mount
71-205-02-01	71-205-02	71-205-02		INSPECTION - DETAILED	Inspection of the Forward Mount
71-210-01-01	71-210-01	71-210-01		INSPECTION - DETAILED	Inspection of the Aft Lower Mount
71-210-02-01	71-210-02	71-210-02		INSPECTION - DETAILED	Inspection of the Aft Lower Mount



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
71-350-01-01	71-350-01	71-350-01		INSPECTION - DETAILED	Inspection of the Forward Mount
71-350-02-01	71-350-02	71-350-02		INSPECTION - DETAILED	Inspection of the Forward Mount
71-355-01-01	71-355-01	71-355-01		INSPECTION - DETAILED	Inspection of the AFT Engine Mount
71-355-02-01	71-355-02	71-355-02		INSPECTION - DETAILED	Inspection of the AFT Engine Mount
71-800-01-01	71-800-01	71-800-01		ZONAL (GV)	Left Powerplant
71-802-01-01	71-802-01	71-802-01		ZONAL (GV)	Left Engine
71-804-01-01	71-804-01	71-804-01		ZONAL (GV)	Inlet Cowl - Left Engine
71-806-01-01	71-806-01	71-806-01		ZONAL (GV)	Left Engine Fan Cowls
71-808-01-01	71-808-01	71-808-01		ZONAL (GV)	Left Engine Thrust Reversers
71-810-01-01	71-810-01	71-810-01		ZONAL (GV)	Left Engine Thrust Reversers
71-812-02-01	71-812-02	71-812-02		ZONAL (GV)	Right Powerplant
71-814-02-01	71-814-02	71-814-02		ZONAL (GV)	Right Engine
71-816-02-01	71-816-02	71-816-02		ZONAL (GV)	Inlet Cowl - Right Engine
71-818-02-01	71-818-02	71-818-02		ZONAL (GV)	Right Engine Fan Cowls
71-820-02-01	71-820-02	71-820-02		ZONAL (GV)	Right Engine Thrust Reversers
71-822-02-01	71-822-02	71-822-02		ZONAL (GV)	Right Engine Thrust Reversers
71-830-01-01	71-830-01	71-830-01		ZONAL (GV)	Left Powerplant - From the Ground
71-832-01-01	71-832-01	71-832-01		ZONAL (GV)	Left Powerplant
71-834-01-01	71-834-01	71-834-01		ZONAL (GV)	Left Engine
71-836-01-01	71-836-01	71-836-01		ZONAL (GV)	Inlet Cowl - Left Engine
71-838-01-01	71-838-01	71-838-01		ZONAL (GV)	Left Engine Fan Cowls





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
71-840-01-01	71-840-01	71-840-01		ZONAL (GV)	Left Engine Thrust Reversers
71-842-01-01	71-842-01	71-842-01		ZONAL (GV)	Left Engine Thrust Reversers
71-844-02-01	71-844-02	71-844-02		ZONAL (GV)	Right Powerplant - From the Ground
71-846-02-01	71-846-02	71-846-02		ZONAL (GV)	Right Powerplant
71-848-02-01	71-848-02	71-848-02		ZONAL (GV)	Right Engine
71-850-02-01	71-850-02	71-850-02		ZONAL (GV)	Inlet Cowl - Right Engine
71-852-02-01	71-852-02	71-852-02		ZONAL (GV)	Right Engine Fan Cowl
71-854-02-01	71-854-02	71-854-02		ZONAL (GV)	Right Engine Thrust Reversers
71-856-02-01	71-856-02	71-856-02		ZONAL (GV)	Right Engine Thrust Reversers
71-860-01-01	71-860-01	71-860-01		ZONAL (GV)	Left Powerplant - From the Ground
71-862-01-01	71-862-01	71-862-01		ZONAL (GV)	Left Powerplant
71-864-01-01	71-864-01	71-864-01		ZONAL (GV)	Left Engine
71-866-01-01	71-866-01	71-866-01		ZONAL (GV)	Inlet Cowl - Left Engine
71-868-01-01	71-868-01	71-868-01		ZONAL (GV)	Left Engine Fan Cowl
71-870-01-01	71-870-01	71-870-01		ZONAL (GV)	Left Engine Thrust Reversers
71-872-01-01	71-872-01	71-872-01		ZONAL (GV)	Left Engine Thrust Reversers
71-874-02-01	71-874-02	71-874-02		ZONAL (GV)	Right Powerplant - From the Ground
71-876-02-01	71-876-02	71-876-02		ZONAL (GV)	Right Powerplant
71-878-02-01	71-878-02	71-878-02		ZONAL (GV)	Right Engine
71-880-02-01	71-880-02	71-880-02		ZONAL (GV)	Inlet Cowl - Right Engine
71-882-02-01	71-882-02	71-882-02		ZONAL (GV)	Right Engine Fan Cowl
71-884-02-01	71-884-02	71-884-02		ZONAL (GV)	Right Engine Thrust Reversers
71-886-02-01	71-886-02	71-886-02		ZONAL (GV)	Right Engine Thrust Reversers
72-001-00-01	72-001-00	72-001-00		CLEAN	Engine Gas Path



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-001-00-02	72-001-00	72-001-00		CLEAN	Engine Gas Path
72-005-01-01	72-005-01	72-005-01		INSPECTION - DETAILED	Fan Blade Inspection - Left (for GE90-70/80/90 series engines only)
72-005-01-03	72-005-01	72-005-01		INSPECTION - DETAILED	Fan Blade Inspection - Left (for GE90-100 series engines only)
72-005-02-02	72-005-02	72-005-02		INSPECTION - DETAILED	Fan Blade Inspection - Right (for GE90-70/80/90 series engines only)
72-005-02-04	72-005-02	72-005-02		INSPECTION - DETAILED	Fan Blade Inspection - Right (for GE90-100 series engines only)
72-010-00-01	72-010-00	72-010-00		REPLACE	Discard Fan Disk and Booster Spool (for GE90-70/80/90 series engines only)
72-010-00-02	72-010-00	72-010-00		REPLACE	Discard Fan Disk and Booster Spool (for GE90-100 series engines only)
72-015-00-01	72-015-00	72-015-00		REPLACE	Discard Fan Shaft (for GE90-70/80/90 series engines only)
72-015-00-02	72-015-00	72-015-00		REPLACE	Discard Fan Shaft (for GE90-100 series engines only)
72-020-01-01	72-020-01	72-020-01		INSPECTION - DETAILED	Check for Bearing and Gear Degradation - Left
72-020-01-02	72-020-01	72-020-01		INSPECTION - DETAILED	Check for Bearing and Gear Degradation - Left
72-020-02-01	72-020-02	72-020-02		INSPECTION - DETAILED	Check for Bearing and Gear Degradation - Right
72-020-02-02	72-020-02	72-020-02		INSPECTION - DETAILED	Check for Bearing and Gear Degradation - Right
72-021-01-01	72-021-01	72-021-01		INSPECTION - DETAILED	Check for Bearing and Gear Degradation - Left
72-021-02-01	72-021-02	72-021-02		INSPECTION - DETAILED	Check for Bearing and Gear Degradation - Right
72-025-01-01	72-025-01	72-025-01		INSPECTION - DETAILED	Inspection of the forward Mount - Left (GE90-70/80/90 series engines only)
72-025-01-03	72-025-01	72-025-01		INSPECTION - DETAILED	Inspection of the forward Mount - Left (GE90-100 series engines only)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-025-02-02	72-025-02	72-025-02		INSPECTION - DETAILED	Inspection of the forward Mount - Right (for GE90-70/80/90 series engines only)
72-025-02-04	72-025-02	72-025-02		INSPECTION - DETAILED	Inspection of the forward Mount - Right (for GE90-100 series engines only)
72-030-01-01	72-030-01	72-030-01		INSPECTION - GEN VISUAL	General Visual Inspection of the Fan Area- Left (for GE90-70/80/90 series engines only)
72-030-01-03	72-030-01	72-030-01		INSPECTION - GEN VISUAL	General Visual Inspection of the Fan Area- Left (for GE90-100 series engines only)
72-030-02-02	72-030-02	72-030-02		INSPECTION - GEN VISUAL	General Visual Inspection of the Fan Area - Right (for GE90-70/80/90 series engines only)
72-030-02-04	72-030-02	72-030-02		INSPECTION - GEN VISUAL	General Visual Inspection of the Fan Area - Right (for GE90-100 series engines only)
72-035-00-01	72-035-00	72-035-00		REPLACE	Discard HPC Stage 1 Disk/Shaft (for GE90-70/80/90 series engines only)
72-035-00-02	72-035-00	72-035-00		REPLACE	Discard HPC Stage 1 Disk/Shaft (for GE90-100 series engines only)
72-040-00-01	72-040-00	72-040-00		REPLACE	Discard HPC Stage 2 thru 6 Spool (for GE90-70/80/90 series engines only)
72-040-00-02	72-040-00	72-040-00		REPLACE	Discard HPC Stage 2 thru 5 Spool (for GE90-100 series engines only)
72-045-00-01	72-045-00	72-045-00		REPLACE	Discard HPC Stage 7 Disk (for GE90-70/80/90 series engines only)
72-045-00-02	72-045-00	72-045-00		REPLACE	Discard HPC Stage 6 Disk (for GE90-100 series engines only)
72-050-00-01	72-050-00	72-050-00		REPLACE	Discard HPC Stage 8 thru 10 Spool (for GE90-70/80/90 series engines only)
72-050-00-02	72-050-00	72-050-00		REPLACE	Discard HPC Stage 7 thru 9 Spool (for GE90-100 series engines only)
72-055-00-01	72-055-00	72-055-00		REPLACE	Discard CDP Seal (for GE90-70/80/90 series engines only)
72-055-00-02	72-055-00	72-055-00		REPLACE	Discard CDP Seal (for GE90-100 series engines only)
72-060-01-01	72-060-01	72-060-01		SPECIAL DETAILED	Borescope Inspection of the Combustor - Left (for GE90-70/80/90 series engines only)
72-060-01-03	72-060-01	72-060-01		SPECIAL DETAILED	Borescope Inspection of the Combustor - Left (for GE90-100 series engines only)



## 777-200/300 MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-060-02-02	72-060-02	72-060-02		SPECIAL DETAILED	Borescope Inspection of the Combustor - Right (for GE90-70/80/90 series engines only)
72-060-02-04	72-060-02	72-060-02		SPECIAL DETAILED	Borescope Inspection of the Combustor - Right (for GE90-100 series engines only)
72-065-01-01	72-065-01	72-065-01		SPECIAL DETAILED	Borescope Inspection of the 1 St. & 2 ND. Stage Turbine Blades - Left (for GE90-70/80/90 series engines only)
72-065-01-03	72-065-01	72-065-01		SPECIAL DETAILED	Borescope Inspection of the 1 St. & 2 ND. Stage Turbine Blades - Left (for GE90-100 series engines only)
72-065-02-02	72-065-02	72-065-02		SPECIAL DETAILED	Borescope Inspection of the 1 St. & 2 ND. Stage Turbine Blades - Right (for GE90-70/80/90 series engines only)
72-065-02-04	72-065-02	72-065-02		SPECIAL DETAILED	Borescope Inspection of the 1 St. & 2 ND. Stage Turbine Blades - Right (for GE90-100 series engines only)
72-070-00-01	72-070-00	72-070-00		REPLACE	Discard HPT Stage 1 and 2 Disks and Seals (for GE90-70/80/90 series engines only)
72-070-00-02	72-070-00	72-070-00		REPLACE	Discard HPT Stage 1 and 2 Disks and Seals (for GE90-100 series engines only)
72-075-00-01	72-075-00	72-075-00		REPLACE	Discard LPT Shaft, LPT Cone Shaft and LPT Stage 1 thru 6 Disks (for GE90-70/80/90 series engines only)
72-075-00-02	72-075-00	72-075-00		REPLACE	Discard LPT Shaft, LPT Cone Shaft and LPT Stage 1 thru 6 Disks (for GE90-100 series engines only)
72-080-01-01	72-080-01	72-080-01		INSPECTION - DETAILED	Detailed Inspection of TRF AFT Engine Mount Lugs- Left (for GE90-70/80/90 series engines only)
72-080-02-02	72-080-02	72-080-02		INSPECTION - DETAILED	Detailed Inspection of TRF AFT Engine Mount Lugs - Right (for GE90-70/80/90 series engines only)
72-083-01-01	72-083-01	72-083-01		INSPECTION - DETAILED	Detailed Inspection of TRF AFT Engine Mount Lugs- Left (for GE90-100 series engines only)
72-083-02-01	72-083-02	72-083-02		INSPECTION - DETAILED	Detailed Inspection of TRF AFT Engine Mount Lugs - Right (for GE90-100 series engines only)
72-090-01-01	72-090-01	72-090-01		INSPECTION - DETAILED	Detailed Inspection ACC GB. and Fittings - Left (for GE90-70/80/90 series engines only)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-090-01-03	72-090-01	72-090-01		INSPECTION - DETAILED	Detailed Inspection ACC GB. and Fittings - Left (for GE90-100 series engines only)
72-090-02-02	72-090-02	72-090-02		INSPECTION - DETAILED	Detailed Inspection ACC GB. and Fittings - Right (for GE90-70/80/90 series engines only)
72-090-02-04	72-090-02	72-090-02		INSPECTION - DETAILED	Detailed Inspection ACC GB. and Fittings - Right (for GE90-100 series engines only)
72-206-01-01	72-206-01	72-206-01		INSPECTION - DETAILED	Turbine Section - Left
72-206-02-01	72-206-02	72-206-02		INSPECTION - DETAILED	Turbine Section - Right
72-207-01-01	72-207-01	72-207-01		INSPECTION - DETAILED	Turbine Section - Left
72-207-02-01	72-207-02	72-207-02		INSPECTION - DETAILED	Turbine Section - Right
72-211-01-01	72-211-01	72-211-01		INSPECTION - DETAILED	Diffuser Case Section - Left
72-211-02-01	72-211-02	72-211-02		INSPECTION - DETAILED	Diffuser Case Section - Right
72-212-01-01	72-212-01	72-212-01		INSPECTION - DETAILED	Diffuser Case Section - Left
72-212-02-01	72-212-02	72-212-02		INSPECTION - DETAILED	Diffuser Case Section - Right
72-220-01-01	72-220-01	72-220-01		INSPECTION - DETAILED	Low Pressure Compressor Section - Left
72-220-02-01	72-220-02	72-220-02		INSPECTION - DETAILED	Low Pressure Compressor Section - Right
72-225-00-01	72-225-00	72-225-00		REPLACE	Discard Fan Hub & LPC Drum Rotor
72-235-01-01	72-235-01	72-235-01		CHECK/INSP	Fan Case Section - Left
72-235-02-01	72-235-02	72-235-02		CHECK/INSP	Fan Case Section - Right



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
72-240-01-01	72-240-01	72-240-01		INSPECTION - GEN VISUAL	Kevlar Inspection on Fan Case - Left
72-240-02-01	72-240-02	72-240-02		INSPECTION - GEN VISUAL	Kevlar Inspection on Fan Case - Right
72-245-01-01	72-245-01	72-245-01		INSPECTION - DETAILED	Fan Case Section - Left
72-245-01-02	72-245-01	72-245-01		INSPECTION - DETAILED	Fan Case Section - Left (For all PW4000 engine series except 4090D and 4098)
72-245-01-04	72-245-01	72-245-01		INSPECTION - DETAILED	Fan Case Section - Left (For PW4000 engine series 4074, 4077, and 4084)
72-245-01-05	72-245-01	72-245-01		INSPECTION - DETAILED	Fan Case Section - Left -For PW4000 engine series 4074D, 4077D, 4084D, 4090, 4090D, and 4098
72-245-01-06	72-245-01	72-245-01		INSPECTION - DETAILED	Fan Case Section - Left (All PW4000 engines)
72-245-02-01	72-245-02	72-245-02		INSPECTION - DETAILED	Fan Case Section - Right
72-245-02-02	72-245-02	72-245-02		INSPECTION - DETAILED	Fan Case Section - Right (For all PW4000 engine series except 4090D and 4098)
72-245-02-04	72-245-02	72-245-02		INSPECTION - DETAILED	Fan Case Section - Right (For PW4000 engine series 4074, 4077, and 4084)
72-245-02-05	72-245-02	72-245-02		INSPECTION - DETAILED	Fan Case Section - Right (For PW4000 engine series 4074D, 4077D, 4084D, 4090, 4090D, and 4098)
72-245-02-06	72-245-02	72-245-02		INSPECTION - DETAILED	Fan Case Section - Right (All PW4000 engines)
72-250-00-01	72-250-00	72-250-00		REPLACE	Discard Front HUB, 5th Disk, Drum Rotor/Drive Turbine Shaft
72-255-00-01	72-255-00	72-255-00		REPLACE	Discard HUBS, ROTATING AIRSEAL, AND BLADE RETAINING PLATES
72-260-00-01	72-260-00	72-260-00		REPLACE	Discard LPC/LPT COUPLING
72-265-00-01	72-265-00	72-265-00		REPLACE	Discard Disks, Rotating Airseals and Shafts



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
72-270-01-01	72-270-01	72-270-01		INSPECTION - DETAILED	Lubrication and Scavage System - Left
72-270-02-01	72-270-02	72-270-02		INSPECTION - DETAILED	Lubrication and Scavage System - Right
72-280-01-01	72-280-01	72-280-01		INSPECTION - DETAILED	Inspection of the Turbine Exhaust Case Rail Mount (AFT Eng Mount) - Left
72-280-02-01	72-280-02	72-280-02		INSPECTION - DETAILED	Inspection of the Turbine Exhaust Case Rail Mount (AFT Eng Mount) - Right
72-345-01-01	72-345-01			SPECIAL DETAILED	Fan Blade Ultrasonic Test
72-345-02-01	72-345-02			SPECIAL DETAILED	Fan Blade Ultrasonic Test
72-346-01-01	72-346-01			LUBRICATE	Fan Blade Lubrication
72-346-02-01	72-346-02			LUBRICATE	Fan Blade Lubrication
72-350-01-01	72-350-01	72-350-01		INSPECTION - DETAILED	Fan Blade Inspection
72-350-02-01	72-350-02	72-350-02		INSPECTION - DETAILED	Fan Blade Inspection
72-355-00-01	72-355-00	72-355-00		REPLACE	Discard LPC Disk
72-360-00-01	72-360-00	72-360-00		REPLACE	Discard LPC Shaft
72-365-00-01	72-365-00	72-365-00		REPLACE	Discard Fan Shaft
72-370-01-01	72-370-01	72-370-01		INSPECTION - DETAILED	Inspection of the Lugs
72-370-02-01	72-370-02	72-370-02		INSPECTION - DETAILED	Inspection of the Lugs
72-375-01-01	72-375-01	72-375-01		INSPECTION - DETAILED	MCD Inspection
72-375-02-01	72-375-02	72-375-02		INSPECTION - DETAILED	MCD Inspection



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
72-376-01-01	72-376-01	72-376-01		RESTORE	Restore (Clean) Master Electric Chip Detector (active DMS) Left Engine
72-376-02-01	72-376-02	72-376-02		RESTORE	Restore (Clean) Master Electric Chip Detector (active DMS) Right Engine
72-377-01-01	72-377-01	72-377-01		FUNCTIONAL	Functionally Check Master Electric Chip Detector (active DMS) Left Engine
72-377-02-01	72-377-02	72-377-02		FUNCTIONAL	Functionally Check Master Electric Chip Detector (active DMS) Right Engine
72-380-00-01	72-380-00	72-380-00		REPLACE	Discard IPC Rear Stubshaft
72-385-01-01	72-385-01	72-385-01		INSPECTION - DETAILED	Inspect Detailed Kevlar
72-385-02-01	72-385-02	72-385-02		INSPECTION - DETAILED	Inspect Detailed Kevlar
72-390-01-01	72-390-01	72-390-01		INSPECTION - GEN VISUAL	General Visual of the Splitter Fairing
72-390-02-01	72-390-02	72-390-02		INSPECTION - GEN VISUAL	General Visual of the Splitter Fairing
72-400-01-01	72-400-01	72-400-01		INSPECTION - GEN VISUAL	General Visual of OGV's
72-400-02-01	72-400-02	72-400-02		INSPECTION - GEN VISUAL	General Visual of OGV's
72-405-00-01	72-405-00	72-405-00		REPLACE	Discard HPC Shaft/Assemblies
72-410-01-01	72-410-01	72-410-01		INSPECTION - DETAILED	Borescope Combustor
72-410-02-01	72-410-02	72-410-02		INSPECTION - DETAILED	Borescope Combustor
72-415-01-01	72-415-01	72-415-01		INSPECTION - DETAILED	Borescope Turbine Blades
72-415-02-01	72-415-02	72-415-02		INSPECTION - DETAILED	Borescope Turbine Blades
72-420-00-01	72-420-00	72-420-00		REPLACE	Discard HPT Disk
72-425-00-01	72-425-00	72-425-00		REPLACE	Discard IPT Disk





**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-430-00-01	72-430-00	72-430-00		REPLACE	Discard IPT Shaft
72-435-00-01	72-435-00	72-435-00		REPLACE	Discard IPT Disks
72-440-00-01	72-440-00	72-440-00		REPLACE	Discard LPT Shaft
72-445-01-01	72-445-01	72-445-01		INSPECTION - DETAILED	Borescope Nozzle Guide Vanes
72-445-02-01	72-445-02	72-445-02		INSPECTION - DETAILED	Borescope Nozzle Guide Vanes
73-010-01-01	73-010-01	73-010-01		OPERATIONAL	Restore All C2 Messages - Left (for GE90-70/80/90 series engines only)
73-010-01-03	73-010-01	73-010-01		OPERATIONAL	Restore All C2 Messages - Left (for GE90-100 series engines only)
73-010-02-02	73-010-02	73-010-02		OPERATIONAL	Restore All C2 Messages - Right (for GE90-70/80/90 series engines only)
73-010-02-04	73-010-02	73-010-02		OPERATIONAL	Restore All C2 Messages - Right (for GE90-100 series engines only)
73-011-00-01	73-011-00	73-011-00		RESTORE	Engine Fuel
73-011-00-02	73-011-00	73-011-00		RESTORE	Engine Fuel
73-011-00-03	73-011-00	73-011-00		RESTORE	Engine Fuel
73-011-00-04	73-011-00	73-011-00		RESTORE	Engine Fuel
73-055-01-01	73-055-01	73-055-01		INSPECTION - DETAILED	Inspect Detailed Fuel Filter (for GE90-70/80/90 series engines only)
73-055-01-03	73-055-01	73-055-01		INSPECTION - DETAILED	Inspect Detailed Fuel Filter (for GE90-100 series engines only)
73-055-02-02	73-055-02	73-055-02		INSPECTION - DETAILED	Inspect Detailed Fuel Filter (for GE90-70/80/90 series engines only)
73-055-02-04	73-055-02	73-055-02		INSPECTION - DETAILED	Inspect Detailed Fuel Filter (for GE90-100 series engines only)
73-210-01-01	73-210-01	73-210-01		REPLACE	Fuel Pump Filter Element - Left
73-210-02-01	73-210-02	73-210-02		REPLACE	Fuel Pump Filter Element - Right
73-350-01-01	73-350-01	73-350-01		DISCARD	Discard LP Fuel Filter



## 777-200/300 MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
73-350-02-01	73-350-02	73-350-02		DISCARD	Discard LP Fuel Filter
77-005-01-01	77-005-01	77-005-01		INSPECTION - DETAILED	Inspect for EGT System Degradation - Left (for GE90-70/80/90 series engines only)
77-005-01-03	77-005-01	77-005-01		INSPECTION - DETAILED	Inspect for EGT System Degradation - Left (for GE90-100 series engines only)
77-005-02-02	77-005-02	77-005-02		INSPECTION - DETAILED	Inspect for EGT System Degradation - Right (for GE90-70/80/90 series engines only)
77-005-02-04	77-005-02	77-005-02		INSPECTION - DETAILED	Inspect for EGT System Degradation - Right (for GE90-100 series engines only)
78-005-01-01	78-005-01	78-005-01		INSPECTION - GEN VISUAL	Inspect General Visual Exhaust Sleeve/Center Body - Left (for GE90-70/80/90 series engines only)
78-005-01-03	78-005-01	78-005-01		INSPECTION - GEN VISUAL	Inspect General Visual Exhaust Sleeve/Center Body - Left (for GE90-100 series engines only)
78-005-02-02	78-005-02	78-005-02		INSPECTION - GEN VISUAL	Inspect General Visual Exhaust Sleeve/Center Body - Right (for GE90-70/80/90 series engines only)
78-005-02-04	78-005-02	78-005-02		INSPECTION - GEN VISUAL	Inspect General Visual Exhaust Sleeve/Center Body - Right (for GE90-100 series engines only)
78-010-01-01	78-010-01	78-010-01		INSPECTION - DETAILED	Inspect Detailed T/R Blocker Door Hinges, Drag Links and Attachments - Left (for GE90-70/80/90 series engines only)
78-010-01-03	78-010-01	78-010-01		INSPECTION - DETAILED	Inspect Detailed T/R Blocker Door Hinges, Drag Links and Attachments - Left (for GE90-100 series engines only)
78-010-02-02	78-010-02	78-010-02		INSPECTION - DETAILED	Inspect Detailed T/R Blocker Door Hinges, Drag Links and Attachments - Right (for GE90-70/80/90 series engines only)
78-010-02-04	78-010-02	78-010-02		INSPECTION - DETAILED	Inspect Detailed T/R Blocker Door Hinges, Drag Links and Attachments - Right (for GE90-100 series engines only)
78-015-01-01	78-015-01	78-015-01		INSPECTION - DETAILED	Thrust Reverser Bullnose Seal (for GE90-70/80/90 series engines only)
78-015-01-03	78-015-01	78-015-01		INSPECTION - DETAILED	Thrust Reverser Bullnose Seal (for GE90-100 series engines only)



## 777-200/300 MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
78-015-02-02	78-015-02	78-015-02		INSPECTION - DETAILED	Thrust Reverser Bullnose Seal (for GE90-70/80/90 series engines only)
78-015-02-04	78-015-02	78-015-02		INSPECTION - DETAILED	Thrust Reverser Bullnose Seal (for GE90-100 series engines only)
78-020-01-01	78-020-01	78-020-01		OPERATIONAL	Thrust Reverser Locks - Left (for GE90-70/80/90 series engines only)
78-020-01-03	78-020-01	78-020-01		OPERATIONAL	Thrust Reverser Locks - Left (for GE90-100 series engines only)
78-020-02-02	78-020-02	78-020-02		OPERATIONAL	Thrust Reverser Locks - Right (for GE90-70/80/90 series engines only)
78-020-02-04	78-020-02	78-020-02		OPERATIONAL	Thrust Reverser Locks - Right (for GE90-100 series engines only)
78-025-01-01	78-025-01	78-025-01		OPERATIONAL	Thrust Reverser Sync Lock- Left (for GE90-70/80/90 series engines only)
78-025-01-03	78-025-01	78-025-01		OPERATIONAL	Thrust Reverser Sync Lock- Left (for GE90-100 series engines only)
78-025-02-02	78-025-02	78-025-02		OPERATIONAL	Thrust Reverser Sync Lock - Right (for GE90-70/80/90 series engines only)
78-025-02-04	78-025-02	78-025-02		OPERATIONAL	Thrust Reverser Sync Lock - Right (for GE90-100 series engines only)
78-030-01-01	78-030-01	78-030-01		OPERATIONAL	Operationally Check DCV and Locking Sensors - Left (for GE90-70/80/90 series engines only)
78-030-01-03	78-030-01	78-030-01		OPERATIONAL	Operationally Check DCV and Locking Sensors - Left (for GE90-100 series engines only)
78-030-02-02	78-030-02	78-030-02		OPERATIONAL	Operationally Check DCV and Locking Sensors - Right (for GE90-70/80/90 series engines only)
78-030-02-04	78-030-02	78-030-02		OPERATIONAL	Operationally Check DCV and Locking Sensors - Right (for GE90-100 series engines only)
78-205-01-01	78-205-01	78-205-01		INSPECTION - GEN VISUAL	Thrust Reverser Bullnose Seal - Left
78-205-02-01	78-205-02	78-205-02		INSPECTION - GEN VISUAL	Thrust Reverser Bullnose Seal - Right
78-210-01-01	78-210-01	78-210-01		OPERATIONAL	Thrust Reverser System
78-210-02-01	78-210-02	78-210-02		OPERATIONAL	Thrust Reverser System
78-215-01-01	78-215-01	78-215-01		OPERATIONAL	Thrust Reverser System



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
78-215-02-01	78-215-02	78-215-02		OPERATIONAL	Thrust Reverser System
78-220-01-01	78-220-01	78-220-01		OPERATIONAL	Operationally Check Sync Lock on Thrust Reverser
78-220-02-01	78-220-02	78-220-02		OPERATIONAL	Operationally Check Sync Lock on Thrust Reverser
78-225-01-01	78-225-01	78-225-01		INSPECTION - DETAILED	Inspect Detailed T/R Blocker Door Hinge and Drag Link Attachments - Left
78-225-02-01	78-225-02	78-225-02		INSPECTION - DETAILED	Inspect Detailed T/R Blocker Door Hinge and Drag Link Attachments - Right
78-350-01-01	78-350-01	78-350-01		INSPECTION - DETAILED	Inspect Detailed Thrust Reverser Blocker Door Hinge and Drag Link Attachments
78-350-02-01	78-350-02	78-350-02		INSPECTION - DETAILED	Inspect Detailed Thrust Reverser Blocker Door Hinge and Drag Link Attachments
78-355-01-01	78-355-01	78-355-01		INSPECTION - DETAILED	Thrust Reverser Bullnose Seal
78-355-02-01	78-355-02	78-355-02		INSPECTION - DETAILED	Thrust Reverser Bullnose Seal
78-360-01-01	78-360-01	78-360-01		OPERATIONAL	Thrust Reverser Locks
78-360-02-01	78-360-02	78-360-02		OPERATIONAL	Thrust Reverser Locks
78-365-01-01	78-365-01	78-365-01		OPERATIONAL	Thrust Reverser Sync Lock
78-365-02-01	78-365-02	78-365-02		OPERATIONAL	Thrust Reverser Sync Lock
78-370-01-01	78-370-01	78-370-01		OPERATIONAL	Thrust Reverser Sensor Checks
78-370-02-01	78-370-02	78-370-02		OPERATIONAL	Thrust Reverser Sensor Checks
78-375-01-01	78-375-01	78-375-01		INSPECTION - GEN VISUAL	Inspect Fire Seal
78-375-02-01	78-375-02	78-375-02		INSPECTION - GEN VISUAL	Inspect Fire Seal
78-380-01-01	78-380-01	78-380-01		INSPECTION - GEN VISUAL	Inspect Thrust Reverser Hinges



## 777-200/300 MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
78-380-02-01	78-380-02	78-380-02		INSPECTION - GEN VISUAL	Inspect Thrust Reverser Hinges
78-385-01-01	78-385-01	78-385-01		VISUAL CHECK	Thrust Reverser Thermal Protection System
78-385-02-01	78-385-02	78-385-02		VISUAL CHECK	Thrust Reverser Thermal Protection System
78-390-01-01	78-390-01			INSPECTION - DETAILED	Inspect Thrust Reverser Inner Wall
78-390-02-01	78-390-02			INSPECTION - DETAILED	Inspect Thrust Reverser Inner Wall
79-010-01-01	79-010-01	79-010-01		INSPECTION - DETAILED	Inspect Oil Filter Scavenge Screen - Left (for GE90-70/80/90 series engines only)
79-010-01-03	79-010-01	79-010-01		INSPECTION - DETAILED	Inspect Oil Filter Scavenge Screen - Left (for GE90-100 series engines only)
79-010-02-02	79-010-02	79-010-02		INSPECTION - DETAILED	Inspect Oil Filter Scavenge Screen - Right (for GE90-70/80/90 series engines only)
79-010-02-04	79-010-02	79-010-02		INSPECTION - DETAILED	Inspect Oil Filter Scavenge Screen - Right (for GE90-100 series engines only)
79-385-01-01	79-385-01	79-385-01		RESTORE	Restore Oil Pressure Filter
79-385-02-01	79-385-02	79-385-02		RESTORE	Restore Oil Pressure Filter
79-390-01-01	79-390-01	79-390-01		REPLACE	Replace Scavenge Oil Filter
79-390-02-01	79-390-02	79-390-02		REPLACE	Replace Scavenge Oil Filter
80-005-01-01	80-005-01	80-005-01		INSPECTION - DETAILED	Inspect Starter Chip Detector - Left (for GE90-70/80/90 series engines only)
80-005-01-03	80-005-01	80-005-01		INSPECTION - DETAILED	Inspect Starter Chip Detector - Left (for GE90-100 series engines only)
80-005-02-02	80-005-02	80-005-02		INSPECTION - DETAILED	Inspect Starter Chip Detector - Right (for GE90-70/80/90 series engines only)
80-005-02-04	80-005-02	80-005-02		INSPECTION - DETAILED	Inspect Starter Chip Detector - Right (for GE90-100 series engines only)



**777-200/300 MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
80-205-01-01	80-205-01	80-205-01		SERVICE	Starter Oil
80-205-02-01	80-205-02	80-205-02		SERVICE	Starter Oil
80-210-01-01	80-210-01	80-210-01		INSPECTION - DETAILED	Starter Chip Detector
80-210-02-01	80-210-02	80-210-02		INSPECTION - DETAILED	Starter Chip Detector
80-350-01-01	80-350-01	80-350-01		SERVICE	Starter Oil
80-350-02-01	80-350-02	80-350-02		SERVICE	Starter Oil
80-355-01-01	80-355-01	80-355-01		INSPECTION - DETAILED	Starter Chip Detector
80-355-02-01	80-355-02	80-355-02		INSPECTION - DETAILED	Starter Chip Detector